

Silverado and Sierra 1500 Tailgate Assist

1999–2006 | INSTALLATION GUIDE



IMPORTANT Park on level ground, switch off the ignition, and fully open the tailgate. Install on the driver side.

1 Remove the upper cable bolt

On the driver side, remove the factory bolt as shown and detach the support cable.



2 Install the upper stud

Fit the supplied washer and upper stud in the original cable mounting hole. Tighten securely.



3 Remove the lower bolt

Remove the factory bolt at the lower tailgate mounting point. Keep it for the next step.



4 Install the lower bracket

Position the lower bracket at the mounting point and secure it with the factory bolt.



5 Attach the upper end

Refit the support cable onto the upper stud, followed by the damper eyelet. Install the washer and nut; tighten securely.



6 Attach the lower end and test

Fit the lower damper eyelet onto the bracket stud. Install the washer and nut; tighten securely. Slowly cycle the tailgate and check for interference.



FINAL CHECK Both ends secure • Cable fully seated • Tailgate opens and closes smoothly without contact