

TOYOTA TUNDRA

TAILGATE ASSIST INSTALLATION GUIDE



BEFORE YOU START Park on level ground, turn off the ignition, fully open and support the tailgate. Install on the driver side.

1 DISCONNECT THE SUPPORT CABLE

Lift the driver-side cable eyelet. Align its slot with the post, then slide it off.



2 REMOVE THE UPPER BOLT

Use the supplied Torx key to remove the factory upper bolt. Keep the bolt for Step 3.



3 INSTALL THE UPPER BRACKET

Position the bracket as shown. Reinstall the factory bolt and tighten it securely.



4 REMOVE THE LOWER BOLT

Remove the factory bolt at the lower mounting point shown.



5 INSTALL THE LOWER BALL STUD

Thread in the supplied ball stud and washer. Tighten securely.



6 CONNECT THE DAMPER

Press both sockets firmly onto the upper and lower ball studs. Reattach the support cable.



FINAL CHECK Both sockets are fully seated; both brackets are tight; the support cable is reattached; the tailgate lowers smoothly without binding.