PREPARATION / STEPS 1-2

Before you begin

1 Unpack and verify contents

Remove all items from the package.

(2) Gas springs
(2) Fender brackets
(1) Hood bracket - RH - B
(1) Hood bracket - LH - A



RH / B
Hood
passenger side



LH / A
Hood
driver side



Fender
Both sides



Rod-end fitting

Body-end fitting

2 Gather the required tools

Please gather the following tools before you begin installation:

- 10 mm socket
- 13 mm deep-well socket
- Socket wrench

Before installation: Securely support the open hood while removing hardware and fitting the brackets.

FENDER / STEP 3

Install the fender brackets

3 Fit the bracket on each side

A. Remove the fender bolt in the middle of the inner fender using a 10 mm socket.
B. Install the fender bracket here. It overhangs the lip with the ball stud below, aiming **inward toward the engine**.
C. Repeat on the passenger side.



REMOVE THE FENDER BOLT

Use a **10 mm socket** to remove the original bolt.



BRACKET OVERHANGS THE LIP

Keep the ball stud below the lip and facing toward the engine.

HOOD / STEPS 4-5

Install the hood brackets

4 Remove the upper hood hinge nut

A. Remove the upper hood hinge nut using a 13 mm socket.

B. Install the correct bracket as shown with the ball stud pointing **INWARD toward the center of the vehicle**.



5 Mount brackets A and B

A. Mount A on the LH / driver's side; mount B on the RH / passenger side.
B. Align bracket A as shown, with the ball stud forward, aiming **outward** and overhanging the top of the hood hinge.
C. Tighten with the same 13 mm socket.
D. Repeat with mirror-image bracket B on the RH / passenger side. The ball studs should point outward on both sides.

RH / PASSENGER



VIEWED FROM FRONT





LH / DRIVER



CONNECTIONS / STEP 6

Install the gas springs

6 Connect the hood and fender ends

A. Start at the hood. Snap the large body end of the gas spring onto the hood bracket. Rock it with light pressure so the metal C-clip spreads and wraps around the ball stud.

B. Attach the lower end while someone holds up the hood to help align the socket and ball stud.

DO NOT FORCE ON. Carefully rock the end fitting back and forth with light pressure. The inner C-clip expands and wraps around the ball stud so the socket can snap into place.

UPPER / BODY END



LOWER / ROD END

