

# UEFI AND EDK II BASE TRAINING

Lab and Reference Guide Assumes Windows 10

Revised: 07/06/2018

UEFI Driver Wizard – Adding HII	2
1. Adding Strings and Forms to Setup HII for User Configuration	3
a. Setup for Lab adding HII	3
b. Edit Driver for adding HII	6
2. Updating HII to Save Data Settings	20
3. Updating your driver to initialize data from the VFR data to the HII Database	33
a. Add HII Library Calls to Your Driver	33
b. Add your Driver to the platform	40
4. Updating the Menu: Reset Button	42
5. Updating the Menu: Pop-up Box	45
6. Updating the Menu: Creating a String to Name a Saved Configuration	51
7. Updating the Menu: Numeric Entry	58
8. Updating your Driver for Interactive Call Backs	63
a. Add the Case statements to the Call back routine	63
b. Update the Menu for Interactive items	66
9. Add code to your driver when Call Back events occur for Interactive Items	70
10. Adding an Additional Form Page	74
11. Adding Communication from Driver to Console through HII	82
Lab Setup	87
Pin Visual Studio Command Prompt for Windows	87
Preparing for the BUILD Command	87
Configuring Build Tools	89
Use the Microsoft Windows and Visual Studio Matrix	89
Microsoft Windows 10 – Visual Studio command prompt	90
Microsoft Windows and Visual Studio Matrix	94
Reference	95
Glossary of UEFI Terms and Acronyms	96
Helpful Links	96
Acknowledgement	97

## **UEFI Driver Wizard – Adding HII**




# 1. Adding Strings and Forms to Setup HII for User Configuration


In this lab, you'll learn how to use HII to add strings and forms to a firmware setup menu for user configuration. Once you've complete this lab, your end result will match Figure 1.



Figure 1 My Wizard Driver menu with strings and forms

## a. Setup for Lab adding HII





## Step Action Type Edksetup (This is only needed if starting out with a new Visual 7 Studio Command Prompt Window ) Developer Command Prompt for VS2013 c:\fw\edk2>edksetup = c:\fw\edk2\BaseTools\Bin\Win32;C:\Program Files (x86)\Micr udio 12.0\Common7\IDE\CommonExtensions\Microsoft\TestWindow;C:\Program Files (x8 Ks\F#\3.1\Framework\v4.0\;C:\Program Files (x86)\MSBuild\12.0\bin;C:\Program Fil oft Visual Studio 12.0\Common7\IDE\;C:\Program Files (x86)\Microsoft Visual Stud C:\Program Files (x86)\Microsoft Visual Studio 12.0\Common7\Tools;C:\windows\Mic ework\v4.0.30319;C:\Program Files (x86)\Microsoft Visual Studio 12.0\VC\VCPackag a\Local\Microsoft\WindowsApps;C:\Users\ljarlstr\AppData\Roaming\npm;C:\Users\ljarl ocal\Pandoc\ WORKSPACE = c:\fw\edk2 = c:\fw\edk2\BaseTools EDK TOOLS PATH BASE\_TOOLS\_PATH = c:\fw\edk2\BaseTools EDK\_TOOLS\_BIN = c:\fw\edk2\BaseTools\Bin\Win32 CONF\_PATH = c:\fw\edk2\Conf !!! WARNING !!! NASM PREFIX environment variable is not set Found nasm.exe, setting the environment variable to C:\nasm\ !!! WARNING !!! No CYGWIN\_HOME set, gcc build may not be used !!! c:\fw\edk2>

## b. Edit Driver for adding HII

Step	Action
1	Open C:\fw\edk2\MyWizardDriver
2	Open the following files for updating:  1) MyWizardDriverNVDataStruc.h  2) MyWizardDriver.vfr  3) MyWizardDriver.uni  4) MyWizardDriver.h  5) MyWizardDriver.c  6) MyWizardDriver.inf
3	<b>Update</b> the MyWizardDriverNVDataStruc.h file by copying and pasting the following GUID as shown below:
	This GUID is used to communicate to the HII Database and Browser Engine  #define MYWIZARDDRIVER_FORMSET_GUID \     { \
	6 7
	19 typedef struct { 20 21  UINT16  MyWizardDriverStringData[20]; 22  UINT8  MyWizardDriverHexData; 23  UINT8  MyWizardDriverBaseAddress;
4	Save MyWizardDriverNVDataStruc.h
5	Update the MyWizardDriver.vfr file. Delete its contents and replace it with the following by copying and pasting:  You're adding a reference to the GUID and to the NVRAM storage where the configuration will be saved. In fact, you're replacing most of the original .vfr.

```
#include "MyWizardDriverNVDataStruc.h"
   formset
     guid = MYWIZARDDRIVER FORMSET GUID,
            = STRING TOKEN(STR SAMPLE FORM SET TITLE),
     title
     help = STRING TOKEN(STR SAMPLE FORM SET HELP),
     classquid = EFI HII PLATFORM SETUP FORMSET GUID,
     // Define a Buffer Storage (EFI IFR VARSTORE)
       varstore MYWIZARDDRIVER CONFIGURATION, // This is the data
   structure type
       ΙD
                                            // Define referenced
       name = MWD IfrNVData,
   name in vfr
       guid = MYWIZARDDRIVER FORMSET GUID;  // GUID of this buffer
   storage
6
   Continue adding the remaining code to MyWizardDriver.vfr.
   This is a Enable/ Disable question for the setup menu in the form of a Check box.
     form formid = 1, title = STRING TOKEN(STR SAMPLE FORM1 TITLE);
       subtitle text = STRING TOKEN(STR SUBTITLE TEXT);
       subtitle text = STRING TOKEN(STR SUBTITLE TEXT2);
     //
     // Define a checkbox to enable / disable the device
         checkbox varid = MWD IfrNVData.MyWizardDriverChooseToEnable,
                   prompt = STRING TOKEN(STR CHECK BOX PROMPT),
                   help = STRING TOKEN(STR CHECK BOX HELP),
                   //
                   // CHECKBOX DEFAULT indicate this checkbox is
   marked with
                   EFI IFR CHECKBOX DEFAULT
                   //
                    flags = CHECKBOX DEFAULT ,
                    key = 0,
                    default = 1,
        endcheckbox;
      endform;
   endformset;
   Save MyWizardDriver.vfr
```

```
Now onto the MyWizardDriver.uni file. You'll add new strings to support the forms.
       Delete the file's content and replace it with the following by copying and pasting:
       #langdef en "English"
       #string STR SAMPLE FORM SET TITLE
                                             #language en "My Wizard Driver Sample
       Formset"
       #string STR SAMPLE FORM SET HELP
                                            #language en "Help for Sample Formset"
       #string STR SAMPLE FORM1 TITLE
                                             #language en "My Wizard Driver"
       #string STR SUBTITLE TEXT
                                             #language en "My Wizard Driver
       Configuration"
      #string STR_SUBTITLE_TEXT2
#string STR_CHECK_BOX_PROMPT
                                             #language en "Device XYZ Configuration"
                                             #language en "Enable My XYZ Device"
       #string STR_CHECK BOX HELP
                                             #language en "This is the help message
      for the enable My XYZ device. Check this box to enable this device."
  9
      Save MyWizardDriver.uni
 10
      Now update the MyWizardDriver.h file. Add the following HII libraries starting at
      approximately line 41 (as shown below) by copying and pasting:
       By adding this code, now your driver will be consuming the HII Protocols and
      producing the CONFIG ACCESS PROTOCOL:
       // Added for HII
       #include <Protocol/HiiConfigRouting.h>
       #include <Protocol/FormBrowser2.h>
       #include <Protocol/HiiString.h>
       #include <Library/DevicePathLib.h>
        42 // Added for HII
       43 #include <Protocol/HiiConfigRouting.h>
       44 #include <Protocol/FormBrowser2.h>
        45 #include <Protocol/HiiString.h>
       46 #include <Library/DevicePathLib.h>
       47
        49 // Consumed Protocols
 11
      To add a data structure for HII routing and access, add the following code at
       approximately line 75 by copying and pasting after the "extern" statements:
       #define MYWIZARDDRIVER DEV SIGNATURE SIGNATURE 32 ('m', 'w', 'd',
11
       'r')
       // Need a Data structure for HII routing and accessing
       typedef struct {
         UINT32
                                               Signature;
         EFI HANDLE
                                               Handle;
         MYWIZARDDRIVER CONFIGURATION
                                              Configuration;
```

```
EFI HANDLE
                                   DriverHandle[2];
       EFI HII HANDLE
                                     HiiHandle[2];
       // Consumed protocol
      *HiiDatabase;
      EFI HII CONFIG ROUTING PROTOCOL *HiiConfigRouting;
       EFI_FORM_BROWSER2_PROTOCOL *FormBrowser2;
       //
       // Produced protocol
      EFI HII CONFIG ACCESS PROTOCOL ConfigAccess;
     } MYWIZARDDRIVER DEV;
     #define MYWIZARDDRIVER DEV FROM THIS(a) CR (a, MYWIZARDDRIVER DEV,
     ConfigAccess, MYWIZARDDRIVER DEV SIGNATURE)
     #pragma pack(1)
     ///
     /// HII specific Vendor Device Path definition.
     typedef struct {
                                 VendorDevicePath;
End;
      VENDOR DEVICE PATH
      EFI DEVICE PATH PROTOCOL
     } HII VENDOR DEVICE PATH;
     #pragma pack()
11
```

```
73 extern EFI_HII_CONFIG_ACCESS_PROTOCOL gMyWizardDriverHiiConfigAccess;
74
75 #define MYWIZARDDRIVER DEV SIGNATURE SIGNATURE 32 ('m', 'w', 'd', 'r') *
76
77 // Need a Data structure for HII routing and accessing
78 typedef struct {
79 UINT32
                                     Signature;
80
81 EFI HANDLE
                                    Handle;
    MYWIZARDDRIVER CONFIGURATION Configuration;
82
83
                                   DriverHandle[2];
84 EFI_HANDLE
85 EFI_HII_HANDLE
                                    HiiHandle[2];
86 //
87 // Consumed protocol
     11
88
89 EFI_HII_DATABASE_PROTOCOL *HiiDatabase;
90 EFI_HII_STRING_PROTOCOL *HiiString;
91 EFI_HII_CONFIG_ROUTING_PROTOCOL *HiiConfigRouting;
92 EFI_FORM_BROWSER2_PROTOCOL *FormBrowser2;
93
94 //
95 // Produced protocol
96
    EFI_HII_CONFIG_ACCESS_PROTOCOL ConfigAccess;
97
98
99 } MYWIZARDDRIVER_DEV;
100
101 #define MYWIZARDDRIVER DEV FROM THIS(a) CR (a, MYWIZARDDRIVER DEV, Config
103 #pragma pack(1)
104 ///
105 /// HII specific Vendor Device Path definition.
106 ///
107 typedef struct {
108 VENDOR_DEVICE_PATH
109 EFI_DEVICE_PATH_PROTOCOL
                                  VendorDevicePath;
                                  End;
110 } HII_VENDOR_DEVICE_PATH;
111
112 #pragma pack()
114 // Include files with function prototypes
```

Save MyWizardDriver.h

Now onto the MyWizardDriver.c file.

**Add** local definitions for the form GUID, variable name, and device path for HII at approximately line 13 after the #include "MyWizardDriver.h" by coping and pasting the following code.

In this step, you declare a local (to the module "m") variable for the GUID we declared; the NVRAM variable name; driver handles; our configuration data; and the device path support.

```
//HII support
13
      EFI GUID
                 mMyWizardDriverFormSetGuid = MYWIZARDDRIVER FORMSET GUID;
                  mIfrVariableName[] = L"MWD IfrNVData";
      CHAR16
                                          mDriverHandle[2] = {NULL, NULL};
      EFI HANDLE
     MYWIZARDDRIVER DEV
                                              *PrivateData = NULL;
      // HII support for Device Path
     HII VENDOR DEVICE PATH mHiiVendorDevicePath = {
        {
            HARDWARE DEVICE PATH,
            HW VENDOR DP,
               (UINT8) (sizeof (VENDOR DEVICE PATH)),
               (UINT8) ((sizeof (VENDOR DEVICE PATH)) >> 8)
          },
          MYWIZARDDRIVER FORMSET GUID
        },
          END DEVICE PATH TYPE,
          END ENTIRE DEVICE PATH SUBTYPE,
             (UINT8) (END DEVICE PATH LENGTH),
             (UINT8) ((END DEVICE PATH LENGTH) >> 8)
        }
      Locate EFI STATUS within the function MyWizardDriverDriverEntryPoint in the
14
      MyWizardDriver.c file (approx. Line 184) and add HII local definitions by copying
     and pasting (as shown below):
       // HII Locals
14
       EFI HII PACKAGE LIST HEADER
                                    *PackageListHeader;
       EFI HII DATABASE PROTOCOL
                                    *HiiDatabase;
                                 HiiHandle<mark>[2];</mark>
       EFI HII HANDLE
       EFI STRING
                                     ConfigRequestHdr;
       UINTN
                                     BufferSize;
14
      178 {
      179
           EFI STATUS Status;
      180
      181
           // HII Locals
      182
           EFI HII PACKAGE LIST HEADER
                                        *PackageListHeader;
            EFI HII DATABASE PROTOCOL
      183
                                        *HiiDatabase:
      184
           EFI HII HANDLE
                                        HiiHandle[2];
      185
           EFI STRING
                                        ConfigRequestHdr;
      186
           UINTN
                                        BufferSize;
      187
      188
           Status = EFI_SUCCESS;
      189
```

```
15
     Locate the ASSERT EFI ERROR (Status); statement and the line: // Retrieve
     HII Package List Header on ImageHandle (approximately line 202).
     Now, add the following code to install the configuration access protocol (produced)
     by copying and pasting (as shown below) before the line:// Retrieve HII
     Package List Header on ImageHandle
15
     //Now do HII Stuff
     // Initialize the local variables.
       ConfigRequestHdr = NULL;
     // Initialize driver private data
       PrivateData = AllocateZeroPool (sizeof (MYWIZARDDRIVER DEV));
       if (PrivateData == NULL) {
         return EFI OUT OF RESOURCES;
       PrivateData->Signature = MYWIZARDDRIVER DEV SIGNATURE;
       PrivateData->ConfigAccess.ExtractConfig =
     MyWizardDriverHiiConfigAccessExtractConfig;
       PrivateData->ConfigAccess.RouteConfig =
     MyWizardDriverHiiConfigAccessRouteConfig;
       PrivateData->ConfigAccess.Callback =
     MyWizardDriverHiiConfigAccessCallback;
       // Publish sample Fromset and config access
       Status = gBS->InstallMultipleProtocolInterfaces (
                        &mDriverHandle[0],
                        &gEfiDevicePathProtocolGuid,
                        &mHiiVendorDevicePath,
                        &gEfiHiiConfigAccessProtocolGuid,
                        &PrivateData->ConfigAccess,
                        NULL
                        );
       ASSERT EFI ERROR (Status);
       PrivateData->DriverHandle[0] = mDriverHandle[0];
```

```
15
            ASSERT_EFI_ERROR (Status);
      201
      202
      203
      204
            //Now do HII Stuff
      205
      206
      207
            // Initialize the local variables.
          ConfigRequestHdr = NULL;
      208
      209
           // Initialize driver private data
      210
          //
      211
      212 PrivateData = AllocateZeroPool (sizeof (MYWIZARDDRIVER_DEV));
      213 if (PrivateData == NULL) {
      214
            return EFI_OUT_OF_RESOURCES;
      215
      216
      217 PrivateData->Signature = MYWIZARDDRIVER_DEV_SIGNATURE;
      218
      219 PrivateData->ConfigAccess.ExtractConfig = MyWizardDriverHiiConfigAccess
      220 PrivateData->ConfigAccess.RouteConfig = MyWizardDriverHiiConfigAccessRc
      221 PrivateData->ConfigAccess.Callback = MyWizardDriverHiiConfigAccessCallk
      222
      223
      224 //
      225 // Publish sample Fromset and config access
      226 //
      227 Status = gBS->InstallMultipleProtocolInterfaces (
      228
                          &mDriverHandle[0],
      229
                          &gEfiDevicePathProtocolGuid,
      230
                          &mHiiVendorDevicePath,
      231
                          &gEfiHiiConfigAccessProtocolGuid,
      232
                          &PrivateData->ConfigAccess,
      233
                          NULL
      234
                          );
      235 ASSERT_EFI_ERROR (Status);
      236
      237
           PrivateData->DriverHandle[0] = mDriverHandle[0];
      238
           // Retrieve HII Package List Header on ImageHandle
      239
      240
      241
            Status = gBS->OpenProtocol (
16
      Next, add code to register a list of HII packages in the HII Database with the HII
      device path. This requires you to replace existing code (see below) by copying and
      pasting the new code at approx. line 265.
      Find: // Register list of HII packages in the HII Database and replace
                                        NULL,
                                        &HiiHandle
       The HII Browser will need to find your HII Package and it does this when the
      call is made to NewPackageList with the device path of your driver's HII
      packages. The mDriverHandle is your Driver's Device path. Use this in the
      call to NewPackageList instead of the NULL parameter used before.
16
```

Old Code


```
190
       191
              if (!EFI_ERROR (Status)) {
       192
               //
       193
               // Register list of HII packages in the HII Database
       194
               //
       195
               Status = HiiDatabase->NewPackageList (
       196
                                   HiiDatabase,
       197
                                   rackageListHe
       198
                                   NULL
       199
                                   &HiiHandle
       200
               ASSERT_EFI_ERROR (Status);
       201
       202
             }
       203
           Status = EFI_SUCCESS;
       204
       205
       206
      mDriverHandle[0],
16
      &HiiHandle[0]
16
      New Code
       257
       258
              if (!EFI_ERROR (Status)) {
       259
       260
                // Register list of HII packages in the HII Database
       261
                11
       262
                Status = HiiDatabase->NewPackageList (
       263
                                    HiiDatabase,
       264
                                     ackageListHeader
                                     mDriverHandle[0]
       265
       266
                                     &HiiHandle[0]
       267
       268
                ASSERT EFI ERROR (Status);
       269
             }
       270
       271 Status = EFI_SUCCESS;
17
      Next, you'll add code to initialize the My Wizard Driver NVRAM variable by
      copying and pasting the following code before the // Install Driver
      Supported EFI Version Protocol onto ImageHandle comment (as shown
      below at approximately line 273):
         PrivateData->HiiHandle[0] = HiiHandle[0];
17
        BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
         // IF driver is not part of the Platform then need to get/set
      defaults for the NVRAM configuration that the driver will use.
         Status = gRT->GetVariable (
                     mIfrVariableName,
```


&mMyWizardDriverFormSetGuid,

```
NULL.
                     &BufferSize,
                     &PrivateData->Configuration
        if (EFI ERROR (Status)) { // Not definded yet so add it to the NV
      Variables.
                 // zero out buffer
                ZeroMem (&PrivateData->Configuration, sizeof
      (MYWIZARDDRIVER CONFIGURATION));
                Status = gRT->SetVariable(
                            mIfrVariableName,
                            &mMyWizardDriverFormSetGuid,
                            EFI VARIABLE NON VOLATILE |
      EFI VARIABLE BOOTSERVICE ACCESS,
                            sizeof (MYWIZARDDRIVER CONFIGURATION),
                            &PrivateData->Configuration // buffer is 000000
      now
                            );
17
       270
       271
            Status = EFI SUCCESS;
       272
            PrivateData->HiiHandle[0] = HiiHandle[0];
       273
       274
       275
            BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
       276
       277 // IF driver is not part of the Platform then need to get/set defaults for
       278 Status = gRT->GetVariable (
       279
                    mIfrVariableName,
       280
                    &mMyWizardDriverFormSetGuid,
       281
      282
                    &BufferSize,
      283
                    &PrivateData->Configuration
      284
                    );
      285 if (EFI_ERROR (Status)) { // Not definded yet so add it to the NV Variables
      286
                    // zero out buffer
       287
                 ZeroMem (&PrivateData->Configuration, sizeof (MYWIZARDDRIVER_CONFIGURA
       288
                 Status = gRT->SetVariable(
      289
                          mIfrVariableName,
       290
                          &mMyWizardDriverFormSetGuid,
       291
                          EFI VARIABLE NON VOLATILE | EFI VARIABLE BOOTSERVICE ACCESS,
       292
                          sizeof (MYWIZARDDRIVER CONFIGURATION),
       293
                          &PrivateData->Configuration // buffer is 000000 now
       294
       295
       296
            // Install Driver Supported EFI Version Protocol onto ImageHandle
18
      Save MyWizardDriver.c
19
      Now onto the final file, MyWizardDriver.inf. Add the following protocols in the
      [protocols] section that are being used by copying and pasting (as shown below):
      qEfiHiiStringProtocolGuid
                                                            ## CONSUMES
19
```

	gEfiHiiConfigRoutingProtocolGuid ## CONSUMES
	gEfiFormBrowser2ProtocolGuid ## CONSUMES
	gEfiHiiDatabaseProtocolGuid ## CONSUMES
19	55 gEfiComponentNameProtocolGuid 56 gEfiHiiConfigAccessProtocolGuid 57 gEfiSimpleTextOutProtocolGuid 58 59 60 gEfiHiiStringProtocolGuid 61 gEfiHiiConfigRoutingProtocolGuid 62 gEfiFormBrowser2ProtocolGuid 63 gEfiHiiDatabaseProtocolGuid 64
20	<b>Save</b> the MyWizardDriver.inf file. All the files should be saved at this point.
21	Re-Open the Visual Studio Command Prompt
22	<b>Add</b> MyWizardDriver.inf to the Nt32Pkg.dsc (See Lab 2 building MyWizardDriver from the Driver Porting Lab)
23	Type build
24	Press "Enter"
25	Type build run
26	Press "Enter"
27	At the UEFI Shell prompt,type fs0:
28	Press "Enter"
29	Type Load MyWizardDriver.efi
30	Press "Enter" This will load your driver into memory
31	FSO:\> load MyWizardDriver.efi Image 'FSO:\MyWizardDriver.efi' loaded at 5EB9000 - Success FSO:\> exit_
32	Type exit
	Press "Enter"
33	Now at the setup front page menu, select "Device Manager"

Continue This selection will Select Language <English> take you to the ▶ Boot Manager Device Manager Device Manager ▶ Boot Maintenance Manager 34 Press "Enter" 35 Inside the Device Manager menu **press** the down to "My Wizard Driver Sample Formset" Device Manager Devices List Help for Sample ▶ Platform Driver Override selection Formset ▶ iSCSI Configuration ▶ Browser Testcase Engine ▶ ABC Information Sample ▶ My Wizard Driver Sample Formset Press "Enter". 36 My Wizard Driver My Wizard Driver Configuration This is the help Device XYZ Configuration message for the Enable My XYZ Device [X] enable My XYZ device. Check this box to enable this device. **Note:** Notice that your form is now displayed with a choice to enable your device. Also notice the titles and help strings that are in the .UNI file you edited.





You've completed the first lab and added strings and forms to setup HII for user configuration. However, **the data is not saved to NVRAM**. In the next lab, you'll learn how to update HII to save data to NVRAM.

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.1

## 2. Updating HII to Save Data Settings

In this lab, you'll learn how to modify and update your driver's HII code to save the users settings into NVRAM. The UEFI Driver Wizard created the protocols for your driver to update and interface with the HII browser engine and database. The HII configuration access Protocol functions for MyWizardDriver are in the file C:\fw\edk2\MyWizardDriver\HiiConfigAccess.c. This next lab will install these protocols and update them to save the user data from the HII menus into NVRAM.

Step	Action
1	<b>Update</b> the MyWizardDriver.c file Your driver will need to keep track of the consumed protocols in it's own data structure so it will need to declare local pointers to these and then store them in its own private context data structure.
2	Add the following local variable declarations in the function MyWizardDriverDriverEntryPoint Entry Point (as shown below Approx. line 185):
	<pre>EFI_HII_STRING_PROTOCOL</pre>
	179 EFI_STATUS Status;  180  181
3	Add the following code to locate and store consumed protocols before the // Publish sample Fromset and config access comment (as shown below Approx. line 227): The reason is to Locate the Hii Database, Hii String, Hii Form browser and config routing protocols and store their pointers into the Private context data structure for your driver to access.

```
Step
        Action
         //
         // Locate Hii Database protocol
         Status = gBS->LocateProtocol (&gEfiHiiDatabaseProtocolGuid, NULL, (VOID **) &HiiDatabase);
         if (EFI ERROR (Status)) {
          return Status;
         PrivateData->HiiDatabase = HiiDatabase;
         // Locate HiiString protocol
         Status = gBS->LocateProtocol (&gEfiHiiStringProtocolGuid, NULL, (VOID **) &HiiString);
         if (EFI ERROR (Status)) {
           return Status;
         PrivateData->HiiString = HiiString;
         // Locate Formbrowser2 protocol
         //
         Status = gBS->LocateProtocol (&gEfiFormBrowser2ProtocolGuid, NULL, (VOID **) &FormBrowser2);
         if (EFI ERROR (Status)) {
           return Status;
         PrivateData->FormBrowser2 = FormBrowser2;
         // Locate ConfigRouting protocol
         //
         Status = gBS->LocateProtocol (&gEfiHiiConfigRoutingProtocolGuid, NULL, (VOID **)
       &HiiConfigRouting);
         if (EFI ERROR (Status)) {
           return Status;
         PrivateData->HiiConfigRouting = HiiConfigRouting;
```


```
Step
         Action
        225
        226
        227
            // Locate Hii Database protocol
        228
        229
        230 Status = gBS->LocateProtocol (&gEfiHiiDatabaseProtocolGuid, NUL:
        231 if (EFI_ERROR (Status)) {
        232
              return Status;
        233 }
        234 PrivateData->HiiDatabase = HiiDatabase;
        235
        236 //
            // Locate HiiString protocol
//
        237
        238
        239 Status = gBS->LocateProtocol (&gEfiHiiStringProtocolGuid, NULL,
        240 if (EFI ERROR (Status)) {
        241 return Status;
        242 }
        243 PrivateData->HiiString = HiiString;
        244
        245 //
246 // Locate Formbrowser2 protocol
        248 Status = gBS->LocateProtocol (&gEfiFormBrowser2ProtocolGuid, NU.
        249 if (EFI_ERROR (Status)) {
        250
              return Status;
        251 }
        252 PrivateData->FormBrowser2 = FormBrowser2;
        253
        254
             // Locate ConfigRouting protocol
//
        255
        256
        257 Status = gBS->LocateProtocol (&gEfiHiiConfigRoutingProtocolGuid
        258 if (EFI_ERROR (Status)) {
        259
              return Status;
        260 }
        261 PrivateData->HiiConfigRouting = HiiConfigRouting;
        262
        263
        264
              // Publish sample Fromset and config access
        265
        266 //
        267 Status = gBS->InstallMultipleProtocolInterfaces (
```

#### Action Step Since the Hii Database Protocol was located earlier in the code with the previous code insertion and is no 4 longer necessary, comment out the old OpenProtocol code with the "//" (approx. lines 289-298, as shown below) and add the comment // Done above Make sure not to comment out the second " if (!EFI ERROR (Status)) {" 281 Status = gBS->OpenProtocol ( 282 ImageHandle, 283 &gEfiHiiPackageListProtocolGuid, 284 (VOID \*\*) & PackageListHeader, 285 ImageHandle, 286 NULL, 287 EFI\_OPEN\_PROTOCOL\_GET\_PROTOCOL 288 289 // Done above 290 // if (!EFI\_ERROR (Status)) { 291 // // // Retrieve the pointer to the UEFI HII Database Protocol 292 // 293 // // 294 // Status = gBS->LocateProtocol ( 295 // &gEfiHiiDatabaseProtocolGuid, 296 // NULL. (VOID \*\*) &HiiDatabase 297 // 298 // ); if (!EFI ERROR (Status)) { **Note**: The earlier LocateProtocol code already found the pointer to the Hii Database protocol and stored it to the local pointer variable HiiDatabase. When we added the driver-consumed protocols, we searched via LocateProtocol for the Hii Database pointer function. Since we did it above we're now commenting out this code. Comment out the matching "}" with "//" to the if statement (as shown below at 5 approx. line 310): 299 if (!EFI ERROR (Status)) { 300 // 301 // Register list of HII packages in the HII Database 302 // 303 Status = HiiDatabase->NewPackageList ( 304 HiiDatabase. 305 PackageListHeader, 306 mDriverHandle[0], 307 &HiiHandle[0] 308 ); 309 ASSERT EFI ERROR (Status); 310 // 312 Status = EFI\_SUCCESS; 313 Save MyWizardDriver.c 6


Step	Action
7	<b>Open</b> C:\fw\edk2\MyWizardDriver\HiiConfigAccess.c. The Driver Wizard only made dummy functions for the extract, route and callback functions. In order to save the Data passed into the forms from the Hii Browser engine, you will need to port these functions to be functional.
8	<b>Add</b> the following <code>extern</code> statements for the form GUID and the NVRam variable (as shown below) these are global to the driver module only hence the beginning lower case " $m$ " is the standard for a global for a module :
	<pre>extern EFI_GUID mMyWizardDriverFormSetGuid; extern CHAR16 mIfrVariableName[];</pre>
	12 #include "MyWizardDriver.h" 13
	14 extern EFI_GUID mMyWizardDriverFormSetGuid; 15 extern CHAR16 mIfrVariableName[]; 16 17 18 /// 19 /// HII Config Access Protocol instance
9	Locate MyWizardDriverHiiConfigAccessExtractConfig and replace line 108, "return EFI_NOT_FOUND", with the following code spread over two pages:
	FROM:    Star
	104 return EFI_NOT_FDUND; 105 } 106

```
Step
       Action
         EFI STATUS
                                         Status;
                                         BufferSize;
         UINTN
        MYWIZARDDRIVER DEV
                                              *PrivateData;
        EFI HII CONFIG ROUTING PROTOCOL *HiiConfigRouting;
        EFI STRING
                                         ConfigRequest;
        EFI STRING
                                          ConfigRequestHdr;
        UINTN
                                          Size;
         BOOLEAN
                                          AllocatedRequest;
         if (Progress == NULL || Results == NULL) {
          return EFI INVALID PARAMETER;
         //
         // Initialize the local variables.
         //
         ConfigRequestHdr = NULL;
        ConfigRequest = NULL;
         Size
                          = 0;
        size = 0;
*Progress = Request;
        AllocatedRequest = FALSE;
        PrivateData = MYWIZARDDRIVER DEV FROM THIS (This);
        HiiConfigRouting = PrivateData->HiiConfigRouting;
         // Get Buffer Storage data from EFI variable.
         // Try to get the current setting from variable.
         //
         BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
         Status = gRT->GetVariable (
                  mIfrVariableName,
                   &mMyWizardDriverFormSetGuid,
                   NULL,
                   &BufferSize,
                  &PrivateData->Configuration
```

```
Step
      Action
      if (EFI ERROR (Status)) {
        return EFI NOT FOUND;
        if (Request == NULL) {
                DEBUG ((DEBUG INFO, "\n:: Inside of Extract Config and Request ==
      Null "));
        } else {
          ConfigRequest = Request;
          // Convert buffer data to <ConfigResp> by helper function BlockToConfig()
          //
          Status = HiiConfigRouting->BlockToConfig (
                                         HiiConfigRouting,
                                         ConfigRequest,
                                         (UINT8 *) &PrivateData->Configuration,
                                         BufferSize,
                                         Results,
                                         Progress
                                         );
        // Free the allocated config request string.
        if (AllocatedRequest) {
         FreePool (ConfigRequest);
        //
        // Set Progress string to the original request string.
        if (Request == NULL) {
          *Progress = NULL;
        } else if (StrStr (Request, L"OFFSET") == NULL) {
          *Progress = Request + StrLen (Request);
        return Status;
      Now locate MyWizardDriverHiiConfigAccessRouteConfig and replace line at approx.
10
      228, "return EFI NOT FOUND", with the following code:
```




```
Step
        Action
          EFI STATUS
                                           Status;
         UINTN
                                           BufferSize;
         MYWIZARDDRIVER DEV
                                                *PrivateData;
         EFI HII CONFIG ROUTING PROTOCOL *HiiConfigRouting;
          if (Configuration == NULL || Progress == NULL) {
           return EFI INVALID PARAMETER;
          PrivateData = MYWIZARDDRIVER DEV FROM THIS (This);
          HiiConfigRouting = PrivateData->HiiConfigRouting;
          *Progress = Configuration;
          // Get Buffer Storage data from EFI variable
          BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
          Status = gRT->GetVariable (
                    mIfrVariableName,
                    &mMyWizardDriverFormSetGuid,
                    NULL,
                    &BufferSize,
                    &PrivateData->Configuration
          if (EFI ERROR (Status)) {
           return Status;
          }
          // Convert <ConfigResp> to buffer data by helper function ConfigToBlock()
          BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
          Status = HiiConfigRouting->ConfigToBlock (
                                       HiiConfigRouting,
                                       Configuration,
                                        (UINT8 *) &PrivateData->Configuration,
                                       &BufferSize,
                                       Progress
          if (EFI_ERROR (Status)) {
           return Status;
         // Store Buffer Storage back to EFI variable
          Status = gRT->SetVariable(
                          mIfrVariableName,
                          &mMyWizardDriverFormSetGuid,
                          EFI VARIABLE NON VOLATILE | EFI VARIABLE BOOTSERVICE ACCESS,
                          sizeof (MYWIZARDDRIVER CONFIGURATION),
                          &PrivateData->Configuration
                          );
                  DEBUG ((DEBUG_INFO, "\n:: ROUTE CONFIG Saving the configuration to NVRAM \n"));
          return Status;
          //return EFI NOT FOUND;
```



Ston	Action
Step	Action
21	<pre>FSO:\&gt; load MyWizardDriver.efi Image 'FSO:\MyWizardDriver.efi' loaded at 5EB9000 - Success FSO:\&gt; exit_</pre> Type exit
22	Press "Enter"
23	Continue Select Language Boot Manager  Continue Select Manager  Continue Select Language  Contin
	▶ Boot Maintenance Manager
24	Press "Enter"
25	Device Manager  Device Manager  Devices List Platform Driver Override selection Formset  Formset  Browser Testcase Engine ABC Information Sample My Wizard Driver Sample Formset  Press "Enter".
26	My Wizard Driver  My Wizard Driver Configuration  This is the help
	Device XYZ Configuration  Enable My XYZ Device  [X]  Enable My XYZ Device  [X]  Check this box to enable this device.

Step	Action
27	<b>Note</b> : Once you hit "Enter", notice that your form is now displayed with a choice to enable your Device. Also notice the titles and help strings that are in the .UNI file you edited.
28	Test by <b>Press</b> the space bar to Enable and Disable the "Enable My XYZ Device" to change its value from: [X] to [1]
29	Note: Notice the "Configuration changed" message at the menu bottom.  F9=Reset to Defaults F10=Save  14=Move Highlight <spacebar>Toggle Checkbox Esc=Exit</spacebar>
	Configuration changed
30	Press "F10"
31	Press "Escape" to exit
32	Press "Escape" to exit the "Device Manager" Page
33	Press Up Arrow to "Continue"
	Continue Select Language ⟨Standard English⟩ direct the system to boot Manager Continue to booting Continu
34	Press "Enter"
35	At the Shell Prompt type dmpstore -all



For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.2 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean

# 3. Updating your driver to initialize data from the VFR data to the HII Database

In this lab, you'll learn how to update your driver to initialize the data according to the defaults set in the .VFR file. Thus when the user enters your driver's menu for the first time, the values will display the defaults according to the .VFR file settings. You will also learn the rich set of HII function calls that are part of the MdeModulePkg in the HiiLib by reviewing the "MdeModulePkg Document.chm".

### a. Add HII Library Calls to Your Driver

For this lab you will update the following files: MyWizardDriver.inf, MyWizardDriver.h, and MyWizardDriver.c

Step	Action
1	Update the MyWizardDriver.inf file
2	Add the following package (as shown below):
	The HII Library in the MdeModulePkg has many functions to help with Communication to/from the Hii Database and Hii forms. One function call HiiSetToDefaults will compare the default settings from the .VFR file and update the driver's configuration buffer according to the settings in the .VFR file.
	MdeModulePkg/MdeModulePkg.dec
	22 [Packages] 23 MdePkg/MdePkg.dec 24 MdeModulePkg/MdeModulePkg.dec
	<b>Note</b> : For other functions from the HII Library, open the .chm file "MdeModulePkg Document.chm" and search for HiiLib.h.
3	Add the following library class (as shown below):
	HiiLib
	39 [LibraryClasses] 40    UefiDriverEntryPoint 41    UefiBootServicesTableLib 42    MemoryAllocationLib 43    BaseMemoryLib 44    BaseLib 45    UefiLib 46    DevicePathLib 47    DebugLib 48    HiiLib

Step	Action
4	Save MyWizardDriver.inf
5	Update the MyWizardDriver.h file
6	Add the following code (as shown below):
	<pre>#include <library hiilib.h=""></library></pre>
	42 // Added for HII 43 #include <protocol hiiconfigrouting.h=""> 44 #include <protocol formbrowser2.h=""> 45 #include <protocol hiistring.h=""> 46 #include <library devicepathlib.h=""> 47 #include <library hiilib.h=""></library></library></protocol></protocol></protocol>
7	Save MyWizardDriver.h
8	Update the MyWizardDriver.c file
9	Add Locals: first add 2 locals for your drivers configuration buffer and a boolean flag from the Hii Library calls  Add the following at Approx. Line 190.  MYWIZARDDRIVER_CONFIGURATION *Configuration; BOOLEAN *Configuration; ActionFlag;
	180  181  // HII Locals  182  EFI_HII_PACKAGE_LIST_HEADER
10	Add the following to the MyWizardDriverDriverEntryPoint entry point funtion to line 319, approximately after "BufferSize =" as shown below

```
Action
Step
               //
               // Initialize configuration data
               Configuration = &PrivateData->Configuration;
               ZeroMem (Configuration, sizeof (MYWIZARDDRIVER CONFIGURATION));
               //
               // Try to read NV config EFI variable first
               ConfigRequestHdr = HiiConstructConfigHdr (&mMyWizardDriverFormSetGuid,
           mIfrVariableName, mDriverHandle[0]);
               ASSERT (ConfigRequestHdr != NULL);
            317
            318
                   BufferSize = sizeof (MYWIZARDDRIVER CONFIGURATION);
            319 //
            320
                  // Initialize configuration data
            321
                 //
            322
                  Configuration = &PrivateData->Configuration;
            323
                   ZeroMem (Configuration, sizeof (MYWIZARDDRIVER_CONFIGURATION));
            324
            325 //
            326 // Try to read NV config EFI variable first
            327 //
            328 ConfigRequestHdr = HiiConstructConfigHdr (&mMyWizardDriverFormSetGuid, mIfrVa
            329
                  ASSERT (ConfigRequestHdr != NULL);
            330
            331
                   // IF driver is not part of the Platform then need to get/set defaults for the
            332
                   Status = gRT->GetVariable (
            333
11
           Modify the following lines:
           @~338: remove: "&PrivateData->" from the "&PrivateData->Configuration"
           @~342: remove line: ZeroMem (&PrivateData->Configuration, sizeof
           (MYWIZARDDRIVER CONFIGURATION));
           @~347: remove: "&PrivateData->" from the "&PrivateData->Configuration"
           FROM
                                                                                                                                 TO
                // IF driver is not part of the Platform then need to get/set defaults for the N Status = gRT->GetVariable (
                                                                                      // IF driver is not part of the Platform then need to get/set defaults for
            320
                       mIfrVariableName
                                                                                  333
                                                                                      Status = gRT->GetVariable
                       .....varıableName,
&mMyWizardDriverFormSetGuid,
NULL.
            321
                                                                                             mIfrVariableName,
&mMyWizardDriverFormSetGuid,
                                                                                  334
                                                                                  335
            323
                        &BufferSize
                                                                                 336
                                                                                             NULL,
           324
325
                                                                                             &BufferSize
                       &PrivateData->Configuration
                                                                                             Configuration
                if (EFI ERROR
            326
                     // zero out buffer
ZeroMem (&PrivateData->Configuration, sizeof (MYWIZARDDRIVER_CONFIGURAT_W)
                                                                                  340
                                                                                     if (EFI_ERROR (Status)) { // Not definded yet so add it to the NV Variables
                                                                                             // zero out buffer
Status = gRT->SetVariable(
                              s = gRT->SetVariable(
                                                                                  342
            330
                            mTfrVariableName
                                                                                  343
                                                                                                 mTfrVariableName
                            mIfr'variableName,

6mMyWizardDriverFormSetGuid,

EFI_VARIABLE_NON_VOLATILE | EFI_VARIABLE_BOOTSERVICE_ACCESS,

Sizeof (MYWIZARDDSLYER_CONFIGURATION),

EPrivateData=>Configuration // buffer is 000000 now
                                                                                                 EFI_VARIABLE_NON_VOLATILE | EFI_VARIABLE_BOOTSERVICE_ACCESS,
            332
                                                                                  345
                                                                                  346
                                                                                                  sizeof (MYWIZARDDRIVER_CONFIGURATION)
                                                                                                  Configuration // buffer is 000000 now
            335
                                                                                 348
                                                                                 349
350
                                                                                       // EFI variable for NV config doesn't exist, we should build this variable
```

#### Action Step 12 Add the following code to the MyWizardDriverDriverEntryPoint entry point code at approximately line 349 before // Install Driver Supported EFI Version Protocol onto ImageHandle // You're **deleting** the "}' and replacing it with the following code (as shown below). With this replacement we are adding an "else" to the "if" statement: // EFI variable for NV config doesn't exist, we should build this variable // based on default values stored in IFR ActionFlag = HiiSetToDefaults (ConfigRequestHdr, EFI HII DEFAULT CLASS STANDARD); ASSERT (ActionFlag); } else { // // EFI variable does exist and Validate Current Setting ActionFlag = HiiValidateSettings (ConfigRequestHdr); ASSERT (ActionFlag); } // Match if (EFI ERROR (Status)) FreePool (ConfigRequestHdr); // end HII 347 Configuration // buffer is 000000 now 348 349 // // EFI variable for NV config doesn't exist, we should build this variable 350 351 // based on default values stored in IFR 352 ActionFlag = HiiSetToDefaults (ConfigRequestHdr, EFI\_HII\_DEFAULT\_CLASS\_STAN 353 354 ASSERT (ActionFlag); 355 } else { 356 // EFI variable does exist and Validate Current Setting 357 358 ActionFlag = HiiValidateSettings (ConfigRequestHdr); 359 360 ASSERT (ActionFlag); 361 } // Match if (EFI\_ERROR (Status)) 362 FreePool (ConfigRequestHdr); 363 364 365 // end HII 366 // Install Driver Supported EFI Version Protocol onto ImageHandle 367 368 // 369 Status = gBS->InstallMultipleProtocolInterfaces (

Step	Action	
	Note the "}" on line 361 is still matching the initial if statement.	
	Make sure you do not have a duplicate "}"	
13	Save the MyWizardDriver.c file	
14	In the Visual Studio Command Prompt, type build	
15	Press "Enter"	
16	Type build run	
17	Press "Enter"	
18	At the UEFI Shell prompt, <b>type</b> fs0:	
19	Press "Enter"	
20	Type Load MyWizardDriver.efi	
21	Press "Enter"	
22	Type exit	
	FSO:\> load MyWizardDriver.efi	
	Image 'FSO:\MyWizardDriver.efi' loaded at 5EB9000 - Success	
	FSO:\> exit_	
23	Press "Enter"	
24	Now at the setup front page menu select "Device Manager"	
24	Now at the setup from page mena select Bevice Flanager	
	Continue This selection will	
	Select Language <english> take you to the  ▶ Boot Manager Device Manager</english>	
	Device Manager  Device Manager	
	▶ Boot Maintenance Manager	
25	Press "Enter"	
	Inside the Device Manager menu press the down arrow to "My Wizard Driver	
	Sample Formset"	
	Device Manager	
	Devices List Help for Sample	
	► Platform Driver Override selection Formset	
	<ul><li>▶ iSCSI Configuration</li><li>▶ Browser Testcase Engine</li></ul>	
	► ABC Information Sample	
	My Wizard Driver Sample Formset	
	Proce ESC to exit	

Step	Action
26	Press "Enter" .
	My Wizard Driver
	My Wizard Driver Configuration  Device XYZ Configuration  Enable My XYZ Device  [X]  Enable My XYZ Device  Check this box to enable this device.
27	Press "Escape" to exit
28	To Exit the "Device Manager" Page: <b>Press</b> "Escape"
	Devices List  Platform Driver Override selection  iSCSI Configuration  Browser Testcase Engine  ABC Information Sample  My Wizard Driver Sample Formset  Press ESC to exit.
29	Press Up Arrow to "Continue"
	Continue Select Language Standard English> Boot Manager  Device Manager  Boot Manager  Boot Manager  Double Manager  Boot Maintenance Manager  Double Manager  Boot Maintenance Manager
30	Press "Enter"
31	Type Reset
	Press ESC in 4 seconds to skip Shell> reset_


Step	Action
32	Press "Enter" to return to the Visual Studio Command Prompt
	C:\FW\edk2>

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.3 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean

#### b. Add your Driver to the platform

As of now, your driver needs to be soft loaded each time from the shell prompt. In this lab, you'll update the platform .FDF file to force your driver to load as part of the platform UEFI driver.

Step	
1	<pre>Open to update: C:\fw\edk2\Nt32PkgNt32Pkg.Fdf Add the following code (as shown below before "!if \$(BUILD_NEW_SHELL) == TRUE"):</pre>
2	<pre>INF MyWizardDriver/MyWizardDriver.inf INF MdeModulePkg/Universal/Network/IScsiDxe/IScsiDxe.inf INF MyWizardDriver/MyWizardDriver.inf !if \$(BUILD_NEW_SHELL) == TRUE INF ShellPkg/Application/Shell/Shell.inf !endif</pre>
3	Save Nt32pkg.fdf
4	In the Visual Studio Command Prompt, type build
5	Press "Enter"
6	Type build run
7	Press "Enter"
8	At the Shell prompt type: exit Press ESC in 1 seconds to skip : Shell> exit_
9	Press "Enter"
10	Now at the setup front page menu press the down arrow to "Device Manager"  Continue Select Language Boot Manager  Boot Manager  Boot Maintenance Manager
11	Press "Enter"




### 4. Updating the Menu: Reset Button

In this lab, you'll learn how to add a reset button to your driver's form menu. It's time to add more configuration fields to your menu, enabling users to modify more fields now that you've built a driver that 1) saves data from forms into NVRAM 2) updates data from the .VFR forms and 3) builds into the platform drivers.

The next set of labs will update .VFR, MyWizardDriver.vfr, and UNI MyWizardDriver.uni string files to incrementally add a reset button (Lab 4), pop-up box (Lab 5), string name (Lab 6), and numeric hex value (Lab 7) to your driver's form menu:

Ste p	Action
1	<b>Update</b> the MyWizardDriver.vfr file
2	<b>Add</b> the following code (as shown below after the "GUID" definition Apprx. Line 29):
	With this code you are created a VFR sub-function called "MyStandardDefault"
	<pre>defaultstore MyStandardDefault,     prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT),     attribute = 0x0000;    // Default ID: 0000 standard default</pre>
	27 guid = MYWIZARDDRIVER_FORMSET_GUID; // GUID of this buffer storage 28 29 defaultstore MyStandardDefault, 30 prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT), 31 attribute = 0x0000; // Default ID: 0000 standard default 32
3	Add the following code before the "endform" (as shown below Approx. Line 55):
	resetbutton defaultstore = MyStandardDefault, prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT_RESET), help = STRING_TOKEN(STR_STANDARD_DEFAULT_HELP), endresetbutton;

S2	Ste p	Action
Signature		52 endcheckbox:
SS   resetbutton   S6   defaultstore = MyStandardDefault,   S7   prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT_RESET),   S8   help = STRING_TOKEN(STR_STANDARD_DEFAULT_HELP),   S9   endresetbutton;   60   61   62   endform;   63   64   endformset;   63   64   endformset;   64   endformset;   65   Update the MyWizardDriver.uni file   Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:   #string_STR_STANDARD_DEFAULT_PROMPT_RESET_#language_en   "Standard_Default"   #string_STR_STANDARD_DEFAULT_PROMPT_RESET_#language_en   "Reset_to_Standard_Default"   #string_STR_STANDARD_DEFAULT_HELP_#language_en   "This will reset_all the Questions to their standard_default_value"   7   Save_MyWizardDriver.uni   8   In the Visual_Studio_Command_Prompt, type_build_   9   Press_"Enter"   10   Type_build_run_   11   Press_"Enter"   12   Type_exit_   13   Press_"Enter"   14   Now at the setup front page_menu_press_the_down_arrow_to_"Device_Manager"   15   Press_"Enter"   16   Inside_the_Device_Manager_menu_press_the_down_arrow_to_"My		
S6		54
STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT_RESET),   SS		
58 help = STRING_TOKEN(STR_STANDARD_DEFAULT_HELP), 59 endresetbutton; 60 61 62 endform; 63 64 endformset;  4 Save MyWizardDriver.vfr  5 Update the MyWizardDriver.uni file 6 Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
59 endresetbutton; 60 61 62 endform; 63 64 endformset;  4 Save MyWizardDriver.vfr  5 Update the MyWizardDriver.uni file 6 Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
4 Save MyWizardDriver.vfr 5 Update the MyWizardDriver.uni file 6 Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
4 Save MyWizardDriver.vfr  5 Update the MyWizardDriver.uni file  Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni  8 In the Visual Studio Command Prompt, type build  9 Press "Enter"  10 Type build run  11 Press "Enter"  12 Type exit  13 Press "Enter"  14 Now at the setup front page menu press the down arrow to "Device Manager"  15 Press "Enter"  16 Inside the Device Manager menu press the down arrow to "My		60
4 Save MyWizardDriver.vfr  5 Update the MyWizardDriver.uni file  6 Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni  8 In the Visual Studio Command Prompt, type build  9 Press "Enter"  10 Type build run  11 Press "Enter"  12 Type exit  13 Press "Enter"  14 Now at the setup front page menu press the down arrow to "Device Manager"  15 Press "Enter"  16 Inside the Device Manager menu press the down arrow to "My		
4 Save MyWizardDriver.vfr 5 Update the MyWizardDriver.uni file 6 Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
Jupited the MyWizardDriver.uni file  Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
Jupited the MyWizardDriver.uni file  Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My	4	Save MyWizardDriver vfr
Add the following strings at the end of the file to support the "STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My	_	,
"STR_" referenced added in the .vfr file:  #string STR_STANDARD_DEFAULT_PROMPT #language en "Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
"Standard Default" #string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		· · ·
#string STR_STANDARD_DEFAULT_PROMPT_RESET #language en "Reset to Standard Default" #string STR_STANDARD_DEFAULT_HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		#string STR STANDARD DEFAULT PROMPT #language en
"Reset to Standard Default" #string STR STANDARD DEFAULT HELP #language en "This will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		"Standard Default"
#string STR STANDARD DEFAULT HELP #language en "This will reset all the Questions to their standard default value"  7		<pre>#string STR_STANDARD_DEFAULT_PROMPT_RESET #language en</pre>
will reset all the Questions to their standard default value"  7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		"Reset to Standard Default"
7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
7 Save MyWizardDriver.uni 8 In the Visual Studio Command Prompt, type build 9 Press "Enter" 10 Type build run 11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
In the Visual Studio Command Prompt, type build Press "Enter" Type build run Type exit Press "Enter" Now at the setup front page menu press the down arrow to "Device Manager" Typess "Enter" Inside the Device Manager menu press the down arrow to "My		value"
In the Visual Studio Command Prompt, type build Press "Enter" Type build run Type exit Press "Enter" Now at the setup front page menu press the down arrow to "Device Manager" Typess "Enter" Inside the Device Manager menu press the down arrow to "My		
9 Press "Enter"  10 Type build run  11 Press "Enter"  12 Type exit  13 Press "Enter"  14 Now at the setup front page menu press the down arrow to "Device Manager"  15 Press "Enter"  16 Inside the Device Manager menu press the down arrow to "My		,
10 Type build run  11 Press "Enter"  12 Type exit  13 Press "Enter"  14 Now at the setup front page menu press the down arrow to "Device Manager"  15 Press "Enter"  16 Inside the Device Manager menu press the down arrow to "My		· · · • •
11 Press "Enter" 12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My		
12 Type exit 13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My	10	, .
13 Press "Enter" 14 Now at the setup front page menu press the down arrow to "Device Manager" 15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My	11	
Now at the setup front page menu press the down arrow to "Device Manager"  15 Press "Enter"  16 Inside the Device Manager menu press the down arrow to "My		
<ul> <li>Manager"</li> <li>15 Press "Enter"</li> <li>16 Inside the Device Manager menu press the down arrow to "My</li> </ul>	13	
15 Press "Enter" 16 Inside the Device Manager menu press the down arrow to "My	14	Now at the setup front page menu press the <b>down arrow</b> to <b>"Device</b>
16 Inside the Device Manager menu press the down arrow to "My		Manager"
	15	Press "Enter"
Wizard Driver Sample Formset"	16	Inside the Device Manager menu press the down arrow to "My Wizard Driver Sample Formset"



For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.4 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

## 5. Updating the Menu: Pop-up Box

In this lab, you'll learn how to add a *pop-up box* to your driver's form menu by using the "oneof" VFR term. We will also only update the MyWizardDriver.vfr and MyWizardDriver.uni files.





Figure 5 My Wizard Driver with a pop-up box

Step	Action		
	<u>Backgrou</u>	nd Information	(not a step)
	The VFR t	erm "oneof"	will declare a pop-up menu. The user then selects one field that will
		e value stored	in the NVRAM variable. Looking at Figure 6 above, there are three
	values:		
	Value	Display	String token
	0	500 Hex	STR_ONE_OF_TEXT3
	1	480 Hex	STR_ONE_OF_TEXT2
	2	400 Hex	STR_ONE_OF_TEXT1
	Add code	e to give you	driver menu a pop-up menu item by defining a "oneof"
	item. Al	so, if the dev	ice is "disabled", then use the VFR term "grayoutif"
			pop-up menu is not accessible and cannot be
			er engine will use the configuration variable
		•	/izardDriverChooseToEnable with a value of 0x0 to
			ce is enabled or disabled
1	<b>Update</b> th	ne MyWizardDı	iver.vfr file
2	<b>Add</b> the 53)	following cod	de before the "resetbutton" statement (approximately line

```
Step
      Action
          //
          // Define oneof (EFI IFR ONE OF)
         qrayoutif ideqval MWD IfrNVData.MyWizardDriverChooseToEnable ==
      0x0;
                                                                 // Define
          oneof name = MyOneOf2,
      reference name for Question
            varid = MWD IfrNVData.MyWizardDriverBaseAddress,
            // Use "DataStructure.Member" to reference Buffer Storage
            prompt = STRING TOKEN(STR ONE OF PROMPT),
            help = STRING TOKEN(STR ONE OF HELP),
            //
            // Define an option (EFI IFR ONE OF OPTION)
            option text = STRING TOKEN(STR ONE OF TEXT3), value = 0x0,
      flags = 0;
            option text = STRING TOKEN(STR ONE OF TEXT2), value = 0x1,
      flags = 0;
            //
            // DEFAULT indicate this option will be marked with
            // EFI IFR OPTION DEFAULT
            //
            option text = STRING TOKEN(STR ONE OF TEXT1), value = 0x2,
                flags = DEFAULT;
          endoneof;
         endif;
```

```
Action
Step
                             default = 1,
         52
                 endcheckbox;
         53
              // Define oneof (EFI_IFR_ONE_OF)
         54
         55
         56
              grayoutif ideqval MWD IfrNVData.MyWizardDriverChooseToEnable == 0x0;
         57
         58
               oneof name = MyOneOf2,
                                                                       // Define reference
                varid = MWD_IfrNVData.MyWizardDriverBaseAddress,
         59
                 // Use "DataStructure.Member" to reference Buffer Storage
         60
         61
                prompt = STRING_TOKEN(STR_ONE_OF_PROMPT),
         62
                 help = STRING_TOKEN(STR_ONE_OF_HELP),
         63
         64
                 // Define an option (EFI_IFR_ONE_OF_OPTION)
         65
                 option text = STRING_TOKEN(STR_ONE_OF_TEXT3), value = 0x0, flags = 0;
         66
                 option text = STRING_TOKEN(STR_ONE_OF_TEXT2), value = 0x1, flags = 0;
         67
                 // DEFAULT indicate this option will be marked with
         70
                 // EFI_IFR_OPTION_DEFAULT
         71
         72
                 option text = STRING_TOKEN(STR_ONE_OF_TEXT1), value = 0x2,
         73
                     flags = DEFAULT;
         74
               endoneof;
         75
             endif;
         76
         77
         78
               resetbutton
         79
                  defaultstore = MyStandardDefault,
         Save the MyWizardDriver.vfr file
3
         Update the MyWizardDriver.uni file
4
         Add the following code to the end of the file (as shown below):
5
        #string STR ONE OF PROMPT
                                                   #language en "Select Base Address"
         #string STR ONE OF HELP
                                                   #language en "Select a Base address of 400,
        480 or 500 Hex. Values 0,1 or 2(default) is stored in the NVRAM Data"
        #string STR ONE OF TEXT1
                                                   #language en "400 Hex"
        #string STR ONE OF TEXT2
                                                   #language en "480 Hex"
         #string STR ONE OF TEXT3
                                                   #language en "500 Hex"
         33 #string STR_STANDARD_DEFAULT_HELP
                                      #language en "This will reset all the Questions to their
         35 #string STR_ONE_OF_PROMPT
                                      #language en "Select Base Address"
         37 #string STR ONE OF HELP
                                      #language en "Select a Base address of 400, 480 or 500 H
         39 #string STR_ONE_OF_TEXT1
                                      ‡language en "400 Hex"
         41 #string STR_ONE_OF_TEXT2
                                      #language en "480 Hex"
          43 #string STR ONE OF TEXT3
         Save MyWizardDriver.uni
6
        In the Visual Studio Command Prompt, type build
         Press "Enter"
8
```





Step	Action
29	Type "reset" at the Shell prompt
30	Press "Enter" to return to the Visual Studio Command Prompt C:\FW\edk2>

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.5 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

# 6. Updating the Menu: Creating a String to Name a Saved Configuration

In this lab, you'll create a string to name a saved configuration that will be stored into the NVRAM variable space. This lab uses the VFR term "string" to prompt the user to enter a string value. The VFR can determine the minimum and maximum number of characters of the string length with the terms "minsize" and "maxsize". Since there is also an enable/disable switch, the VFR can use the "grayoutif" term again to allow or disallow changes to this field.





Figure 6: Menu with a string item

Step	Action
1	<b>Update</b> the MyWizardDriver.vfr file
2	<b>Add</b> the following code to the location at approx. line 77 and before the "resetbutton" item (as shown below):

```
Step
        Action
        // Define a string (EFI IFR STRING) to name the configuration in
        // NVRAM variable
          grayoutif ideqval MWD IfrNVData.MyWizardDriverChooseToEnable ==
        0x0;
             string
                        varid = MWD IfrNVData.MyWizardDriverStringData,
                        prompt = STRING TOKEN(STR MY STRING PROMPT),
                        help = STRING TOKEN (STR MY STRING HELP),
                        minsize = 3,
                        maxsize = 20,
            endstring;
          endif;
               endoneof;
        75
               endif;
        76
        77
        78
               77
        79
               // Define a string (EFI_IFR_STRING) to name the configuration in the
        80
               // NVRAM variable
        81
               11
        82
        83
               11
        84
             grayoutif ideqval MWD IfrNVData.MyWizardDriverChooseToEnable == 0x0;
        85
        86
               string varid = MWD_IfrNVData.MyWizardDriverStringData,
        87
                       prompt = STRING_TOKEN(STR_MY_STRING_PROMPT),
                       help = STRING_TOKEN(STR_MY_STRING_HELP),
        88
        89
                       minsize = 3,
        90
                       maxsize = 20,
        91
        92
              endstring;
        93
             endif;
        94
        95
             resetbutton
        96
                defaultstore = MyStandardDefault,
        97
                prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT_RESET),
                help = STRING_TOKEN(STR_STANDARD_DEFAULT_HELP),
        98
        99
              endresetbutton;
        Save MyWizardDriver.vfr
 3
        Update MyWizardDriver.uni
 4
        Add the following code to the bottom of the file:
 5
```

Step	Action		
	#string STR_MY_STRING_PROMPT #language en "Name of Configuration"		
	<pre>#string STR_MY_STRING_HELP #language en "Enter a name for this configuration. This string can is 3 to 20 characters"</pre>		
	39 #string STR_ONE_OF_TEXT1 #language en "400 Hex" 40 41 #string STR_ONE_OF_TEXT2 #language en "480 Hex" 42		
	43 #string STR_ONE_OF_TEXTS #language en "500 Hex"  44  45 #string STR_MY_STRING_PROMPT #language en "Name of Configuration"  46  47 #string STR_MY_STRING_HELP #language en "Enter a name for this configuration. This  48  49		
	Save MyWizardDriver upi		
6	Save MyWizardDriver.uni In the Visual Studio Command Prompt, type build		
7 8	Press "Enter"		
9	Type build run		
10	Press "Enter"		
11	Type exit		
12	Press "Enter"		
13	Now at the setup front page menu, select "Device Manager"		
14	Press "Enter"		
15	Inside the Device Manager menu, select "My Wizard Driver Sample Formset"		
16	Select "Name of Configuration"		
17	Press "Enter"		





Step	Action		
26	Press the "Spacebar" to toggle off/disable		
	<b>Notice</b> that the "Select Base Address" and "Name of Configruation" fields are now grayed out and not selectable		
	My Wizard Driver		
	My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address Name of Configuration Reset to Standard Default  This is the help message for the enable My XYZ device. Check this box to enable this device.		
27	Press "Space" again to Enable		
28	Press "F10" to save		
29	Press "Escape" to exit		
30	Press "Escape" to exit the "Device Manager"		
31	Select "Continue"		
32	Press "Enter"		
33	At the Shell Prompt, <b>type</b> dmpstore -all  Notice the unicode string "12345678901234567890" is now stored because you entered those characters in the HII form menu. This is because the file WizardDriverNVDataStruc.h has the data structure stored in NVRAM with the GUID define name MWD_IfrNVData of type  MYWIZARDDRIVER_CONFIGURATION. Notice that string data is the first 20 bytes in the data structure MWD_IfrNVData.MyWizardDriverStringData		

```
Action
Step
           00000020: 04 00 00 00 00 10 00 00-0E 00 00 00 00 00 00 0 *.....
34
          Variable - NV+BS - '5481DB09-E5F7-4158-A5C5-2DBEA49534FF:MVD_IfrNVData' - DataSi
         ze = 0x2B
           000000000: 31 00 32 00 33 00 34 00-35 00 36 00 37 00 38 00 *1.2.3.4.5.6.7.8.*
           00000010: 39 00 30 00 31 00 32 00-33 00 34 00 35 00 36 00 *9.0.1.2.3.4.5.6.*
           00000020: 37 00 38 00 39 00 30 00-00 01 01
                                                                     *7.8.9.0....*
         Shell>_
         21 #pragma pack(1)
         22 typedef struct {
              UINT16 MyWizardDriverStringData[20]
              UINT8 MyWizarquriverHexDava,
         25
               UINT8 MyWizardDriverBaseAddress;
         27
               UINT8 MyWizardDriverChooseToEnable;
         29 } MYWIZARDDRIVER_CONFIGURATION;
        Type "reset" at the Shell prompt
35
        Press "Enter" to return to the Visual Studio Command Prompt
36
         C:\FW\edk2>
```

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.6 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

### 7. Updating the Menu: Numeric Entry

In this lab, you'll learn how to add a numeric entry to your driver menu. This lab uses the VFR term "numeric" that prompts the user to enter a free-form numeric value. The VFR determines the minimum and maximum values with the terms "minimum" and "maximum". Since there is also an enable/disable switch, the VFR uses the "suppressif" term to display or hide this field when disabled. Also this field displays as decimal (default) or hexadecimal with the "flags" switch.




Figure 7: Menu with Numeric item entry

Step	Action
1	Update the MyWizardDriver.vfr file
2	<b>Add</b> the following code in the location shown below at approx. Line 90 and before the "resetbutton" item:
	//
	<pre>// Define a numeric free form menu item //</pre>
	<pre>suppressif ideqval MWD_IfrNVData.MyWizardDriverChooseToEnable == 0x0; numeric varid = MWD_IfrNVData.MyWizardDriverHexData,</pre>
	<pre>prompt = STRING_TOKEN(STR_DATA_HEX_PROMPT), help = STRING_TOKEN(STR_NUMERIC_HELP),</pre>
	<pre>flags = DISPLAY_UINT_HEX ,</pre>
	minimum = 0,

```
maximum = 250,
                default = 0x22, defaultstore = MyStandardDefault,
          endnumeric;
        endif;
             endstring;
       88
           endif;
       89
       90 //
       91 // Define a numeric free form menu item
      92 //
          suppressif ideqval MWD_IfrNVData.MyWizardDriverChooseToEnable == 0x0;
       93
           numeric varid = MWD_IfrNVData.MyWizardDriverHexData,
       94
                   prompt = STRING_TOKEN(STR_DATA_HEX_PROMPT),
       95
                    help = STRING_TOKEN(STR_NUMERIC_HELP),
       96
      97
                    flags = DISPLAY_UINT_HEX , // Display in HEX format (if
       98
                   minimum = 0,
      99
                   maximum = 250,
      100
                    default = 0x22, defaultstore = MyStandardDefault,
       101
       102
            endnumeric;
       103 endif;
       104
       105
       106
            resetbutton
      107
               defaultstore = MyStandardDefault,
      108
               prompt = STRING TOKEN(STR STANDARD DEFAULT PROMPT RESET),
 3
      Save MyWizardDriver.vfr
 4
      Update the MyWizardDriver.uni file
      Add the following code to the bottom of the file:
       #string STR DATA HEX PROMPT
                                                    #language en "Enter ZY Base
       (Hex)"
       #string STR NUMERIC HELP
                                                   #language en "This is the
      help for entering a Base address in Hex. The valid range in this
       case is from 0 to 250."
      Save MyWizardDriver.uni
      In the Visual Studio Command Prompt, type build
      Press "Enter"
 8
      Type build run
10
      Press "Enter"
11
      Type exit
      Press "Enter"
12
13
      Now at the setup front page menu, select "Device Manager"
```

Inside the Device Manager menu, select "My Wizard Driver Sample F  Notice the value for "Enter ZY Base(Hex)" is 022. Hex is the default of the VFR field "default = 0x22"  Select "Enter ZY Base(Hex)"  Press "Enter"  Test by typing a "M" character  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device [X] Select Base Address <400 Hex> Name of Configuration Enter ZY Base (Hex) Reset to Standard Default  Notice that only Numeric characters are allowed and also only values of the configuration of the case is from the case in the case is from the case in the case is from the case in	elp for se c. The		
of the VFR field "default = 0x22"  16 Select "Enter ZY Base(Hex)"  17 Press "Enter"  18 Test by typing a "M" character  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Enter ZY Base (Hex) Reset to Standard Default	elp for se c. The n this		
Test by typing a "M" character  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address Name of Configuration Enter ZY Base (Hex) Reset to Standard Default  This is the herentering a Base address in Hex valid range in case is from 0	se c. The n this		
Test by typing a "M" character  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address Name of Configuration Enter ZY Base (Hex) Reset to Standard Default  This is the heentering a Base address in Hex valid range in case is from 0	se c. The n this		
My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Enable My XYZ Device Select Base Address Name of Configuration Enter ZY Base (Hex) Reset to Standard Default  This is the he entering a Bas entering a Bas address in Hex valid range in case is from 0	se c. The n this		
Device XYZ Configuration Enable My XYZ Device Select Base Address Name of Configuration Enter ZY Base (Hex) Reset to Standard Default    Configuration   Confi	se c. The n this		
18 Notice that only Numeric characters are allowed and also only values to			
Notice that only Numeric characters are allowed and also only values 00 to the Hex. When values outside the range or none numeric characters are entered the red "II" sting is displayed at the bottom of the menu. The string "!!" is part of the Browser engine:  MdeModulePkg\Universal\SetupBrowserDxe\SetupBrowserStr.uni #string INPUT_ERROR_MESSAGE #language en-US "!!"			
My Wizard Driver			
My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Enable My XYZ Device Select Base Address Name of Configuration Enter ZY Base (Hex) Reset to Standard Default  This is the help for entering a Base address in Hex. The valid range in this case is from 0 to 250.			
0-9 a-f are valid inputs <enter>=Complete Entry</enter>			
19 Press "Enter" again			
<b>Test</b> by typing a value of '99' Hex			

	Notice that the "Configuration changed" messa	
22	<b>Test the</b> "surpressif" by pressing the "spacebar	
22	then press the "Space" bar to toggle off or "Disabl	
23	Notice the "Select Base Address" and "Name	_
	now grayed out and not selectable and the "Enter	ZY Base(Hex)" does not
	appear at all.	
	M. U 1 N.	
	My Wizard Driver	
	My Wizard Driver Configuration	This is the help
	Device XYZ Configuration	message for the
	Enable My XYZ Device	enable My XYZ device.
	Select Base Address <400 Hex>	Check this box to
	Name of Configuration	enable this device.
	Reset to Standard Default	chable this device.
	Reset to Standard Derault	
24	Press "Space bar" again to "Enable My XYZ Device	e" and the " <b>Enter ZY</b>
24	Press "Space bar" again to "Enable My XYZ Device Base(Hex)" is displayed again	e" and the " <b>Enter ZY</b>
24	Base(Hex)" is displayed again	e" and the " <b>Enter ZY</b>
24		e" and the " <b>Enter ZY</b>
24	Base(Hex)" is displayed again  My Wizard Driver	
24	Base(Hex)" is displayed again  My Wizard Driver  My Wizard Driver Configuration	This is the help
24	My Wizard Driver  My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration	This is the help message for the
24	My Wizard Driver  My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device  [X]	This is the help message for the enable My XYZ device.
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address <400 Hex>	This is the help message for the enable My XYZ device. Check this box to
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address <400 Hex> Name of Configuration	This is the help message for the enable My XYZ device.
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99]	This is the help message for the enable My XYZ device. Check this box to
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address <400 Hex> Name of Configuration	This is the help message for the enable My XYZ device. Check this box to
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99]	This is the help message for the enable My XYZ device. Check this box to
24	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99]	This is the help message for the enable My XYZ device. Check this box to
	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address <400 Hex> Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default	This is the help message for the enable My XYZ device. Check this box to
24 25 26	My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default  Press "F10" then "Escape" to exit	This is the help message for the enable My XYZ device. Check this box to
25 26	My Wizard Driver  My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address <400 Hex> Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default	This is the help message for the enable My XYZ device. Check this box to
25	My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default  Press "F10" then "Escape" to exit  Press "Escape" to exit the "Device Manager"	This is the help message for the enable My XYZ device. Check this box to
25 26 27	My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default  Press "F10" then "Escape" to exit	This is the help message for the enable My XYZ device. Check this box to
25 26	My Wizard Driver Configuration Device XYZ Configuration Enable My XYZ Device Select Base Address (400 Hex) Name of Configuration Enter ZY Base (Hex) [99] Reset to Standard Default  Press "F10" then "Escape" to exit  Press "Escape" to exit the "Device Manager"	This is the help message for the enable My XYZ device. Check this box to



For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.7 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

### 8. Updating your Driver for Interactive Call Backs

In this lab, you'll update your driver for interactive call backs. Call backs are a way to communicate changes the user is making in "real time" where your driver needs to intervene as the changes are made and before the user exits the current menu being displayed. These would be exception cases that the driver could interrupt the normal browser engine process.

To add call backs, the file HiiConfigAccess.c of your driver will be updated in the function MyWizardDriverHiiConfigAccessCallback. This function is called whenever any VFR items have a flag for INTERACTIVE set. So far, the previous labs did not have any call back items.

We can see this because there was a "Debug" call made in the MyWizardDriverHiiConfigAccessCallback function that never gets called:

#### HiiConfigAccess.c (line 331)


DEBUG ((DEBUG\_INFO, "\n:: START Call back ,Question ID=0x%08x Type=0x%04x Action=0x%04x", QuestionId, Type, Action));

#### a. Add the Case statements to the Call back routine


Step	Action
1	
_	Update the HiiConfigAccess.c file
2	Add the following code before return status; to include a "case"
	statement in the call back routine for the "action" passed.
	Add the following code at approx. line 343 before:
	Add the following code at approximite 3 to Before:
	return status;

```
Step
       Action
         switch (Action) { // Start switch and passed param Action
         case EFI BROWSER ACTION FORM OPEN: // 3
          }
          break;
         case EFI BROWSER ACTION FORM CLOSE: // 4
          }
          break;
         case EFI_BROWSER_ACTION_RETRIEVE: // 2
          break;
         case EFI BROWSER ACTION DEFAULT STANDARD: // 0x1000
           }
          break;
         case EFI BROWSER ACTION DEFAULT MANUFACTURING: // 0x1001
          {
          break;
         case EFI BROWSER ACTION CHANGING: // 0
          break;
         case EFI BROWSER ACTION CHANGED: // 1
          break;
        default:
          Status = EFI UNSUPPORTED;
          break;
        } // end switch case on Action
```

```
Step
       Action
       340 FormId = 0;
       341 Status = EFI_SUCCESS;
       342 PrivateData = MYWIZARDDRIVER_DEV_FROM_THIS (This);
       343
       344
       345 switch (Action) { // Start switch and passed param Action
       346 case EFI_BROWSER_ACTION_FORM_OPEN: // 3
           {
       347
       348
       349
            break;
       350
       351 case EFI BROWSER ACTION FORM CLOSE: // 4
       352 {
       353
       353
354
                break;
       355
       356 case EFI_BROWSER_ACTION_RETRIEVE: // 2
       357 {
                 - }
       358
       359
                break;
       360
       361 case EFI_BROWSER_ACTION_DEFAULT_STANDARD: // 0x1000
           {
       362
       363
       364
                break;
       365
       366 case EFI BROWSER ACTION DEFAULT MANUFACTURING: // 0x1001
       367 {
       368
       368
369
                break;
       370
       371 case EFI_BROWSER_ACTION_CHANGING: // 0
       372 {
       373
       374 break;
       375
       376 case EFI_BROWSER_ACTION_CHANGED: // 1
            -{
       377
       378
             break;
       379
       380
       381 default:
       382 Status = EFI UNSUPPORTED;
             break;
       383
       384 } // end switch case on Action
       385
       386 return Status;
       387
       388 // return EFI UNSUPPORTED;
3
       Save HiiConfigAccess.c
4
      In the Visual Studio Command Prompt, type build
```



#### b. Update the Menu for Interactive items



```
78 // Define a string (EFI_IFR_STRING) to name the configuration in the
79 // NVRAM variable
      //
   grayoutif ideqval MWD_IfrNVData.MyWizardDriverChooseToEnable == 0x0;
              varid = MWD_IfrNVData.MyWizardDriverStringData,
82
      string
     questionid = 0x1001,
83
84 prompt = STRING_TOKEN(STR_MY_STRING_PROMPT),
85
                      = STRING_TOKEN(STR_MY_STRING_HELP),
            help
86 flags = INTERACTIVE,
     minsize = 3,
87
88
              maxsize = 20.
90 endif;
91
```

Include the numeric item by adding the following code in the location shown below, Approx. line 97 and line 100

questionid =  $0x11\overline{11}$ ,

INTERACTIVE

```
93 // Define a numeric free form menu item
95 suppressif ideqval MWD_IfrNVData.MyWizardDriverChooseToEnable == 0x0;
   numeric varid = MWD_IfrNVData.MyWizardDriverHexData,
96
       questionid = 0x1111,
98 prompt = STRING_TOKEN(STR_DATA_HEX_PROMPT),
99
           help = STRING_TOKEN(STR_NUMERIC_HELP),
100 flags = DISPLAY_UINT_HEX | INTERACTIVE, // Display in HEX
101
             minimum = 0.
102 maximum = 250,
103
            default = 0x22, defaultstore = MyStandardDefault,
104
105
      endnumeric:
106 endif;
```

- Save MyWizardDriver.vfr
- In the Visual Studio Command Prompt, type build
- Press "Enter"
- 7 Type build run
- 8 Press "Enter"
- Type exit
- 10 Press "Enter"
- 11 Now at the setup front page menu, select "Device Manager"
- 12 Press "Enter"
- 13 Inside the Device Manager menu, select "My Wizard Driver Sample Formset"
- 14 Press "Enter"
- 15 Take a moment and review the Visual Studio build run command prompt window
- In the NT32 emulation window, **click** on "Name of Configuration" and "Enter ZY Base(Hex)"

**Notice** the following in the Visual Studio Command Prompt window: Every time the browser does anything with the interactive labeled fields there is a call made to your driver's call back function. We can determine which item by the quetionid and what action by the Action passed to your call back function. Your call back function can then add code to special case when these transitions occur. **Entering Form** START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x0003 START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x0003 START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x0002 Changing a Value for Question ID 0x1111 START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x0003 START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x0003 START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x0002 :: START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x0002 :: START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x0000 :: START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x0001 :: START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x0002 Changing a Value for Question ID 0x1001 Type=0x0007 Action=0x0003 Type=0x0000 Action=0x0003 Type=0x0007 Action=0x0002 Type=0x0000 Action=0x0002 START Call START Call back ,Question ID=0x00001001 back ,Question ID=0x00001111 START Call START Call START Call ID=0×00001111 ID=0×00001001 , Question , Question :: back ID=0x00001111 88 back Type=0x0000 Action=0x0000 Type=0x0000 Action=0x0001 Type=0x0000 Action=0x0001 Call Call back Question START ID=0x00001111 Question ID=0x00001111 ID=0x00001001 START back :: :: START Call back ,Question :: START Call back ,Question :: START Call back ,Question ID=0×00001111 Type=0x0000 Action=0x0002 ID=0×000011001 ID=0×00001001 Type=0x0007 Action=0x00001
Type=0x0007 Action=0x0001
Type=0x0007 Action=0x0002 START Call back .Question ID=0×00001001 START Call START Call START Call START Call Action=0x0003 back ,Question 88 ,Question back Action=0x0003 Action=0x0002 :: back Question back ,Question back ,Question back ,Question Action=0x0002 88 START **Call** Action=0x0000 back , back , START Ca11 Question Action=0x0001 Action=0x0002 Action=0x0002 back Question back Question Ca11 :: START START Ca11 88 ID=0x00001001 Type=0x0007 Call back , Question Action=0x0000 START :: :: START Call back ,Question ID=0x00001001 Type=0x0007 Action=0x00002 :: START Call back ,Question ID=0x00001111 Type=0x0000 Action=0x00002 :: ROUTE CONFIG Saving the configuration to NVRAM ID=0x00001001 Type=0x0007 ID=0x00001111 Type=0x0000 ID=0x00001001 Type=0x0007 ID=0x00001111 Type=0x0000 ID=0x00001111 Type=0x0000 :: back ,Question Action=0x0003 START Ca11 back Question Action=0x0003 Call Call START Question Action=0x0002 back Action=0x0002 Action=0x0000 ,Question ,Question :: START back START Ca11 back 88 Type =0x0000 Type =0x0007 Type =0x0000 Type =0x0000 Call Call ID=0x00001111 Action=0x0001 START back ,Question ID=0×00001001 ID=0×00001111 ID=0×00001001 back ,Question back ,Question back ,Question Action=0x0002 :: START Call Action=0x0002 ::: START START Ca11 Action=0x0000 Call Call Call ID=0x00001001 Type = 0x0007 START Action=0x0001 START Call back ,Question ID=0x00001001 Type=0x0007 START Call back ,Question ID=0x00001001 Type=0x0007 START Call back ,Question ID=0x00001111 Type=0x0000 ROUTE CONFIG Saving the configuration to NURAM Question 88 back Action=0x0002 Action=0x0002 :: 88 

Press "Escape" to exit

Press "Escape" to exit the "Device Manager"

Select "Continue"

Press "Enter"

Type "reset" at the Shell prompt

Press "Enter" to return to the Visual Studio Command Prompt

C:\FW\edk2>

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.8 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

## 9. Add code to your driver when Call Back events occur for Interactive Items

In this lab, you'll update your driver to print debug statements when the Hii browser engine calls back into your call back function. Every time the browser does anything with the interactive labeled fields there is a call made to your driver's call back function. We can determine the item by the quetionid and what action based on the action passed to your call back function. Your call back function can then add code to special case when these transitions occur.

For this lab we will simply add Debug print statements. However, the use of adding call backs to a driver's HII functions adds the capability of providing more manageability and flexibility for the interactions between the user, the browser engine, and your driver code. In a real driver firmware situation, it may be desired to implement more complex features and functionality based upon an item changing.

Step	Action
1	Update the HiiConfigAccess.c file
2	Comment out the DEBUG statement with "//" in the MyWizardDriverHiiConfigAccessCallback call back function approx. line 330: Because this will get called so many times that it will be hard to determine where your code is actually doing something
	//
	326 MYWIZARDDRIVER_DEV *PrivateData; 327 EFI_STATUS Status; 328 EFI_FORM_ID FormId; 329 330 // DEBUG ((DEBUG INFO, "\n:: START Call back ,Question ID=0
	331 332 333 334 if (((Value == NULL) && (Action != EFI_BROWSER_ACTION_FORM_O
3	<b>Add</b> a switch case statement of the question ID's to the "Action" switch case of EFI_BROWSER_ACTION_CHANGING in the call back function by <b>adding</b> a nested switch case code (as shown below at approx. line 372)

```
Action
Step
                      switch (QuestionId) {
                            case 0x1111:
                                       DEBUG ((DEBUG INFO, "\n:: START Call back-
       Changing ,Question ID=0x%08x Type=0x%04x Action=0x%04x", QuestionId, Type,
       Action));
                                   break;
                            case 0x1001:
                                       DEBUG ((DEBUG INFO, "\n:: START Call back-
       Changing ,Question ID=0x%08x Type=0x%04x Action=0x%04x", QuestionId, Type,
       Action));
                                   break;
                            default:
                                   Status = EFI UNSUPPORTED;
                                   break;
        369
        370
              case EFI_BROWSER_ACTION_CHANGING: // 0
        371
        372
                            switch (QuestionId) {
        373
                                    case 0x1111:
                                               DEBUG ((DEBUG_INFO, "\n:: START Call back- Chan
        374
        375
                                            break;
                                    case 0x1001:
        376
                                                DEBUG ((DEBUG_INFO, "\n:: START Call back- Chan
        377
        378
                                            break;
        379
                                    default:
        380
                                            Status = EFI_UNSUPPORTED;
        381
                                            break;
        382
        383
        384
               break;
        385
              case EFI_BROWSER_ACTION_CHANGED: // 1
        386
       Add another nested switch case statement of the question ID's to the "Action" switch case
 4
       of EFI_BROWSER_ACTION_CHANGED in the call back function (as show below at approx.
       line 388):
```

```
Action
Step
                                    switch (QuestionId) {
                             case 0x1111:
                                        DEBUG ((DEBUG INFO, "\n:: START Call back-
       Changed , Question ID=0x%08x Type=0x%04x Action=0x%04x", QuestionId, Type,
       Action));
                                    break;
                             case 0x1001:
                                        DEBUG ((DEBUG INFO, "\n:: START Call back-
        Changed , Question ID=0x%08x Type=0x%04x Action=0x%04x", QuestionId, Type,
       Action));
                                    break;
                             default:
                                    Status = EFI UNSUPPORTED;
                                    break;
        385
              case EFI_BROWSER_ACTION_CHANGED: // 1
        386
        387
        388
                                          switch (QuestionId) {
        389
                                  case 0x1111:
                                             DEBUG ((DEBUG_INFO, "\n:: START Call back- Changed
        390
                                         break;
        391
        392
                                  case 0x1001:
                                             DEBUG ((DEBUG INFO, "\n:: START Call back- Changed
        393
        394
                                         break;
        395
                                  default:
        396
                                          Status = EFI_UNSUPPORTED;
        397
        398
        399
        400
               break:
        401
        402 default:
        403
              Status = EFI UNSUPPORTED;
        404
        405
              } // end switch case on Action
        406
        407 return Status;
        408
       Save MyWizardDriver.c
 5
       In the Visual Studio Command Prompt, type build
 6
        Press "Enter"
 7
       Type build run
 8
 9
       Type exit
       Press "Enter"
10
        Now at the setup front page menu, select "Device Manager"
11
        Press "Enter"
12
       Inside the Device Manager menu, select "My Wizard Driver Sample Formset"
13
       Press "Enter"
14
```

Step	Action			
15	Observe the Visual Studio Command Prompt – build run Window Test: changing the "Name of Configuration" and the "Enter ZY Base(Hex)" fields while observing the Visual Studio Command Prompt – build run Window			
16	Switch back to Visual Studio and notice the changes that you made.			
17	:: START Call back- Changing ,Question ID=0x00001001 Type=0x0007 Action=0x000			
	Notice: when changing the "Name of Configuration" field			
18	:: START Call back- Changing ,Question ID=0x00001001 Type=0x0007 Action=0x000 :: START Call back- Changed ,Question ID=0x00001001 Type=0x0007 Action=0x0001 :: START Call back- Changing ,Question ID=0x00001111 Type=0x0000 Action=0x000			
	Notice: when changing the "Enter ZY Base(Hex)" field			
19	:: START Call back- Changing ,Question ID=0x00001001 Type=0x0007 Action=0x0000 :: START Call back- Changed ,Question ID=0x00001001 Type=0x0007 Action=0x0001 :: START Call back- Changing ,Question ID=0x00001111 Type=0x0000 Action=0x0000 :: START Call back- Changed ,Question ID=0x00001111 Type=0x0000 Action=0x0001 :: ROUTE CONFIG Saving the configuration to NVRAM			
	Notice: when Pressing "F10"			
20	Press "Escape" to exit			
21	Press "Escape" to exit the "Device Manager"			
22	Select "Continue"			
23	Press "Enter"			
24	Type "reset" at the Shell prompt			
25	Press "Enter" to return to the Visual Studio Command Prompt C:\FW\edk2>			

For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.9 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

### 10. Adding an Additional Form Page

In this lab, you'll learn how to add another form page to your My Wizard Driver menu by using the "goto" VFR term along with the "form" and "formid" VFR statements. Additionally, use "surpressif" or "grayoutif" to conditionally allow the user to enter your additional forms.

In addition, this lab will show how the "time" and "date" VFR terms are used within the VFR language to special case how the browser engine checks the time instead of your driver manually checking (e.g. leap year).




Figure 10: Second setup page

Step	Action		
1	<b>Update</b> the MyWizardDriverNVDataStruc.h file		
2	<b>Add</b> the following date and time fields to the configuration typedef (to to the location shown below):		
	EFI_HII_TIME Time; EFI_HII_DATE Date;		


```
Action
Step
        21 #pragma pack(1)
        22 typedef struct {
        23
        24 UINT16 MyWizardDriverStringData[20];
        25 UINT8 MyWizardDriverHexData;
             UINT8 MyWizardDriverBaseAddress;
        26
              UINTS MyWizardDriverChooseToEnable;
        27
              EFI_HII_TIME Time;
              EFI HII DATE Date;
        30 } MYWIZARDDRIVER_CONFIGURATION;
       Save MyWizardDriverNVDataStruc.h
 3
       Update the MyWizardDriver.uni file
 4
       Add the following code to the end of the file to update the second page's
 5
       strina:
       #string STR FORM2 TITLE
                                               #language en "MyWizardDriver
       Second Setup Page"
       #string STR DATE PROMPT
                                               #language en "Windows System
       Date"
       #string STR DATE HELP
                                               #language en "This is the help
       for the Date (month/day/year). (Error checking will be done against
       month/day/year combinations that are not supported.)"
       #string STR TIME PROMPT
                                               #language en "Windows System
       Time"
       #string STR TIME HELP
                                               #language en "This is the help
       for the Time (hour/minute/second)."
       #string STR ERROR POPUP
                                               #language en "You typed in the
       wrong value!"
       #string STR GOTO FORM1
                                              #language en "Enter Page 1"
       #string STR GOTO FORM2
                                              #language en "Enter Page 2"
       #string STR GOTO HELP
                                              #language en "This is my goto
       help"
       #string STR MY DATE PROMPT
                                               #language en "My System Date"
                                               #language en "My System Time"
        #string STR MY TIME PROMPT
       Save MyWizardDriver.uni
 6
       Update the MyWizardDriver.vfr file
 7
       Add the "goto" VFR item to allow browser to ender another form by adding
 8
       the following code before the "endform" at approx. line 114
           grayoutif ideqval MWD IfrNVData.MyWizardDriverChooseToEnable
       == 0x0;
                goto 2,
              prompt = STRING TOKEN(STR GOTO FORM2), //SecondSetupPage
              help = STRING TOKEN(STR GOTO HELP);
           endif;
```


Step	Action
	108 resetbutton
	109 defaultstore = MyStandardDefault,
	110 prompt = STRING_TOKEN(STR_STANDARD_DEFAULT_PROMPT_RESET),
	111 help = STRING_TOKEN(STR_STANDARD_DEFAULT_HELP),
	112 endresetbutton;
	113
	<pre>114 grayoutif ideqval MWD_IfrNVData.MyWizardDriverChooseToEnable == 0x0;</pre>
	115 goto 2,
	116 prompt = STRING_TOKEN(STR_GOTO_FORM2), //SecondSetupPage
	117 help = STRING_TOKEN(STR_GOTO_HELP);
	118 endif;
	119
	120 endform;
	121
9	Add the following code between "endform" at approx. line 120 and
	"endformset" (the code continues for three pages in this lab guide):
	tine to the court of the court

```
Step
       Action
           form formid = 2,
                                         // SecondSetupPage,
             title = STRING TOKEN(STR FORM2 TITLE);
             grayoutif TRUE; // DATE is the date of the Windows Host so can
       not change it.;
            date year varid = Date. Year, // Note that it is a member of
       NULL,
                      //so the RTC will be the system resource to retrieve
       and save from
                              = STRING TOKEN(STR DATE PROMPT),
                    prompt
                    help = STRING_TOKEN(STR_DATE_HELP),
                    minimum = 1998,
                              = 2099,
                    maximum
                               = 1,
                    step
                    default = 2010,
                    month varid = Date.Month, // Note that it is a member of
       NULL,
                      //so the RTC will be the system resource to retrieve
       and save from
                             = STRING_TOKEN(STR_DATE PROMPT),
                    prompt
                               = STRING TOKEN(STR DATE HELP),
                    help
                    minimum
                               = 1,
                    maximum = 12,
                               = 1,
                    step
                    default = 1,
                    day varid = Date.Day, // Note that it is a member of
       NULL,
                      //so the RTC will be the system resource to retrieve
       and save from
                    prompt = STRING_TOKEN(STR_DATE_PROMPT),
help = STRING_TOKEN(STR_DATE_HELP),
                    minimum
                              = 1,
                    maximum
                               = 31,
                               = 0x1,
                    step
                    default = 1,
             enddate;
           endif; //grayoutif TRUE DATE
```

```
Step
       Action
          grayoutif TRUE; // TIME - WINDOWS TIME
                  hour varid = Time. Hour, // Note that it is a
       member of NULL,
                      //so the RTC will be the system resource to
       retrieve and save from
                    prompt = STRING_TOKEN(STR_TIME_PROMPT),
                    help = STRING_TOKEN(STR_TIME_HELP),
minimum = 0,
maximum = 23,
                    step
                               = 1,
                    default = 0,
                    minute varid = Time.Minute, // Note that it is a
      member of NULL,
                       //so the RTC will be the system resource to
       retrieve and save from
                    prompt = STRING_TOKEN(STR_TIME_PROMPT),
                                = STRING TOKEN(STR TIME HELP),
                    help
                                = 0,
                    minimum
                                 = 59,
                    maximum
                    step
                                 = 1,
                    default = 0,
                    second varid = Time.Second, // Note that it is a
       member of NULL,
                       //so the RTC will be the system resource to
                    prompt = STRI
help = STRI
minimum = 0,
= 59,
       retrieve and save from
                                = STRING TOKEN(STR TIME PROMPT),
                                 = STRING TOKEN(STR TIME HELP),
                                 = 1,
                    step
                                = 0,
                    default
            endtime;
           endif; //grayoutif TRUE TIME
```

Step	Action					
	date // My Wizard Driver Date					
	<pre>varid = MWD_IfrNVData.Date ,</pre>					
	prompt = STRING_TOKEN(STR_MY_DATE_PROMPT),					
	help = STRING_TOKEN(STR_DATE_HELP), flags = STORAGE NORMAL,					
	default = 2013/01/01,					
	enddate;					
	time // My Wizard Driver Time					
	name = MyTimeMWD,					
	<pre>varid = MWD_IfrNVData.Time,</pre>					
	<pre>prompt = STRING_TOKEN(STR_MY_TIME_PROMPT),</pre>					
	help = STRING_TOKEN(STR_TIME_HELP),					
	<pre>flags = STORAGE_NORMAL , default = 15:33:33,</pre>					
	endtime;					
	goto 1,					
	<pre>prompt = STRING_TOKEN(STR_GOTO_FORM1), //MainSetupPage</pre>					
	<pre>// this too has no end-op and basically it's a jump to a form</pre>					
	ONLY					
	help = STRING_TOKEN(STR_GOTO_HELP);					
	endform;					
10	Save MyWizardDriver.vfr					
11	In the Visual Studio Command Prompt, type build					
12	Press "Enter"					
13	Type build run					
14	Press "Enter"					
15	Type exit					
16	Now at the setup front page menu, select "Device Manager"					
17	Press "Enter"					
18	Inside the Device Manager menu, select "My Wizard Driver Sample Formset"					






For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.10 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean.

## 11. Adding Communication from Driver to Console through HII


In this lab, you'll add communication from the driver to the console through HII. More specifically, you'll add code to retrieve a string from the HII database and print the string to the console. Then, you'll add the string in French, change the language, and test to ensure the correct language is displayed. The reason the driver should avoid direct string text to the console without the HII support is because there is no localization for text string inside the driver's source code. By using the HII database the strings are tokenized making localization easier.



Step	Action				
5	Update the C:\Fw\edk2\Nt32pkg\Nt32pkg.fdf file				
6	Make your driver stand alone. <b>Remove</b> (or comment out) the include statement in the Nt32pkg.fdf file:				
	#INF MyWizardDriver/MyWizardDriver.inf				
	<pre>INF MdeModulePkg/Universal/Network/IScsiD: #INF MyWizardDriver/MyWizardDriver.inf !if \$(BUILD_NEW_SHELL) == TRUE INF ShellPkg/Application/Shell/Shell.inf !endif</pre>				
7	Save Nt32pkg.fdf				
8	Update the MyWizardDriver.uni file				
9	Add the following code to the top of the file at approx. line 14 as shown:				
	#langdef fr-FR "Francais"				
	12 13 #langdef en "English" 14 #langdef fr-FR "Français"				
	15 16 #string STR_SAMPLE_FORM_SET_TITLE #language en "My Wizard I 17 #string STR_SAMPLE_FORM_SET_HELP #language en "Help for Sa 18 #string STR_SAMPLE_FORM1_TITLE #language en "My Wizard I 19				
10	Add the following code to the end of the file:				
	#string STR_LANGUAGE_TEST_STRING #language en "Laurie's Test String"				
	#language fr-FR "Chaîne de test de Laurie"				
	75 76 #string STR_MY_TIME_PROMPT #language en "My System Time" 77				
	78 ‡string STR_LANGUAGE_TEST_STRING				
11	Save MyWizardDriver.uni				
12	Update the MyWizardDriver.c file				
13	Add the following local variable for StringPtr after "BOOLEAN ActionFlag;" and before "Status = EFI SUCCESS;"(as shown below):				


```
Action
Step
           EFI STRING
                                                    StringPtr;
           189 UINTN
                                                BufferSize:
           190 MYWIZARDDRIVER_CONFIGURATION
                                                *Configuration;
           191
                BOOLEAN
                                                ActionFlag;
           192 EFI_STRING
                                                StringPtr;
                Status = EFI_SUCCESS;
           193
           194
 14
           Add the following code after "FreePool (ConfigReguestHdr);" (as shown
           below) to edit the driver's entry point with a debug and print statement by
           making a call to the HiiGetString for the token to print (at approx line 364):
                                = HiiGetString (HiiHandle[0], STRING TOKEN
           StringPtr
           (STR LANGUAGE TEST STRING), NULL);
               DEBUG ((EFI D INFO, "[MyWizardDriver-Entrypoint] My String
           was: %s\n", StringPtr) );
               Print(L"%s\n", StringPtr );
            362 FreePool (ConfigRequestHdr);
            363
           364 StringPtr = HiiGetString (HiiHandle[0], STRING_TOKEN (STR_LANGUAGE_TEST_S
365 DEBUG ((EFI_D_INFO,"[MyWizardDriver-Entrypoint] My String was: %s\n", StringPtr)
                              = HiiGetString (HiiHandle[0], STRING TOKEN (STR LANGUAGE TEST ST
            366 Print(L"%s\n", StringPtr );
            367
            368 // end HII
           369 //
           370
                // Install Driver Supported EFI Version Protocol onto ImageHandle
 15
           Save the MyWizardDriver.c
 16
           In the Visual Studio Command Prompt, type build
 17
           Press "Enter"
 18
           Type build run
 19
           Press "Enter"
 20
           Type Fs0:
 21
           Press "Enter"
 22
           Type load MyWizardDriver.efi and notice that the string's English version is
           displayed:
            Shell> fs0:
            FS0:\> load MyWizardDriver.efi
            Laurie's Test String
            Image 'FSO:\MyWizardDriver.efi' loaded at 604A000 - Success
            FS0:\> _
```

Step	Action			
23	Type Reset FS0:\> reset_			
24	Press "Enter"			
25	Type build			
26	Type build run			
27	Press "Enter"			
28	Type exit at the shell prompt			
29	Select Language  NT32 Emulation Environment NT32 Emulated Processor 1.23 GHz R9 Prime 128 MB RAM			
	Continue Select Language Boot Manager  Device Manager  Boot Maintenance Manager  Continue This is the option one adjusts to change the language for the current system			
30	Press "Enter"			
31	Français English Standard Français Standard English  Select "Français"			
32	Press "Enter"			
33	Continuer Choisir la Langue ⟨Français⟩ dirigera le système ► Charger le Directeur pour continuer au ► Directeur d'appareil charger de procédé ► Directeur d'Entretien			
	Select "Continuer"			
34	Press "Enter"			



For any build issues copy the solution files from C:\Fw\LabSolutions\LessonE.11 NOTE: Del Directory C:\fw\edk2\Build\NT32IA32\DEBUG\_VS2010x86\IA32\MyWizardDriver before the Build command to build the MyWizardDriver Clean. Make sure you update Nt32Pkg.fdf.

## Lab Setup




### Pin Visual Studio Command Prompt for Windows




#### Preparing for the BUILD Command

**Note**: You'll need to repeat this step each time you exit the Visual Studio Command Prompt window. It is recommended that you keep your command prompt open during the training.





#### **Configuring Build Tools**


**Note**: You only need to edit Target.txt and/or Tools\_Def.txt once after the first edksetup command after downloading the Training materials .zip file.




## Microsoft Windows 10 – Visual Studio command prompt












## **Microsoft Windows and Visual Studio Matrix**

Files C: /fw/edk2/conf/target.txt and tools\_def.txt (Return to Configuring Build Tools)

Visual Studio	Version	Win7,Win8 & Win10 x64
VS2005	8.0	target.txt TOOL_CHAIN_TAG = <mark>VS2005x86</mark> Requires WinDDK Link16**
VS2008	9.0	target.txt TOOL_CHAIN_TAG = <b>VS2008x86</b>
V32006		target.txt TOOL_CHAIN_TAG = <b>VS2010</b> x86
VS2010	10.0	
VS2012	11.0	target.txt TOOL_CHAIN_TAG = <mark>VS2012x86</mark>
VS2013	12.0	target.txt TOOL_CHAIN_TAG= <b>VS2013x86</b>
VS2015	14.0	target.txt TOOL_CHAIN_TAG= <mark>VS2015x86</mark>
VS2017	15.0	target.txt TOOL_CHAIN_TAG = <mark>VS2017x86</mark>

# Reference



## **Glossary of UEFI Terms and Acronyms**

https://github.com/tianocore/tianocore.github.io/wiki/Acronyms-and-Glossary

## **Helpful Links**

<b>UEFI Forum</b>	http://www.uefi.org
<b>UEFI Open</b>	http://www.tianocore.org
Source	
EFI Developer	http://tianocore.github.io/edk2.html
Kit (EDK II)	
EDK II	http://www.tianocore.org/docs/
Documents	
<b>UEFI Shell</b>	https://github.com/tianocore/tianocore.github.io/wiki/ShellPkg
Documents	

### **Acknowledgement**

 Redistribution and use in source (original document form) and 'compiled' forms (converted to PDF, epub, HTML and other formats) with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code (original document form) must retain the above copyright notice, this list of conditions and the following disclaimer as the first lines of this file unmodified.
- Redistributions in compiled form (transformed to other DTDs, converted to PDF, epub, HTML and other formats) must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- THIS DOCUMENTATION IS PROVIDED BY TIANOCORE PROJECT "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL TIANOCORE PROJECT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
- Copyright (c) 2018, Intel Corporation. All rights reserved.