

William Stallings Computer Organization and Architecture 10th Edition


© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Chapter 14

Processor Structure and Function

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Processor Organization



Processor Requirements:

- Fetch instruction
  - The processor reads an instruction from memory (register, cache, main memory)
- Interpret instruction
  - The instruction is decoded to determine what action is required
- Fetch data
  - The execution of an instruction may require reading data from memory or an I/O module
- Process data
  - The execution of an instruction may require performing some arithmetic or logical operation on data
- Write data
  - The results of an execution may require writing data to memory or an I/O module
- In order to do these things the processor needs to store some data temporarily and therefore needs a small internal memory

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.1 The CPU with the System Bus

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.2 Internal Structure of the CPU

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Register Organization

- Within the processor there is a set of registers that function as a level of memory above main memory and cache in the hierarchy
- The registers in the processor perform two roles:

User-Visible Registers

- Enable the machine or assembly language programmer to minimize main memory references by optimizing use of registers

Control and Status Registers

- Used by the control unit to control the operation of the processor and by privileged operating system programs to control the execution of programs

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

User-Visible Registers

Referenced by means of the machine language that the processor executes

Categories:

- **General purpose**
  - Can be assigned to a variety of functions by the programmer
- **Data**
  - May be used only to hold data and cannot be employed in the calculation of an operand address
- **Address**
  - May be somewhat general purpose or may be devoted to a particular addressing mode
  - Examples: segment pointers, index registers, stack pointer
- **Condition codes**
  - Also referred to as *flags*
  - Bits set by the processor hardware as the result of operations

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Table 14.1
Condition Codes

Advantages	Disadvantages
1. Because condition codes are set by normal arithmetic and data movement instructions, they should reduce the number of COMPARE and TEST instructions needed.	**1.** Condition codes add complexity, both to the hardware and software. Condition code bits are often modified in different ways by different instructions, making life more difficult for both the microprogrammer and compiler writer.
2. Conditional instructions, such as BRANCH are simplified relative to composite instructions, such as TEST AND BRANCH.	**2.** Condition codes are irregular; they are typically not part of the main data path, so they require extra hardware connections.
3. Condition codes facilitate multiway branches. For example, a TEST instruction can be followed by two branches, one on less than or equal to zero and one on greater than zero.	**3.** Often condition code machines must add special non-condition-code instructions for special situations anyway, such as bit checking, loop control, and atomic semaphore operations.
4. Condition codes can be saved on the stack during subroutine calls along with other register information.	**4.** In a pipelined implementation, condition codes require special synchronization to avoid conflicts.

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Control and Status Registers

Four registers are essential to instruction execution:

- Program counter (PC)
  - Contains the address of an instruction to be fetched
- Instruction register (IR)
  - Contains the instruction most recently fetched
- Memory address register (MAR)
  - Contains the address of a location in memory
- Memory buffer register (MBR)
  - Contains a word of data to be written to memory or the word most recently read



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Program Status Word (PSW)



Register or set of registers that contain status information

Common fields or flags include:

- Sign
- Zero
- Carry
- Equal
- Overflow
- Interrupt Enable/Disable
- Supervisor

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.





Figure 14.3 Example Microprocessor Register Organizations

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Instruction Cycle



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.4 The Instruction Cycle

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.





Figure 14.5 Instruction Cycle State Diagram

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.



MBR = Memory buffer register
MAR = Memory address register
IR = Instruction register
PC = Program counter

Figure 14.6 Data Flow, Fetch Cycle

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.7 Data Flow, Indirect Cycle

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.





Figure 14.8 Data Flow, Interrupt Cycle

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Pipelining Strategy

Similar to the use of an assembly line in a manufacturing plant

To apply this concept to instruction execution we must recognize that an instruction has a number of stages



New inputs are accepted at one end before previously accepted inputs appear as outputs at the other end

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.9 Two-Stage Instruction Pipeline

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Additional Stages

- Fetch instruction (FI)
  - Read the next expected instruction into a buffer
- Decode instruction (DI)
  - Determine the opcode and the operand specifiers
- Calculate operands (CO)
  - Calculate the effective address of each source operand
  - This may involve displacement, register indirect, indirect, or other forms of address calculation
- Fetch operands (FO)
  - Fetch each operand from memory
  - Operands in registers need not be fetched
- Execute instruction (EI)
  - Perform the indicated operation and store the result, if any, in the specified destination operand location
- Write operand (WO)
  - Store the result in memory

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.10 Timing Diagram for Instruction Pipeline Operation

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.11 The Effect of a Conditional Branch on Instruction Pipeline Operation

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.





Figure 14.12 Six-Stage Instruction Pipeline

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




(a) No branches

(b) With conditional branch

Figure 14.13 An Alternative Pipeline Depiction

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.






Figure 14.14 Speedup Factors with Instruction Pipelining

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Pipeline Hazards

Occur when the pipeline, or some portion of the pipeline, must stall because conditions do not permit continued execution


There are three types of hazards:

- Resource
- Data
- Control


Also referred to as a *pipeline bubble*



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.



(a) Five-stage pipeline, ideal case



(b) I1 source operand in memory

Figure 14.15 Example of Resource Hazard

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.16 Example of Data Hazard

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Types of Data Hazard

- Read after write (RAW), or true dependency
  - An instruction modifies a register or memory location
  - Succeeding instruction reads data in memory or register location
  - Hazard occurs if the read takes place before write operation is complete
- Write after read (WAR), or antidependency
  - An instruction reads a register or memory location
  - Succeeding instruction writes to the location
  - Hazard occurs if the write operation completes before the read operation takes place
- Write after write (WAW), or output dependency
  - Two instructions both write to the same location
  - Hazard occurs if the write operations take place in the reverse order of the intended sequence

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Control Hazard

- Also known as a *branch hazard*
- Occurs when the pipeline makes the wrong decision on a branch prediction
- Brings instructions into the pipeline that must subsequently be discarded
- Dealing with Branches:
  - Multiple streams
  - Prefetch branch target
  - Loop buffer
  - Branch prediction
  - Delayed branch



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Multiple Streams

A simple pipeline suffers a penalty for a branch instruction because it must choose one of two instructions to fetch next and may make the wrong choice

A brute-force approach is to replicate the initial portions of the pipeline and allow the pipeline to fetch both instructions, making use of two streams


Drawbacks:

- With multiple pipelines there are contention delays for access to the registers and to memory
- Additional branch instructions may enter the pipeline before the original branch decision is resolved

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Prefetch Branch Target

- When a conditional branch is recognized, the target of the branch is prefetched, in addition to the instruction following the branch
- Target is then saved until the branch instruction is executed
- If the branch is taken, the target has already been prefetched
- IBM 360/91 uses this approach



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Loop Buffer

- Small, very-high speed memory maintained by the instruction fetch stage of the pipeline and containing the *n* most recently fetched instructions, in sequence
- Benefits:
  - Instructions fetched in sequence will be available without the usual memory access time
  - If a branch occurs to a target just a few locations ahead of the address of the branch instruction, the target will already be in the buffer
  - This strategy is particularly well suited to dealing with loops
- Similar in principle to a cache dedicated to instructions
  - Differences:
    - The loop buffer only retains instructions in sequence
    - Is much smaller in size and hence lower in cost

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.17 Loop Buffer

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Branch Prediction

- Various techniques can be used to predict whether a branch will be taken:

1. Predict never taken
2. Predict always taken
3. Predict by opcode

- These approaches are static
- They do not depend on the execution history up to the time of the conditional branch instruction

1. Taken/not taken switch
2. Branch history table

- These approaches are dynamic
- They depend on the execution history

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.18 Branch Prediction Flow Chart

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.19 Branch Prediction State Diagram

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.






Figure 14.20 Dealing with Branches

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.


Intel 80486 Pipelining



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.



(a) No Data Load Delay in the Pipeline



(b) Pointer Load Delay



(c) Branch Instruction Timing

Figure 14.21 80486 Instruction Pipeline Examples

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Table 14.2

x86 Processor Registers

(a) Integer Unit in 32-bit Mode

Type	Number	Length (bits)	Purpose
General	8	32	General-purpose user registers
Segment	6	16	Contain segment selectors
EFLAGS	1	32	Status and control bits
Instruction Pointer	1	32	Instruction pointer


(b) Integer Unit in 64-bit Mode

Type	Number	Length (bits)	Purpose
General	16	32	General-purpose user registers
Segment	6	16	Contain segment selectors
RFLAGS	1	64	Status and control bits
Instruction Pointer	1	64	Instruction pointer

(c) Floating-Point Unit

Type	Number	Length (bits)	Purpose
Numeric	8	80	Hold floating-point numbers
Control	1	16	Control bits
Status	1	16	Status bits
Tag Word	1	16	Specifies contents of numeric registers
Instruction Pointer	1	48	Points to instruction interrupted by exception
Data Pointer	1	48	Points to operand interrupted by exception

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




X ID = Identification flag
X VIP = Virtual interrupt pending
X VIF = Virtual interrupt flag
X AC = Alignment check
X VM = Virtual 8086 mode
X RF = Resume flag
X NT = Nested task flag
X IOPL = I/O privilege level
S OF = Overflow flag

C DF = Direction flag
X IF = Interrupt enable flag
X TF = Trap flag
S SF = Sign flag
S ZF = Zero flag
S AF = Auxiliary carry flag
S PF = Parity flag
S CF = Carry flag

S Indicates a Status Flag
C Indicates a Control Flag
X Indicates a System Flag
Shaded bits are reserved

Figure 14.22 x86 EFLAGS Register

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.



shaded area indicates reserved bits

OSXSAVE	=	XSAVE enable bit	VME	=	Virtual 8086 Mode Extensions
PCIDE	=	Enables process-context identifiers	PCD	=	Page-level Cache Disable
FSGSBASE	=	Enables segment base instructions	PWT	=	Page-level Writes Transparent
SMXE	=	Enable Safer mode extensions	PG	=	Paging
VMXE	=	Enable virtual machine extensions	CD	=	Cache Disable
OSXMMEXCPT	=	Support unmasked SIMD FP exceptions	NW	=	Not Write Through
OSFXSR	=	Support FXSAVE, FXSTOR	AM	=	Alignment Mask
PCE	=	Performance Counter Enable	WP	=	Write Protect
PGE	=	Page Global Enable	NE	=	Numeric Error
MCE	=	Machine Check Enable	ET	=	Extension Type
PAE	=	Physical Address Extension	TS	=	Task Switched
PSE	=	Page Size Extensions	EM	=	Emulation
DE	=	Debug Extensions	MP	=	Monitor Coprocessor
TSD	=	Time Stamp Disable	PE	=	Protection Enable
PVI	=	Protected Mode Virtual Interrupt			

Figure 14.23 x86 Control Registers

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.24 Mapping of MMX Registers to Floating-Point Registers

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Interrupt Processing

Interrupts and Exceptions

- Interrupts
  - Generated by a signal from hardware and it may occur at random times during the execution of a program
  - Maskable
  - Nonmaskable
- Exceptions
  - Generated from software and is provoked by the execution of an instruction
  - Processor detected
  - Programmed
- Interrupt vector table
  - Every type of interrupt is assigned a number
  - Number is used to index into the interrupt vector table

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Vector Number	Description
0	Divide error; division overflow or division by zero
1	Debug exception; includes various faults and traps related to debugging
2	NMI pin interrupt; signal on NMI pin
3	Breakpoint; caused by INT 3 instruction, which is a 1-byte instruction useful for debugging
4	INTO-detected overflow; occurs when the processor executes INTO with the OF flag set
5	BOUND range exceeded; the BOUND instruction compares a register with boundaries stored in memory and generates an interrupt if the contents of the register is out of bounds.
6	Undefined opcode
7	Device not available; attempt to use ESC or WAIT instruction fails due to lack of external device
8	Double fault; two interrupts occur during the same instruction and cannot be handled serially
9	Reserved
10	Invalid task state segment; segment describing a requested task is not initialized or not valid
11	Segment not present; required segment not present
12	Stack fault; limit of stack segment exceeded or stack segment not present
13	General protection; protection violation that does not cause another exception (e.g., writing to a read-only segment)
14	Page fault
15	Reserved
16	Floating-point error; generated by a floating-point arithmetic instruction
17	Alignment check; access to a word stored at an odd byte address or a doubleword stored at an address not a multiple of 4
18	Machine check; model specific
19-31	Reserved
32-255	User interrupt vectors; provided when INTR signal is activated

Table 14.3

x86 Exception and Interrupt Vector Table

Unshaded: exceptions
Shaded: interrupts

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

The ARM Processor

ARM is primarily a RISC system with the following attributes:

- Moderate array of uniform registers
- A load/store model of data processing in which operations only perform on operands in registers and not directly in memory
- A uniform fixed-length instruction of 32 bits for the standard set and 16 bits for the Thumb instruction set
- Separate arithmetic logic unit (ALU) and shifter units
- A small number of addressing modes with all load/store addresses determined from registers and instruction fields
- Auto-increment and auto-decrement addressing modes are used to improve the operation of program loops
- Conditional execution of instructions minimizes the need for conditional branch instructions, thereby improving pipeline efficiency, because pipeline flushing is reduced

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.





Figure 14.25 Simplified ARM Organization

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Processor Modes



© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Exception Modes

Have full access to system resources and can change modes freely

Entered when specific exceptions occur

Exception modes:

- Supervisor mode
- Abort mode
- Undefined mode
- Fast interrupt mode
- Interrupt mode

System mode:

- Not entered by any exception and uses the same registers available in User mode
- Is used for running certain privileged operating system tasks
- May be interrupted by any of the five exception categories

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Modes						
	Privileged modes					
		Exception modes				
User	**System**	**Supervisor**	**Abort**	**Undefined**	**Interrupt**	**Fast Interrupt**
R0	R0	R0	R0	R0	R0	R0
R1	R1	R1	R1	R1	R1	R1
R2	R2	R2	R2	R2	R2	R2
R3	R3	R3	R3	R3	R3	R3
R4	R4	R4	R4	R4	R4	R4
R5	R5	R5	R5	R5	R5	R5
R6	R6	R6	R6	R6	R6	R6
R7	R7	R7	R7	R7	R7	R7
R8	R8	R8	R8	R8	R8	R8_fiq
R9	R9	R9	R9	R9	R9	R9_fiq
R10	R10	R10	R10	R10	R10	R10_fiq
R11	R11	R11	R11	R11	R11	R11_fiq
R12	R12	R12	R12	R12	R12	R12_fiq
R13 (SP)	R13 (SP)	R13_svc	R13_abt	R13_und	R13_irq	R13_fiq
R14 (LR)	R14 (LR)	R14_svc	R14_abt	R14_und	R14_irq	R14_fiq
R15 (PC)	R15 (PC)	R15 (PC)	R15 (PC)	R15 (PC)	R15 (PC)	R15 (PC)
CPSR	CPSR	CPSR	CPSR	CPSR	CPSR	CPSR
		SPSR_svc	SPSR_abt	SPSR_und	SPSR_irq	SPSR_fiq

Shading indicates that the normal register used by User or System mode has been replaced by an alternative register specific to the exception mode.

SP = stack pointer
LR = link register
PC = program counter

CPSR = current program status register
SPSR = saved program status register

Figure 14.26 ARM Register Organization

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.




Figure 14.27 Format of ARM CPSR AND SPSR

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Exception type	Mode	Normal entry address	Description
Reset	Supervisor	0x00000000	Occurs when the system is initialized.
Data abort	Abort	0x00000010	Occurs when an invalid memory address has been accessed, such as if there is no physical memory for an address or the correct access permission is lacking.
FIQ (fast interrupt)	FIQ	0x0000001C	Occurs when an external device asserts the FIQ pin on the processor. An interrupt cannot be interrupted except by an FIQ. FIQ is designed to support a data transfer or channel process, and has sufficient private registers to remove the need for register saving in such applications, therefore minimizing the overhead of context switching. A fast interrupt cannot be interrupted.
IRQ (interrupt)	IRQ	0x00000018	Occurs when an external device asserts the IRQ pin on the processor. An interrupt cannot be interrupted except by an FIQ.
Prefetch abort	Abort	0x0000000C	Occurs when an attempt to fetch an instruction results in a memory fault. The exception is raised when the instruction enters the execute stage of the pipeline.
Undefined instructions	Undefined	0x00000004	Occurs when an instruction not in the instruction set reaches the execute stage of the pipeline.
Software interrupt	Supervisor	0x00000008	Generally used to allow user mode programs to call the OS. The user program executes a SWI instruction with an argument that identifies the function the user wishes to perform.

Table 14.4

ARM Interrupt Vector

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.

Summary

Chapter 14

Processor Structure and Function

- Processor organization
- Register organization
  - User-visible registers
  - Control and status registers
- Instruction cycle
  - The indirect cycle
  - Data flow
- The x86 processor family
  - Register organization
  - Interrupt processing
- Instruction pipelining
  - Pipelining strategy
  - Pipeline performance
  - Pipeline hazards
  - Dealing with branches
  - Intel 80486 pipelining
- The Arm processor
  - Processor organization
  - Processor modes
  - Register organization
  - Interrupt processing

© 2016 Pearson Education, Inc., Hoboken, NJ. All rights reserved.