## Architecture

Part 1:




# Telephone networks

- 1 application (voice)
- Long unicast connections/sessions (calls)
- Almost constant traffic generation during the connection
- Sparse call arrival




# **Topologies**



**Figure 2-29.** (a) Fully interconnected network. (b) Centralized switch. (c) Two-level hierarchy.

Tanenbaum fig. 2-29

#### Fully-connected topology




 Large number of links



Expensive infrastructure!

### Centralized switch topology




 Small number of links

#### Local infrastructure:

- Connections from any point to a central switch
- Very long wires

#### Multi-level hierarchical topology



 Slightly larger number of links (2 levels)

#### Scalable infrastructure:

- Many short connections
- Fewer long-distance connections

# Topology with long distance




Fig. 2-16. The relationship of LATAs, LECs, and IXCs. All the circles are LEC switching offices. Each diamond belongs to the IXC whose number is in it


Multiple longdistance carriers

LATA = Local Access and Transport Area

LEC = local exchange carrier

IXC =
Interexchange
(long distance)
carrier

## Lines and trunks



Tanenbaum fig. 2-15

Local loop line is often twisted-pair copper (low capacity, analog) Trunks are often fiber (high capacity, digital)



## **Trunks**

 Trunk lines carry more than 1 call simultaneously (thousands-millions)



Digital vs Analog



#### Signal degrades with distance

- Analog sensitive to noise
- Digital: regeneration, recovery