PrimeCell[®] AHB SDR and NAND Memory Controller (PL242)

Revision: r0p1

Technical Reference Manual



PrimeCell AHB SDR and NAND Memory Controller (PL242) Technical Reference Manual

Copyright © 2006 ARM Limited. All rights reserved.

Release Information

The following changes have been made to this book.

Change History

| Date | Issue | Confidentiality | Change |
|------------------|-------|------------------|------------------------|
| 17 May 2006 | A | Non-Confidential | First release for r0p0 |
| 20 December 2006 | В | Non-Confidential | Updated for r0p1 |

Proprietary Notice

Words and logos marked with ® or ™ are registered trademarks or trademarks of ARM Limited in the EU and other countries, except as otherwise stated below in this proprietary notice. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM Limited in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means "ARM or any of its subsidiaries as appropriate".

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

http://www.arm.com

Contents

PrimeCell AHB SDR and NAND Memory Controller (PL242) Technical Reference Manual

| | Prefa | | |
|-----------|-------|------------------------------|-------|
| | | About this manual | xiv |
| | | Feedback | xviii |
| Chapter 1 | Intro | oduction | |
| - | 1.1 | About the AHB MC | 1-2 |
| | 1.2 | Supported devices | |
| Chapter 2 | Fund | ctional Overview | |
| - | 2.1 | Functional description | 2-2 |
| | 2.2 | DMC | 2-5 |
| | 2.3 | SMC | |
| | 2.4 | Functional operation | 2-13 |
| | 2.5 | DMC functional operation | |
| | 2.6 | SMC functional operation | 2-46 |
| Chapter 3 | Proc | grammer's Model | |
| • | 3.1 | About the programmer's model | 3-2 |
| | 3.2 | DMC Register summary | |
| | 3.3 | DMC Register descriptions | |
| | | | |

| | 3.4 | SMC Register summary | 3-29 | |
|------------|---------------------|--|------|--|
| | 3.5 | SMC Register descriptions | 3-32 | |
| Chapter 4 | Prog | rammer's Model for Test | | |
| | 4.1 | DMC and SMC integration test registers | 4-2 | |
| Chapter 5 | Devi | ce Driver Requirements | | |
| - | 5.1 | DMC memory initialization | 5-2 | |
| | 5.2 | SMC memory initialization | | |
| Appendix A | Signal Descriptions | | | |
| | A.1 | About the signals list | A-2 | |
| | A.2 | Clocks and resets | | |
| | A.3 | AHB signals | | |
| | A.4 | DMC memory interface signals | A-5 | |
| | A.5 | DMC miscellaneous signals | A-6 | |
| | A.6 | SMC memory interface signals | A-7 | |
| | A.7 | SMC miscellaneous signals | A-8 | |
| | A.8 | Low-power interface signals | A-9 | |
| | A.9 | Configuration signals | A-10 | |
| | A.10 | Scan chain signals | | |
| | | | | |

Glossary

List of Tables

PrimeCell AHB SDR and NAND Memory Controller (PL242) Technical Reference Manual

| | Change History | II |
|------------|---|------|
| Table 2-1 | Dynamic memory clocking options | |
| Table 2-2 | Static memory clocking options | |
| Table 2-3 | Example SDR setup | 2-38 |
| Table 2-4 | Valid system states for FSMs | 2-41 |
| Table 2-5 | Recommended power states | 2-42 |
| Table 2-6 | NAND AHB address setup | 2-51 |
| Table 2-7 | NAND cycles register settings for command | 2-61 |
| Table 2-8 | NAND flash address input example haddr fields | |
| Table 2-9 | NAND cycles register settings for read | 2-62 |
| Table 2-10 | NAND flash page read example haddr fields | 2-62 |
| Table 2-11 | NAND cycles register settings for write | |
| Table 2-12 | NAND flash page write example haddr fields | 2-64 |
| Table 3-1 | DMC register summary | 3-6 |
| Table 3-2 | dmc_memc_status Register bit assignments | 3-8 |
| Table 3-3 | dmc_memc_cmd Register bit assignments | 3-10 |
| Table 3-4 | dmc_direct_cmd Register bit assignments | 3-11 |
| Table 3-5 | dmc_memory_cfg Register bit assignments | 3-12 |
| Table 3-6 | dmc_refresh_prd Register bit assignments | 3-13 |
| Table 3-7 | dmc_cas_latency Register bit assignments | |
| Table 3-8 | dmc_t_dqss Register bit assignments | 3-15 |
| | | |

| Table 3-9 | dmc_t_mrd Register bit assignments | 3-15 |
|------------|--|------|
| Table 3-10 | dmc_t_ras Register bit assignments | 3-16 |
| Table 3-11 | dmc_t_rc Register bit assignments | 3-16 |
| Table 3-12 | dmc_t_rcd Register bit assignments | 3-17 |
| Table 3-13 | dmc_t_rfc Register bit assignments | 3-17 |
| Table 3-14 | dmc_t_rp Register bit assignments | |
| Table 3-15 | dmc_t_rrd Register bit assignments | 3-18 |
| Table 3-16 | dmc_t_wr Register bit assignments | 3-19 |
| Table 3-17 | dmc_t_wtr Register bit assignments | 3-19 |
| Table 3-18 | dmc_t_xp Register bit assignments | 3-20 |
| Table 3-19 | dmc_t_xsr Register bit assignments | 3-20 |
| Table 3-20 | dmc_t_esr Register bit assignments | 3-21 |
| Table 3-21 | dmc_id_<0-3>_cfg Registers bit assignments | 3-22 |
| Table 3-22 | dmc_chip_<0-3>_cfg Registers bit assignments | 3-22 |
| Table 3-23 | dmc_user_status Register bit assignments | 3-23 |
| Table 3-24 | dmc_user_status Registers bit assignments | 3-23 |
| Table 3-25 | dmc_periph_id Register bit assignments | 3-24 |
| Table 3-26 | dmc_periph_id_0 Register bit assignments | 3-25 |
| Table 3-27 | dmc_periph_id_1 Register bit assignments | 3-25 |
| Table 3-28 | dmc_periph_id_2 Register bit assignments | 3-25 |
| Table 3-29 | dmc_periph_id_3 Register bit assignments | 3-26 |
| Table 3-30 | dmc_pcell_id Register bit assignments | |
| Table 3-31 | dmc_pcell_id_0 Register bit assignments | 3-27 |
| Table 3-32 | dmc_pcell_id_1 Register bit assignments | |
| Table 3-33 | dmc_pcell_id_2 Register bit assignments | |
| Table 3-34 | dmc_pcell_id_3 Register bit assignments | |
| Table 3-35 | SMC register summary | |
| Table 3-36 | smc_memc_status Register bit assignments | |
| Table 3-37 | smc_memif_cfg Register bit assignments | |
| Table 3-38 | smc_memc_cfg_set Register bit assignments | |
| Table 3-39 | smc_memc_cfg_clr Register bit assignments | |
| Table 3-40 | smc_directcmd Register bit assignments | |
| Table 3-41 | smc_set_cycles Register bit assignments | |
| Table 3-42 | smc_set_opmode Register bit assignments | |
| Table 3-43 | smc_nand_cycles Register bit assignments | |
| Table 3-44 | smc_opmode Register bit assignments | |
| Table 3-45 | smc_user_status Register bit assignments | |
| Table 3-46 | smc_user_config Register bit assignments | |
| Table 3-47 | smc_periph_id Register bit assignments | |
| Table 3-48 | smc_periph_id_0 Register bit assignments | |
| Table 3-49 | smc_periph_id_1 Register bit assignments | |
| Table 3-50 | smc_periph_id_2 Register bit assignments | |
| Table 3-51 | smc_periph_id_3 Register bit assignments | |
| Table 3-52 | smc_pcell_id Register bit assignments | |
| Table 3-53 | smc_pcell_id_0 Register bit assignments | |
| Table 3-54 | smc_pcell_id_1 Register bit assignments | |
| Table 3-55 | smc_pcell_id_2 Register bit assignments | 3-46 |

| Table 3-56 | smc_pcell_id_3 Register bit assignments | 3-46 |
|------------|--|------|
| Table 4-1 | DMC integration test register summary | 4-2 |
| Table 4-2 | SMC integration test register summary | 4-3 |
| Table 4-3 | dmc_int_cfg Register bit assignments | 4-4 |
| Table 4-4 | dmc_int_inputs Register bit assignments | 4-4 |
| Table 4-5 | dmc_int_outputs Register bit assignments | 4-5 |
| Table 4-6 | smc_int_cfg Register bit assignments | 4-6 |
| Table 4-7 | smc_int_inputs Register bit assignments | |
| Table 4-8 | smc_int_outputs Register bit assignments | 4-8 |
| Table A-1 | Clocks and resets | A-3 |
| Table A-2 | AHB signals | A-4 |
| Table A-3 | DMC memory interface signals | A-5 |
| Table A-4 | DMC miscellaneous signals | A-6 |
| Table A-5 | SMC memory interface signals | A-7 |
| Table A-6 | SMC miscellaneous signals | A-8 |
| Table A-7 | Low-power interface signals | A-9 |
| Table A-8 | Configuration signals | A-10 |
| Table A-9 | Scan chain signals | A-11 |

List of Tables

List of Figures

PrimeCell AHB SDR and NAND Memory Controller (PL242) Technical Reference Manual

| | Key to timing diagram conventions | XV |
|-------------|--|------|
| Figure 1-1 | AHB MC (PL242) configuration | 1-2 |
| Figure 2-1 | AHB MC (PL242) configuration | 2-2 |
| Figure 2-2 | AHB MC (PL242) clock domains | 2-4 |
| Figure 2-3 | DMC block diagram | 2-5 |
| Figure 2-4 | dmc_aclk domain FSM diagram | 2-6 |
| Figure 2-5 | Low-power interface channel signals | 2-6 |
| Figure 2-6 | dmc_mclk domain FSM diagram | 2-8 |
| Figure 2-7 | DMC pad interface external connections | 2-8 |
| Figure 2-8 | SMC block diagram | 2-10 |
| Figure 2-9 | NAND interface | 2-12 |
| Figure 2-10 | Big-endian implementation | 2-16 |
| Figure 2-11 | AHBC memory map | |
| Figure 2-12 | Memory map | 2-18 |
| Figure 2-13 | Request to enter low-power mode | 2-22 |
| Figure 2-14 | AHB domain denying a low-power request | 2-22 |
| Figure 2-15 | Accepting requests | 2-23 |
| Figure 2-16 | Command control output timing | 2-34 |
| Figure 2-17 | Activate to read or write command timing, tRCD | 2-34 |
| Figure 2-18 | Bank activate to bank activate or auto-refresh command timing, tRC | 2-34 |
| Figure 2-19 | Bank activate to different bank activate for a memory timing, tRRD | 2-34 |
| | | |

| Figure 2-20 | Precharge to command and auto-refresh timing, tRP and tRFC | 2-35 |
|--|--|--|
| Figure 2-21 | Activate to precharge, and precharge to precharge timing, tRAS and tRP | 2-35 |
| Figure 2-22 | Mode register write to command timing, tMRD | |
| Figure 2-23 | Self-refresh entry and exit timing, tESR and tXSR | 2-36 |
| Figure 2-24 | Power-down entry and exit timing, tXP | 2-36 |
| Figure 2-25 | Data output timing, tWTR | |
| Figure 2-26 | Data output timing, tDQSS = 1 | 2-37 |
| Figure 2-27 | Data input timing | |
| Figure 2-28 | DMC system state transitions | 2-43 |
| Figure 2-29 | smc_aclk domain FSM diagram | 2-46 |
| Figure 2-30 | NAND flash page read operations | 2-54 |
| Figure 2-31 | NAND flash page program operations | |
| Figure 2-32 | NAND flash status register read | 2-56 |
| Figure 2-33 | Chip configuration registers | |
| Figure 2-34 | Nand flash command phase | 2-61 |
| Figure 2-35 | NAND flash read data phase | 2-62 |
| Figure 2-36 | NAND flash write data phase | 2-63 |
| Figure 2-37 | NAND read example | 2-64 |
| Figure 2-38 | NAND write example | 2-65 |
| Figure 3-1 | DMC and SMC register map | 3-3 |
| Figure 3-2 | DMC configuration register map | 3-4 |
| Figure 3-3 | DMC id configuration register map | 3-5 |
| Figure 3-4 | DMC chip configuration register map | 3-5 |
| Figure 3-5 | DMC peripheral and PrimeCell Identification configuration register map | |
| Figure 3-6 | dmc_memc_status Register bit assignments | |
| Figure 3-7 | dmc_memc_cmd Register bit assignments | |
| Figure 3-8 | dmc_direct_cmd Register bit assignments | |
| Figure 3-9 | dmc_memory_cfg Register bit assignments | |
| Figure 3-10 | dmc_refresh_prd Register bit assignments | |
| Figure 3-11 | dmc_cas_latency Register bit assignments | |
| Figure 3-12 | dmc_t_dqss Register bit assignments | |
| Figure 3-13 | dmc_t_mrd Register bit assignments | |
| Figure 3-14 | dmc_t_ras Register bit assignments | |
| Figure 3-15 | dmc_t_rc Register bit assignments | |
| Figure 3-16 | dmc_t_rcd Register bit assignments | |
| Figure 3-17 | dmc_t_rfc Register bit assignments | |
| Figure 3-18 | | 3-18 |
| Figure 3-19 | dmc_t_rp Register bit assignments | |
| _ . ~ | dmc_t_rrd Register bit assignments | 3-18 |
| Figure 3-20 | dmc_t_rrd Register bit assignments | 3-18 3-19 |
| Figure 3-21 | dmc_t_rrd Register bit assignments | 3-18 3-19 3-19 |
| Figure 3-21 Figure 3-22 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments | 3-18 3-19 3-19 3-20 |
| Figure 3-21 Figure 3-22 Figure 3-23 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments dmc_t_xr Register bit assignments | 3-18 3-19 3-19 3-20 3-20 |
| Figure 3-21 Figure 3-22 Figure 3-23 Figure 3-24 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments dmc_t_xr Register bit assignments dmc_t_xr Register bit assignments dmc_t_esr Register bit assignments | 3-18 3-19 3-19 3-20 3-21 |
| Figure 3-21 Figure 3-22 Figure 3-23 Figure 3-24 Figure 3-25 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments dmc_t_xr Register bit assignments dmc_t_sr Register bit assignments dmc_t_esr Register bit assignments dmc_id_<0-3>_cfg Registers bit assignments | 3-18 3-19 3-19 3-20 3-21 3-21 |
| Figure 3-21 Figure 3-22 Figure 3-23 Figure 3-24 Figure 3-25 Figure 3-26 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments dmc_t_xr Register bit assignments dmc_t_sr Register bit assignments dmc_t_esr Register bit assignments dmc_id_<0-3>_cfg Registers bit assignments dmc_chip_<0-3>_cfg Registers bit assignments | 3-18 3-19 3-29 3-20 3-21 3-21 |
| Figure 3-21 Figure 3-22 Figure 3-23 Figure 3-24 Figure 3-25 | dmc_t_rrd Register bit assignments dmc_t_wr Register bit assignments dmc_t_wtr Register bit assignments dmc_t_xp Register bit assignments dmc_t_xr Register bit assignments dmc_t_sr Register bit assignments dmc_t_esr Register bit assignments dmc_id_<0-3>_cfg Registers bit assignments | 3-18 3-19 3-19 3-20 3-20 3-21 3-21 3-22 3-23 |

| Figure 3-29 | dmc_periph_id Register bit assignments | 3-24 |
|-------------|--|-------|
| igure 3-30 | dmc_pcell_id Register bit assignments | 3-27 |
| Figure 3-31 | SMC configuration register map | 3-29 |
| Figure 3-32 | SMC chip configuration register map | 3-29 |
| igure 3-33 | SMC user configuration register map | |
| Figure 3-34 | SMC peripheral and PrimeCell identification configuration register map | 3-30 |
| Figure 3-35 | smc_memc_status Register bit assignments | 3-32 |
| Figure 3-36 | smc_memif_cfg Register bit assignments | |
| Figure 3-37 | smc_memc_cfg_set Register bit assignments | 3-34 |
| Figure 3-38 | smc_memc_cfg_clr Register bit assignments | 3-35 |
| Figure 3-39 | smc_direct_cmd Register bit assignments | 3-36 |
| Figure 3-40 | smc_set_cycles Register bit assignments | 3-37 |
| Figure 3-41 | smc_set_opmode Register bit assignments | 3-38 |
| Figure 3-42 | smc_nand_cycles Register bit assignments | 3-38 |
| Figure 3-43 | smc_opmode Register bit assignments | 3-39 |
| Figure 3-44 | smc_user_status Register bit assignments | 3-40 |
| Figure 3-45 | smc_user_config Register bit assignments | 3-41 |
| Figure 3-46 | smc_periph_id Register bit assignments | 3-42 |
| Figure 3-47 | smc_pcell_id Register bit assignments | 3-44 |
| Figure 4-1 | DMC integration test register map | . 4-2 |
| igure 4-2 | SMC integration test register map | . 4-2 |
| Figure 4-3 | dmc_int_cfg Register bit assignments | . 4-3 |
| igure 4-4 | dmc_int_inputs Register bit assignments | . 4-4 |
| Figure 4-5 | dmc_int_outputs Register bit assignments | . 4-5 |
| igure 4-6 | smc_int_cfg Register bit assignments | . 4-6 |
| igure 4-7 | smc_int_inputs Register bit assignments | . 4-6 |
| Figure 4-8 | smc_int_outputs Register bit assignments | |
| Figure 5-1 | DMC and memory initialization sheet 1 of 2 | . 5-3 |
| igure 5-2 | DMC and memory initialization sheet 2 of 2 | . 5-4 |
| Figure 5-3 | SMC and memory initialization sheet 1 of 2 | |
| Figure 5-4 | SMC and memory initialization sheet 2 of 2 | . 5-7 |
| igure A-1 | AHB MC (PL242) grouping of signals | . A-2 |

List of Figures

Preface

This preface introduces the *PrimeCell AHB SDR and NAND Memory Controller (MC)* (*PL242*) *Technical Reference Manual*. It contains the following sections:

- About this manual on page xiv
- Feedback on page xviii.

About this manual

This is the *Technical Reference Manual* (TRM) for the *PrimeCell AHB SDR and NAND Memory Controller*.

Product revision status

The rnpn identifier indicates the revision status of the product described in this manual, where:

rn Identifies the major revision of the product.

pn Identifies the minor revision or modification status of the product.

Intended audience

This manual is written for system designers, system integrators, and verification engineers who are designing a *System-on-Chip* (SoC) device that uses the AHB MC. The manual describes the external functionality of the AHB MC.

Using this manual

This manual is organized into the following chapters:

Chapter 1 Introduction

Read this chapter for a high-level view of the AHB MC.

Chapter 2 Functional Overview

Read this chapter for a description of the major components of the AHB MC and how they operate.

Chapter 3 Programmer's Model

Read this chapter for a description of the AHB MC registers.

Chapter 4 Programmer's Model for Test

Read this chapter for a description of the additional logic for integration testing.

Chapter 5 Device Driver Requirements

Read this chapter for a description of device driver requirements for the *Dynamic Memory Controller* (DMC) and *Static Memory Controller* (SMC).

Appendix A Signal Descriptions

Read this appendix for a description of the AHB MC input and output

signals.

Glossary Read the Glossary for definitions of terms used in this manual.

Conventions

Conventions that this manual can use are described in:

Typographical

Timing diagrams on page xvi

• Signals on page xvi

• Numbering on page xvii.

Typographical

The typographical conventions are:

italic Highlights important notes, introduces special terminology,

denotes internal cross-references, and citations.

bold Highlights interface elements, such as menu names. Denotes

signal names. Also used for terms in descriptive lists, where

appropriate.

monospace Denotes text that you can enter at the keyboard, such as

commands, file and program names, and source code.

monospace Denotes a permitted abbreviation for a command or option. You

can enter the underlined text instead of the full command or option

name.

monospace italic Denotes arguments to monospace text where the argument is to be

replaced by a specific value.

monospace bold Denotes language keywords when used outside example code.

< and > Angle brackets enclose replaceable terms for assembler syntax

where they appear in code or code fragments. They appear in

normal font in running text. For example:

MRC p15, 0 <Rd>, <CRn>, <CRm>, <Opcode_2>


The Opcode_2 value selects which register is accessed.

Angle brackets can also enclose a permitted range of values. The example, <0-3>, shows that in name extensions, only one of the values 0, 1, 2, or 3 is valid.

Timing diagrams

The figure named *Key to timing diagram conventions* explains the components used in timing diagrams. Variations, when they occur, have clear labels. You must not assume any timing information that is not explicit in the diagrams.

Shaded bus and signal areas are undefined, so the bus or signal can assume any value within the shaded area at that time. The actual level is unimportant and does not affect normal operation.



Key to timing diagram conventions

Signals

The signal conventions are:

| Signal level | The level of an asserted | d signal depends on w | hether the signal is |
|--------------|--------------------------|-----------------------|----------------------|
| | | | |

active-HIGH or active-LOW. Asserted means HIGH for active-HIGH signals and LOW for active-LOW signals.

Lower-case n Denotes an active-LOW signal.

Prefix A Denotes global *Advanced eXtensible Interface* (AXI) signals.

Prefix AR Denotes AXI read address channel signals.

Prefix AW Denotes AXI write address channel signals.

| Prefix B Denotes A | XI write response cl | hannel signals. |
|---------------------------|----------------------|-----------------|
|---------------------------|----------------------|-----------------|

Prefix C Denotes AXI low-power interface signals.

Prefix H Denotes Advanced High-performance Bus (AHB) signals.

Prefix P Denotes Advanced Peripheral Bus (APB) signals.

Prefix R Denotes AXI read data channel signals.

Prefix W Denotes AXI write data channel signals.

Numbering

The Verilog numbering convention is:

<size in bits>'<base><number>

This is a Verilog method of abbreviating constant numbers. For example:

- 'h7B4 is an unsized hexadecimal value.
- 'o7654 is an unsized octal value.
- 8'd9 is an eight-bit wide decimal value of 9.
- 8'h3F is an eight-bit wide hexadecimal value of 0x3F. This is equivalent to b00111111.
- 8'b1111 is an eight-bit wide binary value of b00001111.

Further reading

This section lists publications by ARM Limited, and by third parties.

ARM Limited periodically provides updates and corrections to its documentation. See http://www.arm.com for current errata sheets, addenda, and the Frequently Asked Questions list.

ARM publications

This manual contains information that is specific to the AHB MC. See the following documents for other relevant information:

- PrimeCell AHB SDR and NAND Memory Controller (PL242) Integration Manual (ARM DII 0152)
- PrimeCell AHB SDR and NAND Memory Controller (PL242) Implementation Guide (ARM DII 0147)
- *AMBA*™ *Specification* (Rev 2.0) (ARM IHI 0011)
- AMBA 3 APB Protocol v1.0 Specification (ARM IHI 0024).

Feedback

ARM Limited welcomes feedback on the AHB MC and its documentation.

Feedback on this product

If you have any comments or suggestions about this product, contact your supplier giving:

- the product name
- a concise explanation of your comments.

Feedback on this manual

If you have any comments on this manual, send email to errata@arm.com giving:

- the title
- the number
- the relevant page number(s) to which your comments apply
- a concise explanation of your comments.

ARM Limited also welcomes general suggestions for additions and improvements.

Chapter 1 Introduction

This chapter introduces the AHB MC. It contains the following sections:

- About the AHB MC on page 1-2
- Supported devices on page 1-6.

1.1 About the AHB MC

The AHB MC is an *Advanced Microcontroller Bus Architecture* (AMBA) compliant *System-on-Chip* (SoC) peripheral. It is developed, tested, and licensed by ARM Limited.

The AHB MC takes advantage of the newly developed *Dynamic Memory Controller* (*DMC*) and *Static Memory Controller* (SMC). The AHB MC has four AHB ports with access to the external memory. Each AHB port has a bridge interface to the memory controllers. There is a separate AHB port to configure the memory controllers. Specific configurations of the SMC and DMC are instantiated to target specific memory devices. Figure 1-1 shows the AHB MC (PL242) configuration.




Figure 1-1 AHB MC (PL242) configuration

This section describes:

- *AHB interface* on page 1-3
- AHB to APB bridge on page 1-3
- Bus matrix on page 1-3
- *DMC* on page 1-4
- *SMC* on page 1-4

- *Clock domains* on page 1-5
- *Low-power interfaces* on page 1-5.

1.1.1 AHB interface

The interface converts the incoming AHB transfers to the protocol used internally by the AHB MC.

The interface has the following features:

- all AHB fixed length burst types are directly translated to fixed length bursts
- all undefined length INCR bursts are converted to INCR4 bursts
- broken bursts are supported
- the bufferable bit of the **HPROT** signal determines if the interface must wait for a write transfer to complete internally
- a Read After Write (RAW) hazard detection buffer avoids RAW hazards
- AHB response signals are registered to improve timing
- locked transfers are supported within a 512MB region
- **HWDATA** is registered to improve internal timing paths
- a big-endian 32-bit mode option is implemented
- AHB error response logic is removed because no internal components generate errors.

This interface is a fully validated component. This ensures that it obeys both the AHB protocol and the internal protocol that the interconnect uses.

See Chapter 2 Functional Overview for more information.

1.1.2 AHB to APB bridge

This bridge converts AHB transfers from the configuration port to the APB transfers that the internal memory controllers require.

See Chapter 2 Functional Overview for more information.

1.1.3 Bus matrix

The bus matrix enables each AHB port to access the two memory controllers.

See Chapter 2 Functional Overview for more information.

1.1.4 DMC

The DMC is optimized for 32-bit SDR SDRAM. The DMC supports four chip selects that you can individually program.

The DMC is pre-configured and validated for:

- the SDRAM memory type
- the number of SDRAM memory devices
- the maximum SDRAM memory width.

The DMC block offers the following features:

- synchronous or asynchronous operation between AHB and the external memory bus
- active and precharge power down supported in the SDRAM
- quality of service features for low latency transfers
- support for the PL220 External Bus Interface (EBI) PrimeCell, enabling sharing
 of external address and data bus pins between memory controller interfaces
- optimized utilization of external memory bus
- tie-off pin to select external memory widths
- multiple outstanding addresses.

See Chapter 2 Functional Overview for more information.

1.1.5 SMC

The SMC is a high-performance, area-optimized NAND memory controller.

The SMC is pre-configured and validated for:

- the NAND memory type
- the number of NAND memory devices
- the maximum NAND memory width.

The memory interface supports asynchronous NAND.

The SMC block offers the following features:

- it is configured to support the maximum NAND memory data width of 16-bit
- programmable cycle timings and memory width per chip select
- atomic switching of memory device and controller operating modes

- support for the PL220 *External Bus Interface* (EBI) PrimeCell, enabling sharing of external address and data bus pins between memory controller interfaces
- support for a low-power interface
- support for a remap signal
- support for clock domains to be synchronous or asynchronous.

See Chapter 2 Functional Overview for more information.

1.1.6 Clock domains

The memory controller has three clock domains:

- AHB clock domain
- dynamic memory clock domain
- static memory clock domain.

See Chapter 2 Functional Overview for more information.

1.1.7 Low-power interfaces

The memory controller has three low-power interfaces, one for each clock domain.

See Chapter 2 Functional Overview for more information.

1.2 Supported devices

The DMC supports SDRAM, see *DMC* on page 1-4. The *Release Note* provides a specific list of memory devices tested with each configuration.

The SMC supports NAND, see *SMC* on page 1-4. The *Release Note* provides a specific list of memory devices tested with each configuration.

Note

Because the memory controller maps INCR transfers into INCR4 transfers, it does not support memory mapped FIFO components.

Chapter 2 Functional Overview

This chapter describes the major components of the AHB MC and how they operate. It contains the following sections:

- Functional description on page 2-2
- *DMC* on page 2-5
- *SMC* on page 2-10
- Functional operation on page 2-13
- DMC functional operation on page 2-24
- *SMC functional operation* on page 2-46.

2.1 Functional description

Figure 2-1 shows the AHB MC (PL242) configuration.




Figure 2-1 AHB MC (PL242) configuration

This section is divided into:

- *AHB interface* on page 2-3
- AHB to APB bridge on page 2-3
- Bus matrix on page 2-3
- *Clock domains* on page 2-3
- Low-power interface on page 2-4
- *DMC* on page 2-5
- *SMC* on page 2-10.

2.1.1 AHB interface

The AHB MC fully supports the AMBA AHB 2.0 specification. This interface component converts the incoming AHB transfers to the required transfers of the internal interconnect protocol. Because of the design of the internal interconnect, some optimizations are made in the interface to improve performance.

See *AHB interface operation* on page 2-13 for more information.

2.1.2 AHB to APB bridge

The internal memory controllers of the AHB MC use the AMBA3 APB protocol for their configuration ports. To enable the AHB MC to externally function as an AHB device, the APB configuration ports are connected to an AHB to APB bridge. The bridge converts incoming AHB transfers from the configuration port to the APB transfers that the internal memory controllers require. This bridge is part of the PrimeCell infrastructure components, part BP127.

See AHB to APB bridge operation on page 2-16 for more information.

2.1.3 Bus matrix

The bus matrix enables the AHB ports to access either of the internal memory controllers. The matrix uses round robin arbitration enabling each AHB port to have equal priority.

See *Bus matrix operation* on page 2-17 for more information.

2.1.4 Clock domains

The memory controller has three clock domains:

AHB clock domain

This is clocked by hclk, dmc_aclk and smc_aclk and is reset by hresetn.

Dynamic memory clock domain

This is clocked by **dmc_mclk** and **dmc_mclkn** and is reset by **dmc_mresetn**.

Static memory clock domain

This is clocked by **smc_mclk0** and **smc_mclk0n** and is reset by **smc_mreset0n**.

Figure 2-2 on page 2-4 shows the three clock domains.




Figure 2-2 AHB MC (PL242) clock domains

The memory controller supports many different options for clocking the different domains. The DMC and SMC clock domains are completely independent and each have clocking options.

See Clock domain operation on page 2-19 for more information.

2.1.5 Low-power interface

The memory controller has three low-power interfaces, one for each clock domain. These operate with a simple three signal protocol. It is expected that a system clock controller drives these interfaces and associated clocks. Each domain has individual control that enables one memory clock domain or all clock domains to be powered down.

See Low-power interface operation on page 2-21 for more information.

2.2 DMC

Figure 2-3 shows a block diagram of the DMC.




Figure 2-3 DMC block diagram

The DMC interface processes the incoming transfers from the AHB ports. It can only add a read or write to the queue at any one time. It uses round robin arbitration to decide between a simultaneous read or write.

The DMC uses a scheduling algorithm to determine the item in the queue to process next to maximize data bandwidth. The algorithm uses information including:

- the memory rows that are currently open
- the order of transfers received from each AHB port
- timing of refresh commands from the manager
- the *Quality Of Service* (QoS) required by each port.

The QoS is set by a register within the DMC on a port by port basis. The QoS value indicates a required read maximum latency. A QoS timeout causes the transaction to be raised to a higher priority. You can also set the QoS to minimum for a specific port so that its transfers are serviced with a higher priority. This impacts the overall memory bandwidth because it limits the options of the scheduling algorithm.

The main blocks of the DMC are:

- Arbiter on page 2-6
- *Memory manager* on page 2-6
- *APB slave interface* on page 2-7

- *Memory interface* on page 2-7
- *Pad interface* on page 2-8.

2.2.1 Arbiter

The arbiter receives memory access commands from the DMC interface and the memory manager. It passes the highest priority command to the memory interface after arbitration. Read data is passed from the memory interface to the DMC interface.

See Arbiter operation on page 2-27 for more information.

2.2.2 Memory manager

The memory manager tracks and controls the current state of the DMC using a *Finite State Machine* (FSM) as Figure 2-4 shows.




Figure 2-4 dmc_aclk domain FSM diagram

In Figure 2-4, non-state moving transitions are omitted for clarity. See Table 2-4 on page 2-41 for valid system states.

APB commands to the Direct Command Register or the low-power interface control the state of the DMC. Figure 2-5 shows the low-power interface channel signals.




Figure 2-5 Low-power interface channel signals

The low-power interface channel enables low-power mode to be entered using discrete lines. You can tie off this interface to be inactive if it is not required.

The APB slave interface stalls the **psel** and **penable** signals using the **pready** signal if a previous command has not completed.

If an APB command is received that is illegal to carry out from the current state then it is ignored and the FSM stays in the current state.

The memory manager enables the APB slave interface to directly send initialization commands to the external memory SDRAM and periodically generate refresh commands for the external memory SDRAM.

See *Memory manager operation* on page 2-31 for more information.

2.2.3 APB slave interface

| The APB interface implements the register file as Chapter 3 <i>Programmer's Model</i> describes. |
|---|
| Note |
| APB only supports single-word 32-bit accesses. Bits [1:0] of the paddr signal are no used within the DMC, resulting in byte and half-word accesses being treated as word |

See APB slave interface operation on page 2-32 for more information.

2.2.4 Memory interface

accesses.

The memory interface provides a clean and defined interface between the pad interface and the arbiter ensuring the external memory interface command protocols are met in accordance with the programmed timings in the register block. See Chapter 3 *Programmer's Model*.

The only external IOs to this block are **dmc_mclk** and **dmc_mresetn**.

The memory interface tracks and controls the state of the external memories using an FSM. See Figure 2-6 on page 2-8.




Figure 2-6 dmc_mclk domain FSM diagram

See Table 2-4 on page 2-41 for valid system states.

See *Memory interface operation* on page 2-32 for more information.

2.2.5 Pad interface

The pad interface provides a flip-flop for each external signal.

Figure 2-7 shows the pad interface external connections.




Figure 2-7 DMC pad interface external connections

Pad interface to external memory devices

The pad interface block registers the relevant command signals with clocks that enable the external memory device timings to be met.

To support a PrimeCell EBI (PL220) the **dmc_ap** precharge bit signal is also an external signal to the DMC. Having **dmc_ap** separate to the address bus means that PRECHARGEALL commands to dynamic memory can be issued when the EBI has granted the external memory interface to another memory controller.

See Pad interface operation on page 2-37 for more information.

2.3 SMC

Figure 2-8 shows a block diagram of the SMC.




Figure 2-8 SMC block diagram

The main blocks of the SMC are:

- *SMC interface* on page 2-11
- *APB slave interface* on page 2-11
- Format on page 2-11
- Memory manager on page 2-11
- Memory interface on page 2-11
- Pad interface on page 2-12
- *Interrupts* on page 2-12.

2.3.1 SMC interface

The SMC interface processes the incoming AHB transfers and sends them to the command format block.

2.3.2 APB slave interface

The SMC has 4KB of memory allocated to it.

The APB slave interface accesses the SMC registers to program the memory system configuration parameters and to provide status information. See Chapter 3 *Programmer's Model* and *APB slave interface operation* on page 2-50 for more information.

2.3.3 Format

The format block receives memory accesses from the SMC interface and the memory manager. Read and write requests are arbitrated on a round robin basis. Requests from the manager have the highest priority. The format block also maps AHB memory transfers onto appropriate memory transfers and passes these to the memory interface through the command FIFO.

See Format block on page 2-50 for more information.

2.3.4 Memory manager

The memory manager tracks and controls the current state of **smc_aclk** domain logic. The block is responsible for:

- updating timing registers and controlling direct commands issued to memory
- controlling entry-to and exit-from low-power mode through the APB interface
- the low-power interface.

See *Memory manager operation* on page 2-57 for more information.

2.3.5 Memory interface

The SMC supports a NAND memory interface. The NAND memory interface is composed of command, read data and write data FIFOs, plus control logic. The memory interface logic is specific to NAND. The memory interface also contains logic that controls interaction with the EBI and prevents the memory interface from issuing commands until it is granted the external bus.

See *Memory interface operation* on page 2-60 for more information.

2.3.6 Pad interface

The pad interface module provides a registered I/O interface for data and control signals. It also contains interrupt generation logic.

Figure 2-9 shows the NAND interface. Clock and reset signals have been omitted.




Figure 2-9 NAND interface

2.3.7 Interrupts

The SMC series provides interrupt outputs for use with NAND flash, because of the long wait times associated with this memory. The NAND memory interface supports interrupts. The interrupt is triggered on the rising edge of the **smc_busy_0** input for the NAND memory interface.

See Interrupts operation on page 2-60 for more information.

2.4 Functional operation

This section is divided into:

- AHB interface operation
- AHB to APB bridge operation on page 2-16
- Bus matrix operation on page 2-17
- *Clock domain operation* on page 2-19
- Low-power interface operation on page 2-21
- DMC functional operation on page 2-24
- *SMC functional operation* on page 2-46.

2.4.1 AHB interface operation

This section describes:

- AHB fixed burst types
- *Undefined length INCR bursts* on page 2-14
- Broken bursts on page 2-14
- Bufferable bit of the HPROT signal on page 2-14
- Read after write hazard detection buffer on page 2-15
- AHB response signals on page 2-15
- Locked transfers on page 2-15
- Registered HWDATA on page 2-16
- Big-endian 32-bit mode on page 2-16
- *Removal of AHB error response logic* on page 2-16.

AHB fixed burst types

All AHB fixed length bursts directly map to burst types that the internal interconnect uses. The internal interconnect and the memory controllers are based on transferring bursts of data. The larger the burst size, the more efficient the transfer and overall performance. The standard AHB fixed length burst types are directly mapped to the internal protocol.

Burst operation has performance benefits because when the first beat of a burst is accepted, it contains data about the remaining beats. For example, from the first beat of a read burst, all the data required to complete the transfer can be read from memory. This first transfer has some delay before data is returned. Subsequent beats of the burst can have less delay because the data they require might have already been read from the memory.

Undefined length INCR bursts

All undefined length INCR bursts are converted to INCR bursts of length four. Many AHB masters rely on using undefined length INCR bursts to access data. If each INCR transfer is processed as a single transfer by the internal protocol then the performance is significantly degraded.

The bridge converts the incoming INCR transfers to INCR transfers of length four, INCR4. This mean that the bridge speculatively requests data from the internal interconnect, before it knows it is going to require it. If the AHB master continues the burst, then the data can be returned quickly because it has already been requested. When the INCR burst finishes, the bridge disregards any data requested from the internal interconnect that is not required.

Any INCR burst of less than four beats results in a broken INCR4. Undefined length INCR bursts of more than four beats are split into an appropriate number of INCR4s plus a broken INCR4, if required.

Broken bursts

To fully support the AMBA AHB 2.0 specification, the bridge supports all broken AHB bursts. Although bursts cannot be broken by an AHB master, if the AHB system has multiple masters then the AHB system arbitration can break a burst. Also, because the bridge converts INCR to INCR4, broken INCR4s occur when undefined length INCRs of a length not equal to a multiple of four are performed.

To support broken bursts, the bridge must keep track of how many beats of a burst have been performed and ensure it obeys the protocol of the interconnect. For read bursts, this means draining the interconnect of any requested data that is not required. For write bursts this means artificially extending write data with enough beats to obey the protocol. The interconnect uses write strobes to indicate the bytes of the data bus that are valid. When extending broken bursts, these strobes are deasserted so that the artificial data does not corrupt the actual memory.

Bufferable bit of the HPROT signal

The bufferable bit of the **HPROT** signal determines whether the bridge must wait for a write transfer to complete internally. The AHB protection control bits support the concept of bufferable data accesses. The **HPROT**[2] signal determines this. The internal interconnect supports the concept of a write response to indicate when data has actually been written to memory. The bridge exploits these features by not waiting for the write response if the access is described as bufferable. This enables numerous bufferable writes to occur with minimum latency. These are accepted by the interconnect and queued in the memory controller.

If transfers are described as non-bufferable then the bridge must wait for the write response to indicate that the transfer has been completed to memory. If numerous bufferable writes are performed, followed by a non-bufferable write, then the bridge must wait until it receives the write response associated with the final write.

Read after write hazard detection buffer

A RAW hazard detection buffer avoids potential RAW hazards. The protocol used internally to AHB MC does not perform memory coherency checks to catch *Write After Read* (WAR) or RAW hazards.

Because of the nature of the AHB protocol, WAR hazards never occur because the read must have completed before the write can be accepted.

Because the bridge permits writes to be buffered internally, there is a potential for a RAW hazard to occur. If you perform a bufferable write then it might not complete immediately. If a read to that same memory location is performed then both transfers can be in the queue and the internal memory controllers can reorder these transactions for performance reasons so that the read occurs before the write. This means that the data read might be the value before the most recent write. The bridge has to detect these potential cases and stall the read transfer until any buffered writes that might cause a RAW hazard have been completed.

The bridge contains logic to monitor up to four outstanding write addresses. If an incoming read occurs to a 4KB region that has been written to, then it is stalled. If four bufferable writes occur then the AHB is stalled until a response is seen for the first of the four writes in the buffer.

AHB response signals

The interconnect used within the AHB MC contains many combinatorial paths that link different AHB input ports. To improve the synthesis timing, the AHB responses are registered to limit these paths to within the design.

Locked transfers

AHB MC supports locked transfers, within a 512MB region. This is because of the way the interconnect processes locked transfers. There is a significant performance penalty in using locked transfers. Transfers that are locked together wait for all other ports to complete any outstanding transfers to that region before they can begin. While a locked sequence occurs to a specific 512MB memory region, all other access to that region is stalled. All locked writes are processed as non-bufferable writes and so have to wait for the appropriate write response before indicating their completion.

You can lock the DMC and SMC channels independently. Therefore you can have:

- DMC locked accesses, SMC unlocked accesses
- DMC unlocked accesses, SMC locked accesses
- DMC and SMC locked accesses.

Registered HWDATA

The interconnect used within the AHB MC contains combinatorial paths for the write data. To improve the synthesis timing, **HWDATA** is registered and makes these paths internal to the design.

Big-endian 32-bit mode

The AHB MC supports the option of storing data to memory in big-endian 32-bit mode. Each bridge contains the logic to implement this data mapping depending on the **big_endian** input tie-off. Figure 2-10 shows that if the tie off is asserted then the data buses are reordered.





Figure 2-10 Big-endian implementation

Removal of AHB error response logic

The internal protocol used within AHB MC supports the concept of errors. However none of the components used ever generate errors. This means that the bridge does not require any logic to generate AHB errors because there are no circumstances when errors can be generated.

2.4.2 AHB to APB bridge operation

The internal memory controllers each have an APB configuration port. The AHB configuration port is mapped to these controllers using an AHB to APB bridge. Figure 2-11 on page 2-17 shows that each internal memory controller configuration port has a 4KB address space.



AHBC memory map

Figure 2-11 AHBC memory map

The other fourteen 4KB regions are read as zero. The lower 16 bits of the AHB address decode the memory controller that is being used. An external AHB decoder determines where in the system memory map, this 64KB region is located. See *About the programmer's model* on page 3-2 for descriptions of the internal memory controller configuration registers. The configuration ports of the internal memory controllers are APB, so only word reads and writes are supported.

2.4.3 Bus matrix operation

The following sections explain the bus matrix configuration features and options:

- Arbitration scheme
- Locked transfers
- *Memory map* on page 2-18.

Arbitration scheme

The bus matrix supports a round robin arbitration scheme. This enables each port to have an equal opportunity to access memory.

Locked transfers

A locked sequential transfer must be within the same 512MB address region to guarantee that it is to a single memory controller. To maintain data integrity throughout a locked sequence, the interconnect only accepts the locked transfer after the target slave has completed all outstanding transactions. The slave then becomes locked and

only the locking master can access it. The slave remains locked until the locking master completes an unlocked transfer to that slave. This unlocking transfer is added by the AHB interface at the end of a locked sequence.

Memory map

The bus matrix is configured with predefined 512MB regions of memory allocated to the internal memory controllers. Figure 2-12 shows the memory map.

| | 0xFFFFFFF | | 0xFFFFFFF |
|-----------|------------|-----------|------------|
| SMC | 0×E0000000 | SMC | 0×E0000000 |
| DMC | 0×C0000000 | DMC | 0×C0000000 |
| SMC | | SMC | |
| DMC | 0×A0000000 | DMC | 0xA0000000 |
| SMC | 0×80000000 | SMC | 0x80000000 |
| DMC | 0×60000000 | DMC | 0×60000000 |
| SMC | 0x40000000 | SMC | 0x40000000 |
| | 0×20000000 | | 0×20000000 |
| DMC | 0×00000000 | SMC | 0×00000000 |
| remap = 0 | | remap = 1 | |

Figure 2-12 Memory map

This enables the system designer maximum flexibility with memory regions for a fixed bus matrix memory map. You must program the address match and mask fields of the static and dynamic memory controllers to determine the address decode for each chip select. See *DMC chip_<0-3>_cfg Registers at 0x0200* on page 3-22 and *SMC Opmode Registers <0-1> at 0x1104*, 0x1124 on page 3-39. The selected values must be within the constraints of the bus matrix memory map shown in Figure 2-12. The **remap** pin enables either the static or the dynamic memory controller to be decoded to address 0x00000000.

The SMC also contains some independent remap functionality. You can use the **smc_remap_0** signal to alias SMC chip select 0 to address 0x00000000 in addition to its address match and mask tie-off. If the **smc_remap_0** signal is HIGH, then the memory controller uses the **smc_nand_mw_0** tie-off to determine the width of the external memory chip.

2.4.4 Clock domain operation

The memory controller supports three clock domains:

- the AHB clock domain
- the dynamic memory clock domain
- the static memory clock domain.

The **hclk** input drives the AHB clock domain. This clock drives the AHB interfaces and bus matrix. Each of the internal memory controllers has a separate clock input in this domain. These are called **dmc_aclk** and **smc_aclk**. These signals are separated to enable the clock to be stopped on an individual memory controller for low-power operation, see *Low-power interface operation* on page 2-21. These three clocks must always be driven from the same clock source. The input signal **hresetn** resets the clock domain.

The dynamic memory clock domain controls the memory interface logic of the DMC. The input signal **dmc_mclk** and its inverse **dmc_mclk** drive this domain. Each external dynamic memory chip is driven by a gated **dmc_mclk** signal, these are called **dmc_clk_out[3:0]**. Clocks are only driven out to chips that require them. The dynamic memory interface has a fed back clock input, **dmc_fbclk_in**, to help with clock skews on the external pads.

The static memory clock domain controls the memory interface logic of the SMC. The input signal **smc_mclk0** and its inverse **smc_mclk0n** drive this domain. This is the clock used for the timings of asynchronous drive signals to the NAND memory.

The memory controller supports many different options for clocking the different domains. The dynamic and static clock domains are completely independent and have clocking options:

- Dynamic memory clocking options on page 2-20
- Static memory clocking options on page 2-20.

Dynamic memory clocking options

Table 2-1 lists the dynamic memory clocking options.

Table 2-1 Dynamic memory clocking options

| Options | Tie-off values |
|--|--|
| Fully synchronous | |
| hclk = dmc_mclk | dmc_async = dmc_msync = 1 dmc_a_gt_m_sync = 0 |
| Synchronous multiples | |
| hclk = n x dmc_mclk where: n = integer value | dmc_async = dmc_msync = 1 dmc_a_gt_m_sync = 0 |
| m x hclk = dmc_mclk where: m = integer value | dmc_async = dmc_msync = 1 dmc_a_gt_m_sync = 1 |
| Asynchronous | |
| Extra registers are used to avoid metastability when crossing the asynchronous clock boundary. | dmc_async = dmc_msync = 0 dmc_a_gt_m_sync = 0 |

Static memory clocking options

Table 2-2 lists the static memory clocking options.

Table 2-2 Static memory clocking options

| Options | Tie-off values |
|-----------------------|-------------------------------|
| Fully synchronous | |
| hclk = smc_mclk0 | $smc_async0 = smc_msync0 = 1$ |
| | $smc_a_gt_m0_sync = 0$ |
| Synchronous multiples | |
| hclk = n x smc_mclk0 | smc_async0 = smc_msync0 = 1 |
| where: | $smc_a_gt_m0_sync = 0$ |
| n = integer value | |

Table 2-2 Static memory clocking options (continued)

| Options | Tie-off values |
|--|---|
| m x hclk = smc_mclk0 where: m = integer value | smc_async0 = smc_msync0 = 1 smc_a_gt_m0_sync = 1 |
| Asynchronous | |
| Extra registers are used to avoid metastability when crossing the asynchronous clock boundary. | smc_async0 = smc_msync0 = 0 smc_a_gt_m0_sync = 0 |

2.4.5 Low-power interface operation

The memory controller has three low-power interfaces. These interfaces indicate whether the clock for a specific domain can be switched off to reduce power consumption. It is expected that these interfaces are controlled by a system clock controller. One interface controls each of the following domains:

- AHB clock domain
- dynamic memory clock domain
- static memory clock domain.

Each domain uses a simple three signal interface to indicate whether the clocks are required. The signals consist of:

a request input

<domain> csyreq

an acknowledge output

<domain> csysack

an active output

<domain>_cactive

where:

<domain> is ahb, dmc or smc.

The following diagrams explain the protocol for the interface:

Figure 2-13 on page 2-22 shows a request to enter low-power mode.




Figure 2-13 Request to enter low-power mode

The memory controller receives a request to enter low-power mode, indicated by <domain>_csysreq being driven LOW by the system clock controller, as shown at T1. The memory controller then has the chance to perform any required operations to prepare for the clock to be switched off. The memory controller acknowledges the request by asserting <domain>_csysack LOW, as shown at T2. At this point the <domain>_cactive signal is used to indicate whether the request has been accepted or denied. If the request is accepted, <domain>_cactive is LOW, as Figure 2-13 shows. If the request is denied, <domain>_cactive is HIGH. If the request is accepted, then the clock to that domain can be switched off. The peripheral is brought out of Low-power state by restarting the clock and driving <domain>_csysreq HIGH, as shown at T4. The memory controller completes the handshake by driving <domain>_csysack HIGH, as shown at T5. Figure 2-14 shows the AHB domain denying a low-power request.




Figure 2-14 AHB domain denying a low-power request

When **ahb_csysack** is asserted LOW, the **ahb_cactive** signal is HIGH, as shown at T3, indicating the AHB domain is busy and the clock cannot be switched off. The handshake must be completed.

The AHB domain accepts or denies requests based on whether it is busy performing any transfers. Figure 2-15 on page 2-23 shows that dynamic and static memory controllers always accept requests after they have performed the required operations to prepare the external memory for the clock to be switched off.




Figure 2-15 Accepting requests

The low-power request **dmc_csysreq** is driven LOW, at time T1. When the memory controller is happy for the clock to be switched off, the **dmc_csysack** signal is driven LOW to acknowledge the request, as shown at T2. **dmc_cactive** is driven LOW, so the system clock controller knows the request has been accepted. When acknowledged, the system clock controller can disable both the **dmc_aclk** and **dmc_mclk** signals because the external memory is now in self refresh mode.

The three domains have separate interfaces to enable one or more domains to be switched off. The simple usage model is be to switch off all domains. In this usage each individual low-power interface protocol must be observed before all the clocks can be disabled.

Another option is to put either the static or dynamic memory controller into low-power mode individually. This saves power on the memory controller not being used, while enabling the other memory controller to still perform data accesses. For example, if the system calculated that it did not require any data from dynamic memory for some considerable time it can use the DMC low-power interface to put the external memory into self refresh mode and then turn off the dmc_aclk and dmc_mclk signals. The memory controller can still access the static memory. In this situation, any access to the dynamic memory can cause the entire memory controller to stall as it waits for a response from the DMC that has no clock. You must take care to ensure that this scenario never arises.

2.5 DMC functional operation

This section describes:

- Clocking and resets
- Miscellaneous signals on page 2-26
- *DMC slave interface* on page 2-27
- Arbiter operation on page 2-27
- Memory manager operation on page 2-31
- *APB slave interface operation* on page 2-32
- *Memory interface operation* on page 2-32
- Pad interface operation on page 2-37
- *Initialization* on page 2-38
- Power-down support and usage model on page 2-40.

2.5.1 Clocking and resets

This section describes:

- Clocking
- Resets on page 2-25.

Clocking

The DMC has the following functional clock inputs:

- dmc aclk
- dmc mclk
- dmc_mclkn
- dmc fbclk in.

These clocks can be grouped into two clock domains:

dmc_aclk domain dmc_aclk is in this domain. The **dmc_aclk** domain signals can only be stopped if the external memories are put in Self-refresh

mode.

dmc_mclk domain All clocks except dmc_aclk are in this domain. The dmc_mclk

signal must be clocked at the rate of the external memory clock. The **dmc_mclk** domain signals can only be stopped if the external

memories are put in Self-refresh mode.

You can tie off the DMC **dmc_async** and **dmc_msync** pins so that the two clock domains can operate synchronously or asynchronously with respect to each other:

Synchronous clocking

The benefit of synchronous clocking is that you can reduce the read and write latency by removing the synchronization registers between clock domains. However, because of the integer relationship of the clocks, you might not be able to get the maximum performance from the system because of constraints placed on the bus frequency by the external memory clock speed. In synchronous mode, the handshaking between the **dmc_aclk** and **dmc_mclk** domains enables synchronous operation of the two clocks at multiples of each other, that is ratios of n:1 and 1:m.

Asynchronous clocking

The main benefit of asynchronous clocking is that you can maximize the system performance, while running the memory interface at a fixed system frequency. Additionally, in sleep-mode situations when the system is not required to do much work, you can lower the frequency to reduce power consumption.

Output clocks

A clock output is provided for every external memory device. These are called **dmc_clk_out** [3:0]. These outputs are gated versions of the input **dmc_mclk**.

Resets

The DMC has two reset inputs:

hresetn This is the reset signal for the **dmc_aclk** domain.

dmc_mresetn

This is the reset signal for the **dmc_mclk** domain.

Both reset signals can be changed asynchronously to their respective clock domain. Internally to the DMC, the deassertion of the **hresetn** signal is synchronized to **dmc_aclk**, and the deassertion of the **dmc_mresetn** signal is synchronized to the **dmc_mclk** and **dmc_mclkn** clock signals.

2.5.2 Miscellaneous signals

You can use the following signals as general-purpose control signals for logic external to the DMC:

dmc_user_status[7:0]

General-purpose ports that are readable from the APB interface. If you do not require these ports, you must tie them either HIGH or LOW. These ports are connected directly to the APB interface block. Therefore, if they are driven from external logic that is not clocked by the **dmc_aclk** signal, then external synchronization registers are required.

dmc_user_config[7:0]

General-purpose ports that are driven directly from a write-only APB register. If you do not require these ports leave them unconnected.

You can use the following miscellaneous signals as tie-offs to change the operational behavior of the DMC:

dmc_cke_init

The **dmc_cke** output port to the external memory resets to this value.

dmc_dqm_init

The **dmc_dqm** output ports to the external memory reset to this value.

dmc_memory_width[1:0]

This configures the external memory width. See *dmc_memc_status Register bit assignments* on page 3-8 for the definition of these two pins.

dmc_msyncWhen HIGH, indicates dmc_mclk is synchronous to dmc_aclk.Otherwise they are asynchronous. Ensure that dmc_msync is tied to the same value as dmc_async.

dmc_async When HIGH, indicates dmc_aclk is synchronous to dmc_mclk.
Otherwise they are asynchronous. Ensure that dmc_async is tied to the same value as dmc_msync.

dmc_a_gt_m_sync

When HIGH, indicates **dmc_aclk** is synchronous to **dmc_mclk** and **dmc_aclk** is greater than **dmc_mclk**.

dmc_use_ebi

When HIGH, indicates that the DMC must operate with a PrimeCell EBI. See *ARM PrimeCell External Bus Interface (PL220) Technical Reference Manual*.

dmc_rst_bypass

Use this signal for ATPG testing only. It must be tied LOW for normal operation.

dmc dft en clk out

Use this signal for ATPG testing only. It must be tied LOW for normal operation.

2.5.3 DMC slave interface

The programmer's view is of a flat area of memory. The full range of AHB operations are supported.

The base addresses of the external memory devices are programmable using the dmc_chip_cfg Registers, see *DMC chip_<0-3>_cfg Registers at 0x0200* on page 3-22.

2.5.4 Arbiter operation

This section describes:

- Formatting from the DMC interface
- Formatting from the memory manager on page 2-29
- Arbiter access mux on page 2-29
- *QoS* on page 2-29
- *Hazard detection* on page 2-29
- *Scheduler* on page 2-30
- Arbitration algorithm on page 2-30
- *Command formatting* on page 2-31.

Formatting from the DMC interface

Formatting is as follows:

Chip select decoding

Using the programmed values in the dmc_chip_<0-3>_cfg Registers defined in Chapter 3 *Programmer's Model*, an incoming address has the most significant eight address bits compared with the address match bits. The later method uses the address mask to ignore any don't care bits to select an external chip.

The transfer is still carried out if there is no match but the result is undefined.

Row select decoding

The row address is determined from the address using bits [5:3] of the dmc_memory_cfg Register, and also the brc_n_rbc bit for the selected chip defined in the dmc_chip_<0-3>_cfg Register.

Column select decoding

The column address is determined from the address using bits [2:0] of the dmc_memory_cfg Register.

Bank select decoding

The chip bank is determined using the brc_n_rbc bit for the selected chip defined in the dmc_chip_<0-3>_cfg Register.

Number of beats

The number of memory beats is determined, depending on the effective external memory width and the burst size of the access. Wrapping bursts are split into two incrementing bursts.

Quality of Service (QoS) selection

QoS is defined for the DMC as a method of increasing the arbitration priority of a read access that requires low-latency read data. The QoS for a read access is determined when it is received by the arbiter. There is no quality of service for write accesses.

There are two forms of quality of service tracking:

- qos_max time-out
- qos_min time-out.

Example 2-1 shows that the type of QoS and QoS value is determined by the dmc_id_<0-3>_cfg Register.

Example 2-1

If a transfer is received from port 1, the dmc_id_1_cfg Register determines the qos_enable, qos_min, and qos_max values for this transfer. If the qos_enable bit is HIGH then the new arbiter entry that is created for this transfer is assigned the qos_min value and qos_max value from the dmc_id_1_cfg Register. In addition to this, if the qos_override bit associated with this port, dmc_qos_override[1], is HIGH when the transfer is accepted then the qos_min arbiter entry is forced HIGH irrespective of whether the qos_enable bit is HIGH.

See also *DMC id_<0-3>_cfg Registers at 0x0100* on page 3-21.

Formatting from the memory manager

The direct command bits [21:20] determines the memory chip to access.

The command to be carried out is either an auto refresh, or from the APB interface. The memory manager encodes it to match the format required by the arbiter.

Arbiter access mux

The selection of a command from the DMC interface or the memory manager is fixed, with the memory manager having a higher priority.

The selection between a DMC read access and a write access is made using a round-robin arbitration, unless a read access has a low latency QoS value. In this case it is arbitrated immediately.

QoS

For write accesses, no quality of service is provided.

If the QoS enable bit for the port is set in the register bank, the QoS maximum latency value is decremented every cycle until it reaches zero.

If the entry is still in the queue when the QoS maximum latency value reaches zero then the entry becomes high priority. This is called a *time-out*. Also, any entry in the queue with a minimum latency QoS also produces a time-out. Minimum latency time-outs have priority over maximum latency time-outs.

A QoS is also provided for the auto-refresh commands from the memory manager. The arbiter keeps track of the number of auto-refresh commands in the arbiter queue with a simple increment-decrement counter. If the number of auto-refresh commands reaches a set limit of six, a refresh time-out is signalled to the arbiter queue. This forces all of the auto-refresh queue entries to have a time-out. This time-out is sticky, and does not disappear when the number of time-outs drops back below the threshold. Instead it remains asserted until all of the auto-refreshes have been serviced. This provides a guaranteed refresh rate in the SDRAM.

Hazard detection

There are two types of hazard:

Read After Read (RAR)

There is a read already in the arbiter queue with the same ID as the incoming entry, and that is also a read.

Write After Write (WAW)

There is a write already in the arbiter queue with the same ID as the incoming entry, and that is also a write.

The arbiter entry is flagged as having a dependency if a hazard is detected. There might be dependencies against a number of other arbiter entries. As the arbiter entries are invalidated, so the dependencies are reduced until finally there are no outstanding dependencies and the entry is free to start.

| Note | - |
|-------------------------|--------------------------|
| There are no RAW or WAR | hazard checks in the DMC |

Scheduler

The scheduler keeps track of the activity of the bank of FSMs in the memory interface. This enables the arbiter to select an entry from the queue that does not stall the memory pipeline.

Arbitration algorithm

This is combinatorial logic that selects the read pointer from the current queue state.

The ordering of commands to be carried out from the arbiter queue is arbitrated with a priority scheme of the following order:

- 1. read min-latency timeout
- 2. read max-latency timeout.

If the last command was an open-row access:

 next access to a bank, for which there are no pending open-row accesses, that is an open-row miss.

If the last open-row access was a read:

- 1. open-row read
- 2. open-row write.

Else:

- 1. open-row write
- 2. open-row read
- 3. open-row miss.

Command formatting

For every memory burst access necessary to complete an arbiter queue entry, a memory interface command is required.

Command formatting calculates the number of memory interface commands and memory cycles for each command to complete the next arbiter queue entry that is to be sent to the memory interface. It contains an address incrementor and a beat decrementor so that the arbiter entry can be interrupted and restarted.

2.5.5 Memory manager operation

The major functions of the memory manager are described in:

- DMC tracking and control
- Issuing commands to memory
- Programmable options on page 2-32.

DMC tracking and control

The memory manager tracks and controls the state of operation of the DMC. This is controlled by the **dmc_aclk** domain FSM and it can be traversed by writing to the dmc_memc_cmd Register. The state of this FSM can only be traversed when the DMC is idle. For example, the ready state can only be entered from the Config state when all direct commands are completed.

Issuing commands to memory

The commands that the memory manager issues to memory are:

Direct commands

These are received over the APB interface as a result of a write to the dmc_direct_cmd Register. See *DMC Direct Command Register at 0x0008* on page 3-10. They initialize the SDRAM. The only valid commands that the memory manager can handle are:

- NOP
- PRECHARGEALL
- AUTOREFRESH
- MODEREG
- EXTENDED MODEREG.

Refresh commands

The refresh FSM can issue commands to the arbiter to refresh the SDRAM chips. The refresh counter is clocked by the memory clock to enable the frequency of the DMC to be scaled without affecting the

refresh rate. You can program the refresh rate period using the dmc_refresh_prd Register. The value of this register is the count value in **dmc_mclk** cycles.

When the refresh counter wraps around zero, an individual auto-refresh sequence is requested for each external chip in turn.

Programmable options

Auto Refresh Request Period, also known as RefreshPrd, is the time period in **dmc_mclk** clock cycles during which the memory manager generates a request for the arbiter to generate an auto-refresh command. This request is arbitrated as another command and is not necessarily initiated immediately. See *Arbiter operation* on page 2-27.

2.5.6 APB slave interface operation

The APB interface is clocked by the same clock as the AHB domain clock, **dmc_aclk**.

To enable a clean registered interface to the external infrastructure, the APB interface always adds a wait state for all reads and writes by driving **pready** LOW. In the following instances a delay of more than one wait state can be generated:

- when a direct command is received and there are outstanding commands that prevent a new command being stored in the command FIFO
- when a memory command is received and a previous memory command has not been completed.

The only registers that can be accessed when the DMC is not in the Config or Low-power state are the Memory Controller Status Register, to read the current state, and the Memory Controller Command Register to change state.

To guarantee no missed auto-refresh commands it is recommended that any change of **dmc_mclk** period, and therefore update of the refresh period, is carried out when the DMC is in the Low-power state. This is because the refresh rate is depends on the **dmc_mclk** period. It is recommended that direct commands to the external memories are only written when the DMC is in the Config state and not in the Low-power state.

2.5.7 Memory interface operation

The interface is separated from the arbiter using three configurable synchronous or asynchronous FIFOs:

- command FIFO
- read data FIFO
- write data FIFO.

There is also a static interface that has configuration signals that cannot be changed when the interface is operating.

The memory interface reads commands from the arbiter using a FIFO but only when that command can be executed. The memory interface ensures a command is only executed when all the inter-command delays, defined in this section, for that bank or chip are met. The memory interface enables multiple banks to be active at any one time. However, only one bank can be carrying out a data transfer at any one time. If the command at the head of the FIFO cannot be executed, then the command pipeline stalls until it can be executed.

You can program all the timing parameters in Figure 2-16 on page 2-34 to Figure 2-27 on page 2-37 using the APB interface. See Chapter 3 *Programmer's Model*.

When the auto_power_down Register bit is set then the **dmc_cke** output pin is negated to take the external memories into active or precharge power down depending on whether there is a row open. See Figure 2-24 on page 2-36. When exiting power down mode, the delay before the next command is issued is defined by the register value t_{XP}.

There is an FSM to control the operation of the power-down mode. This FSM has a state that is entered when the SDRAM is put into Self-refresh mode. This is used so that if power is removed from all of the DMC apart from the memory interface and pad interface the state of the memory is known. When the rest of the DMC is powered-up the status FSM enters the Low-power state rather than the Config state.

Memory interface to pad interface timing

All command control outputs are clocked on the same edge. In Figure 2-16 on page 2-34 to Figure 2-27 on page 2-37 the control outputs to the external memory are always clocked on the falling edge of the memory clock.

The relative times between control signals from the memory interface are maintained when output from the pad interface to the actual SDRAM devices. Therefore, the timing register values required for a particular SDRAM device can be determined from the data sheet of the SDRAM device. Figure 2-16 on page 2-34 to Figure 2-27 on page 2-37 show how the data sheet timings map onto the DMC timing registers.

The times in Figure 2-16 on page 2-34 to Figure 2-27 on page 2-37 are not necessarily the default timing values but are values that are small enough to show the entire delay in one figure.

| Note | <u></u> | | |
|-----------------------|--------------------|----------------------|------------------|
| The command_en, data_ | cntl_en, and read_ | _en signals are inte | rnal to the DMC. |

Figure 2-16 shows the command control output timing.




Figure 2-16 Command control output timing

Figure 2-17 shows the activate to read or write command timing.




Figure 2-17 Activate to read or write command timing, $t_{\mbox{\scriptsize RCD}}$

Figure 2-18 shows the bank activate to bank activate or auto-refresh command timing.




Figure 2-18 Bank activate to bank activate or auto-refresh command timing, t_{RC}

Figure 2-19 shows the bank activate to different bank activate for a memory timing.




Figure 2-19 Bank activate to different bank activate for a memory timing, t_{RRD}

Figure 2-20 shows the precharge to command and auto-refresh timing.




Figure 2-20 Precharge to command and auto-refresh timing, t_{RP} and t_{RFC}

Figure 2-21 shows activate to precharge, and precharge to precharge timing.




Figure 2-21 Activate to precharge, and precharge to precharge timing, t_{RAS} and t_{RP}

Figure 2-22 shows mode register write to command timing.




Figure 2-22 Mode register write to command timing, t_{MRD}

Figure 2-23 shows self-refresh entry and exit timing.




Figure 2-23 Self-refresh entry and exit timing, t_{ESR} and t_{XSR}

Figure 2-24 shows power-down entry and exit timing.




Figure 2-24 Power-down entry and exit timing, t_{XP}

The **pwr_down_prd** count is timed from the memory interface becoming idle, that is after a command delay has timed out or the read data FIFO is emptied. **dmc_cke** is asserted when the command FIFO is not empty.

Figure 2-25 shows the turnaround time, t_{WTR} , for the memory interface to output a Write command followed immediately by a Read command.




Figure 2-25 Data output timing, twTR

Figure 2-26 shows the relationship between memory interface outputting the Write command and the WDATA when t_{DQSS} is set to 1. It also highlights the t_{WR} minimum time between a Write and a Precharge command.




Figure 2-26 Data output timing, t_{DQSS} = 1

Figure 2-27 shows the timing relationship between the Read command being output from the memory interface and the RDATA being returned to the memory interface from the pad interface.




Figure 2-27 Data input timing

2.5.8 Pad interface operation

You can replace or modify the pad interface if required for additional optimization for a particular memory type or target library or to use a hard macro.

It is important if the pad interface is modified or replaced that the relative timings of the control output signals enabled by **command_en** and **data_cntl_en** signals are maintained to ensure the timings carried out in the memory interface block are still

correct at the external memory bus interface. The **read_en** signal is always asserted one **dmc_mclk** period before the expected read data. Therefore, the timing of **read_en** changes as CAS latency is changed using the APB interface.

When read commands are being executed, the data is clock-enabled into a FIFO clocked by **dmc_mclk** a set time from the command being clocked out. See Figure 2-27 on page 2-37. This delay is dependent on the current **cas_latency** value programmed and the delays in the pad interface.

2.5.9 Initialization

Before you can use the DMC operationally to access external memory, you must:

- set up the DMC configuration registers
- initialize the external memory devices.

You might not have to configure all the DMC registers because some might power-up to the correct value, see Chapter 3 Programmer's Model. For completeness, all register values are included in Table 2-3.

| ——Note ——— | |
|--|------------------------------|
| You might create a deadlock situation if the DMC interface | e is accessed before the DMC |
| is configured to use the APB port. | |

Example setup

Table 2-3 shows an example SDR setup.

Table 2-3 Example SDR setup

| Register address | Write data | Description |
|------------------|------------|--|
| 0x0014 | 0x00000006 | Set cas_latency to 3 |
| 0x0018 | 0x00000000 | Set t_dqss to 0 |
| 0x001C | 0x00000002 | Set t_mrd to 2 |
| 0x0020 | 0x00000007 | Set t_ras to 7 |
| 0x0024 | 0x0000000B | Set t_rc to 11 |
| 0x0028 | 0x00000015 | Set t_rcd to 5 and schedule_rcd to 2 |
| 0x002C | 0x000001F2 | Set t_rfc to 18 and schedule_rfc to 15 |

Table 2-3 Example SDR setup (continued)

| Register address | Write data | Description |
|------------------|------------|--|
| 0x0030 | 0x00000015 | Set t_rp to 5 and schedule_rp to 2 |
| 0x0034 | 0x00000002 | Set t_rrd to 2 |
| 0x0038 | 0x00000003 | Set t_wr to 3 |
| 0x003C | 0x00000002 | Set t_wtr to 2 |
| 0x0040 | 0x00000001 | Set t_xp to 1 |
| 0x0044 | 0x0000000A | Set t_xsr to 10 |
| 0x0048 | 0x00000014 | Set t_esr to 20 |
| 0x000C | 0x00610020 | Set memory configuration ^a |
| 0x0010 | 0x00000A60 | Set auto refresh period to be every 2656 dmc_mclk periods |
| 0x0200 | 0x000000FF | Set chip select for chip 0 to be 0x00XXXXXX, rbc configuration |
| 0x0204 | 0x000040FF | Set chip select for chip 1 to be 0x40XXXXXX, rbc configuration |
| 0x0208 | 0x000080FF | Set chip select for chip 2 to be 0x80XXXXXX, rbc configuration |
| 0x020C | 0x0000C0FF | Set chip select for chip 3 to be 0xC0XXXXXX, rbc configuration |
| 0x0008 | 0x000C0000 | Carry out chip0 Nop command |
| 0x0008 | 0x00000000 | Carry out chip0 Prechargeall command |
| 0x0008 | 0x00040000 | Carry out chip0 Autorefresh command |
| 0x0008 | 0x00040000 | Carry out chip0 Autorefresh command |
| 0x0008 | 0x00080032 | Carry out chip0 Mode Reg command 0x32 mapped to low add bits |
| 0x0008 | 0x001C0000 | Carry out chip1 Nop command |
| 0x0008 | 0x00100000 | Carry out chip1 Prechargeall command |
| 0x0008 | 0x00140000 | Carry out chip1 Autorefresh command |
| 0x0008 | 0x00140000 | Carry out chip1 Autorefresh command |
| 0x0008 | 0x00180032 | Carry out chip1 Mode Reg command 0x32 mapped to low add bits |
| 0x0008 | 0x002C0000 | Carry out chip2 Nop command |

Table 2-3 Example SDR setup (continued)

| Register address | Write data | Description |
|------------------|------------|--|
| 0x0008 | 0x00200000 | Carry out chip2 Prechargeall command |
| 0x0008 | 0x00240000 | Carry out chip2 Autorefresh command |
| 0x0008 | 0x00240000 | Carry out chip2 Autorefresh command |
| 0x0008 | 0x00280032 | Carry out chip2 Mode Reg command 0x32 mapped to low add bits |
| 0x0008 | 0x003C0000 | Carry out chip3 Nop command |
| 0x0008 | 0x00300000 | Carry out chip3 Prechargeall command |
| 0x0008 | 0x00340000 | Carry out chip3 Autorefresh command |
| 0x0008 | 0x00340000 | Carry out chip3 Autorefresh command |
| 0x0008 | 0x00380032 | Carry out chip3 Mode Reg command 0x32 mapped to low add bits |
| 0x0004 | 0x00000000 | Change DMC state to Ready |

- a. The memory is configured as follows:
- 8 column bits, 11 row bits
- precharge all bit is shared with A10
- power-down period of 0
- auto power down is disabled
- dynamic clock stopping is disabled
- memory burst size of 4.

2.5.10 Power-down support and usage model

The DMC provides architectural support for low-power operation in three ways:

- By using the dmc_memory_cfg Register at address offset 0x000C. The DMC can automatically place the SDRAM into either the precharge power-down or active power-down states by deasserting **dmc_cke** when the SDRAM has been inactive for a number of clock cycles. This occurs with the DMC in its Ready state.
- By using the dmc_memc_cmd and dmc_memc_status Registers at address offsets 0x0004 and 0x0000. The DMC can place the SDRAM into the Self-refresh state under software control.
- By using the DMC low-power interface, the DMC can place the SDRAM into the Self-refresh state under hardware control.

Additionally, the DMC microarchitecture provides more power savings through extensive use of clock gating. This includes clock gating of the external memory clocks by selecting the stop_mem_clock bit in the dmc_memory_cfg Register.

It is possible to implement the DMC with two power domains:

- dmc_aclk
- dmc_mclk.

See Figure 2-2 on page 2-4.

Table 2-4 shows the valid system states of the **dmc_aclk** domain FSM and the **dmc_mclk** domain FSM. It also shows the valid power, clock, and reset states in the **dmc_aclk** and **dmc_mclk** domains. Figure 2-28 on page 2-43 shows the valid transitions, and the text following it explains how to traverse the system states.

Table 2-4 Valid system states for FSMs

| SDR | АМ | DMC | | | | | | | | System state |
|----------|--------------|----------|---------|-------|---------------|----------|----------|-------|------------------|--------------|
| | | aclk | FSM | | | mclk | mclk FSM | | | |
| V_{DD} | State | V_{DD} | Clock | Reset | State | V_{DD} | Clock | Reset | State | |
| 0 | Null | 0 | N/a | N/a | Null | 0 | N/a | N/a | Null | 1 |
| 0 | Null | >0 | Running | No | POR | >0 | Running | No | POR | 2 |
| 0 | Null | >0 | Running | Yes | Reset | >0 | Running | Yes | Reset | 3 |
| 0 | Null | >0 | Running | No | Config | >0 | Running | No | Powered_ up | 4 |
| >0 | Accessible | >0 | Running | No | Config | >0 | Running | No | Powered_ up | 5 |
| >0 | Accessible | >0 | Running | No | Ready | >0 | Running | No | Powered_up | 6 |
| >0 | Powered-down | >0 | Running | No | Ready | >0 | Running | No | Powered_ down | 7 |
| >0 | Self_refresh | >0 | Running | No | Low_ power | >0 | Running | No | Self_refresh | 8 |
| >0 | Self_refresh | >0 | Running | No | Low_ power | >0 | Stopped | No | Self_refresh | 9 |
| >0 | Self_refresh | >0 | Stopped | No | Low_ power | >0 | Running | No | Self_refresh | 10 |

Table 2-4 Valid system states for FSMs (continued)

| SDR | AM | DMC | | | | | | | | System state |
|----------|--------------|----------|----------|-------|---------------|----------|----------|-------|--------------|--------------|
| | | aclk | aclk FSM | | | mclk | mclk FSM | | | |
| V_{DD} | State | V_{DD} | Clock | Reset | State | V_{DD} | Clock | Reset | State | |
| >0 | Self_refresh | >0 | Stopped | No | Low_ power | >0 | Stopped | No | Self_refresh | 11 |
| >0 | Self_refresh | 0 | N/a | N/a | Null | >0 | Stopped | No | Self_refresh | 12 |
| >0 | Self_refresh | 0 | N/a | N/a | Null | >0 | Running | No | Self_refresh | 13 |
| >0 | Self_refresh | >0 | Running | No | POR | >0 | Stopped | No | Self_refresh | 14 |
| >0 | Self_refresh | >0 | Running | No | POR | >0 | Running | No | Self_refresh | 15 |
| >0 | Self_refresh | >0 | Running | Yes | Reset | >0 | Stopped | No | Self_refresh | 16 |
| >0 | Self_refresh | >0 | Running | Yes | Reset | >0 | Running | No | Self_refresh | 17 |

The ranking of system power states, from highest power to lowest power is as follows: 6, 7, 8, 10, 9, 11, 13, 12.

However, states 8-11 are similar and the recommendation is to use state 11 from this group if clock-stopping techniques are available. Similarly, states 12 and 13 are similar and the recommendation is to use state 12 from this pair. Table 2-5 lists a recommended set of power states.

Table 2-5 Recommended power states

| System state | Power name |
|--------------|----------------------|
| 6 | Running |
| 7 | Auto power-down |
| 11 | Shallow self-refresh |
| 12 | Deep self-refresh |

These states and arcs are highlighted in Figure 2-28 on page 2-43.

_____ Note _____

Arcs are lines between states.

States 1-5, 9, 14, and 16 are only used as transitional states.




Figure 2-28 DMC system state transitions

State transitions are as follows:

- Arc 1 to 2 Apply power to all DMC power domains, and ensure that dmc_aclk and dmc_mclk are running.
- Arc 2 to 3 Assert reset in both the dmc_aclk reset domain and the dmc_mclk reset domain.
- Arc 3 to 4 Deassert reset in both the dmc_aclk reset domain and the dmc_mclk reset domain.
- **Arc 4 to 5** Apply power to the SDRAM power domain.
- Arc 5 to 6 You must:
 - 1. Write to all of the memory timing parameters, address offsets 0x0014 to 0x0044.

- Write to the dmc_memory_cfg and dmc_refresh_prd Registers, address offsets 0x000C and 0x0010.
- 3. Initialize the memory, using the dmc_direct_cmd Register, offset 0x0008, with the sequence of commands specified by the memory vendor. When you have sent these commands to the memory, you can write to the dmc_memc_cmd Register, offset 0x0004 with the GO command. 0x0.
- 4. Poll the dmc_memc_status Register until the value of 0x1 is returned, Ready, signifying that the DMC is ready to accept accesses to the SDRAM.
- Arc 6 to 5 If you want to reconfigure either the DMC or SDRAM, you must first write to the dmc_memc_cmd Register, offset 0x0004, with the Pause command, 0x3, and poll the dmc_memc_status Register until the value of 0x2 is returned, Paused. Then you can write to the dmc_memc_cmd Register with the Configure command, 0x4 and poll the dmc_memc_status Register until the value of 0x0000 is returned, Config.
- Arc 6 to 7 If auto_power_down is set in the dmc_memory_cfg Register, see *DMC Memory Configuration Register at 0x000C* on page 3-11, then this arc is automatically taken when the SDRAM has been idle for power_down_prd multiplied by dmc_mclk cycles, for example, 10 x dmc_mclk cycles.
- Arc 7 to 6 When an SDRAM access command has been received in the dmc_mclk domain, this arc is taken.
- **Arc 6 to 8** You can take this arc under either hardware or software control:
 - To take this arc under software control:
 - 1. Issue the Pause command.
 - 2. Poll for the Paused state.
 - 3. Issue the Sleep command.
 - To take this arc under hardware control, use the DMC low-power interface to request a Low-power state.
- **Arc 6 to 9** The same as arc 6 to 8, but additionally stop the **mclk** domain clock.
- **Arc 6 to 10** The same as arc 6 to 8, but additionally stop the **dmc_aclk** domain clock.
- Arc 6 to 11 The same as arc 6 to 8, but additionally stop both the dmc_mclk and the dmc_aclk domain clocks.

- Arc 6 to 12 The same as arc 6 to 8, but additionally stop the dmc_mclk domain clock and remove power from the dmc_aclk power domain. You can only do this if the DMC implementation has separate power domains for dmc_aclk and dmc_mclk.
- Arc 6 to 13 The same as arc 6 to 8, but additionally remove power from the dmc_aclk power domain. You can only do this if the DMC implementation has separate power domains for dmc_aclk and dmc_mclk.
- **Arc 8 to 6** You can take this arc under either hardware or software control:
 - To take this arc under software control:
 - 1. Issue the Wakeup command to the memc_cmd Register.
 - 2. Poll the dmc_memc_status Register for the Paused state.
 - 3. Issue the Go command and poll for the Ready state.
 - To take this arc under hardware control, use the DMC low-power interface to bring the DMC out of a Low-power state.
- **Arc 9 to 6** The same as arc 8 to 6, but you must first start the **dmc_mclk** domain clock.
- **Arc 10 to 6** The same as arc 8 to 6, but you must first start the **dmc_aclk** domain clock.
- Arc 11 to 6 The same as arc 8 to 6, but you must first start both the dmc_aclk and dmc mclk domain clocks.
- **Arc 12 to 14** Apply power to the **dmc_aclk** power domain.
- Arc 14 to 16 Assert reset to the dmc aclk reset domain.
- Arc 16 to 9 Deassert reset to the dmc aclk reset domain.
- **Arc 13 to 15** Apply power to the **dmc_aclk** power domain.
- **Arc 15 to 17** Assert reset to the **dmc_aclk** reset domain.
- **Arc 17 to 8** Deassert reset to the **dmc aclk** reset domain.

2.6 SMC functional operation

This section describes:

- Operating states
- *Clocking and resets* on page 2-47
- *Miscellaneous signals* on page 2-49
- APB slave interface operation on page 2-50
- Format block on page 2-50
- *Memory manager operation* on page 2-57
- *Interrupts operation* on page 2-60
- Memory interface operation on page 2-60.

2.6.1 Operating states

The operation of the SMC is based on three operating states. In this section, each state is described. Figure 2-29 shows the state machine.




Figure 2-29 smc_aclk domain FSM diagram

The SMC states are as follows:

Reset Power is applied to the device, and **hresetn** is held LOW.

Ready Normal operation of the device. You can access the SMC register bank

through the AHB configuration port and external memory devices

accessed through the SMC interface.

Low-power The device does not accept new AHB transfers, and you can only access

certain registers through the APB interface. You can stop the SMC clocks

to reduce power consumption.

The state transitions are:

Ready to Reset

When reset is asserted to the **smc_aclk** domain, it enters the Reset state.

Reset to Ready

When reset is deasserted to the **smc_aclk** domain, it enters the Ready state.

Ready to Low-power

The Low-power state is entered when the SMC next becomes idle after either:

- the SMC receives a low-power request through the APB smc_memc_cfg_set Register
- the SMC receives a low-power request through the SMC low-power interface.

Low-power to Ready

The SMC exits the Low-power state back to Ready when either:

- the SMC low-power request bit is cleared in the APB smc_memc_cfg_clr Register
- the SMC low-power interface negates the low-power request.

Low-power to Reset

When Reset is asserted to the **smc_aclk** reset domain, it enters the Reset state.

2.6.2 Clocking and resets

This section describes:

- Clocking
- Resets on page 2-48.

Clocking

All configurations of the SMC support at least two clock domains, and have the following clock inputs:

- smc aclk
- smc mclk0
- smc mclk0n

These clocks can be grouped into two clock domains:

AHB domain

smc_aclk is in this domain. You can only stop the **smc_aclk** domain signals when the SMC is in low-power mode.

Memory clock domain

The smc_mclk0 and smc_mclk0n are in this domain. smc_mclk0n is an inverted version of smc_mclk0. smc_mclk0 is used for timing and control signals.

You can tie off the **smc_async0** and **smc_msync0** pins so that the **smc_aclk** and **smc_mclk0** clock domains can operate synchronously or asynchronously with respect to each other.

Synchronous clocking

The benefit of synchronous clocking is that you can reduce the read and write latency by removing the synchronization registers between clock domains. However, because of the integer relationship of the clocks, you might not be able to get the maximum performance from the system because of constraints placed on the bus frequency by the external memory clock speed. In synchronous mode, the handshaking between the **smc_aclk** and **smc_mclk0** domains enables synchronous operation of the two clocks at multiples of each other, that is, ratios of n:1 and 1:m.

Asynchronous clocking

The main benefit of asynchronous clocking is that you can maximize the system performance, while running the memory interface at a fixed system frequency. Additionally, in sleep-mode situations when the system is not required to do much work, you can lower the frequency to reduce power consumption.

Resets

The SMC has two reset inputs:

hresetn This is the reset signal for the **smc aclk** domain.

smc mreset0n

This is the reset signal for the **smc_mclk0** domain.

You can change both reset signals asynchronously to their respective clock domain. Internally to the SMC the deassertion of the **hresetn** signal is synchronized to **smc_aclk**. The deassertion of **smc_mreset0n** is synchronized internally to smc_mclk0 and **smc_mclk0n**.

2.6.3 Miscellaneous signals

You can use the following signals as general-purpose control signals for logic external to the SMC:

smc_user_config[7:0]

General purpose output ports that are driven directly from the write-only APB register. If you do not require these ports leave them unconnected. See also the *SMC User Configuration Register* at 0x1204 on page 3-41.

smc_user_status[7:0]

General purpose input ports that are readable from the APB interface through the smc_user_status Register. If you do not require these ports then tie them either HIGH or LOW. These ports are connected directly to the APB interface block. Therefore, if they are driven from external logic that is not clocked by the SMC smc_aclk signal, then you require external synchronization registers. See also the SMC User Status Register at 0x1200 on page 3-40.

You can use the following miscellaneous signals as tie-offs to change the operational behavior of the SMC:

smc_a_gt_m0_sync

When HIGH, indicates that **smc_aclk** is greater than and synchronous to **smc_mclk0**.

smc_async0 When HIGH, indicates smc_aclk is synchronous to smc_mclk0.
Otherwise they are asynchronous. Ensure that smc_async0 is tied to the same value as smc_msync0.

smc_dft_en_clk_out

Use this signal for *Automatic Test Pattern Generator* (ATPG) testing only. Tie it LOW for normal operation.

smc_msync0

When HIGH, indicates **smc_mclk0** is synchronous to **smc_aclk**. Otherwise they are asynchronous. Ensure that **smc_msync0** is tied to the same value as **smc_async0**.

smc_rst_bypass

Use this signal for ATPG testing only. Tie it LOW for normal operation.

smc use ebi

When HIGH, indicates that the SMC must operate with a PrimeCell EBI. See the *ARM PrimeCell External Bus Interface (PL220) Technical Reference Manual*.

2.6.4 APB slave interface operation

To enable a clean registered interface to the external infrastructure, the APB interface always adds a wait state for all reads and writes by driving **pready** LOW during the first cycle of the access phase.

In two instances, a delay of more than one wait state can be generated:

- when a direct command is received and there are outstanding commands that prevent a new command being stored in the command FIFO
- when an APB access is received and a previous direct command has not completed.

2.6.5 Format block

This section describes:

- Hazard handling
- NAND memory accesses.

Hazard handling

There are four types of hazard:

- Read After Read (RAR)
- Write After Write (WAW)
- Read After Write (RAW)
- Write After Read (WAR).

The AHB interface deals with RAW hazards. WAR hazards do not occur in the AHB.

The SMC ensures the ordering of read transfers from a single port is maintained, RAR, and additionally that the ordering of write transfers from a single master is maintained, WAW.

NAND memory accesses

This section describes:

- Two phase NAND access on page 2-51
- Booting from NAND flash on page 2-57.

Two phase NAND access

The SMC defines two phases of commands when transferring data to/from NAND flash.

Command phase

Commands and optional address information are written to the NAND flash. The command and address can be associated with either a data phase operation to write to or read from the array, or a status/ID register transfer.

Data phase Data is either written to or read from the NAND flash. This data can be either data transferred to or from the array, or status/ID register information.

The SMC uses information contained in the AHB address bus haddr[31:0] signals to determine whether the AHB transfer is a command or data phase access.

This information contained in the address bus additionally determines:

- the value of the command
- the number of address cycles
- the chip select to be accessed.

During a command phase transfer, the address to be written to the NAND memory is transferred to the SMC using hwdata.

Table 2-6 describes the fields of the haddr[31:0] signal used to control a NAND flash transfer.

Table 2-6 NAND AHB address setup

| AHB address | Command phase | Data phase |
|-------------|-------------------|-------------------|
| [31:24] | Chip Address | Chip Address |
| [23] | NoOfAddCycles_2 | Reserved |
| [22] | NoOfAddCycles_1 | Reserved |
| [21] | NoOfAddCycles_0 | Clear CS |
| [20] | End command valid | End command valid |
| [19] | 0 | 1 |
| [18:11] | End command | End command |
| [10:3] | Start command | Reserved |
| [2:0] | Reserved | Reserved |

NAND command phase transfers

A command phase transfer is always performed as an AHB write. The following information is contained in the AHB **haddr[31:0]** bus, and listed in Table 2-6 on page 2-51:

Address cycles

The number of address cycles can be any value from zero to seven. Generally, up to five cycles are used during an array read or write, but a maximum of seven enables support for future devices.

Start command

The NAND command is used to initiate the required operation, for example:

- a page read
- page program
- random page read
- status or ID register read.

End command

The value of the second command, if required. This command is executed when all address cycles have completed. For example, some NAND memories require an additional command, following the address cycles, for a page read.

End command valid

Indicates whether the end command must be issued to the NAND flash.

Each address cycle consumes eight bits of address information. This is transferred to the SMC through the AHB write data.



To ease system integration, the SMC supports the use of multiple AHB write transactions to transfer address information. The following restrictions apply in this case:

- All other address information must be the same.
- Data must be transferred in incrementing, consecutive accesses, that is, not wrapping.

NAND data phase transfers

Transfers data to/from the NAND flash, and can be performed as either an AHB read or write, depending on the required operation. The following information is contained in the **haddr[31:0]** bus, and shown in Table 2-6 on page 2-51:

End command

The value of a command that is issued following the data transfer. This is required by some memories to indicate a page program following input of write data.

End command valid

Indicates whether the end command must be issued to NAND flash.

Clear CS

When set, the chip select for a NAND flash is de-asserted on completion of this command. When not set, the chip select remains asserted.

A NAND flash data phase program or read operation is expected to require multiple AHB transfers because of the large page size of NAND memories. You can therefore use the ClearCS bit to hold a chip select asserted while multiple AHB transfers transfer data to or from the NAND flash internal page. On the last AHB transfer, you can de-assert the chip select by setting the ClearCS bit.

Figure 2-30 on page 2-54 and Figure 2-31 on page 2-55 show the steps taken to perform NAND flash page read and page program operations respectively.




Figure 2-30 NAND flash page read operations




Figure 2-31 NAND flash page program operations

_____Note _____

You can poll for either a page program or page read completion in two ways:

Poll the raw_int_status0 bit in the smc_memc_status Register to
determine when the memory smc_busy_0 input has gone HIGH,
indicating a page program completion or read data ready.

 In a system with multiple NAND flash devices connected to the SMC, the busy outputs are wire-ANDed to produce the single busy input to the SMC, that only transitions HIGH when all devices have completed. The status of each NAND chip can be determined by reading the individual device status register.

Figure 2-32 shows the steps taken to perform a NAND flash status register read.




Figure 2-32 NAND flash status register read


The process boxes shown in Figure 2-32 are defined as:

Command phase write

Data phase read

Ensure burst length is 1, the transfer is a single, the transfer size is eight or sixteen, **hsize**=0x0 or 0x1

hrdata = NAND flash status output



Certain NAND flash devices can support multiple status register reads without reissuing the STATUS_READ_CMD. In this case the flow described in *NAND flash status register read* on page 2-56 can be modified to include multiple data phase transfers for each command phase transfer.

The chip select being accessed is determined by the upper byte of the address bus, haddr[31:24]. The base address of external memory devices are defined by the smc_address_match0_<0-1>[7:0] and smc_address_mask0_<0-1>[7:0] tie-off pins. You can read the values of these tie-off pins through the opmode registers.

Booting from NAND flash

Because the format of AHB commands used to access NAND flash through the SMC, additional external logic is required to enable a processor to boot from this memory type. This additional logic enables boot code to be executed in-place from the first block within the NAND flash.

2.6.6 Memory manager operation

The memory manager module is responsible for controlling the state of the SMC and the updating of chip configuration registers.

This subsection describes:

- Low-power operation on page 2-58
- Chip configuration registers on page 2-58
- *Direct commands* on page 2-59.

Low-power operation

The SMC accepts requests to enter the Low-power state through either the SMC low-power interface or the APB register interface.

The SMC does not enter the power-down state until it has received an idle indication from all areas of the peripheral, that is:

- there is no valid transfer held in the Format block
- there are no valid transfers held in the SMC interface
- all FIFOs are empty
- all memory interface blocks are IDLE.

When the Low-power state is entered, no new memory transfers are accepted until the SMC has been moved out of Low-power state. The SMC does not request to move out of Low-power state, and never refuses a power-down request.

Chip configuration registers

The SMC provides a mechanism for synchronizing the switching of operating modes of the SMC with that of the memory device.

The smc_set_cycles Register and smc_set_opmode Register act as holding registers for new operating parameters until the SMC detects the memory device has switched modes.

Figure 2-33 on page 2-59 shows the memory manager containing a bank of registers for each memory chip supported by the SMC. The manager register bank consists of all the timing parameters smc_nand_cycles0_<0-1> and smc_opmode0_<0-1>, that are required for the controller to correctly time any type of access to a supported memory type.

The APB registers smc_set_cycles and smc_set_opmode act as holding registers, the configuration registers within the manager are only updated if the smc_direct_cmd Register indicates only a register update is taking place.

The chip configuration registers are available as read-only registers in the address map of the APB interface.




Figure 2-33 Chip configuration registers

Direct commands

The SMC enables code to be executed from the memory while simultaneously, from the software perspective, moving the same chip to a different operating mode. Because NAND devices do not have operating modes, you must only use the direct command to update the registers.

2.6.7 Interrupts operation

The **busy** outputs of each NAND chip are wire-ANDed together outside the SMC to create a single interrupt input. Multiple outstanding accesses to NAND chips only trigger an interrupt when all chips have completed the respective operations. During the busy phase you can read the status register of each chip to determine the chips that have completed.

An interrupt is cleared by the next AHB read to any chip select on the memory interface.

The interrupt outputs are generated through a combinational path from the relevant input pin. This enables the SMC to be placed in Low-power state, and the clocks stopped, while waiting for an interrupt.

When interrupts are disabled, a synchronized version of the interrupt input is still readable through the APB interface. This enables software to poll, rather than use an interrupt to determine when NAND operations can proceed.

2.6.8 Memory interface operation

The memory interface issues commands to the memory from the command FIFO, and controls the cycle timings of these commands. A new command is only issued when the previous command is complete and any turn-around times have been met. Additionally, a read command is not issued unless there is space for all the impending data in the read data FIFO.

If enabled, the EBI can prevent commands being issued when the SMC is not granted the external bus.

The NAND timing parameters are shown in Figure 2-34 on page 2-61 to Figure 2-35 on page 2-62.

The internal signal **read_data** is included in the read transfer waveforms to indicate the clock edge on which data is registered by the SMC.

NAND timing tables and diagrams

All NAND control and data outputs are registered on the falling edge of **smc_mclk0**. Additionally read data from the memory device is registered by the SMC on the falling edge of **smc_mclk0** before being pushed onto the read data FIFO.

| | Note ——— |
|------|---|
| NAND | opmode registers only set memory width and are not included in this section |

This subsection describes:

- Command phase access
- Data phase access
- NAND read example
- NAND write example.

Command phase access

Table 2-7 lists the smc_opmode0_<0-1> and NAND Register settings.

Table 2-7 NAND cycles register settings for command

| Field | t_rc | t_wc | t_rea | t_wp | t_clr | t_ar | t_ar | t_rr |
|-------|------|------|-------|------|-------|------|------|------|
| Value | - | b011 | - | b010 | - | - | - | - |

Figure 2-34 shows an address input phase. The cycle time is set to three, and the **smc_we_n_0** assertion duration set to two. The address consists of four cycles, and the second command is not required.




Figure 2-34 Nand flash command phase

Table 2-8 lists example **haddr** fields for NAND flash address input.

Table 2-8 NAND flash address input example haddr fields

| haddr bit field | Value | Description |
|-----------------|-------------|--------------------------|
| [31:24] | chip select | - |
| [23:21] | b100 | 4 address cycles |
| [20] | b0 | End command not required |
| [19] | b0 | Command phase transfer |

Table 2-8 NAND flash address input example haddr fields (continued)

| haddr bit field | Value | Description |
|-----------------|-------|-------------------|
| [18:11] | CMD2 | - |
| [10:3] | CMD1 | - |
| [2:0] | b000 | Address alignment |

Data phase access

Table 2-9 lists the smc_opmode0_<0-1> and NAND Register settings.

Table 2-9 NAND cycles register settings for read

| Field | t_rc | t_wc | t_rea | t_wp | t_clr | t_ar | t_ar | t_rr |
|-------|------|------|-------|------|-------|------|------|------|
| Value | b011 | - | b010 | - | - | - | - | - |

Figure 2-35 shows a read from NAND flash. The cycle time is set to three and the **smc_re_n_0** assertion delay to two cycles. Four data items are read.




Figure 2-35 NAND flash read data phase

Table 2-10 lists example **haddr** fields for NAND flash page read.

Table 2-10 NAND flash page read example haddr fields

| haddr bit field | Value | Description |
|-----------------|-------------|--|
| [31:24] | chip select | - |
| [23:22] | b00 | Reserved |
| [21] | b1 | Last transfer, de-assert chip select when complete |
| [20] | b0 | End command not required |

Table 2-10 NAND flash page read example haddr fields (continued)

| haddr bit field | Value | Description |
|-----------------|------------|---------------------|
| [19] | b1 | Data phase transfer |
| [18:11] | b0000_0000 | Reserved |
| [10:3] | b0000_0000 | Reserved |
| [2:0] | b000 | Address alignment |

_____Note _____

Read data phases cannot have end commands associated with them.

Table 2-11 lists the smc_opmode0_<0-1> and NAND Register settings.

Table 2-11 NAND cycles register settings for write

| Field | t_rc | t_wc | t_rea | t_wp | t_clr | t_ar | t_ar | t_rr |
|-------|------|------|-------|------|-------|------|------|------|
| Value | - | b011 | - | b010 | - | - | - | - |

Figure 2-36 shows a write to NAND flash. The cycle time is set to three and the **smc_we_n_0** assertion duration to two cycles. Four data items are written.




Figure 2-36 NAND flash write data phase

Table 2-12 lists example **haddr** fields for NAND flash page write.

Table 2-12 NAND flash page write example haddr fields

| Value | Description |
|-------------|--|
| chip select | - |
| b00 | Reserved |
| b1 | Last transfer, de-assert chip select when complete |
| b1 | End command required |
| b1 | Data phase transfer |
| b0000_0000 | CMD2 |
| b0000_0000 | Reserved |
| b000 | Address alignment |
| | chip select b00 b1 b1 b1 b1 b0000_0000 b0000_0000 |

NAND Read example

Figure 2-37 shows a NAND read example, including the delay inserted by the memory device.




Figure 2-37 NAND read example

NAND write example

Figure 2-38 shows a NAND write example, including the delay inserted by the memory device.




Figure 2-38 NAND write example

Functional Overview

Chapter 3 **Programmer's Model**

This chapter describes the registers of the DMC and SMC and provides information for programming the devices. It contains the following sections:

- *About the programmer's model* on page 3-2
- DMC Register summary on page 3-4
- DMC Register descriptions on page 3-8
- *SMC Register summary* on page 3-29
- *SMC Register descriptions* on page 3-32.

3.1 About the programmer's model

Both the DMC and SMC have 4KB of memory allocated to each of them. The DMC memory extends from a base address of 0x0000 to a maximum address of 0x0FFF. The SMC memory extends from a base address of 0x1000 to a maximum address of 0x1FFF. Figure 3-1 on page 3-3 shows that the register map address range is split into ten regions:

DMC and SMC configuration registers

Use these registers for the global configuration, and to control the operating state of the DMC and SMC.

DMC and SMC chip select configuration registers

These registers hold the operating parameters of each chip select.

DMC and SMC user configuration registers

These registers provide general purpose I/O for user specific applications.

DMC and SMC integration test registers

Use these registers to verify correct integration of the DMC and SMC within a system, by enabling non-AMBA ports to be set and read.

DMC and SMC PrimeCell Id registers

These registers enable the software to identify the system components.




Figure 3-1 DMC and SMC register map

3.2 DMC Register summary

Figure 3-2 shows the DMC configuration register map.

| | _ |
|-----------------------|--------|
| dmc_t _{ESR} | 0x0048 |
| dmc_t _{xsr} | 0x0044 |
| dmc_t _{XP} | 0x0040 |
| dmc_t _{WTR} | 0x003C |
| dmc_t _{WR} | 0x0038 |
| dmc_t _{RRD} | 0x0034 |
| dmc_t _{RP} | 0x0030 |
| dmc_t _{RFC} | 0x002C |
| dmc_t _{RCD} | 0x0028 |
| dmc_t _{RC} | 0x0028 |
| dmc_t _{RAS} | 0x0024 |
| dmc_t _{MRD} | |
| dmc_t _{DQSS} | 0x001C |
| dmc_cas_latency | 0x0018 |
| dmc_refresh_prd | 0x0014 |
| dmc_memory_cfg | 0x0010 |
| | 0x000C |
| dmc_direct_cmd | 0x0008 |
| dmc_memc_cmd | 0x0004 |
| dmc_memc_status | 0×0000 |

Figure 3-2 DMC configuration register map

Figure 3-3 on page 3-5 shows the DMC id configuration registers map.




Figure 3-3 DMC id configuration register map

Figure 3-4 shows the DMC chip configuration register map.




Figure 3-4 DMC chip configuration register map

Figure 3-5 shows the DMC peripheral and PrimeCell identification configuration register map.

| dmc_pcell_id_3 | 0x0FFC |
|-----------------|--------|
| dmc_pcell_id_2 | 0x0FF8 |
| dmc_pcell_id_1 | 0x0FF4 |
| dmc_pcell_id_0 | 0x0FF0 |
| | 0x0FEC |
| | 0x0FE8 |
| | 0x0FE4 |
| dmc_periph_id_0 | 0x0FE0 |
| | |

Figure 3-5 DMC peripheral and PrimeCell Identification configuration register map

Table 3-1 on page 3-6 lists the DMC registers.

Table 3-1 DMC register summary

| Name | Base offset | Туре | Reset value | Description |
|------------------|-------------|------|-------------|--|
| dmc_memc_status | 0x0000 | RO | 0x00000784 | See DMC Memory Controller Status Register at 0x0000 on page 3-8 |
| dmc_memc_cmd | 0x0004 | WO | - | See DMC Memory Controller Command Register at 0x0004 on page 3-9 |
| dmc_direct_cmd | 0x0008 | WO | - | See DMC Direct Command Register at 0x0008 on page 3-10 |
| dmc_memory_cfg | 0x000C | R/W | 0x00010020 | See DMC Memory Configuration Register at 0x000C on page 3-11 |
| dmc_refresh_prd | 0x0010 | R/W | 0x00000A60 | See DMC Refresh Period Register at 0x0010 on page 3-13 |
| dmc_cas_latency | 0x0014 | R/W | 0x00000006 | See DMC CAS Latency Register at 0x0014 on page 3-14 |
| dmc_t_dqss | 0x0018 | R/W | 0x00000001 | See DMC t_dqss Register at 0x0018 on page 3-14 |
| dmc_t_mrd | 0x001C | R/W | 0x00000002 | See DMC t_mrd Register at 0x001C on page 3-15 |
| dmc_t_ras | 0x0020 | R/W | 0x00000007 | See DMC t_ras Register at 0x0020 on page 3-15 |
| dmc_t_rc | 0x0024 | R/W | 0x0000000B | See DMC t_rc Register at 0x0024 on page 3-16 |
| dmc_t_rcd | 0x0028 | R/W | 0x0000001D | See DMC t_rcd Register at 0x0028 on page 3-16 |
| dmc_t_rfc | 0x002C | R/W | 0x00000212 | See DMC t_rfc Register at 0x002C on page 3-17 |
| dmc_t_rp | 0x0030 | R/W | 0x0000001D | See DMC t_rp Register at 0x0030 on page 3-17 |
| dmc_t_rrd | 0x0034 | R/W | 0x00000002 | See DMC t_rrd Register at 0x0034 on page 3-18 |
| dmc_t_wr | 0x0038 | R/W | 0x00000003 | See DMC t_wr Register at 0x0038 on page 3-19 |
| dmc_t_wtr | 0x003C | R/W | 0x00000002 | See DMC t_wtr Register at 0x003C on page 3-19 |
| dmc_t_xp | 0x0040 | R/W | 0x00000001 | See DMC t_xp Register at 0x0040 on page 3-20 |
| dmc_t_xsr | 0x0044 | R/W | 0x0000000A | See DMC t_xsr Register at 0x0044 on page 3-20 |
| dmc_t_esr | 0x0048 | R/W | 0x00000014 | See DMC t_esr Register at 0x0048 on page 3-21 |
| dmc_id_<0-3>_cfg | 0x0100 | R/W | 0x00000000 | See DMC id_<0-3>_cfg Registers at 0x0100 on page 3-21 |

Table 3-1 DMC register summary (continued)

| Name | Base offset | Туре | Reset value | Description |
|---------------------|---------------|------|----------------------|---|
| dmc_chip_<0-3>_cfg | 0x0200 | R/W | 0x0000FF00 | See DMC chip_<0-3>_cfg Registers at 0x0200 on page 3-22 |
| dmc_user_status | 0x0300 | RO | - | See <i>DMC user_status Register at 0x0300</i> on page 3-23 |
| dmc_user_config | 0x0304 | WO | - | See DMC user_config Register at 0x0304 on page 3-23 |
| dmc_int_cfg | 0x0E00 | R/W | 0x0 | See DMC Integration Configuration Register at 0x0E00 on page 4-3 |
| dmc_int_inputs | 0x0E04 | RO | Tie-off dependent | See DMC Integration Inputs Register at 0x0E04 on page 4-4 |
| dmc_int_outputs | 0x0E08 | WO | - | See DMC Integration Outputs Register at 0x0E08 on page 4-5 |
| dmc_periph_id_<0-3> | 0x0FE0-0x0FEC | RO | - | See DMC Peripheral Identification Registers <0-3> at 0x0FE0-0x0FEC on page 3-24 |
| dmc_pcell_id_<0-3> | 0x0FF0-0x0FFC | RO | - | See DMC PrimeCell Identification Registers <0-3> at 0x0FF0-0x0FFC on page 3-26 |

3.3 DMC Register descriptions

This section describes the DMC registers.

3.3.1 DMC Memory Controller Status Register at 0x0000

The read-only dmc_memc_status Register provides information on the configuration of the DMC and also the current state of the DMC. It cannot be read in either the Reset or POR states. Figure 3-6 shows the register bit assignments.




Figure 3-6 dmc_memc_status Register bit assignments

Table 3-2 lists the register bit assignments.

Table 3-2 dmc_memc_status Register bit assignments

| Bits | Name | Function |
|---------|--------------------|--|
| [31:12] | - | Read undefined. |
| [11:10] | exclusive_monitors | Returns the number of exclusive access monitor resources implemented in the DMC: $b00 = 0$ monitors $b01 = 1$ monitor $b10 = 2$ monitors $b11 = 4$ monitors. |
| [9] | memory_banks | Returns the maximum number of banks that the DMC supports on each chip. This is fixed at 1'b1 = 4 banks. |
| [8:7] | memory_chips | Returns the number of different chip selects that the DMC supports: b00 = 1 chip b01 = 2 chips b10 = 3 chips b11 = 4 chips. |

Table 3-2 dmc_memc_status Register bit assignments (continued)

| Bits | Name | Function |
|-------|--------------|---|
| [6:4] | memory_ddr | Returns the SDRAM that the DMC supports: |
| | | b000 = SDR SDRAM |
| | | b001 = Reserved |
| | | b011 = Reserved |
| | | b010 = Reserved |
| | | b1xx = Reserved. |
| | | SDR SDRAM is supported so the cas_half_cycle bit at address offset 0x14 is ignored. |
| [3:2] | memory_width | Returns the width of the external memory: |
| | | b00 = 16-bit |
| | | b01 = 32-bit |
| | | b10 = 64-bit |
| | | b11 = Reserved. |
| [1:0] | memc_status | Returns the state of the memory controller: |
| | | b00 = Config |
| | | b01 = Ready |
| | | b10 = Paused |
| | | b11 = Low_power. |

3.3.2 DMC Memory Controller Command Register at 0x0004

The write-only dmc_memc_cmd Register enables the DMC to be traversed. The command register controls the programmer's view FSM. By writing to this register the FSM can be traversed. If a new command is received to change state, and a previous command to change state has not completed, the **pready** signal is held LOW until the new command can be carried out.

Figure 3-7 shows the register bit assignments.



Figure 3-7 dmc_memc_cmd Register bit assignments

Table 3-3 lists the register bit assignments.

Table 3-3 dmc_memc_cmd Register bit assignments

| Bits | Name | Function |
|--------|----------|--|
| [31:3] | - | Undefined. Write as zero. |
| [2:0] | memc_cmd | Changes the state of the memory controller: b000 = Go b001 = Sleep b010 = Wakeup b011 = Pause b100 = Configure. |

3.3.3 DMC Direct Command Register at 0x0008

The write-only dmc_direct_cmd Register passes commands to the external memory. The configuration of the dmc_direct_cmd Register enables you to write to any type of Mode register supported by the external memory device and also to generate NOP, Prechargeall, and Autorefresh commands. The dmc_direct_cmd Register therefore enables any initialization sequence that an external memory device might require. The only timing information associated with the dmc_direct_cmd Register are the command delays defined in the timing registers. Therefore, if an initialization sequence requires additional delays between commands they must be timed by the master driving the initialization sequence.

This register can only be written in the Config or Low-power state. Figure 3-8 shows the register bit assignments.




Figure 3-8 dmc_direct_cmd Register bit assignments

Table 3-4 lists the register bit assignments.

Table 3-4 dmc_direct_cmd Register bit assignments

| Bits | Name | Function |
|---------|--------------|---|
| [31:22] | - | Reserved. Write as zero. |
| [21:20] | chip_nmbr | Bits mapped to external memory chip address bits. |
| [19:18] | memory_cmd | Determines the command required: $b00 = \text{Prechargeall}$ $b01 = \text{Autorefresh}$ $b10 = \text{Modereg or Extended modereg access}$ $b11 = \text{NOP.}$ |
| [17:16] | bank_addr | Bits mapped to external memory bank address bits when command is Modereg access. |
| [15:14] | - | Undefined. Write as zero. |
| [13:0] | addr_13_to_0 | Bits mapped to external memory address bits [13:0] when command is Modereg access. |

3.3.4 DMC Memory Configuration Register at 0x000C

The read/write dmc_memory_cfg Register configures the memory. It can only be read and written in the Config or Low-power state. Figure 3-9 shows the register bit assignments.




Figure 3-9 dmc_memory_cfg Register bit assignments

Table 3-5 lists the register bit assignments.

Table 3-5 dmc_memory_cfg Register bit assignments

| Bits | Name | Function |
|---------|-----------------|---|
| [31:23] | - | Read undefined. Write as zero. |
| [22:21] | active_chips | Enables the refresh command generation for the number of memory chips. It is only possible to generate commands up to and including the number of chips in the configuration defined in the memc_status Register: |
| | | b00 = 1 chip |
| | | b01 = 2 chips |
| | | b10 = 3 chips |
| | | b11 = 4 chips. |
| [20:18] | - | Reserved, read undefined. Write as zero. |
| [17:15] | memory_burst | Encodes the number of data accesses that are performed to the SDRAM for each Read and Write command: |
| | | b000 = Burst 1 |
| | | b001 = Burst 2 |
| | | b010 = Burst 4 |
| | | b011 = Burst 8 |
| | | b100 = Burst 16. |
| | | You must also program this value into the SDRAM mode register using the direct_cmd Register at offset $0x8$, and it must match it. |
| [14] | stop_mem_clock | When enabled, the memory clock is dynamically stopped when not performing an access to the SDRAM. |
| [13] | auto_power_down | When this is set, the memory interface automatically places the SDRAM into power-down state by deasserting CKE when the command FIFO has been empty for PowerDownPrd number of memory clock cycles. |
| [12:7] | power_down_prd | Number of memory clock cycles for auto power-down of the SDRAM. Minimum value = 1. |
| [6] | ap_bit | Encodes the position of the auto-precharge bit in the memory address: b0 = address bit 10 b1 = address bit 8. |

Table 3-5 dmc_memory_cfg Register bit assignments (continued)

| Bits | Name | Function |
|-------|-------------|---|
| [5:3] | row_bits | Encodes the number of bits of the AHB address that comprise the row address: |
| | | b000 = 11 bits |
| | | b001 = 12 bits |
| | | b010 = 13 bits |
| | | b011 = 14 bits |
| | | b100 = 15 bits |
| | | b101 = 16 bits. |
| | | The combination of row size, column size, BRC/RBC, and memory width must ensure that neither the MSB of the row address nor the MSB of the bank address exceeds address range [27:0]. |
| [2:0] | column_bits | Encodes the number of bits of the AHB address that comprise the column address: |
| | | b000 = 8 bits |
| | | b001 = 9 bits |
| | | b010 = 10 bits |
| | | b011 = 11 bits |
| | | b100 = 12 bits. |

3.3.5 DMC Refresh Period Register at 0x0010

The read/write dmc_refresh_prd Register sets the memory refresh period. It can only be read and written in the Config or Low-power state. Figure 3-10 shows the register bit assignments.




Figure 3-10 dmc_refresh_prd Register bit assignments

Table 3-6 lists the register bit assignments.

Table 3-6 dmc_refresh_prd Register bit assignments

| Bits | Name | Function |
|---------|-------------|---|
| [31:15] | - | Read undefined. Write as zero. |
| [14:0] | refresh_prd | Memory refresh period in memory clock cycles. |

3.3.6 DMC CAS Latency Register at 0x0014

The read/write dmc_cas_latency Register sets the CAS latency in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-11 shows the register bit assignments.




Figure 3-11 dmc_cas_latency Register bit assignments

Table 3-7 lists the register bit assignments.

Table 3-7 dmc_cas_latency Register bit assignments

| Bits | Name | Function |
|--------|-------------|--|
| [31:4] | - | Read undefined. Write as zero. |
| [3:1] | cas_latency | CAS latency in memory clock cycles. |
| [0] | - | Reserved. Read undefined. Write as zero. |

3.3.7 DMC t_dqss Register at 0x0018

The read/write dmc_t_dqss Register writes to DQS in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-12 shows the register bit assignments.




Figure 3-12 dmc_t_dqss Register bit assignments

Table 3-8 lists the register bit assignments.

Table 3-8 dmc_t_dqss Register bit assignments

| Bits | Name | Function |
|--------|--------|--------------------------------------|
| [31:2] | - | Read undefined. Write as zero. |
| [1:0] | t_dqss | Write to DQS in memory clock cycles. |

3.3.8 DMC t_mrd Register at 0x001C

The read/write dmc_t_mrd Register sets the mode register command time in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-13 shows the register bit assignments.




Figure 3-13 dmc_t_mrd Register bit assignments

Table 3-9 lists the register bit assignments.

Table 3-9 dmc_t_mrd Register bit assignments

| Bits | Name | Function |
|--------|-------|--|
| [31:7] | - | Read undefined. Write as zero. |
| [6:0] | t_mrd | Set mode register command time in memory clock cycles. |

3.3.9 DMC t_ras Register at 0x0020

The read/write dmc_t_ras Register sets the RAS to precharge delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-14 shows the register bit assignments.



Figure 3-14 dmc_t_ras Register bit assignments

Table 3-10 lists the register bit assignments.

Table 3-10 dmc_t_ras Register bit assignments

| Bits | Name | Function |
|--------|-------|--|
| [31:4] | - | Read undefined. Write as zero. |
| [3:0] | t_ras | Set RAS to precharge delay in memory clock cycles. |

3.3.10 DMC t_rc Register at 0x0024

The read/write dmc_t_rc Register sets the Active bank x to Active bank x delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-15 shows the register bit assignments.



Figure 3-15 dmc_t_rc Register bit assignments

Table 3-11 lists the register bit assignments.

Table 3-11 dmc_t_rc Register bit assignments

| Bits | Name | Function |
|--------|------|--|
| [31:4] | - | Read undefined. Write as zero. |
| [3:0] | t_rc | Set Active bank x to Active bank x delay in memory clock cycles. |

3.3.11 DMC t_rcd Register at 0x0028

The read/write dmc_t_rcd Register sets the RAS to CAS minimum delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-16 shows the register bit assignments.



Figure 3-16 dmc_t_rcd Register bit assignments

Table 3-12 lists the register bit assignments.

Table 3-12 dmc_t_rcd Register bit assignments

| Bits | Name | Function |
|--------|--------------|--|
| [31:6] | - | Read undefined. Write as zero. |
| [5:3] | schedule_rcd | Set the RAS to CAS minimum delay in dmc_aclk cycles -3. |
| [2:0] | t_rcd | Set the RAS to CAS minimum delay in memory clock cycles. |

3.3.12 DMC t_rfc Register at 0x002C

The read/write dmc_t_rfc Register sets the auto-refresh command time in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-17 shows the register bit assignments.



Figure 3-17 dmc_t_rfc Register bit assignments

Table 3-13 lists the register bit assignments.

Table 3-13 dmc_t_rfc Register bit assignments

| Bits | Name | Function |
|---------|--------------|--|
| [31:10] | - | Read undefined. Write as zero. |
| [9:5] | schedule_rfc | Set the autorefresh command time in dmc_aclk cycles -3. |
| [4:0] | t_rfc | Set the auto-refresh command time in memory clock cycles. |

3.3.13 DMC t_rp Register at 0x0030

The read/write dmc_t_rp Register sets the precharge to RAS delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-18 on page 3-18 shows the register bit assignments.



Figure 3-18 dmc_t_rp Register bit assignments

Table 3-14 lists the register bit assignments.

Table 3-14 dmc_t_rp Register bit assignments

| Bits | Name | Function |
|--------|-------------|--|
| [31:6] | - | Read undefined. Write as zero. |
| [5:3] | schedule_rp | Set the precharge to RAS delay in dmc_aclk cycles -3. |
| [2:0] | t_rp | Set the precharge to RAS delay in memory clock cycles. |

3.3.14 DMC t_rrd Register at 0x0034

The read/write dmc_t_rrd Register sets the Active bank x to Active bank y delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-19 shows the register bit assignments.



Figure 3-19 dmc_t_rrd Register bit assignments

Table 3-15 lists the register bit assignments.

Table 3-15 dmc_t_rrd Register bit assignments

| Bits | Name | Function |
|--------|-------|--|
| [31:4] | - | Read undefined. Write as zero. |
| [3:0] | t_rrd | Set Active bank x to Active bank y delay in memory clock cycles. |

3.3.15 DMC t_wr Register at 0x0038

The read/write dmc_t_wr Register sets the write to precharge delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-20 shows the register bit assignments.



Figure 3-20 dmc_t_wr Register bit assignments

Table 3-16 lists the register bit assignments.

Table 3-16 dmc_t_wr Register bit assignments

| Bits | Name | Function | |
|--------|------|--|--|
| [31:3] | - | Read undefined. Write as zero. | |
| [2:0] | t_wr | Set the write to precharge delay in memory clock cycles. | |

3.3.16 DMC t_wtr Register at 0x003C

The read/write dmc_t_wtr Register sets the write to read delay in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-21 shows the register bit assignments.




Figure 3-21 dmc_t_wtr Register bit assignments

Table 3-17 lists the register bit assignments.

Table 3-17 dmc_t_wtr Register bit assignments

| Bits | Name | Function | |
|--------|-------|---|--|
| [31:3] | - | Read undefined. Write as zero. | |
| [2:0] | t_wtr | Set the write to read delay in memory clock cycles. | |

3.3.17 DMC t_xp Register at 0x0040

The read/write dmc_t_xp Register sets exit power down command time in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-22 shows the register bit assignments.



Figure 3-22 dmc_t_xp Register bit assignments

Table 3-18 lists the register bit assignments.

Table 3-18 dmc_t_xp Register bit assignments

| Bits | Name | Function | |
|--------|------|--|--|
| [31:8] | - | Read undefined. Write as zero. | |
| [7:0] | t_xp | Set the exit power down command time in memory clock cycles. | |

3.3.18 DMC t_xsr Register at 0x0044

The read/write dmc_t_xsr Register sets exit self-refresh command time in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-23 shows the register bit assignments.




Figure 3-23 dmc_t_xsr Register bit assignments

Table 3-19 lists the register bit assignments.

Table 3-19 dmc_t_xsr Register bit assignments

| Bits | Name | Function | |
|--------|-------|--|--|
| [31:8] | - | Read undefined. Write as zero. | |
| [7:0] | t_xsr | Set the exit self-refresh command time in memory clock cycles. | |

3.3.19 DMC t_esr Register at 0x0048

The read/write dmc_t_esr Register sets self-refresh command time in memory clock cycles. It can only be read and written in the Config or Low-power state. Figure 3-24 shows the register bit assignments.



Figure 3-24 dmc_t_esr Register bit assignments

Table 3-20 lists the register bit assignments.

Table 3-20 dmc_t_esr Register bit assignments

| Bits | Name | Function | |
|--------|-------|---|--|
| [31:8] | - | Read undefined. Write as zero. | |
| [7:0] | t_esr | Set the self-refresh command time in memory clock cycles. | |

3.3.20 DMC id_<0-3>_cfg Registers at 0x0100

The read/write dmc_id_<0-3>_cfg Registers are four registers that set the quality of service and span address locations 0x0100-0x0140. The registers can only be read and written in the Config or Low-power states.

Figure 3-25 shows the register bit assignments.



Figure 3-25 dmc_id_<0-3>_cfg Registers bit assignments

Table 3-21 lists the register bit assignments.

Table 3-21 dmc_id_<0-3>_cfg Registers bit assignments

| Bits | Name | Function | |
|---------|------------|--|--|
| [31:10] | - | Read undefined. Write as zero. | |
| [9:2] | qos_max | Set a maximum QoS. | |
| [1] | qos_min | Set a minimum QoS. | |
| [0] | qos_enable | Enables a QoS value to be applied to memory reads from address ID n. | |

3.3.21 DMC chip_<0-3>_cfg Registers at 0x0200

The read/write dmc_chip_<0-3>_cfg Registers set up the external memory device configuration. See the *Release Note* for the number of external chips supported, and therefore the number of these registers. They span address locations 0x0200-0x0300. There is one register per memory device. The registers configure the base address and address decoding method. The registers can only be read and written in the Config or Low-power states.

Figure 3-26 shows the register bit assignments.




Figure 3-26 dmc_chip_<0-3>_cfg Registers bit assignments

Table 3-22 lists the register bit assignments.

Table 3-22 dmc_chip_<0-3>_cfg Registers bit assignments

| Bits | Name | Function | |
|---------|---------------|---|--|
| [31:17] | - | Read undefined. Write as zero. | |
| [16] | brc_n_rbc | Selects the memory organization as decoded from the AHB address: b0 = row, bank, column organization b1 = bank, row, column organization. | |
| [15:8] | address_match | Comparison value for AHB address bits [31:24] to determine the chip that is selected. | |
| [7:0] | address_mask | The mask for AHB address bits [31:24] to determine the chip that is selected: 1 = corresponding address bit is to be used for comparison. | |

3.3.22 DMC user_status Register at 0x0300

The dmc_user_status Register is a general purpose read-only register that returns the state on the **dmc_user_status[7:0]** primary inputs. The dmc_user_status Register can be read in all states. Figure 3-27 shows the register bit assignments.



Figure 3-27 dmc_user_status Register bit assignments

Table 3-23 lists the register bit assignments.

Table 3-23 dmc_user_status Register bit assignments

| Bits | Name | Function |
|--------|-----------------|--|
| [31:8] | - | Reserved, read undefined |
| [7:0] | dmc_user_status | The value returns the state of the dmc_user_status[7:0] primary input pins |

3.3.23 DMC user_config Register at 0x0304

The dmc_user_config Register is a general purpose write-only register. This register sets the value of the **dmc_user_config[7:0]** primary outputs. The dmc_user_config Register can be written in all states. Figure 3-28 shows the register bit assignments.



Figure 3-28 dmc_user_config Register bit assignments

Table 3-24 lists the register bit assignments.

Table 3-24 dmc_user_status Registers bit assignments

| Bits | Name | Function |
|--------|-----------------|---|
| [31:8] | - | Reserved, write as zero |
| [7:0] | dmc_user_config | This value sets the state of the dmc_user_config[7:0] primary output pins |

3.3.24 DMC Peripheral Identification Registers <0-3> at 0x0FE0-0x0FEC


The dmc_periph_id Registers are four 8-bit read-only registers, that span address locations 0x0FE0-0x0FEC. The registers can conceptually be treated as a single register that holds a 32-bit peripheral ID value. They are read by an external master to determine the device version of the DMC.


Table 3-25 lists the register bit assignments.

Table 3-25 dmc_periph_id Register bit assignments

| Bits | Name | Description | |
|---------|-----------------|--|--|
| [31:24] | integration_cfg | Configuration options are peripheral-specific. See <i>DMC Peripheral Identification Register 3</i> on page 3-26. | |
| [23:20] | - | The peripheral revision number is revision dependent. | |
| [19:12] | designer | Designer's ID number. This is 0x41 for ARM. | |
| [11:0] | part_number | Identifies the peripheral. The part number for the DMC is 0x340. | |

Figure 3-29 shows the correspondence between bits of the dmc_periph_id registers and the conceptual 32-bit Peripheral ID Register.





Conceptual register bit assignment

Figure 3-29 dmc_periph_id Register bit assignments

The following sections describe the dmc_periph_id Registers:

- DMC Peripheral Identification Register 0 on page 3-25
- DMC Peripheral Identification Register 1 on page 3-25
- DMC Peripheral Identification Register 2 on page 3-25
- *DMC Peripheral Identification Register 3* on page 3-26.

DMC Peripheral Identification Register 0

The dmc_periph_id_0 Register is hard-coded and the fields within the register indicate the value. Table 3-26 lists the register bit assignments.

Table 3-26 dmc_periph_id_0 Register bit assignments

| Bits | Name | Description |
|--------|---------------|------------------------------|
| [31:8] | - | Read undefined |
| [7:0] | part_number_0 | These bits read back as 0x40 |

DMC Peripheral Identification Register 1

The dmc_periph_id_1 Register is hard-coded and the fields within the register indicate the value. Table 3-27 lists the register bit assignments.

Table 3-27 dmc_periph_id_1 Register bit assignments

| Bits | Name | Description |
|--------|---------------|-----------------------------|
| [31:8] | - | Read undefined |
| [7:4] | designer_0 | These bits read back as 0x1 |
| [3:0] | part_number_1 | These bits read back as 0x3 |

DMC Peripheral Identification Register 2

The dmc_periph_id_2 Register is hard-coded and the fields within the register indicate the value. Table 3-28 lists the register bit assignments.

Table 3-28 dmc_periph_id_2 Register bit assignments

| Bits | Name | Description |
|--------|------------|-----------------------------|
| [31:8] | - | Read undefined. |
| [7:4] | revision | These bits read back as 0x1 |
| [3:0] | designer_1 | These bits read back as 0x4 |

DMC Peripheral Identification Register 3

The dmc_periph_id_3 Register is hard-coded and the fields within the register indicate the value of 0x0. Table 3-29 lists the register bit assignments.

Table 3-29 dmc_periph_id_3 Register bit assignments

| Bits | Name | Description |
|--------|-------------------|---|
| [31:8] | - | Read undefined. |
| [7:4] | - | Reserved for future use, read undefined |
| [3:0] | Customer modified | Customer modified number. 0 from ARM |

3.3.25 DMC PrimeCell Identification Registers <0-3> at 0x0FF0-0x0FFC


The dmc_pcell_id Registers are four 8-bit wide registers, that span address locations 0x0FF0-0x0FFC. The registers can conceptually be treated as a single register that holds a 32-bit component ID value. The register can be used for automatic BIOS configuration. The pcell_id Register is set to 0xB105F00D. The register can be accessed with one wait state. Table 3-30 lists the register bit assignments.

Table 3-30 dmc_pcell_id Register bit assignments

| Component ID register | | ComplD0-3 register | | | |
|-----------------------|-------|--------------------|--------|------------------------------|--|
| Bits | Value | Register | Bits | Description | |
| - | - | dmc_pcell_id_3 | [31:8] | Read undefined | |
| [31:24] | 0xB1 | dmc_pcell_id_3 | [7:0] | These bits read back as 0xB1 | |
| - | - | dmc_pcell_id_2 | [31:8] | Read undefined | |
| [23:16] | 0x05 | dmc_pcell_id_2 | [7:0] | These bits read back as 0x05 | |
| - | - | dmc_pcell_id_1 | [31:8] | Read undefined | |
| [15:8] | 0xF0 | dmc_pcell_id_1 | [7:0] | These bits read back as 0xF0 | |
| - | - | dmc_pcell_id_0 | [31:8] | Read undefined | |
| [7:0] | 0x0D | dmc_pcell_id_0 | [7:0] | These bits read back as 0x0D | |

Figure 3-30 shows the register bit assignments.

Actual register bit assignment



Conceptual register bit assignment

Figure 3-30 dmc_pcell_id Register bit assignments

The following sections describe the dmc pcell id Registers:

- DMC PrimeCell Identification Register 0
- DMC PrimeCell Identification Register 1 on page 3-28
- DMC PrimeCell Identification Register 2 on page 3-28
- DMC PrimeCell Identification Register 3 on page 3-28.

_____Note _____

These registers cannot be read in the Reset state.

DMC PrimeCell Identification Register 0

The dmc_pcell_id_0 Register is hard-coded and the fields within the register indicate the value. Table 3-31 lists the register bit assignments.

Table 3-31 dmc_pcell_id_0 Register bit assignments

| Bits | Name | Function |
|--------|----------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | dmc_pcell_id_0 | These bits read back as 0x0D |

DMC PrimeCell Identification Register 1

The dmc_pcell_id_1 Register is hard-coded and the fields within the register indicate the value. Table 3-32 lists the register bit assignments.

Table 3-32 dmc_pcell_id_1 Register bit assignments

| Bits | Name | Function |
|--------|----------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | dmc_pcell_id_1 | These bits read back as 0xF0 |

DMC PrimeCell Identification Register 2

The dmc_pcell_id_2 Register is hard-coded and the fields within the register indicate the value. Table 3-33 lists the register bit assignments.

Table 3-33 dmc_pcell_id_2 Register bit assignments

| Bits | Name | Function |
|--------|----------------|-----------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | dmc_pcell_id_2 | These bits read back as 0x5 |

DMC PrimeCell Identification Register 3

The dmc_pcell_id_3 Register is hard-coded and the fields within the register indicate the value. Table 3-34 lists the register bit assignments.

Table 3-34 dmc_pcell_id_3 Register bit assignments

| Bits | ts Name Function | |
|--------|------------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | dmc_pcell_id_3 | These bits read back as 0xB1 |

3.4 SMC Register summary

Figure 3-31 shows the SMC configuration register map.

| smc_set_opmode | 0x1018 |
|------------------|--------|
| smc_set_cycles | 0x1014 |
| smc_direct_cmd | 0x1010 |
| smc_memc_cfg_clr | 0x100C |
| smc_memc_cfg_set | 0x1008 |
| smc_memif_cfg | 0x1004 |
| smc_memc_status | 0x1000 |
| | |

Figure 3-31 SMC configuration register map

Figure 3-32 shows the SMC chip<0-1> configuration register map:




Figure 3-32 SMC chip configuration register map

----- Note ------

Figure 3-32 shows the maximum number of supported chips. If you intend to use fewer, then the highest chip configuration blocks of the correct type are read back as zero.

Figure 3-33 shows the SMC user configuration memory register map.

smc_user_config 0x1204
smc_user_status 0x1200

Figure 3-33 SMC user configuration register map

Figure 3-34 shows the SMC peripheral and PrimeCell identification configuration register map.

| smc_pcell_id_3 | 0x1FFC |
|-----------------|--------|
| smc_pcell_id_2 | 0x1FF8 |
| smc_pcell_id_1 | 0x1FF4 |
| smc_pcell_id_0 | 0x1FF0 |
| smc_periph_id_3 | 0x1FEC |
| | 0x1FE8 |
| smc_periph_id_1 | 0x1FE4 |
| | 0x1FE0 |
| | |

Figure 3-34 SMC peripheral and PrimeCell identification configuration register map

Table 3-35 lists the SMC Registers.

Table 3-35 SMC register summary

| Name | Base offset | Туре | Reset value | Description |
|------------------------|--|------|-------------|---|
| smc_memc_status | 0x1000 | RO | 0x00000000 | See SMC Memory Controller Status Register at 0x1000 on page 3-32. |
| smc_memif_cfg | 0x1004 | RO | 0x00000016 | See SMC Memory Interface Configuration Register at 0x1004 on page 3-33. |
| smc_memc_cfg_set | 0x1008 | WO | N/A | See SMC Set Configuration Register at 0x1008 on page 3-34. |
| smc_memc_cfg_clr | 0x100C | WO | N/A | See SMC Clear Configuration Register at 0x100C on page 3-35. |
| smc_direct_cmd | 0x1010 | WO | N/A | See SMC Direct Command Register at 0x1010 on page 3-36. |
| smc_set_cycles | 0x1014 | WO | N/A | See SMC Set Cycles Register at 0x1014 on page 3-36. |
| smc_set_opmode | 0x1018 | WO | N/A | See SMC Set Opmode Register at 0x1018 on page 3-37. |
| smc_nand_cycles0_<0-1> | 0x1000 + chip configuration base address | RO | 0x00092AFF | See SMC NAND Cycles Registers <0-1> at 0x1100, 0x1120 on page 3-38. |
| smc_opmode0_<0-1> | 0x1004 + chip configuration base address | RO | 0x00000001 | See SMC Opmode Registers <0 -1 $>$ at $0x1104$, $0x1124$ on page 3-39. |

Table 3-35 SMC register summary (continued)

| Name | Base offset | Туре | Reset value | Description |
|---------------------|---------------|------|---------------|--|
| smc_user_status | 0x1200 | RO | 0x00000000 | See SMC User Status Register at 0x1200 on page 3-40. |
| smc_user_config | 0x1204 | WO | - | See SMC User Configuration Register at 0x1204 on page 3-41. |
| smc_int_cfg | 0x1E00 | R/W | 0x00000000 | See SMC Integration Configuration Register at 0x1E00 on page 4-6. |
| smc_int_inputs | 0x1E04 | RO | - | See SMC Integration Inputs Register at 0x1E04 on page 4-6. |
| smc_int_outputs | 0x1E08 | WO | - | See SMC Integration Outputs Register at 0x1E08 on page 4-7. |
| smc_periph_id_<0-3> | 0x1FE0-0x1FEC | RO | See registers | See SMC Peripheral Identification Registers <0-3> at 0x1FE0-0x1FEC on page 3-41. |
| smc_pcell_id_<0-3> | 0x1FF0-0x1FFC | RO | See registers | See SMC PrimeCell Identification Registers <0-3> at 0x1FF0-0x1FFC on page 3-44. |

3.5 SMC Register descriptions

This section describes the SMC registers.

3.5.1 SMC Memory Controller Status Register at 0x1000

The read-only smc_memc_status Register provides information on the configuration of the SMC and also the current state of the SMC. This register cannot be read in the Reset state. Figure 3-35 shows the register bit assignments.




Figure 3-35 smc_memc_status Register bit assignments

Table 3-36 lists the register bit assignments.

Table 3-36 smc_memc_status Register bit assignments

| Bits | Name | Function |
|--------|-----------------|--|
| [31:6] | - | Reserved, read undefined |
| [5] | raw_int_status0 | Current raw interrupt status for interface 0 |
| [4] | - | Reserved, read undefined |
| [3] | int_status0 | Current interrupt status for interface 0 |
| [2] | - | Reserved, read undefined |
| [1] | int_en0 | Status of memory interface 0 interrupt enable |
| [0] | state | b0 indicates that the SMC is in Ready state b1 indicates that the SMC is in Low-power state |

3.5.2 SMC Memory Interface Configuration Register at 0x1004

The read-only smc_memif_cfg Register provides information on the configuration of the memory interface. This register cannot be read in the Reset state. Figure 3-36 shows the register bit assignments.




Figure 3-36 smc_memif_cfg Register bit assignments

Table 3-37 lists the register bit assignments.

Table 3-37 smc_memif_cfg Register bit assignments

| Bits | Name | Function | |
|---------|--------------------|---|--|
| [31:18] | - | Reserved, read undefined. | |
| [17:16] | exclusive_monitors | Returns the number of exclusive access monitor resources that are implemented in the SMC: | |
| | | b00 = 0 monitors | |
| | | b01 = 1 monitors | |
| | | b10 = 2 monitors | |
| | | b11 = 4 monitors. | |
| [15:7] | - | Reserved, read undefined. | |
| [6] | remap0 | Returns the value of the smc_remap0 input. | |
| [5:4] | memory_width0 | Returns the maximum width of the SMC memory data bus for interface 0: | |
| | | b00 = 8 bits | |
| | | b01 = 16 bits | |
| | | b10 = 32 bits | |
| | | b11 = Reserved. | |

Table 3-37 smc_memif_cfg Register bit assignments (continued)

| Bits | Name | Function | |
|-------|---------------|--|--|
| [3:2] | memory_chips0 | Returns the number of different chip selects that the memory interface 0 supports: $b00 = 1$ chip $b01 = 2$ chips $b10 = 3$ chips $b11 = 4$ chips. | |
| [1:0] | memory_type0 | Returns the memory interface 0 type: $b00 = reserved$ $b01 = SRAM$ $b10 = NAND$ $b11 = reserved.$ | |

3.5.3 SMC Set Configuration Register at 0x1008

The write-only smc_memc_cfg_set Register enables the memory controller to be changed to Low-power state, and interrupts enabled. This register cannot be written to in the Reset state. Figure 3-37 shows the register bit assignments.



Figure 3-37 smc_memc_cfg_set Register bit assignments

Table 3-38 lists the register bit assignments.

Table 3-38 smc_memc_cfg_set Register bit assignments

| Bits | Name | Function |
|--------|---------------|--|
| [31:3] | - | Reserved, write as zero. |
| [2] | low_power_req | b0 = no effect b1 = request the SMC to enter Low-power state when it next becomes idle. |
| [1] | - | Reserved, write as zero. |
| [0] | int_enable0 | b0 = no effect b1 = interrupt enable, memory interface 0. |

3.5.4 SMC Clear Configuration Register at 0x100C

The write-only smc_memc_cfg_clr Register enables the memory controller to be moved out of the Low-power state, and the interrupts disabled. This register cannot be written to in the Reset state. Figure 3-38 shows the register bit assignments.




Figure 3-38 smc_memc_cfg_clr Register bit assignments

Table 3-39 lists the register bit assignments.

Table 3-39 smc_memc_cfg_clr Register bit assignments

| Bits | Name | Function |
|--------|----------------|---|
| [31:3] | - | Reserved, write as zero. |
| [2] | low_power_exit | b0 = no effect b1 = request the SMC to exit Low-power state. |
| [1] | - | Reserved, write as zero. |
| [0] | int_disable0 | b0 = no effect b1 = interrupt disable, memory interface 0. |

3.5.5 SMC Direct Command Register at 0x1010

The write-only smc_direct_cmd Register passes commands to the external memory, and controls the updating of the chip configuration registers with values held in the set_opmode and set_cycles registers.

This register cannot be written to in either the Reset or Low-power states. Figure 3-39 shows the register bit assignments.




Figure 3-39 smc_direct_cmd Register bit assignments

Table 3-40 lists the register bit assignments.

Table 3-40 smc_directcmd Register bit assignments

| Bits | Name | Function | |
|---------|-------------|--|--|
| [31:26] | - | Reserved, write as zero. | |
| [25:23] | chip_select | Selects chip configuration register bank to update and enables chip mode register access depending on cmd_type. The encoding is: | |
| | | b000-b001 = chip selects 0-1 on interface 0 | |
| | | b010-b111 = Reserved. | |
| [22:21] | cmd_type | Determines the current command. The encoding is: | |
| | | b00 = Reserved | |
| | | b01 = ModeReg access | |
| | | b10 = UpdateRegs | |
| | | b11 = Reserved. | |
| [20:0] | - | Reserved, write as zero. | |

3.5.6 SMC Set Cycles Register at 0x1014

This is the holding register for the smc_nand_cycles0_<0-1>. The write-only smc_set_cycles Register enables the time interval to be set for holding registers before being written to the memory manager specific registers. This register cannot be written to in either the Reset or Low-power states. Figure 3-40 on page 3-37 shows the register bit assignments.

_____ Note _____

Table 3-41 describes register holding, see *Memory manager operation on page 2-57* for more information.




Figure 3-40 smc_set_cycles Register bit assignments

Table 3-41 lists the register bit assignments.

Table 3-41 smc_set_cycles Register bit assignments

| Bits | Name | Function |
|---------|--------|---|
| [31:23] | - | Reserved, write as zero |
| [22:20] | Set_t6 | Holding register for value to be written to the specific chip Register t _{RR} field |
| [19:17] | Set_t5 | Holding register for value to be written to the specific chip Register t _{AR} field |
| [16:14] | Set_t4 | Holding register for value to be written to the specific chip Register t _{CLR} field |
| [13:11] | Set_t3 | Holding register for value to be written to the specific chip Register t _{WP} field |
| [10:8] | Set_t2 | Holding register for value to be written to the specific chip Register t_{REA} field |
| [7:4] | Set_t1 | Holding register for value to be written to the specific chip Register t _{WC} field |
| [3:0] | Set_t0 | Holding register for value to be written to the specific chip Register t _{RC} field |

3.5.7 SMC Set Opmode Register at 0x1018

This register is the holding register for the smc_opmode0_<0-1> working registers. The write-only smc_set_opmode Register cannot be written to in either the Reset or Low-power states. Figure 3-41 on page 3-38 shows the register bit assignments.




Figure 3-41 smc_set_opmode Register bit assignments

Table 3-42 lists the register bit assignments.

Table 3-42 smc_set_opmode Register bit assignments

| Bits | Name | Function |
|----------------|--------|---|
| [31:2] | - | Reserved, write as zero. |
| [1:0] | set_mw | Holding register for value to be written to the specific SRAM chip smc_opmode Register <i>memory width</i> (mw) field. |
| | | Encodes the memory data bus width: |
| | | b00 = 8 bits |
| b01 = 16 bits | | b01 = 16 bits |
| b10 = reserved | | b10 = reserved |
| | | b11 = reserved. |
| | | You can program this to the configured width or half that width. See <i>SMC Memory Interface Configuration Register at 0x1004</i> on page 3-33. |

3.5.8 SMC NAND Cycles Registers <0-1> at 0x1100, 0x1120

There is an instance of this register for each NAND chip supported. The read-only smc_nand_cycles Register cannot be read in the Reset state. Figure 3-42 shows the register bit assignments.




Figure 3-42 smc_nand_cycles Register bit assignments

Table 3-43 lists the register bit assignments.

Table 3-43 smc_nand_cycles Register bit assignments

| Bits | Name | Function |
|---------|-------|-------------------------------|
| [31:21] | - | Reserved, read undefined |
| [20:18] | t_rr | smc_busy_0 to smc_re_n_0 |
| [17:15] | t_ar | ID read time |
| [14:12] | t_clr | Status read time |
| [11:9] | t_wp | smc_we_n_0 assertion duration |
| [8:6] | t_rea | smc_re_n_0 assertion delay |
| [5:3] | t_wc | Write cycle time |
| [2:0] | t_rc | Read cycle time |
| | | |

3.5.9 SMC Opmode Registers <0-1> at 0x1104, 0x1124

There is an instance of the smc_opmode Register for each chip supported. This register is read-only and cannot be read in the Reset state.

The reset values of these registers are configuration-dependent. You can set the memory width for the chip select 0 of each memory interface with a tie off to enable booting from that chip. The reset value of memory width for all other chip selects is the configured width. You must set all other bits to 0x0, apart from address_match and address_mask. These are set by tie-offs at the top level.

Figure 3-43 shows the register bit assignments.




Figure 3-43 smc_opmode Register bit assignments

Table 3-44 lists the register bit assignments.

Table 3-44 smc_opmode Register bit assignments

| Bits | Name | Function | |
|---------|---------------|---|--|
| [31:30] | - | Reserved, read undefined. | |
| [29:22] | address_match | Returns the value of this tie-off. This is the comparison value for address bits [31:24] to determine the chip that is selected. | |
| [21:14] | address_mask | Returns the value of this tie-off. This is the mask for address bits [31:24] to determine the chip that must be selected. Logic 1 indicates the bit is used for comparison. | |
| [13:2] | - | Reserved, read undefined. | |
| [1:0] | mw | Determines the SMC memory data bus width: $b00 = 8 \text{ bits}$ $b01 = 16 \text{ bits}$ $b10 = \text{reserved}$ $b11 = \text{reserved}.$ | |

3.5.10 SMC User Status Register at 0x1200

The smc_user_status Register is a general purpose read-only register that returns the state on the **dmc_user_status[7:0]** primary inputs. The dmc_user_status Register can be read in all states. Figure 3-44 shows the register bit assignments.



Figure 3-44 smc_user_status Register bit assignments

Table 3-45 lists the register bit assignments.

Table 3-45 smc_user_status Register bit assignments

| Bits | Name | Function |
|--------|-----------------|---|
| [31:8] | - | Reserved, read undefined |
| [7:0] | smc_user_status | The value returns the state of the smc_user_status[7:0] primary input pins |

3.5.11 SMC User Configuration Register at 0x1204

The smc_user_config Register is a general purpose write-only register. This register sets the value of the **smc_user_config[7:0]** primary outputs. The smc_user_config Register can be written in all states. Figure 3-45 shows the register bit assignments.



Figure 3-45 smc_user_config Register bit assignments

Table 3-46 lists the register bit assignments.

Table 3-46 smc_user_config Register bit assignments

| Bits | Name | Function |
|--------|-----------------|--|
| [31:8] | - | Reserved, write as zero |
| [7:0] | smc_user_config | This value sets the state of the dmc_user_config[7:0] primary output pins |

3.5.12 SMC Peripheral Identification Registers <0-3> at 0x1FE0-0x1FEC

The smc_periph_id Registers are four 8-bit read-only registers, that span address locations 0xFE0-0xFEC. The registers can conceptually be treated as a single register that holds a 32-bit peripheral ID value. They are read by an external master to determine the SMC device version. None of these registers 0-3 can be read in the Reset state.

Table 3-47 lists the register bit assignments.

Table 3-47 smc_periph_id Register bit assignments

| Bits | Name | Description |
|---------|-----------------|--|
| [31:25] | - | Reserved, read undefined. |
| [24] | integration_cfg | Configuration options are peripheral-specific. See <i>SMC Peripheral Identification Register 3</i> on page 3-43. |
| [23:20] | - | The peripheral revision number is revision dependent. |
| [19:12] | designer | Designer's ID number. This is 0x41 for ARM. |
| [11:0] | part_number | Identifies the peripheral. The part number for the SMC is 0x351. |

Figure 3-46 shows the correspondence between bits of the smc_periph_id registers and the conceptual 32-bit Peripheral ID Register.




Figure 3-46 smc_periph_id Register bit assignments

The following sections describe the smc_periph_id Registers:

- SMC Peripheral Identification Register 0
- SMC Peripheral Identification Register 1 on page 3-43
- SMC Peripheral Identification Register 2 on page 3-43
- *SMC Peripheral Identification Register 3* on page 3-43.

SMC Peripheral Identification Register 0

The smc_periph_id_0 Register is hard-coded and the fields within the register indicate the value. Table 3-48 lists the register bit assignments.

Table 3-48 smc_periph_id_0 Register bit assignments

| Bits | Name | Function |
|--------|---------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | part_number_0 | These bits read back as 0x51 |

SMC Peripheral Identification Register 1

The smc_periph_id_1 Register is hard-coded and the fields within the register indicate the value. Table 3-49 lists the register bit assignments.

Table 3-49 smc_periph_id_1 Register bit assignments

| В | its | Name | Function |
|----|------|---------------|-----------------------------|
| [3 | 1:8] | - | Reserved, read undefined |
| [7 | ':4] | designer_0 | These bits read back as 0x1 |
| [3 | :0] | part_number_1 | These bits read back as 0x3 |

SMC Peripheral Identification Register 2

The smc_periph_id_2 Register is hard-coded and the fields within the register indicate the value. Table 3-50 lists the register bit assignments.

Table 3-50 smc_periph_id_2 Register bit assignments

| Bits | Name | Function |
|--------|------------|-----------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:4] | revision | These bits read back as 0x3 |
| [3:0] | designer_1 | These bits read back as 0x4 |

SMC Peripheral Identification Register 3

The smc_periph_id_3 Register is hard-coded and the fields within the register indicate the value of 0x0. Table 3-51 lists the register bit assignments.

Table 3-51 smc_periph_id_3 Register bit assignments

| Bits | Name | Function |
|--------|-----------------|---|
| [31:8] | - | Reserved, read undefined. |
| [7:1] | - | Reserved for future use. Read undefined. |
| [0] | integration_cfg | When set, the integration test register map at address offset 0xE00 is present for reading and writing. If clear, the integration test registers have not been implemented. |

3.5.13 SMC PrimeCell Identification Registers <0-3> at 0x1FF0-0x1FFC


The smc_pcell_id Registers are four 8-bit wide registers, that span address locations 0xFF0-0FFC. The registers can conceptually be treated as a single register that holds a 32-bit PrimeCell ID value. You can use the register for automatic BIOS configuration. The smc_pcell_id Register is set to 0xB105F00D. The register can be accessed with one wait state. Table 3-52 lists the register bit assignments.

Table 3-52 smc_pcell_id Register bit assignments

| SMC pc | SMC pcell_id_0-3 register | | | | | |
|---------|---------------------------|----------------|--------|------------------------------|--|--|
| Bits | Value | Register | Bits | Description | | |
| - | - | smc_pcell_id_3 | [31:8] | Read undefined | | |
| [31:24] | 0xB1 | smc_pcell_id_3 | [7:0] | These bits read back as 0xB1 | | |
| - | - | smc_pcell_id_2 | [31:8] | Read undefined | | |
| [23:16] | 0x05 | smc_pcell_id_2 | [7:0] | These bits read back as 0x05 | | |
| - | - | smc_pcell_id_1 | [31:8] | Read undefined | | |
| [15:8] | 0xF0 | smc_pcell_id_1 | [7:0] | These bits read back as 0xF0 | | |
| - | - | smc_pcell_id_0 | [31:8] | Read undefined | | |
| [7:0] | 0x0D | smc_pcell_id_0 | [7:0] | These bits read back as 0x0D | | |

Figure 3-47 shows the register bit assignments.

Actual register bit assignment



Conceptual register bit assignment

Figure 3-47 smc_pcell_id Register bit assignments

The following sections describe the smc_pcell_id Registers:

- SMC PrimeCell Identification Register 0
- SMC PrimeCell Identification Register 1
- SMC PrimeCell Identification Register 2 on page 3-46
- *SMC PrimeCell Identification Register 3* on page 3-46.

| —— Note – | | | | |
|-----------------|----------------|--------|-------|--------|
| These registers | cannot be read | in the | Reset | state. |

These registers cannot be read in the reset state.

SMC PrimeCell Identification Register 0

The smc_pcell_id_0 Register is hard-coded and the fields within the register indicate the value. Table 3-53 lists the register bit assignments.

Table 3-53 smc_pcell_id_0 Register bit assignments

| Bits | Name | Function |
|--------|----------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | smc_pcell_id_0 | These bits read back as 0x0D |

SMC PrimeCell Identification Register 1

The smc_pcell_id_1 Register is hard-coded and the fields within the register indicate the value. Table 3-54 lists the register bit assignments.

Table 3-54 smc_pcell_id_1 Register bit assignments

| Bits | Name | Function |
|--------|----------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | smc_pcell_id_1 | These bits read back as 0xF0 |

SMC PrimeCell Identification Register 2

The smc_pcell_id_2 Register is hard-coded and the fields within the register indicate the value. Table 3-55 lists the register bit assignments.

Table 3-55 smc_pcell_id_2 Register bit assignments

| | Bits | Name | Function |
|---|--------|----------------|-----------------------------|
| | [31:8] | - | Reserved, read undefined |
| - | [7:0] | smc_pcell_id_2 | These bits read back as 0x5 |

SMC PrimeCell Identification Register 3

The smc_pcell_id_3 Register is hard-coded and the fields within the register indicate the value. Table 3-56 lists the register bit assignments.

Table 3-56 smc_pcell_id_3 Register bit assignments

| Bits | Name | Function |
|--------|----------------|------------------------------|
| [31:8] | - | Reserved, read undefined |
| [7:0] | smc_pcell_id_3 | These bits read back as 0xB1 |

Chapter 4 **Programmer's Model for Test**

This chapter describes the additional logic for functional verification and production testing. It contains the following section:

• *DMC and SMC integration test registers* on page 4-2.

4.1 DMC and SMC integration test registers

Figure 4-1 shows the DMC integration test register map.




Figure 4-1 DMC integration test register map

Test registers are provided for integration testing. Table 4-1 lists the DMC integration test registers.

Table 4-1 DMC integration test register summary

| Name | Base offset | Туре | Reset value | Description |
|-----------------|-------------|------|----------------------|--|
| dmc_int_cfg | 0x0E00 | R/W | 0x0 | DMC Integration Configuration Register at 0x0E00 on page 4-3 |
| dmc_int_inputs | 0x0E04 | RO | Tie-off dependent | DMC Integration Inputs Register at 0x0E04 on page 4-4 |
| dmc_int_outputs | 0x0E08 | WO | - | DMC Integration Outputs Register at 0x0E08 on page 4-5 |

Figure 4-2 shows the SMC integration Test Register map.




Figure 4-2 SMC integration test register map

Table 4-2 lists the SMC integration test registers.

Table 4-2 SMC integration test register summary

| Name | Base offset | Туре | Reset value | Description |
|-----------------|----------------|------|----------------|--|
| smc_int_cfg | 0x1E00 | R/W | 0x0 | SMC Integration Configuration Register at 0x1E00 on page 4-6 |
| smc_int_inputs | 0x1E04 | RO | - | SMC Integration Inputs Register at 0x1E04 on page 4-6 |
| smc_int_outputs | 0x1E08 | WO | - | SMC Integration Outputs Register at 0x1E08 on page 4-7 |

This section describes:

- DMC Integration Configuration Register at 0x0E00
- DMC Integration Inputs Register at 0x0E04
- DMC Integration Outputs Register at 0x0E08 on page 4-5
- SMC Integration Configuration Register at 0x1E00 on page 4-6
- SMC Integration Inputs Register at 0x1E04 on page 4-6
- *SMC Integration Outputs Register at 0x1E08* on page 4-7.

4.1.1 DMC Integration Configuration Register at 0x0E00

The read/write dmc_int_cfg Register selects the integration test registers. This register is only for test. It can only be read and written in Config state.

Figure 4-3 shows the register bit assignments.



Figure 4-3 dmc_int_cfg Register bit assignments

Table 4-3 lists the register bit assignments.

Table 4-3 dmc_int_cfg Register bit assignments

| Bits | Name | Function |
|--------|-------------|--|
| [31:1] | Undefined | Reserved, read undefined. Write as zero. |
| [0] | int_test_en | When set, outputs are driven from the integration test registers, and input integration register values show external port states. |

4.1.2 DMC Integration Inputs Register at 0x0E04

The read-only dmc_int_inputs Register enables an external master to access the inputs of the DMC using the APB interface. This register is only for test. It can only be read in Config state.

Figure 4-4 shows the register bit assignments.




Figure 4-4 dmc_int_inputs Register bit assignments

Table 4-4 lists the register bit assignments.

Table 4-4 dmc_int_inputs Register bit assignments

| Bits | Name | Function |
|---------|------------------|---|
| [31:24] | - | Read undefined. |
| [23:8] | dmc_qos_override | Returns the value of the dmc_qos_override external input |
| [7] | dmc_dqm_init | Returns the value of the dmc_dqm_init external input |
| [6] | dmc_cke_init | Returns the value of the dmc_cke_init external input |

Table 4-4 dmc_int_inputs Register bit assignments (continued)

| Bits | Name | Function |
|------|----------------|---|
| [5] | dmc_msync | Returns the value of the dmc_msync external input |
| [4] | dmc_async | Returns the value of the dmc_async external input |
| [3] | dmc_use_ebi | Returns the value of the dmc_use_ebi external input |
| [2] | dmc_ebibackoff | Returns the value of the dmc_ebibackoff external input |
| [1] | dmc_ebigrant | Returns the value of the dmc_ebigrant external input |
| [0] | dmc_csysreq | Returns the value of the dmc_csysreq external input |

4.1.3 DMC Integration Outputs Register at 0x0E08

The write-only dmc_int_outputs Register enables an external master to access the outputs of the DMC using the APB interface. It can only be read in Config state.

Figure 4-5 shows the register bit assignments.




Figure 4-5 dmc_int_outputs Register bit assignments

Table 4-5 lists the register bit assignments.

Table 4-5 dmc_int_outputs Register bit assignments

| Bits | Name | Function |
|--------|-------------|---|
| [31:3] | - | Undefined, write as zero |
| [2] | dmc_ebireq | Drives the dmc_ebireq external output |
| [1] | dmc_csysack | Drives the dmc_csysack external output |
| [0] | dmc_cactive | Drives the dmc_cactive external output |

4.1.4 SMC Integration Configuration Register at 0x1E00

The read/write smc_int_cfg Register selects the integration test registers. This register is only for test. This register cannot be read or written to in the Reset state.

Figure 4-6 shows the register bit assignments.




Figure 4-6 smc_int_cfg Register bit assignments

Table 4-6 lists the register bit assignments.

Table 4-6 smc_int_cfg Register bit assignments

| Bits | Name | Function |
|--------|-------------|---|
| [31:1] | Undefined | Reserved, read undefined. Write as zero. |
| [0] | int_test_en | When set, outputs are driven from the integration test registers and tied-off, and inputs can change for integration testing. |

4.1.5 SMC Integration Inputs Register at 0x1E04

The read-only smc_int_inputs Register enables an external master to access the inputs of the SMC using the APB interface. This register is only for test. This register cannot be read in the Reset state.

Figure 4-7 shows the register bit assignments.




Figure 4-7 smc_int_inputs Register bit assignments

Table 4-7 lists the register bit assignments.

Table 4-7 smc_int_inputs Register bit assignments

| Bits | Name | Function |
|--------|-----------------|---|
| [31:6] | - | Reserved, read undefined |
| [5] | smc_msync0 | Returns the value of this top-level tie-off |
| [4] | smc_async0 | Returns the value of this top-level tie-off |
| [3] | smc_ebibackoff0 | Returns the value of the smc_ebibackoff0 input |
| [2] | smc_ebignt0 | Returns the value of the smc_ebigrant0 input |
| [1] | smc_use_ebi | Returns the value of the smc_use_ebi input |
| [0] | smc_csysreq | Returns the value of this external input |

4.1.6 SMC Integration Outputs Register at 0x1E08

The write-only smc_int_outputs Register enables an external master to access the outputs of the SMC using the APB interface. This register cannot be read in the Reset state.

Figure 4-8 shows the register bit assignments.




Figure 4-8 smc_int_outputs Register bit assignments

Table 4-8 lists the register bit assignments.

Table 4-8 smc_int_outputs Register bit assignments

| Bits | Name | Function |
|--------|-------------|---|
| [31:3] | - | Reserved, undefined, write as zero |
| [2] | smc_ebireq0 | Sets the value of the smc_ebireq0 output when in integration test mode |
| [1] | smc_csysack | Sets the value of this external output when in integration test mode |
| [0] | smc_cactive | This value is driven onto the external output when int_test_en is set HIGH |

Chapter 5 **Device Driver Requirements**

This chapter contains various flow diagrams to aid in the development of software drivers for the DMC and SMC. It contains the following sections:

- DMC memory initialization on page 5-2
- *SMC memory initialization* on page 5-5.

5.1 DMC memory initialization

Figure 5-1 on page 5-3 and Figure 5-2 on page 5-4 show the sequence of events that a device driver must carry out to initialize the memory controller and a memory device to ensure the configuration of both is synchronized.




Figure 5-1 DMC and memory initialization sheet 1 of 2




Figure 5-2 DMC and memory initialization sheet 2 of 2

5.2 SMC memory initialization

Figure 5-3 on page 5-6 to Figure 5-4 on page 5-7 show the sequence of events that a device driver must carry out to initialize the memory controller. NAND memory devices only require the memory controller registers to be updated with parameters specific to the device.




Figure 5-3 SMC and memory initialization sheet 1 of 2




Figure 5-4 SMC and memory initialization sheet 2 of 2

Where:

x = denotes the appropriate chip select.

Device Driver Requirements

Appendix A Signal Descriptions

This appendix lists and describes the processor signals. It contains the following sections:

- About the signals list on page A-2
- *Clocks and resets* on page A-3
- AHB signals on page A-4
- *DMC memory interface signals* on page A-5
- DMC miscellaneous signals on page A-6
- SMC memory interface signals on page A-7
- SMC miscellaneous signals on page A-8
- Low-power interface signals on page A-9
- Configuration signals on page A-10
- Scan chain signals on page A-11.

A.1 About the signals list

This appendix lists the PL242 signals. Figure A-1 shows how the signals are grouped.




Figure A-1 AHB MC (PL242) grouping of signals

where:

AHBC = AHB Configuration signals.

A.2 Clocks and resets

Table A-1 lists the clocks and resets.

Table A-1 Clocks and resets

| Name | Туре | Source/ destination | Description |
|--------------|-------|------------------------|-------------------------------|
| hclk | Input | Clock source | AHB clock |
| hresetn | Input | Reset source | AHB clock domain reset |
| dmc_aclk | Input | Clock source | DMC AHB clock |
| dmc_mclk | Input | Clock source | DMC memory clock |
| dmc_mclkn | Input | Clock source | DMC inverted memory clock |
| dmc_mresetn | Input | Reset source | DMC memory clock domain reset |
| smc_aclk | Input | Clock source | SMC AHB clock |
| smc_mclk0 | Input | Clock source | SMC memory clock |
| smc_mclk0n | Input | Clock source | SMC inverted memory clock |
| smc_mreset0n | Input | Reset source | SMC memory clock domain reset |

A.3 AHB signals

Table A-2 lists the AHB signals.

Table A-2 AHB signals

| Name | Туре | Source/ destination | Description |
|----------------------|--------|------------------------|---------------------------|
| hsel <x></x> | Input | AHB | Transfer is to this port |
| haddr <x>[31:0]</x> | Input | AHB | Address of transfer |
| htrans <x>[1:0]</x> | Input | AHB | Transfer type |
| hwrite <x></x> | Input | AHB | Transfer is write or read |
| hsize <x>[2:0]</x> | Input | AHB | Size of transfer |
| hburst <x>[2:0]</x> | Input | AHB | Burst type of transfer |
| hprot <x>[3:0]</x> | Input | AHB | Protection of transfer |
| hwdata <x>[31:0]</x> | Input | AHB | Write data |
| hmastlock <x></x> | Input | AHB | Locked transfer |
| hready <x></x> | Input | AHB | System ready |
| hrdata <x>[31:0]</x> | Output | AHB | Read data |
| hreadyout <x></x> | Output | AHB | Slave ready |
| hresp <x>[1:0]</x> | Output | AHB | Slave response |

where:

 $\langle x \rangle = 0$, 1, 2, 3 or c, where c = configuration.

A.4 DMC memory interface signals

Table A-3 lists the DMC memory interface signals.

Table A-3 DMC memory interface signals

| Name | Type Source/ destination | | Description |
|------------------|--------------------------|--------|-----------------------|
| dmc_fbclk_in | Input | Memory | Fed back clock |
| dmc_dq_in[31:0] | Input | Memory | Data in |
| dmc_clk_out[3:0] | Output | Memory | Clock out |
| dmc_ras_n | Output | Memory | Row address strobe |
| dmc_cas_n | Output | Memory | Column address strobe |
| dmc_we_n | Output | Memory | Write enable |
| dmc_cke | Output | Memory | Clock enable |
| dmc_cs_n[3:0] | Output | Memory | Chip select |
| dmc_add[15:0] | Output | Memory | Address |
| dmc_ba[1:0] | Output | Memory | Bank address |
| dmc_ap | Output | Memory | Auto precharge |
| dmc_dq_out[31:0] | Output | Memory | Data out |
| dmc_data_en | Output | Memory | Data enable |
| dmc_dqm[3:0] | Output | Memory | Data mask |
| dmc_use_ebi | Input | Memory | Use EBI tie-off |
| dmc_ebibackoff | Input | Memory | EBI back off |
| dmc_ebigrant | Input | Memory | EBI grant |
| dmc_ebireq | Output | Memory | EBI request |

A.5 DMC miscellaneous signals

Table A-4 lists the DMC miscellaneous signals.

Table A-4 DMC miscellaneous signals

| Name | Туре | Source/ destination | Description |
|------------------------|--------|------------------------|--|
| dmc_qos_override[15:0] | Input | System | Quality of service override |
| dmc_user_status[7:0] | Input | System | User signals to the configuration port |
| dmc_memory_width[1:0] | Input | System | Memory width tie-off |
| dmc_async | Input | System | AHB clock synchronous to memory clock |
| dmc_msync | Input | System | Memory clock synchronous to AHB clock |
| dmc_a_gt_m_sync | Input | System | AHB clock synchronous to and greater than memory clock |
| dmc_cke_init | Input | System | CKE polarity tie-off |
| dmc_dqm_init | Input | System | DQM polarity tie-off |
| dmc_user_config[7:0] | Output | System | User signals from the configuration port |

A.6 SMC memory interface signals

Table A-5 lists the SMC memory interface signals.

Table A-5 SMC memory interface signals

| Name | Туре | Source/ destination | Description |
|----------------------|--------|------------------------|----------------------|
| smc_data_in_0[15:0] | Input | Memory | Data in |
| smc_busy_0 | Input | Memory | Busy |
| smc_cs_n_0[1:0] | Output | Memory | Chip select |
| smc_ale_0 | Output | Memory | Address latch enable |
| smc_cle_0 | Output | Memory | Command latch enable |
| smc_we_n_0 | Output | Memory | Write enable |
| smc_re_n_0 | Output | Memory | Read enable |
| smc_data_out_0[15:0] | Output | Memory | Data out |
| smc_data_en_0 | Output | Memory | Data enable |
| smc_use_ebi | Input | Memory | Use EBI tie-off |
| smc_ebigrant0 | Input | Memory | EBI grant |
| smc_ebibackoff0 | Input | Memory | EBI back off |
| smc_ebireq0 | Output | Memory | EBI request |

A.7 SMC miscellaneous signals

Table A-6 lists the SMC miscellaneous signals.

Table A-6 SMC miscellaneous signals

| _ |
|-----------|
| |
| nan and |
| |
| |
| |
| |
| |
| |
| ısy times |
| |
| |
| |
| |
| |

A.8 Low-power interface signals

Table A-7 lists the low-power interface signals.

Table A-7 Low-power interface signals

| Name | Туре | Source/ destination | Description |
|-------------|--------|------------------------|---|
| ahb_csysreq | Input | System controller | AHB interfaces low-power mode request |
| dmc_csysreq | Input | System controller | DMC low-power mode request |
| smc_csysreq | Input | System controller | SMC low-power mode request |
| ahb_csysack | Output | System controller | AHB interfaces low-power mode acknowledge |
| ahb_cactive | Output | System controller | AHB interfaces active |
| dmc_csysack | Output | System controller | DMC low-power mode acknowledge |
| dmc_cactive | Output | System controller | DMC active |
| smc_csysack | Output | System controller | SMC low-power mode acknowledge |
| smc_cactive | Output | System controller | SMC active |

A.9 Configuration signals

Table A-8 lists the configuration signals.

Table A-8 Configuration signals

| Name | Туре | Source/ destination | Description |
|------------|-------|------------------------|---------------------------------------|
| big_endian | Input | Tie-off | Big-endian mode configuration tie-off |
| remap | Input | System | Remap signal |

A.10 Scan chain signals

Table A-9 lists the scan chain signals.

Table A-9 Scan chain signals

| Name | Туре | Source/ destination | Description |
|--------------------|--------|------------------------|---|
| se | Input | Scan chains | Scan enable for all clock domains |
| ahb_rst_bypass | Input | Scan chains | AHB reset bypass |
| dmc_rst_bypass | Input | Scan chains | DMC reset bypass |
| dmc_dft_en_clk_out | Input | Scan chains | DMC DFT enable for clock out |
| smc_rst_bypass | Input | Scan chains | SMC reset bypass |
| smc_dft_en_clk_out | Input | Scan chains | SMC DFT enable for clock out |
| si_hclk | Input | Scan chains | Scan in for hclk domain |
| dmc_si_aclk | Input | Scan chains | DMC scan in for dmc_aclk domain |
| dmc_si_mclk | Input | Scan chains | DMC scan in for dmc_mclk domain |
| dmc_si_mclkn | Input | Scan chains | DMC scan in for dmc_mclkn domain |
| dmc_si_fbclk_in | Input | Scan chains | DMC scan in for dmc_fbclk_in domain |
| smc_si_aclk | Input | Scan chains | SMC scan in for smc_aclk domain |
| smc_si_mclk0 | Input | Scan chains | SMC scan in for smc_mclk0 domain |
| smc_si_mclk0n | Input | Scan chains | SMC scan in for smc_mclk0n domain |
| smc_si_busy_0 | Input | Scan chains | SMC scan in for smc_busy_0 domain |
| so_hclk | Output | Scan chains | Scan out for hclk domain |
| dmc_so_aclk | Output | Scan chains | DMC scan out for dmc_aclk domain |
| dmc_so_mclk | Output | Scan chains | DMC scan out for dmc_mclk domain |
| dmc_so_mclkn | Output | Scan chains | DMC scan out for dmc_mclkn domain |
| dmc_so_fbclk_in | Output | Scan chains | DMC scan out for dmc_fbclk_in domain |
| smc_so_aclk | Output | Scan chains | SMC scan out for smc_aclk domain |

Table A-9 Scan chain signals (continued)

| Name | Туре | Source/ destination | Description |
|---------------|--------|------------------------|------------------------------------|
| smc_so_mclk0 | Output | Scan chains | SMC scan out for smc_mclk0 domain |
| smc_so_mclk0n | Output | Scan chains | SMC scan out for smc_mclk0n domain |
| smc_so_busy_0 | Output | Scan chains | SMC scan out for smc_busy_0 domain |

Glossary

This glossary describes some of the terms used in technical documents from ARM Limited.

Advanced High-performance Bus (AHB)

A bus protocol with a fixed pipeline between address/control and data phases. It only supports a subset of the functionality provided by the AMBA AXI protocol. The full AMBA AHB protocol specification includes a number of features that are not commonly required for master and slave IP developments and ARM Limited recommends only a subset of the protocol is usually used. This subset is defined as the AMBA AHB-Lite protocol.

See also Advanced Microcontroller Bus Architecture and AHB-Lite.

Advanced Microcontroller Bus Architecture (AMBA)

A family of protocol specifications that describe a strategy for the interconnect. AMBA is the ARM open standard for on-chip buses. It is an on-chip bus specification that describes a strategy for the interconnection and management of functional blocks that make up a *System-on-Chip* (SoC). It aids in the development of embedded processors with one or more CPUs or signal processors and multiple peripherals. AMBA complements a reusable design methodology by defining a common backbone for SoC modules.

Advanced Peripheral Bus (APB)

A simpler bus protocol than AHB. It is designed for use with ancillary or

general-purpose peripherals such as timers, interrupt controllers, UARTs, and I/O ports. Connection to the main system bus is through a system-to-peripheral bus bridge that

helps to reduce system power consumption.

AHB See Advanced High-performance Bus.

Aligned A data item stored at an address that is divisible by the number of bytes that defines the

data size is said to be aligned. Aligned words and halfwords have addresses that are divisible by four and two respectively. The terms word-aligned and halfword-aligned

therefore stipulate addresses that are divisible by four and two respectively.

AMBA See Advanced Microcontroller Bus Architecture.

APB See Advanced Peripheral Bus.

Beat Alternative word for an individual transfer within a burst. For example, an INCR4 burst

comprises four beats.

See also Burst.

BE-8 Big-endian view of memory in a byte-invariant system.

See also BE-32, LE, Byte-invariant and Word-invariant.

BE-32 Big-endian view of memory in a word-invariant system.

See also BE-8, LE, Byte-invariant and Word-invariant.

Big-endian Byte ordering scheme in which bytes of decreasing significance in a data word are

stored at increasing addresses in memory.

See also Little-endian and Endianness.

Big-endian memory Memory in which:

 a byte or halfword at a word-aligned address is the most significant byte or halfword within the word at that address

 a byte at a halfword-aligned address is the most significant byte within the halfword at that address.

See also Little-endian memory.

Boundary scan chain

A boundary scan chain is made up of serially-connected devices that implement boundary scan technology using a standard JTAG TAP interface. Each device contains at least one TAP controller containing shift registers that form the chain connected between **TDI** and **TDO**, through which test data is shifted. Processors can contain several shift registers to enable you to access selected parts of the device.

Burst

A group of transfers to consecutive addresses. Because the addresses are consecutive, there is no requirement to supply an address for any of the transfers after the first one. This increases the speed at which the group of transfers can occur. Bursts over AMBA are controlled using signals to indicate the length of the burst and how the addresses are incremented.

See also Beat.

Byte

An 8-bit data item.

Byte lane strobe

A signal that is used for unaligned or mixed-endian data accesses to determine the byte lanes that are active in a transfer. One bit of this signal corresponds to eight bits of the data bus.

Multi-master AHB

Typically a shared, not multi-layer, AHB interconnect scheme. More than one master connects to a single AMBA AHB link. In this case, the bus is implemented with a set of full AMBA AHB master interfaces. Masters that use the AMBA AHB-Lite protocol must connect through a wrapper to supply full AMBA AHB master signals to support multi-master operation.

Endianness

Byte ordering. The scheme that determines the order that successive bytes of a data word are stored in memory. An aspect of the system's memory mapping.

See also Little-endian and Big-endian.

Little-endian

Byte ordering scheme in which bytes of increasing significance in a data word are stored at increasing addresses in memory.

See also Big-endian and Endianness.

Little-endian memory

Memory in which:

- a byte or halfword at a word-aligned address is the least significant byte or halfword within the word at that address
- a byte at a halfword-aligned address is the least significant byte within the halfword at that address.

See also Big-endian memory.

SBO See Should Be One.

SBZ See Should Be Zero.

SBZP See Should Be Zero or Preserved.

Scan chain A scan chain is made up of serially-connected devices that implement boundary scan

technology using a standard JTAG TAP interface. Each device contains at least one TAP controller containing shift registers that form the chain connected between **TDI** and **TDO**, through which test data is shifted. Processors can contain several shift registers

to enable you to access selected parts of the device.

Should Be One (SBO)

Should be written as 1 (or all 1s for bit fields) by software. Writing a 0 produces

Unpredictable results.

Should Be Zero (SBZ)

Should be written as 0 (or all 0s for bit fields) by software. Writing a 1 produces

Unpredictable results.

Should Be Zero or Preserved (SBZP)

Should be written as 0 (or all 0s for bit fields) by software, or preserved by writing the

same value back that has been previously read from the same field on the same

processor.

Unaligned A data item stored at an address that is not divisible by the number of bytes that defines

the data size is said to be unaligned. For example, a word stored at an address that is not

divisible by four.

Undefined Indicates an instruction that generates an Undefined instruction trap. See the ARM

Architecture Reference Manual for more information on ARM exceptions.

UNP *See* Unpredictable.

Unpredictable Means that the behavior of the ETM cannot be relied on. Such conditions have not been

validated. When applied to the programming of an event resource, only the output of

that event resource is Unpredictable.

Unpredictable behavior can affect the behavior of the entire system, because the ETM

is capable of causing the core to enter debug state, and external outputs can be used for

other purposes.

Unpredictable For reads, the data returned when reading from this location is unpredictable. It can have

any value. For writes, writing to this location causes unpredictable behavior, or an unpredictable change in device configuration. Unpredictable instructions must not halt

or hang the processor, or any part of the system.

Remapping

Changing the address of physical memory or devices after the application has started executing. This is typically done to permit RAM to replace ROM when the initialization has been completed.

Reserved

A field in a control register or instruction format is reserved if the field is to be defined by the implementation, or produces Unpredictable results if the contents of the field are not zero. These fields are reserved for use in future extensions of the architecture or are implementation-specific. All reserved bits not used by the implementation must be written as 0 and read as 0.

Glossary