RealView Developer Kit for Philips Nexperia Sy.Sol Installation Guide

Copyright @ 2005 ARM Limited, All rights reserved.

Release Information

The following changes have been made to this book.

 Date
 Issue
 Change

 April 2005
 B
 ReadView Developer Kit for Philips Nexperial Sy/Sol v2.2 release

Proprietary Notice

Words and logos marked with " or " are registered trademarks or trademarks owned by ARM Limited. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

http://www.arm.com

Contents

1 Supported platforms

RealView Developer Kit for Philips Nexperia Sy.Sol v2.2 is supported on computer systems running:

- Windows XP Professional
- Windows 2000

— Note —

RealView Developer Kit for Philips Nexperia Sy.Sol v2.2 uses FLEX/m license management software. See the ARM FLEX/m License Management Guide for more information.

2 Installing RealView Developer Kit for Philips Nexperia Sv.Sol

To install RealView Developer Kit for Philips Nexperia Sy.Sol v2.2:

- 1. Read the release notes for important information about this release.
- Insert the CD into the CD-ROM drive. The ARM Installer should start automatically. If it does not start, execute the program setup.exe in the top-level directory of the CD-ROM.
- 3. Follow the prompts to install RealView Developer Kit for Philips Nexperia Sy.Sol.
- 4. Choose the type of installation you require:
 - Typical installs all components of RealView Developer Kit for Philips Nexperia Sy.Sol.
 - **Custom** enables you to choose which components of RealView Developer Kit for Philips Nexperia Sy.Sol to install.
- When the software installation is complete, the ARM License Wizard is launched. If you want to defer installing a license to a later time, click Cancel. Otherwise, follow the prompts to install your license file, or to submit a license request.

2.1 Requesting upgrade licenses

Contact your supplier for details of the upgrade licenses that you can purchase. For details about installing the licenses, see the ARM FLEXIm License Management Guide.

.2 Uninstalling RealView Developer Kit for Philips Nexperia Sy.Sol

Ensure that no RealView Developer Kit for Philips Nexperia Sy.Sol component is running before you uninstall.

To uninstall RealView Developer Kit for Philips Nexperia Sy.Sol:

- 1. Select $Start \rightarrow Programs \rightarrow ARM \rightarrow Uninstallation Wizard$ to launch the ARM Uninstaller.
- 2. Follow the prompts to uninstall RealView Developer Kit for Philips Nexperia Sy.Sol.

Note	
If you are using the default Windows XP settings, select All Programs.	
-	