


SystemReady ES Test and Certification Guide

Non-Confidential Copyright © 2021 Arm Limited (or its affiliates). All rights reserved. **Issue 1.0** 102529



SystemReady ES Test and Certification Guide

Copyright © 2021 Arm Limited (or its affiliates). All rights reserved.

Release information

Document history

Issue	Date	Confidentiality	Change
1.0	18 th October 2021	Non-Confidential	First release

Non-Confidential Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

If any of the provisions contained in these terms conflict with any of the provisions of any click through or signed written agreement covering this document with Arm, then the click through or signed written agreement prevails over and supersedes the conflicting provisions of these terms. This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its affiliates) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm's trademark usage guidelines at http://www.arm.com/company/policies/trademarks.

Copyright © 2021 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

(LES-PRE-20349)

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Web Address

developer.arm.com

Inclusive terminology commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used terms that can be offensive. Arm strives to lead the industry and create change.

We believe that this document contains no offensive terms. If you find offensive terms in this document, please email **terms@arm.com**.

Contents

1 Overview	5
2 What is SystemReady certification?	6
2.1 How the SystemReady certification process works	6
3 Provide certification information	7
3.1 Submit the firmware readiness checklist	7
3.2 Submit the readiness evaluation report	7
3.3 Submit the SystemReady Certification List form	7
3.4 Requesting waivers	8
4 Test SystemReady ES compliance	9
4.1 ACS overview	9
4.1.1 BSA-ACS	10
4.1.2 BBR-ACS	10
4.2 ACS test process	11
4.3 ACS prerequisites	11
4.4 Set up the test environment	12
4.5 Run the tests	12
4.6 Run tests in automated mode	14
4.7 Run tests in normal mode	16
4.8 Review the ACS test result logs	17
5 Related information	19
/ Novt stone	20

1 Overview

This guide provides an overview of the Arm SystemReady certification and test process. By the end of this guide, you will understand the steps required to certify your system with Arm SystemReady certification in the ServerReady (SR) or Embedded Server (ES) bands.

Arm SystemReady is a set of standards and a compliance certification program that enables interoperability with generic, off the shelf operating systems and hypervisors. The Arm SystemReady certification program encompasses a broad set of devices from cloud to IoT edge.

Compliant systems that adhere to the Arm SystemReady terms and conditions are issued with a compliance certificate and can use the Arm SystemReady certified stamp logo.

The Arm SystemReady specifications consist of a generic Base System Architecture (BSA), which contains the minimum requirements to deploy an operating system. SystemReady also includes supplementary specifications, such as the Server Base System Architecture (SBSA) for the server market.

The Base Boot Requirements (BBR) specification provides boot recipes that accommodate the different standards. The specification also provides the boot firmware implementations that are used by a broader range of operating systems and hypervisors.

For more information about the Arm SystemReady certification program, see **Arm SystemReady Certification Program**.

This guide provides guidance for the SystemReady ES and SystemReady SR bands only.

2 What is SystemReady certification?

The SystemReady certification program ensures the highest possible standards for systems supporting off the shelf operating systems and hypervisors. To help you navigate the process, Arm provides the following support:

- This guide, which explains how to get SystemReady certification in a requested band.
- The Arm SystemReady Compliance team helps evaluate your system for certification, and provides feedback and guidance.
- Arm provides checklists, forms, and report templates to ensure necessary information is submitted with your certification request.
- The Arm SystemArchAC mailing list. Contact the **Arm SystemReady Certification Program** for further information.

2.1 How the SystemReady certification process works

The following steps describe the SystemReady certification process:

- 1. Sign a SystemReady Program legal agreement. The certification request goes in a certification backlog to be reviewed.
- 2. Submit a SystemReady firmware readiness checklist to the SystemReady compliance team. When you provide the system hardware and firmware, the compliance team performs a certification readiness evaluation.
- 3. Arm provides feedback, including an estimate of the effort to achieve certification, and asks you to fix any readiness issues. This step is repeated until all issues have been addressed in the firmware and the formal certification process begins.
- 4. Run ACS certification tests, including OS installs, when the compliance team indicates the system is ready for formal certification. You submit the ACS test logs with the SystemReady Readiness evaluation report, and any errata and waiver justification to Arm for review.
- 5. Arm reviews the submission and provides feedback on any issues that prevent certification. You then debug issues, make firmware fixes as necessary, respond to the failure analysis, and prepare any additional waiver requests.
- 6. Run the ACS tests again and submit the forms, logs, waiver requests, and errata to the compliance team for review. This step is repeated until all issues have been addressed. The certification request is then submitted to the Arm Architects for final review and approval. Currently, Arm sends drafts of the certification documents to you for review.
- 7. Arm marketing issues the official certificate, waivers, and certification logo when the Arm architects approve the certification.
- 8. Submit the SystemReady Compliance List (SCL) entry form so that the system can be added to the SystemReady Certification list on the Arm website.

3 Provide certification information

When you submit a request for SystemReady Certification, you must provide forms, reports, and logs to ensure the request can be evaluated. This section tells you about the information required for a certification request.

Arm provides a readiness checklist, forms, and report templates to ensure that all required inputs are provided throughout the certification process.

3.1 Submit the firmware readiness checklist

The SystemReady firmware readiness checklist is submitted before the initial certification evaluation. This checklist ensures you supply the following information:

- Company, system, and SoC information
- The SystemReady band for which you are requesting certification
- Hardware and firmware availability and U-Boot or EDK information
- Arm Base System Architecture (BSA) compliance state
- OS boot, ACS compliance, and security compliance sniff test information

3.2 Submit the readiness evaluation report

The SystemReady readiness evaluation report is submitted when you request formal certification. You must complete the following information in the report:

- General, company, and system information
- Space for the ACS logs
- An area for pictures of the system, setup, and any relevant screenshots such as the firmware boot and menus
- An overall SystemReady evaluation summary and space to report the individual ACS, UEFI sniff test, and OS boot tests

3.3 Submit the SystemReady Certification List form

The SystemReady Certification List (SCL) form is submitted after certification has been granted. The SCL form contains the information needed to list the system on the Arm SCL web page.

3.4 Requesting waivers

In some circumstances, waivers to the SystemReady standards are granted by the Arm architects and the Arm SystemReady compliance team. Waivers must be requested and justification provided when you submit the certification request.

Arm can consult with Independent Software Vendors (ISV) if necessary. If a waiver cannot be granted, feedback is provided by Arm. To develop fixes or workarounds, you can consult the silicon partner (SiP) or independent BIOS vendor (IBV). The certification request can then be resubmitted for further evaluation.

4 Test SystemReady ES compliance

The Arm SystemReady Architecture Compliance Suite (ACS) is a set of tests that ensure architectural compliance across different implementations and variants of the architecture. ACS is delivered in source form with a build environment. The output of the build is a bootable live OS image containing a collection of test suites. This output is collectively known as the BSA and BBR ACS which tests compliance against the BSA and BBR specifications for SystemReady ES certification.

Arm recommends that you sign off architectural implementations against the ACS to prove compliance with these specifications.

4.1 ACS overview

The ACS for SystemReady certification is delivered through a live OS image, which enables the basic automation to run the BSA and BBR tests. The OS image is a set of UEFI applications on UEFI shell and Linux kernel with BusyBox integrated with the Firmware Test Suite (FWTS). The FWTS is a package hosted by Canonical which provides tests for Device tree and UEFI. The FWTS test is customized to run only UEFI tests.

The following diagram shows the different ACS components:




Figure 1: ACS components

4.1.1 BSA-ACS

The BSA test suites check for compliance against the Arm Base System Architecture (BSA) specification. The tests are delivered through two suites:

- BSA tests on UEFI Shell. These tests are written on top of Validation Adaption Layers (VAL) and Platform Adaptation Layers (PAL). The abstraction layers provide the tests with platform information and runtime environment to enable execution of the tests. In Arm deliveries, the VAL and PAL are written on top of UEFI.
- BSA tests on the Linux command line. These tests consist of the Linux command-line application bsa and the kernel module bsa acs.ko.

4.1.2 BBR-ACS

The BBR test suites check compliance against the **Arm Base Boot Requirements (BBR) specification**. For SystemReady ES certification, firmware is tested against the SBBR recipe of BBR.

These tests are delivered through two bodies of code:

- SBBR tests contained in UEFI Self Certification Tests (SCT) tests. UEFI implementation requirements which are tested by SCT.
- SBBR based on FWTS. The Firmware Test Suite (FWTS) is a package hosted by Canonical that provides tests for ACPI and UEFI. The FWTS tests are customized to run only UEFI tests.

4.2 ACS test process

The following diagram shows the overall ACS test process:




Figure 2: ACS test process

4.3 ACS prerequisites

The prerequisites to run the ACS tests are as follows:

• Prepare a USB device with a minimum of 1GB of storage. This USB is used to boot and run the ACS and to store the execution results.



We recommend you use a USB disk enclosure with a fast SSD drive.

- Prepare the SUT (System Under Test) machine and a host machine
- Prepare the SUT machine with the latest firmware loaded, a host machine for console access, then collect the results

4.4 Set up the test environment

To set up the USB device, use the following procedure:

1. Download the prebuilt ACS image for SystemReady ES certification to a local directory on Linux.

The pre-built ACS image for SystemReady ES certification is available on GitHub at the following location:

```
https://github.com/ARM-software/arm-systemready/tree/main/ES/prebuilt_images/
<release tag>/es_acs_live_image.img.xz
```

For information on the latest release and release tags, see the **SystemReady ES ACS README**.

2. Uncompress and deploy the image to the USB disk.

```
Use a utility such as xz on Linux or 7-Zip on Windows to uncompress the es acs live image.img.xz file.
```

3. On the Linux host machine, write the ES ACS bootable image to the USB disk using the following commands:

```
$ lsblk
$ sudo dd if=/path/to/es_acs_live_image.img of=/dev/sdX
$ sync
```

In this code, replace /dev/sdX with the name of your USB device. Use the lsblk command to display the USB device name.

4.5 Run the tests

To execute the ACS ES prebuilt image, do the following:

- 1. Choose the **Boot from USB** option on the SoC.
- 2. Insert the USB in one of the USB slots and start a power cycle.

The live image boots and runs the ACS automatically.

The following diagrams show the complete process of ACS execution through the ES ACS live image:




Figure 3: Test execution process



To skip the debug and test steps shown in the diagram, press any key within five seconds.

As shown in the flowcharts, there are two main modes of execution:

- Fully automated mode
- Normal mode

4.6 Run tests in automated mode

If no option in GRUB is chosen and no tests are skipped, tests are run in fully automated mode.

The following screenshot shows the GRUB bootloader options screen:

Figure 4: GRUB bootloader options

After a few seconds, the image executes the ACS process in the following order:

1. SCT tests:

```
UEFI Interactive Shell v2.2
EDK II
EDK II, 0x08010000)
Mapping table
F59- Alias(s):HD0b:;BLK1:
F51- Alias(s):HD0b:;BLK1:
F51- Alias(s):HD0c:;BLK2:
PC::Roto(Ix0x):PC:(Ix0x_0.0x)/HD(1,GPT,ZD3B8E27-D82A-4BCA-8697-E7E4FACCE545,0x800,0x18FFF)
BLK4: Alias(s):
Venhw(F9B9482-8BA6-4098-9056-B98417F33G3)
BLK3: Alias(s):
Venhw(80470848-7E9C-4C0C-8EBC-DFBBAACACE8F)
BLK0: Alias(s):
PC:Noto(0x0)/Pc:(0x2_0x0)
Press ESC in 1 seconds to skip startup.nsh or any other key to continue.
Shell-cho-off
Shell-cho-off
Continue test of the EFI SCT running
Continue test preparing..
Remaining test cases: 195
Boot services test: createVentEx_Func
Iterations: 1/1
Arm ACS Version: BBRv0.8_BETA-0
CreateEventEx_Func
Revision 0x80010000
Test Intry Guillo: h9F9A263-7396-4759-8F4C-EFC686F15988
Test Support Library Guillo:
IFF2CAEF-Fight Guillo: h9F9A263-7396-4759-8F4C-EFC686F15988
Test Support Library Guillo:
IFF2CAEF-Fight Guillo: h9F9A263-7396-4759-8F4C-EFC686F15988
Test Support Library Guillo:
IFF2CAEF-Fight Guillo: h9F9A263-7396-4759-8F4C-EFC686F15988
Test Configuration #0
```

Figure 5: SCT tests

2. UEFI debug dumps:

```
UEFI Interactive Shell v2.2
EBK II
UEFI v2.70 (EDK II, 0x00010000)
Mapping table
FS9: Alias(s):HD0b:;BLK1:
        Pc:Root(0x0)/Pc1(0x2,0x0)/HD(1,GPT,2D3B8E27-DB2A-4BCA-8697-E7E4FACCE545,0x800,0xFFFFF)
FS1: Alias(s):HD0b:;BLK1:
        Pc:Root(0x0)/Pc1(0x2,0x0)/HD(2,GPT,442169C8-4535-41EE-A1BD-27E1508B4A05,0x100800,0x18FFF)
BLK1: Alias(s):
        VenHwt(F9B94AE2-BBA6-409B-9D56-B9B417F53CB3)
BLK3: Alias(s):
        VenHwt(B047DB4B-7E9C-4C0C-8EBC-DFBBAACACE8F)
BLK0: Alias(s):
        PciRoot(0x0)/Pc1(0x2,0x0)

Press ESC in 1 seconds to skip startup.nsh or any other key to continue.
Shell> echo -off
Press any key utshin 4 seconds
        (ok)
        (ok)
```

Figure 6: UEFI debug dumps

3. BSA ACS:

Figure 7: BSA ACS

4. FWTS tests:

```
Test: UFFI secure boot test.
Test aborted,
Test: Authenticated variable tests.
Authenticated variable test with the same authentica. 1 passed
Authenticated variable test with that same authentica. 1 passed
Authenticated variable test with another valid authe. 1 passed
Authenticated variable test.
Authenticated variable test.
Authenticated variable test.
Authenticated variable test.
Authenticated variable test with old authenticated v.
Delete authenticated variable test vith invalid modified data 1 passed
Authenticated variable test with invalid modified data 1 passed
Authenticated variable test with invalid modified data 1 passed
Authenticated variable test with different guid. 1 passed
Authenticated variable test with different guid. 1 passed
Set and delete authenticated variable reated by dif. 2 passed
Set and delete authenticated variable reated by dif. 2 passed
Stress test for UEFI miscellaneous runtime service interface tests.
Test of UEFI miscellaneous runtime service interface tests.
Test of UEFI miscellaneous runtime service interface tests.
Test UEFI variable info query.
UEFI variable info query.
UEFI variable info query.
UEFI variable info query.
UEFI sort passed test for UEFI Boot Path Boot###.
Test UEFI miscellaneous runtime service interface tests.
Test UEFI miscellaneous
```

Figure 8: FWTS tests

Linux BSA test:

```
Test UEFF NT ownishle services supported status. 1 skipped
Nunning Linux USB 1 ests 1

21.504[54] PE_LNYO: Nunber of PE_detected : 4

21.504[54] PE_LNYO: Nunber of PE_detected : 4

21.504[54] PE_LNYO: Nunber of PE_detected : 9

21.505[75] Perlipheral: Nun of SRIA controllers : 0

21.505[77] Ferlipheral: Nun of SRIA controllers : 0

21.505[77] Ferlipheral: Nun of URB CONTROLLER : 0

21.505[77] Ferlipheral: Nun o
```

Figure 9: Linux BSA test

After these tests are executed, the control returns to a Linux prompt.

4.7 Run tests in normal mode

When the image boots, choose one of the following GRUB options to specify the test automation:

- Linux BusyBox to boot Linux and execute FWTS and Linux BSA
- BBR or BSA to execute the tests in the same sequence as fully automated mode



You can also skip individual test stages by pressing a key at the appropriate point, as shown in the process flowcharts above.

4.8 Review the ACS test result logs

The logs are stored in a separate partition within the image called acs-results.

The following diagram shows the logs directory structure:




Figure 10: ACS results directory

After the tests finish, the acs_results results partition is mounted on /mnt. Navigate to acs_results to view the logs.

Extract the logs from the USB disk to view the logs on the host machine later.

After mounting the acs_results directory, check that the logs shown in the following table were generated:

Log number	ACS	Path	Running time	Notes
1	BSA (UEFI)	acs_results/uefi/BsaResults.log	Less than 2 minutes	
2	BSA (Linux)	<pre>acs_results/uefi/BsaResults.log acs_results/linux/BsaResultsKernel.log</pre>	Less than 2 minutes	
3	SCT	acs_results/sct_results/Summary.log	1-6 hours Note: To execute SCT tests faster, use an SSD in a USB enclosure	Summary.log contains the summary of all tests run. Individual SCT test suite logs are in the same path.
4	FWTS	acs_results/fwts/results.log	Less than 2 minutes	
5	Debug Dumps	<pre>acs_results/linux_dumps acs_results/uefi_dumps</pre>	Less than 2 minutes	Contains output from commands including: acpiview, smbiosview, lspci, drivers, devices, and memmap.

If any logs are missing, run the suite manually and report the error to your Arm Certification Partner.

Mount the RESULT partition to copy the logs to a local directory, then submit the logs in the acs results directory in the RESULT partition to your Arm Certification Partner.

5 Related information

Here are some resources related to material in this guide:

- Base System Architecture (BSA) specification
- Arm Base Boot Requirements
- Arm Community
- Arm SystemReady Certification Program
- Arm SystemReady Requirements Specification
- Introduction to SystemReady
- SystemReady IR

The following GitHub repositories are related to this guide:

- arm-systemready repository
- bsa-acs repository
- Arm Base System Architecture Compliance User Guide
- Arm Base System Architecture Compliance Validation Methodology

6 Next steps

In this guide, you learned how to prepare for SystemReady certification and perform the tasks needed for the compliance program.

At the end of the guide, you are ready to follow the process to certify your system as compliant with the Arm SystemReady specifications in the SR (ServerReady) or ES (Embedded Server) bands. You know how to run the ACS tests and submit the required forms, logs, waiver requests, and errata to the compliance team for review.

For more information about certification registration, go to Arm SystemReady Certification Program.

For support, please send an email to support-systemready-acs@arm.com.