AMBA CXS Protocol Specification



AMBA CXS

Protocol Specification

Copyright © 2018-2023 Arm Limited or its affiliates. All rights reserved.

Release Information

The following changes have been made to this specification.

Change history

Date	Issue	Confidentiality	Change
12 March 2018	A	Non-Confidential	First release
18 December 2020	В	Non-Confidential	 Support for multiple protocol streams Extension to interface protection signaling to support new signals Clarification of continuous delivery guarantees
21 November 2023	С	Non-Confidential	Support for a packetless CXS interface

Proprietary Notice

This document is **NON-CONFIDENTIAL** and any use by you is subject to the terms of this notice and the Arm AMBA Specification Licence set about below.

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with * or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm's trademark usage guidelines at http://www.arm.com/company/policies/trademarks.

Copyright © 2018-2023 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England. 110 Fulbourn Road, Cambridge, England CB1 9NJ. LES-PRE-21451 version 2.2

AMBA SPECIFICATION LICENCE

THIS END USER LICENCE AGREEMENT ("LICENCE") IS A LEGAL AGREEMENT BETWEEN YOU (EITHER A SINGLE INDIVIDUAL, OR SINGLE LEGAL ENTITY) AND ARM LIMITED ("ARM") FOR THE USE OF ARM'S INTELLECTUAL PROPERTY (INCLUDING, WITHOUT LIMITATION, ANY COPYRIGHT) IN THE RELEVANT AMBA SPECIFICATION ACCOMPANYING THIS LICENCE. ARM LICENSES THE RELEVANT AMBA SPECIFICATION TO YOU ON CONDITION THAT YOU ACCEPT ALL OF THE TERMS IN THIS LICENCE. BY CLICKING "I AGREE" OR OTHERWISE USING OR COPYING THE RELEVANT AMBA SPECIFICATION YOU INDICATE THAT YOU AGREE TO BE BOUND BY ALL THE TERMS OF THIS LICENCE.

"LICENSEE" means You and your Subsidiaries.

"Subsidiary" means, if You are a single entity, any company the majority of whose voting shares is now or hereafter owned or controlled, directly or indirectly, by You. A company shall be a Subsidiary only for the period during which such control exists.

- Subject to the provisions of Clauses 2, 3 and 4, Arm hereby grants to LICENSEE a perpetual, non-exclusive, non-transferable, royalty free, worldwide licence to:
 - (i) use and copy the relevant AMBA Specification for the purpose of developing and having developed products that comply with the relevant AMBA Specification;
 - (ii) manufacture and have manufactured products which either: (a) have been created by or for LICENSEE under the licence granted in Clause 1(i); or (b) incorporate a product(s) which has been created by a third party(s) under a licence granted by Arm in Clause 1(i) of such third party's AMBA Specification Licence; and
 - (iii) offer to sell, supply or otherwise distribute products which have either been (a) created by or for LICENSEE under the licence granted in Clause 1(i); or (b) manufactured by or for LICENSEE under the licence granted in Clause 1(ii).
- 2. LICENSEE hereby agrees that the licence granted in Clause 1 is subject to the following restrictions:
 - (i) where a product created under Clause 1(i) is an integrated circuit which includes a CPU then either: (a) such CPU shall only be manufactured under licence from Arm; or (b) such CPU is neither substantially compliant with nor marketed as being compliant with the Arm instruction sets licensed by Arm from time to time;
 - (ii) the licences granted in Clause 1(iii) shall not extend to any portion or function of a product that is not itself compliant with part of the relevant AMBA Specification; and
 - (iii) no right is granted to LICENSEE to sublicense the rights granted to LICENSEE under this Agreement.
- 3. Except as specifically licensed in accordance with Clause 1, LICENSEE acquires no right, title or interest in any Arm technology or any intellectual property embodied therein. In no event shall the licences granted in accordance with Clause 1 be construed as granting LICENSEE, expressly or by implication, estoppel or otherwise, a licence to use any Arm technology except the relevant AMBA Specification.
- 4. THE RELEVANT AMBA SPECIFICATION IS PROVIDED "AS IS" WITH NO REPRESENTATION OR WARRANTIES EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF SATISFACTORY QUALITY, MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT ANY USE OR IMPLEMENTATION OF SUCH ARM TECHNOLOGY WILL NOT INFRINGE ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
- 5. NOTWITHSTANDING ANYTHING TO THE CONTRARY CONTAINED IN THIS AGREEMENT, TO THE FULLEST EXTENT PETMITTED BY LAW, THE MAXIMUM LIABILITY OF ARM IN AGGREGATE FOR ALL CLAIMS MADE AGAINST ARM, IN CONTRACT, TORT OR OTHERWISE, IN CONNECTION WITH THE SUBJECT MATTER OF THIS AGREEMENT (INCLUDING WITHOUT LIMITATION (I) LICENSEE'S USE OF THE ARM TECHNOLOGY; AND (II) THE IMPLEMENTATION OF THE ARM TECHNOLOGY IN ANY PRODUCT CREATED BY LICENSEE UNDER THIS AGREEMENT) SHALL NOT EXCEED THE FEES PAID (IF ANY) BY LICENSEE TO ARM UNDER THIS AGREEMENT. THE EXISTENCE OF MORE THAN ONE CLAIM OR SUIT WILL NOT ENLARGE OR EXTEND THE LIMIT. LICENSEE RELEASES ARM FROM ALL OBLIGATIONS, LIABILITY, CLAIMS OR DEMANDS IN EXCESS OF THIS LIMITATION.
- 6. No licence, express, implied or otherwise, is granted to LICENSEE, under the provisions of Clause 1, to use the Arm tradename, or AMBA trademark in connection with the relevant AMBA Specification or any products based thereon. Nothing in Clause 1 shall be construed as authority for LICENSEE to make any representations on behalf of Arm in respect of the relevant AMBA Specification.
- 7. This Licence shall remain in force until terminated by you or by Arm. Without prejudice to any of its other rights if LICENSEE is in breach of any of the terms and conditions of this Licence then Arm may terminate this Licence immediately upon giving written notice to You. You may terminate this Licence at any time. Upon expiry or termination

of this Licence by You or by Arm LICENSEE shall stop using the relevant AMBA Specification and destroy all copies of the relevant AMBA Specification in your possession together with all documentation and related materials. Upon expiry or termination of this Licence, the provisions of clauses 6 and 7 shall survive.

8. The validity, construction and performance of this Agreement shall be governed by English Law.

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

http://www.arm.com

Contents

AMBA CXS Protocol Specification

	Pref	ace	
		About this specification	viii
		Additional reading	X
		Feedback on this specification	xi
Chapter 1	Intro	oduction	
-	1.1	About the CXS streaming interface protocol	1-14
	1.2	Use case	1-15
Chapter 2	cxs	operation Soperation	
	2.1	Protocol operation	2-18
	2.2	CXS interface properties	2-21
	2.3	Support for contiguous packets	2-24
	2.4	Support for multiple protocol streams	2-25
Chapter 3	Sign	nal descriptions	
-	3.1	Mandatory and optional CXS signals	3-28
	3.2	CXS interface checking signals	
Chapter 4	cxs	5 packets	
-	4.1	Packet position constraints	4-32
	4.2	Packet control signal	4-33
	4.3	Packet size constraints	
	4.4	Packet examples	4-38
Chapter 5	cxs	interface activation and deactivation	
-	5.1	Interface control with explicit credit return	5-44
	5.2	Request and acknowledgment handshaking	

Appendix A	Revisions	
	6.1 Continuous delivery guarantees for CXS packets	6-54
Chapter 6	CXS packet continuous delivery guarantees	
	5.6 Interface activation and deactivation examples	5-51
	5.5 Timing relationships between data and link control signals	5-50
	5.4 Race conditions	5-49
	5.3 Response to a new state	5-48

Preface

This preface introduces the AMBA Credited eXtensible Stream (CXS) protocol Specification.

It contains the following sections:

- About this specification on page viii
- Using this specification on page viii
- Additional reading on page x
- Feedback on this specification on page xi

About this specification

This specification describes the CXS streaming interface protocol. The protocol is designed for point-to-point packetized communication that can support sharing a common CXS link between different protocols.

Intended audience

This specification is written for hardware and software engineers who want to design or debug systems and modules that are compatible with the CXS protocol.

Using this specification

This specification is organized into the following chapters:

Chapter 1 Introduction

Introduces the AMBA Credited eXtensible Stream (CXS) protocol.

Chapter 2 CXS operation

Provides an overview of the CXS protocol operations and the properties that describe the configuration of a CXS interface.

Chapter 3 Signal descriptions

Describes the signal requirements of the CXS interface.

Chapter 4 CXS packets

Describes the CXS packet control field structure, packet control signals, and packets examples.

Chapter 5 CXS interface activation and deactivation

Describes the activation and deactivation mechanisms for a CXS interface.

Chapter 6 CXS packet continuous delivery guarantees

Provides information on CXS packet continuous delivery guarantee.

Appendix A Revisions

Information about the technical changes between released issues of this specification.

Conventions

The following sections describe conventions that this specification can use:

- Typographic conventions
- Signals on page ix
- Numbers on page ix
- Signal Representations on page ix

Typographic conventions

The typographical conventions are:

italic Highlights important notes, introduces special terminology, and indicates internal

cross-references and citations.

bold Denotes signal names, and is used for terms in descriptive lists, where appropriate.

monospace Used for assembler syntax descriptions, pseudocode, and source code examples.

Also used in the main text for instruction mnemonics and for references to other items appearing in assembler syntax descriptions, pseudocode, and source code examples.

SMALL CAPITALS Used for a few terms that have specific technical meanings.

Signals

The signal conventions are:

Signal level The level of an asserted signal depends on whether the signal is active-HIGH or

active-LOW. Asserted means:

• HIGH for active-HIGH signals

• LOW for active-LOW signals

Lowercase n At the start or end of a signal name denotes an active-LOW signal.

Lowercase x At the second letter of a signal name denotes a collective term for both Read and Write.

Numbers

Numbers are normally written in decimal. Binary numbers are preceded by 0b, and hexadecimal numbers by 0x. In both cases, the prefix and the associated value are written in a monospace font, for example, 0xFFFF0000.

Signal Representations

Signal Representations shows the various signal types used in the information flow diagrams in this specification.

Unidirectional signal

Bidirectional signal

Unidirectional bus

Bidirectional bus

Signal Representations

Additional reading

This section lists relevant publications from Arm. See Arm Developer, https://developer.arm.com/documentation for access to Arm documentation.

Arm publications

• AMBA® CXS Protocol Specification, Issue B

Other publications

This section lists relevant documents published by third parties:

- PCI Express Base Specification http://www.pcisig.com
- CCIX specification https://www.ccixconsortium.com
- CXL Specification https://www.computeexpresslink.org

Feedback on this specification

If you have any comments or suggestions for additions and improvements, create a ticket at https://support.developer.arm.com. As part of the ticket, please include:

- The title, AMBA CXS Protocol Specification
- The number, ARM IHI 0079C
- The page number(s) that your comments apply

any document when viewed with any other PDF reader.

• A concise explanation of your comments

— Note —						
Arm tests PDFs only	y in Adobe Acrobat and	Acrobat Reader,	and cannot	guarantee the	appearance or	behavior of

Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used terms that can be offensive.

Arm strives to lead the industry and create change. Previous issues of this document included terms that can be offensive. We have replaced these terms.

If you find offensive terms in this document, please contact terms@arm.com.

Preface Feedback on this specification

Chapter 1 **Introduction**

This chapter introduces the CXS protocol:

- About the CXS streaming interface protocol on page 1-14
- *Use case* on page 1-15

1.1 About the CXS streaming interface protocol

This specification describes the Credited eXtensible Stream (CXS) streaming interface protocol. The CXS protocol can be used for any point-to-point packetized communication, specifically optimized for wide interfaces. Wide interface optimization means that the protocol can be used to pass packets to a high data rate external interface. The availability of a wide interface permits merging of multiple packets into a single transfer.

1.2 Use case

The primary use case for a CXS interface is to transport packets between an on-chip interconnect and PCIe controller. Data transfer in CXS is unidirectional, so it is typical to have a pair of CXS interfaces between communicating blocks. Figure 1-1 shows a typical implementation of CXS that transports both CCIX and CXL packets on both of the CXS interfaces.




Figure 1-1 Typical implementation of CXS

1 Introduction 1.2 Use case

Chapter 2 CXS operation

This chapter gives an overview of the operation of the CXS protocol and the properties that describe the configuration of a CXS interface. It contains the following sections:

- Protocol operation on page 2-18
- CXS interface properties on page 2-21

2.1 Protocol operation

A single instance of the interface has one Transmitter (TX) connected to one Receiver (RX). The data is sent in one direction. The data that is transferred in one cycle is known as a flit. A packet can occupy one or more flits.

Table 2-1 shows the mandatory signals of the interface.

Table 2-1 CXS mandatory signals

Name	Direction	Description
CLK	External	External Clock signal.
RESETn	External	External Reset signal.
CXSVALID	Transmitter to Receiver	Indicates that valid information is being passed this cycle.
CXSDATA	Transmitter to Receiver	The flit data containing the packet bytes being transmitted. Not applicable and recommended to be zero when CXSVALID is deasserted.
CXSCNTL	Transmitter to Receiver	Control information for identifying the start and end of packets within the data field. Not applicable when CXSVALID is deasserted.
CXSCRDGNT	Receiver to Transmitter	Flow control information indicating that the Receiver can accept one flit of data.

2.1.1 Clock and reset

The following rules apply to the clock and reset:

- All input signals are sampled on the rising edge of CLK.
- All output signal changes can only occur after the rising edge of CLK.
- There must be no combinatorial paths between input and output signals on an interface.
- The reset signal RESETn is active-LOW and can be asserted asynchronously, but deassertion can only be synchronous with a rising edge of CLK.
- During reset the following control signals, if present, must be deasserted:
 - CXSVALID
 - CXSCRDGNT
 - CXSCRDRTN
 - CXSACTIVEREQ
 - CXSACTIVEACK
 - CXSDEACTHINT
- During reset all credits are assumed to be at the receiver end of the link.
- The earliest point after reset that a receiver is permitted assert any control signals is after a rising CLK edge when RESETn is HIGH.

2.1.2 Credit exchange mechanism

The Transmitter transfers data by driving **CXSDATA**, placing packet control information on **CXSCNTL**, and asserting the **CXSVALID** signal. See *Packet examples* on page 4-38 for more details.

Flow control on the interface is implemented through a credit exchange mechanism. The rules of the credit mechanism are:

- Data can only be sent when the Transmitter has at least one credit from the Receiver.
- When the interface is reset or first activated, the Transmitter has no credits and therefore cannot send data across the interface.
- Credits are transferred to the Transmitter using the **CXSCRDGNT** signal.
- When the CXSCRDGNT signal is asserted, one credit is transferred to the Transmitter every cycle. Each
 credit permits one flit of data transfer.
- The Receiver must guarantee that it can receive one flit of data for each credit that it grants.
- The Transmitter sends one flit of data for each cycle when the CXSVALID signal is asserted, which
 consumes one credit.
- The maximum number of credits that a Receiver can grant a Transmitter is specified using the CXS MAX CREDIT property.
 - If the interface is configurable, the Transmitter must be able to track up to CXS_MAX_CREDIT number of credits.
 - If the interface is not configurable, the Transmitter must be able to track 15 credits.
- A Transmitter cannot use a credit to send a flit until the cycle after the CXSCRDGNT signal is asserted. This
 specification recommends against a combinational path between the CXSCRDGNT and CXSVALID
 signals.
- Optionally, credits can be returned to the Receiver without a flit transfer, using the CXSCRDRTN signal.
 When the CXSCRDRTN signal is asserted, one credit is returned to the Receiver every cycle. The
 CXSCRDRTN and CXSVALID signals must not be asserted in the same cycle. See *Interface control with*explicit credit return on page 5-44 for more details.
- A Receiver cannot reuse a consumed or returned credit until the cycle after the CXSVALID signal or the CXSCRDRTN signal is asserted. This specification recommends against having a combinational path between the CXSVALID and CXSCRDGNT signals, or between the CXSCRDRTN and CXSCRDGNT signals.
- If the Transmitter receives a credit in the same cycle that it returns or uses a credit, the number of available credits does not change.

This specification expects that most Receivers have sufficient storage to issue multiple credits to the Transmitter. The number of credits that are required to keep the interface flowing at full bandwidth depends on the credit latency. Credit latency is the number of cycles between the Receiver issuing a credit and that credit being reissued after being returned by the Transmitter. If the number of credits the Receiver can issue is greater than or equal to the credit latency, then the interface can sustain one flit per cycle.

This specification defines signal names for a CXS connection. Port names can be differentiated by adding TX or RX into the name after the CXS designation. Figure 2-1 on page 2-20 shows an example of a pair of CXS links between two components.




Figure 2-1 CXS connection example

An example of flit transfers on a channel is shown in Figure 2-2. In this example, the receiver has two credits available.

- At reset, the transmitter has no credits.
- One credit is issued by the receiver at b and a second one in the next cycle.
- One credit is used by the transmitter at c to transfer flit fl and one is used to transfer flit f2 in the next cycle. A credit is reissued by the receiver at d.




Figure 2-2 An example of flit transfers on a channel

2.2 CXS interface properties

A CXS interface is configured for a particular application by setting properties. Table 2-2 describes the properties and their options.

Table 2-2 Interface properties

Property	Options	Default	Description and rules		
CXS_LAST	True, False	False	Used to indica	licate support for the flit insertion indicator.	
			True	The link interface includes the CXSLAST signal.	
			False	The link interface does not include the CXSLAST signal.	
CXS_MAX_CREDIT	1-63	15	Specifies the rissue.	naximum number of credits that the Receiver can	
CXS_MAX_CREDIT_LATENCY	1-16	-	Receiver:	Specifies the maximum number of cycles before a credit is re-used, from the CXSVALID signal HIGH to the CXSCRDGNT signal HIGH.	
			Transmitter:	Specifies the maximum number of cycles before a credit is used when it has flits to send, from the CXSCRDGNT signal to the CXSVALID signal.	
CXS_PROTOCOL_TYPE	True, False	False Used to indicate support for the p		ate support for the protocol type indicator:	
			True	The link interface includes the CXSPRCLTYPE signal.	
			False	The link interface does not include the CXSPRCLTYPE signal.	
				COL_TYPE must be False when TPERFLIT =1.	
CXSCHECKTYPE	None,	None	Integrity check	king on the CXS interface.	
	Odd_Byte_Parity		None:	No signals for integrity checking.	
			Odd_Byte_Pa	arity:	
				Odd parity error detection signals included with a nominal granularity of one byte. See section <i>CXS interface checking signals</i> on page 3-29.	
CXSCONTINUOUSDATA	True, False	False	Receiver:	If set to True, the Receiver requires that after a packet is started, it is completed in consecutive cycles if enough credits are available.	
			Transmitter:	-	
CXSDATAFLITWIDTH	82048	256	Width of the CXSDATA signal in bits. CXSDATAFLITWIDTH must be a multiple of 8.		

Table 2-2 Interface properties (continued)

Property	Options True, False	Default False	Description and rules		
CXSERRORFULLPKT ^a			Receiver:	If set to True, the Receiver requires that the length of every packet matches the packet length that is specified in the packet header. This includes packets that end with EndError.	
			Transmitter:	If set to True, the Transmitter sends the number of bytes specified in the packet header, even if this packet ends with an EndError indication.	
CXSLINKCONTROL	None,	None	None:	Interface has no link control signals.	
	Explicit_Credit_		Explicit_Cred	lit_Return:	
	Return			The interface includes the following signals:	
				 CXSACTIVEREQ 	
				• CXSACTIVEACK	
				• CXSDEACTHINT	
			• CXSCRDRTN control with explicit credit return on page 5-44 for		
CXSMAXPKTPERFLIT	1, 2, 3, 4	1, 2, 3, 4 2		Maximum number of packets that can be present in a single fli of data.	
			When CXSMAXPKTPERFLIT is greater than 1, CXSDATAFLITWIDTH must be 256, 512, or 1024. CXSMAXPKTPERFLIT must be 1 or 2 if CXSDATAFLITWIDTH is 256, When CXSMAXPKTPERFLIT is 1:		
			• CXSCNTLWIDTH must be 0.		
			• CXS LAST must be False.		
			 CXS_PROTOCOL_TYPE must be False. 		
			• CXSCONTINOUSDATA must be False.		
			packet which	AXPKTPERFLIT = 1, every flit has exactly one occupies all byte lanes. It is useful for the CXS nat do not use packets or have a fixed packet size.	

a. The encoding of the packet length within the packet is outside of the scope of the CXS document. For use of this interface for CCIX packet transmission, see the CCIX specification for packet length encoding.

Parameters can be set independently for the Transmitter and the Receiver. When assembling a system, the parameters for connected Transmitter and Receiver interfaces must be compatible. The compatibility requirements for each of the defined properties are shown in Table 2-3.

Table 2-3 Property compatibility requirements

Parameter	Compatibility requirement		
CXSCHECKTYPE	Transmitter and Receiver must match.		
CXSCONTINUOUSDATA	If Receiver CXSCONTINUOUSDATA = True, then Transmitter CXSCONTINUOUSDATA must be True.		
CXSDATAFLITWIDTH	Transmitter and Receiver must match.		

Table 2-3 Property compatibility requirements (continued)

Parameter	Compatibility requirement
CXSERRORFULLPKT	If Receiver CXSERRORFULLPKT = True, then Transmitter CXSERRORFULLPKT must be True.
CXSLINKCONTROL	Transmitter and Receiver must match.
CXSMAXPKTPERFLIT	Transmitter must be less than or equal to Receiver.

2.3 Support for contiguous packets

The CXS protocol supports the transport of packets, which must remain together after passing through different layers of the communication stack.

The CXSLAST signal indicates when flits, such as data link layer information, can be inserted between the protocol layer packets. When the CXSLAST signal is deasserted, the Receiver must expect additional packets from the Transmitter and must not insert packets from another source.

The **CXSLAST** signal is defined in Table 2-4.

Table 2-4 CXSLAST signal definition

Signal	Width	Direction	Description
CXSLAST	1	Transmitter to Receiver	Indicates that flits can be inserted after this cycle.

CXSLAST must be deasserted when:

- The following packet must remain after the current packet.
- When there is an incomplete packet in the current cycle. In other words, a packet has already started, but not
 ended in the current cycle.

If CXSLAST is not present, it is assumed to be asserted, unless a packet has been started, but not ended, in the current flit.

The CXS_LAST property is used to indicate that a link interface supports contiguous packets. CXS_LAST can have the following values:

True The interface includes the CXSLAST signal.

False The interface does not include the CXSLAST signal.

If the CXS_LAST property is not declared, it is considered False.

2.4 Support for multiple protocol streams

This specification enables sharing a CXS link, where packets carrying different protocols can be transmitted on the same link.

CXSPRCLTYPE is an optional signal that indicates the protocol type of a flit.

The **CXSPRCLTYPE** signal is defined in Table 2-5.

Table 2-5 CXSPRCLTYPE signal definition

Signal	Width	Direction	Description	
CXSPRCLTYPE	3	Transmitter to Receiver	Indicates the obood obood Other	ne protocol type of a flit, encoded as: Protocol Type 0 Protocol Type 1 Reserved

The following rules apply when interleaving packets from different protocols on a CXS link:

- A CXS packet that is transported using multiple flits must use the same protocol type for each flit.
- Where a flit contains more than one packet, each must have the same protocol type.
- If CXSCONTINUOUSDATA is False, flits with different protocol types can be interleaved on any cycle.
- If CXSCONTINUOUSDATA is True, the protocol type can only change after the CXSLAST signal is asserted.

The CXS_PROTOCOL_TYPE property is used to indicate that a link interface supports the protocol type indicator, it can have the following values:

True The interface includes the CXSPRCLTYPE signal.

False The interface does not include the CXSPRCLTYPE signal.

If the CXS_PROTOCOL_TYPE property is not declared, it is considered False. CXS_PROTOCOL_TYPE must be False when CXSMAXPKTPERFLIT =1.

Chapter 3 **Signal descriptions**

This chapter describes the signal requirements of the CXS interface. It contains the following section:

• Mandatory and optional CXS signals on page 3-28

3.1 Mandatory and optional CXS signals

Table 3-1 shows the mandatory and optional signals on a CXS interface.

Table 3-1 CXS interface signals

Signal	Width	Optional	Property	Description
CLK	1	-	-	External Clock signal.
RESETn	1	-	-	External Reset signal.
CXSVALID	1	-	-	Current cycle has a valid data flit.
CXSDATA	82048	-	CXSDATAFLITWIDTH	Data bytes being transmitted.
CXSCNTL	0, 14, 18, 22, 27, 33, 36, or 44. Depends on CXSMAXPKTPERFLIT and CXSDATAFLITWIDTH. See Table 4-2 on page 4-34.	-	CXSCNTLWIDTH	Information on packet start, end, and errors. If CXSCNTLWIDTH is 0, CXSCNTL is not present on the interface.
CXSLAST	1	Y	CXS_LAST	Indicates that flits can be inserted into the stream after this cycle.
CXSPRCLTYPE	3	Y	CXS_PROTOCOL_TYPE	Indicates the protocol type of the flit.
CXSCRDGNT	1	-	-	Grants a single credit to Transmitter.
CXSCRDRTN	1	Y	CXSLINKCONTROL	Returns a single credit to Receiver.
CXSACTIVEREQ	1	Y	CXSLINKCONTROL	Link activation or deactivation request.
CXSACTIVEACK	1	Y	CXSLINKCONTROL	Link activation or deactivation acknowledge.
CXSDEACTHINT	1	Y	CXSLINKCONTROL	Indicates Receiver wants the link deactivated.

3.2 CXS interface checking signals

If the CXSCHECKTYPE property is set to Odd_Byte_Parity, the interface has additional signals, which can be used to improve the integrity of the interface.

Odd_Byte_Parity describes an error detection scheme where check bits are added such that the total count of 1s across the signal and check bits is an odd number. In this scheme, signals wider than 8 bits have one bit added per byte. If the signal width is not divisible by 8, then the most significant parity bit covers less than 8 bits. For example, when CXSCNTL is 27 bits wide, CXSCNTLCHK[3] covers CXSCNTL[26:24].

Single bit control signals have one odd parity bit, so are effectively duplicated with an inverted signal.

Table 3-2 shows the check signals that are included if the CXSCHECKTYPE property is set to Odd_Byte_Parity. If the corresponding signal is not present on the interface, then the check signal is not present either.

Table 3-2 Check signal widths (bits)

Signal	Check signal	Signal width	Check signal width
CXSVALID	CXSVALIDCHK	1	1
CXSDATA	CXSDATACHK	CXSDATAFLITWIDTH	CXSDATAFLITWIDTH/8
CXSCNTL	CXSCNTLCHK	14	2
		18	3
		22	3
		27	4
		33	5
		36	5
		44	6
CXSLAST	CXSLASTCHK	1	1
CXSPRCLTYPE	CXSPRCLTYPECHK	3	1
CXSCRDGNT	CXSCRDGNTCHK	1	1
CXSCRDRTN	CXSCRDRTNCHK	1	1
CXSACTIVEREQ	CXSACTIVEREQCHK	1	1
CXSACTIVEACK	CXSACTIVEACKCHK	1	1
CXSDEACTHINT	N/A	1	-

3 Signal descriptions 3.2 CXS interface checking signals

Chapter 4 CXS packets

The data that is transmitted on the CXS interface is organized into packets. When the property CXSMAXPKTPERFLIT is greater than 1, there can be multiple packets per flit. This chapter describes how multiple packets are packed into a CXS flit. In CCIX or PCIe terminology, this is a Transaction Layer Packet (TLP).

The CXS packets are described in the following sections:

- Packet position constraints on page 4-32
- Packet control signal on page 4-33
- Packet size constraints on page 4-37
- Packet examples on page 4-38

4.1 Packet position constraints

CXSMAXPKTPERFLIT specifies the maximum number of packets that can have bytes in a flit. There can be up to CXSMAXPKTPERFLIT new packets starting in a flit, and up to CXSMAXPKTPERFLIT packets ending in a flit. This defines the maximum packets per flit, including any packet started in previous flits and any packet started in this flit which will be completed in subsequent flits.

CXS places restrictions on the placement of packets within each flit of data to simplify data path implementation:

When CXSMAXPKTPERFLIT is 1:

- Packets start on the first byte of CXSDATA.
- Packets end on the last byte of CXSDATA.
- Packets do not span across multiple flits.

When CXSMAXPKTPERFLIT is greater than 1:

- The first byte of a packet must be placed on an aligned 16-byte boundary.
- Subsequent bytes of the packet occupy subsequent bytes of the flit.
- Packets can end on any four-byte aligned boundary.
- The packet that starts at a byte position will occupy every subsequent byte in that flit until the packet ends or the flit ends.
- If there are remaining bytes in the packet when the flit ends, that packet will start at byte[0] of the next flit and occupy every subsequent byte position until the packet ends or the flit ends.
- When a packet ends within a flit, the remaining bytes in the flit can be unused.
- Any packet in a flit must begin at the first available 16-byte boundary relative to the start of the flit or the ending of a previous packet.

4.2 Packet control signal

The control fields of a CXS packet are signaled using **CXSCNTL**. This section describes the fields and positioning within the **CXSCNTL** signal.

4.2.1 Packet control fields

The **CXSCNTL** signal contains five fields. The widths of each field, and therefore the bit position of each field, vary with the properties of the interface. The fields are described in Table 4-1.

Table 4-1 Packet control fields

Field	Description		
START	Each bit in START indicates that a packet is starting in this flit. The number of bits in START is CXSMAXPKTPERFLIT, which is the number of packets that can be present in a flit of data. For example, when CXSMAXPKTPERFLIT = 4, then: START[0] = 1, at least one packet is starting in this flit. START[1] = 1, at least two packets are starting in this flit. START[2] = 1, at least three packets are starting in this flit. START[3] = 1, at least four packets are starting in this flit. If any bit of START is 1, all lower bits of START must be 1.		
START[N:0]PTR	 This field is an array of pointers to the starting location of each of the packets in this flit. There is one pointer for each bit in the START field, valid if that bit of START is set. If the corresponding START bit is 0, the pointer can have any value and should be ignored. All packet starts are 16-byte aligned. The width of each pointer is log₂(CXSDATAFLITWIDTH/128) bits. The first byte of the Nth starting packet is (START[N]PTR << 4). Start pointers are defined to be monotonically increasing, for example START1PTR must be greater than START0PTR. 		

Table 4-1 Packet control fields (continued)

Field	Description			
END	Each bit in END indicates that a packet is ending in this flit.			
	The number of bits in END is CXSMAXPKTPERFLIT, which is the number of packets that can be present in a flit of data. For example, when CXSMAXPKTPERFLIT = 4, then:			
	• END[0] = 1, at least one packet is ending in this flit.			
	• END[1] = 1, at least two packets are ending in this flit.			
	• END[2] = 1, at least three packets are ending in this flit.			
	• END[3] = 1, at least four packets are ending in this flit.			
	If any bit of END is 1, all lower bits of END must be 1.			
ENDERROR	Each bit in ENDERROR indicates that a packet is ending with an error condition in this flit.			
	• ENDERROR[0] = 1, the first packet ending this cycle has an error.			
	• ENDERROR [1] = 1, the second packet ending this cycle has an error.			
	• ENDERROR [2] = 1, the third packet ending this cycle has an error.			
	• ENDERROR [3] = 1, the fourth packet ending this cycle has an error.			
	The number of bits in ENDERROR is the number of bits in END .			
	If ENDERROR[N] is asserted, END[N] must be asserted.			
END[N:0]PTR	This field is an array of pointers to the last 4 bytes of packets ending in this flit.			
	• There is one pointer for each END bit, valid only if that END bit is set.			
	• If the corresponding END bit is 0, the pointer can have any value and should be ignored.			
	All packet ends are 4-byte aligned.			
	• The width of each pointer is log ₂ (CXSDATAFLITWIDTH/32) bits.			
	• Each end pointer points to the first byte of the last aligned 4 bytes of the packet.			
	• The last byte of the N th ending packet is therefore ((END [N] PTR << 2)+3).			
	 Valid end pointers are defined to be monotonically increasing, for example if two packets en in this flit then END1PTR must be greater than END0PTR. 			
	—— Note ———			
	START [N] PTR and END [N] PTR might not point to the same packet, for example if a packet started in a previous flit.			

4.2.2 Packet control field structure

Table 4-2 shows Packet control field widths and placement information for all combinations of CXSMAXPKTPERFLIT and CXSDATAFLITWIDTH. See *Packet examples* on page 4-38 for illustrations of how these structures are used.

Table 4-2 Packet control field widths and placement

CXSMAXPKTPERFLIT	CXSDATAFLITWIDTH	Width of CXSCNTL	Field	Bit positions in CXSCNTL
1	Any	0	-	-
2	256	14	START[1:0]	CXSCNTL[1:0]
			START0PTR[0]	CXSCNTL[2]
			START1PTR[0]	CXSCNTL[3]
			END[1:0]	CXSCNTL[5:4]
			ENDERROR[1:0]	CXSCNTL[7:6]
			END0PTR[2:0]	CXSCNTL[10:8]
			END1PTR[2:0]	CXSCNTL[13:11]

Table 4-2 Packet control field widths and placement (continued)

CXSMAXPKTPERFLIT	CXSDATAFLITWIDTH	Width of CXSCNTL	Field	Bit positions in CXSCNTL
2	512	18	START[1:0]	CXSCNTL[1:0]
			START0PTR[1:0]	CXSCNTL[3:2]
			START1PTR[1:0]	CXSCNTL[5:4]
			END[1:0]	CXSCNTL[7:6]
			ENDERROR[1:0]	CXSCNTL[9:8]
			END0PTR[3:0]	CXSCNTL[13:10]
			END1PTR[3:0]	CXSCNTL[17:14]
2	1024	22	START[1:0]	CXSCNTL[1:0]
			START0PTR[2:0]	CXSCNTL[4:2]
			START1PTR[2:0]	CXSCNTL[7:5]
			END[1:0]	CXSCNTL[9:8]
			ENDERROR[1:0]	CXSCNTL[11:10]
			END0PTR[4:0]	CXSCNTL[16:12]
			END1PTR[4:0]	CXSCNTL[21:17]
3	256	-	Not legal: 256-bit interface has maximum of packets per flit.	
3	512	27	START[2:0]	CXSCNTL[2:0]
			STARTOPTR[1:0]	CXSCNTL[4:3]
			START1PTR[1:0]	CXSCNTL[6:5]
			START2PTR[1:0]	CXSCNTL[8:7]
			END[2:0]	CXSCNTL[11:9]
			ENDERROR[2:0]	CXSCNTL[14:12]
			ENDOPTR[3:0]	CXSCNTL[18:15]
			END1PTR[3:0]	CXSCNTL[22:19]
			END2PTR[3:0]	CXSCNTL[26:23]
3	1024	33	START[2:0]	CXSCNTL[2:0]
			START0PTR[2:0]	CXSCNTL[5:3]
			START1PTR[2:0]	CXSCNTL[8:6]
			START2PTR[2:0]	CXSCNTL[11:9]
			END[2:0]	CXSCNTL[14:12]
			ENDERROR[2:0]	CXSCNTL[17:15]
			END0PTR[4:0]	CXSCNTL[22:18]
			END1PTR[4:0]	CXSCNTL[27:23]
			END2PTR[4:0]	CXSCNTL[32:28]
4	256	-	Not legal: 256-bit into packets per flit.	erface has maximum of 2

Table 4-2 Packet control field widths and placement (continued)

CXSMAXPKTPERFLIT	CXSDATAFLITWIDTH	Width of CXSCNTL	Field	Bit positions in CXSCNTL
4	512	36	START[3:0]	CXSCNTL[3:0]
			STARTOPTR[1:0]	CXSCNTL[5:4]
			START1PTR[1:0]	CXSCNTL[7:6]
			START2PTR[1:0]	CXSCNTL[9:8]
			START3PTR[1:0]	CXSCNTL[11:10]
			END[3:0]	CXSCNTL[15:12]
			ENDERROR[3:0]	CXSCNTL[19:16]
			ENDOPTR[3:0]	CXSCNTL[23:20]
			END1PTR[3:0]	CXSCNTL[27:24]
			END2PTR[3:0]	CXSCNTL[31:28]
			END3PTR[3:0]	CXSCNTL[35:32]
	1024	44	START[3:0]	CXSCNTL[3:0]
			STARTOPTR[2:0]	CXSCNTL[6:4]
			START1PTR[2:0]	CXSCNTL[9:7]
			START2PTR[2:0]	CXSCNTL[12:10]
			START3PTR[2:0]	CXSCNTL[15:13]
			END[3:0]	CXSCNTL[19:16]
			ENDERROR[3:0]	CXSCNTL[23:20]
			END0PTR[4:0]	CXSCNTL[28:24]
			END1PTR[4:0]	CXSCNTL[33:29]
			END2PTR[4:0]	CXSCNTL[38:34]
			END3PTR[4:0]	CXSCNTL[43:39]

4.3 Packet size constraints

A CXS interface transmits packets of data that meet the following requirements:

- At least 4 bytes in size
- A multiple of 4 bytes in size
- No upper limit on packet size

When used to transmit CCIX packets, there may be further constraints on packet size. Refer to the CCIX specification for more details.

4.4 Packet examples

The following examples illustrate packet placement rules and the **CXSCNTL** field usage. Examples that are shown in Table 4-3 and Table 4-4 on page 4-39 both have CXSCONTINUOUSDATA = True and CXSDATACHECK = None. Each data packet in the figures is shaded and has a unique identifier. Unused packet slots have dashes instead of identifiers.

Table 4-3 shows an example with 256-bit data, CXSDATAFLITWIDTH = 256. It has up to two packets per flit, CXSMAXPKTPERFLIT = 2.

Table 4-3 Example 256-bit wide interface with maximum of two packets per flit

	Cycle	е											
Signal	Field	0	1	2	3	4	5	6	7	8	9	10	11
CXSVALID		0	1	1	0	1	1	1	1	1	1	1	1
CXSDATA[31:0]		-	TLPA	TLPB	-	TLPD	TLPD	TLPE	TLPE	TLPF	TLPH	TLPI	TLPK
CXSDATA[63:32]		-	TLPA	TLPB	-	TLPD	-	TLPE	TLPE	-	TLPH	TLPI	TLPK
CXSDATA[95:64]		-	TLPA	TLPB	-	TLPD	-	TLPE	TLPE	-	TLPH	TLPI	TLPK
CXSDATA[127:96]		-	TLPA	-	-	TLPD	-	TLPE	TLPE	-	TLPH	TLPI	TLPK
CXSDATA[159:128]		-	TLPA	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPG	TLPI	TLPJ	TLPL
CXSDATA[191:160]		-	TLPA	TLPC	-	TLPD	TLPE	TLPE	-	TLPG	TLPI	TLPJ	TLPL
CXSDATA[223:192]		-	TLPA	TLPC	-	TLPD	TLPE	TLPE	-	TLPG	TLPI	TLPJ	TLPL
CXSDATA[255:224]		-	-	TLPC	-	TLPD	TLPE	TLPE	-	TLPG	TLPI	TLPJ	TLPL
CXSCNTL[1:0]	START[1:0]		0x1	0x3		0x1	0x1	0x0	0x0	0x3	0x3	0x1	0x3
CXSCNTL[2]	START0PTR[0]	_	0x0	0x0	_	0x0	0x1	-	-	0x0	0x0	0x1	0x0
CXSCNTL[3]	START1PTR[0]	-	-	0x1	-	-	-	-	-	0x1	0x1	-	0x1
CXSCNTL[5:4]	END[1:0]	-	0x1	0x3	-	0x0	0x1	0x0	0x1	0x3	0x1	0x3	0x3
CXSCNTL[7:6]	ENDERROR[1:0]	-	0x0	0x0	-	0x0							
CXSCNTL[10:8]	END0PTR[2:0]	-	0x6	0x2	-	-	0x0	-	0x4	0x0	0x3	0x3	0x3
CXSCNTL[13:11]	END1PTR[2:0]	-	-	0x7	-	-	-	-	-	0x7	-	0x7	0x7

Table 4-4 shows an example with 512-bit data, CXSDATAFLITWIDTH = 512. It has up to four packets per flit, CXSMAXPKTPERFLIT = 4.

Table 4-4 Example 512-bit wide interface with maximum of four packets per flit

		Cycle						e						
Signal	Field	0	1	2	3	4	5	6	7	8	9	10	1	
CXSVALID		0	1	1	0	1	1	1	1	1	1	1	0	
CXSDATA[31:0]		-	TLPA	TLPB	-	TLPD	TLPD	TLPE	TLPE	TLPF	TLPI	TLPM	-	
CXSDATA [63:32]		-	TLPA	TLPB	-	TLPD	-	TLPE	TLPE	-	TLPI	TLPM	-	
CXSDATA[95:64]		-	TLPA	TLPB	-	TLPD	-	TLPE	TLPE	-	TLPI	TLPM	-	
CXSDATA[127:96]		-	TLPA	TLPB	-	TLPD	-	TLPE	TLPE	-	TLPI	TLPM	-	
CXSDATA[159:128]		-	TLPA	TLPB	-	TLPD	TLPE	TLPE	TLPE	TLPG	TLPJ	TLPN	-	
CXSDATA[191:160]		-	TLPA	TLPB	-	TLPD	TLPE	TLPE	TLPE	TLPG	TLPJ	TLPN	-	
CXSDATA[223:192]		-	TLPA	-	-	TLPD	TLPE	TLPE	TLPE	TLPG	TLPJ	TLPN	-	
CXSDATA[255:224]		-	TLPA	-	-	TLPD	TLPE	TLPE	TLPE	TLPG	TLPJ	TLPN	-	
CXSDATA[287:256]		-	TLPA	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPH	TLPK	TLPO	-	
CXSDATA[319:288]		-	-	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPH	TLPK	TLPO	-	
CXSDATA[351:320]		-	-	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPH	TLPK	TLPO	-	
CXSDATA[383:352]		-	-	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPH	TLPK	TLPO	-	
CXSDATA[415:384]		-	-	TLPC	-	TLPD	TLPE	TLPE	TLPE	TLPI	TLPL	TLPP	-	
CXSDATA[447:416]		-	-	TLPC	-	TLPD	TLPE	TLPE	-	TLPI	TLPL	TLPP	-	
CXSDATA[479:448]		-	-	TLPC	-	TLPD	TLPE	TLPE	-	TLPI	TLPL	TLPP	_	
CXSDATA[511:480]		-	-	TLPC	-	TLPD	TLPE	TLPE	-	TLPI	TLPL	TLPP	-	
CXSCNTL[3:0]	START[3:0]	-	0x1	0x3	-	0x1	0x1	0x0	0x0	0xF	0x7	0xF	-	
CXSCNTL[5:4]	START0PTR[1:0]	-	0x0	0x0	-	0x0	0x1	-	-	0x0	0x1	0x0	-	
CXSCNTL[7:6]	START1PTR[1:0]	-	-	0x2	-	-	-	-	-	0x1	0x2	0x1	-	
CXSCNTL[8:9]	START2PTR[1:0]	-	-	-	-	-	-	-	-	0x2	0x3	0x2	-	
CXSCNTL[11:10]	START3PTR[1:0]	-	-	-	-	-	-	-	-	0x3	-	0x3	-	
CXSCNTL[15:12]	END[3:0]	-	0x1	0x3	-	0x0	0x1	0x0	0x1	0x7	0xF	0xF	-	
CXSCNTL [19:16]	ENDERROR[3:0]	-	0x0	0x0	-	0x0	-							
CXSCNTL[23:20]	END0PTR [3:0]	-	0x8	0x5	-	-	0x0	-	0xC	0x0	0x3	0x3	-	
CXSCNTL[27:24]	END1PTR[3:0]	-	-	0xF	-	-	-	-	-	0x7	0x7	0x7		
CXSCNTL[31:28]	END2PTR[3:0]			-		_			-	0xB	0xB	0xB		
CXSCNTL[35:32]	END3PTR[3:0]	-	-	-	-	-	-	-	-	-	0xF	0xF	_	

Table 4-5 shows an example with 512-bit data, CXSDATAFLITWIDTH = 512. It has up to two packets per flit, CXSMAXPKTPERFLIT = 2 and CXSCONTINUOUSDATA is True.

In this example, Protocol 0 uses packets that are variable length and Protocol 1 uses packets that are always 64B.

In the Protocol 0 stream the following groups of packets must remain together:

P0D and P0E

In the Protocol 1 stream the following groups of packets must remain together:

- P1B and P1C
- P1E, P1F, and P1G

Table 4-5 Example 512-bit interface with multiple protocols and CXSCONTINUOUSDATA is True

								Cy	/cle							
Signal	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CXSVALID	-	1	1	1	1	1	1	1	1	1	1	1	1	0	1	1
CXSDATA [31:0]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	P0D	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [63:32]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	-	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [95:64]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	-	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [127:96]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	-	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [159:128]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [191:160]	-	P1A	P0A	P1B	P1C	P0B	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [223:192]	-	P1A	P0A	P1B	P1C	-	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [255:224]	-	P1A	P0A	P1B	P1C	-	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [287:256]	-	P1A	P0A	P1B	P1C	P0C	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [319:288]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [351:320]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [383:352]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [415:384]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	P0E	P1E	P1F	-	P1G	P1H
CXSDATA [447:416]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	-	P1E	P1F	-	P1G	P1H
CXSDATA [479:448]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	-	P1E	P1F	-	P1G	P1H
CXSDATA [511:480]	-	P1A	-	P1B	P1C	P0C	P1D	P0D	P0E	P0E	-	P1E	P1F	-	P1G	P1H
CXSLAST	-	1	1	0	1	1	1	0	0	0	1	0	0	-	1	1
CXSPRCLTYPE [2:0]	-	0x1	0x0	0x1	0x1	0x0	0x1	0x0	0x0	0x0	0x0	0x1	0x1	-	0x1	0x1
START [1:0]	-	0x1	0x1	0x1	0x1	0x3	0x1	0x1	0x1	0x0	0x0	0x1	0x1	-	0x1	0x1
STARTOPTR [1:0]	-	0x0	0x1	-	-	0x0	0x0	-	0x0	0x0						
START1PTR [1:0]	-	-	-	-	-	0x2	-	-	-	-	-	-	-	-	-	-
END [1:0]	-	0x1	0x1	0x1	0x1	0x3	0x1	0x0	0x1	0x0	0x1	0x1	0x1	-	0x1	0x1
ENDERROR [1:0]	-	0x0	0x0	0x0	0x0	0x0	-	0x0	0x0							
END0PTR [3:0]	-	0xF	0x8	0xF	0xF	0x5	0xF	-	0x0	-	0xC	0xF	0xF	-	0xF	0xF
END1PTR [3:0]	-	-	-	-	-	0xF	-	-		-	-	-	-	-	-	-

Table 4-6 shows an example with 512-bit data, CXSDATAFLITWIDTH = 512. It has up to two packets per flit, CXSMAXPKTPERFLIT = 2 and CXSCONTINUOUSDATA is False.

In this example, Protocol 0 uses packets that have variable length and Protocol 1 uses packets that are always 64B.

In the Protocol 0 stream the following groups of packets must remain together:

P0D and P0E

In the Protocol 1 stream the following groups of packets must remain together:

- P1B and P1C
- P1E, P1F, and P1G

With CXSCONTINUOUSDATA set False, packets with a different protocol can be interleaved, even if the CXSLAST signal is deasserted. In the example, CXSLAST is used to indicate that Protocol 1 packets must not be inserted after cycles 3, 8, or 10.

Table 4-6 Example 512-bit interface with multiple protocols and CXSCONTINUOUSDATA is False

								C	/cle							
Signal	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CXSVALID	0	1	1	1	1	1	1	1	1	1	1	0	1	1	1	1
CXSDATA [31:0]	-	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	P0D	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [63:32]	-	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	-	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [95:64]	-	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	-	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [127:96]	_	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	-	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [159:128]	-	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [191:160]	-	P1A	P0A	P1B	P0B	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [223:192]	-	P1A	P0A	P1B	-	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [255:224]	_	P1A	P0A	P1B	-	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [287:256]	-	P1A	P0A	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [319:288]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [351:320]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [383:352]	_	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [415:384]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	P0E	P1H
CXSDATA [447:416]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	-	P1H
CXSDATA [479:448]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	-	P1H
CXSDATA [511:480]	-	P1A	-	P1B	P0C	P1C	P1D	P0D	P1E	P0E	P1F	-	P0E	P1G	-	P1H
CXSLAST	-	1	1	0	1	1	1	0	0	0	0	-	0	1	1	1
CXSPRCLTYPE [2:0]	-	0x1	0x0	0x1	0x0	0x1	0x1	0x0	0x1	0x0	0x1	-	0x0	0x1	0x0	0x1
START [1:0]	-	0x1	0x1	0x1	0x3	0x1	0x1	0x1	0x1	0x1	0x1	-	0x0	0x1	0x0	0x1
STARTOPTR [1:0]	-	0x0	0x1	0x0	-	-	0x0	-	0x0							
START1PTR [1:0]	-	-	-	-	0x2	-	-	-	-	-	-	-	-	-	-	-
END [1:0]	-	0x1	0x1	0x1	0x3	0x1	0x1	0x0	0x1	0x1	0x1	-	0x0	0x1	0x1	0x1
ENDERROR [1:0]	-	0x0	0x0	0x0	-	0x0	0x0	0x0	0x0							
END0PTR [3:0]	-	0xF	0x8	0xF	0x5	0xF	0xF	-	0xF	0x0	0xF	-	-	0xF	0xC	0xF
END1PTR [3:0]	-	-	-	-	0xF	-	-	-	-	-	-	-	-	-	-	-

4 CXS packets 4.4 Packet examples

Chapter 5

CXS interface activation and deactivation

This chapter describes the activation and deactivation mechanisms when the CXSLINKCONTROL property is set to Explicit_Credit_Return:

- Interface control with explicit credit return on page 5-44
- Request and acknowledgment handshaking on page 5-46
- Response to a new state on page 5-48
- Race conditions on page 5-49
- Timing relationships between data and link control signals on page 5-50
- Interface activation and deactivation examples on page 5-51

5.1 Interface control with explicit credit return

A CXS interface can be optionally configured to include signaling for activation and deactivation, using the CXSLINKCONTROL property. The property can be set to *None* or *Explicit Credit Return*.

When the CXSLINKCONTROL property is set to *None*, there are no signals for interface activation and deactivation. This setting requires that the Receiver must always send credits when they are available, and the Transmitter must always be able to receive them.

When the CXSLINKCONTROL property is set to *Explicit_Credit_Return*, the following specification applies, and signals are added to the interface as shown in Table 5-1.

Table 5-1 Signals for link control using explicit credit return

Name	Direction	Description
CXSCRDRTN	Transmitter to Receiver	Flow control information indicating that the Transmitter is returning a previously granted credit without using it. Can only be asserted if the CXSVALID signal is not asserted.
CXSACTIVEREQ	Transmitter to Receiver	Link activation or deactivation request.
CXSACTIVEACK	Receiver to Transmitter	Link activation or deactivation acknowledge.
CXSDEACTHINT	Receiver to Transmitter	Hint that Receiver would like the link to be deactivated.

The interface starts in an idle state either on exit from reset or when moving to a full operational state. Transfer of flits can commence when credits have been granted by the Receiver side. Credits can be granted when the Transmitter side indicates that it is ready to receive them.

A two-signal, four-phase, handshake mechanism is used. This mechanism synchronizes the state of the link between the Transmitter and Receiver and is initiated by the Transmitter. In addition, a signal is available for the Receiver to request that the link be deactivated.

Figure 5-1 on page 5-45 shows a typical connection, with one outbound and one inbound CXS interface, each of which has an instance of the credit control signals.




Figure 5-1 Example with two CXS links

5.2 Request and acknowledgment handshaking

Request and acknowledge handshaking uses CXSACTIVEREQ and CXSACTIVEACK as primary signals.

The Transmitter requires a credit before it can send a flit. A credit is passed from the Receiver when it has resources available to accept a flit.

- On exit from reset, all credits are held by the Receiver and at least one must be passed to the Transmitter before flit transfer can begin.
- During normal operation, there is an ongoing exchange of flits and credits between the two sides of the interface.
- Before entering a low-power state, the sending of payload flits must be stopped, and all credits must be
 returned to the Receiver. This action returns the interface to the same state that it was at immediately after
 reset.

Four states are defined for the interface operation:

STOP

- The interface does not operate in the **STOP** state. All credits are held by the Receiver.
- STOP is a stable state. When this state is entered, a channel can remain in it for an indefinite time.
- The Receiver is guaranteed not to receive flits or credit returns. It must not send credit.
- The Transmitter is guaranteed not to receive credit. It must not send flits or credit returns.
- The Transmitter can move from the STOP state to the ACTIVATE state when it has flits waiting to be sent.

ACTIVATE

- This state is used when transitioning from the STOP state to the RUN state.
- It is expected that when this state is entered, a channel moves to the next stable state in a relatively short time.
- The Transmitter must accept credit, but it cannot send flits until it observes the move to the RUN state.
- The Receiver is guaranteed not to receive flits or credit returns.
- The Receiver is not permitted to send credit in the ACTIVATE state. It is permitted to send credit in the same cycle that it moves to the RUN state. Because of a potential race condition, it is therefore possible for the Transmitter to receive credit while in the ACTIVATE state.
- The Receiver can move from the ACTIVATE state to the RUN state when it is prepared to
 receive flits.

RUN

- This state has an ongoing exchange of flits and credits between the two components.
- RUN is a stable state. A channel can remain in it for an indefinite time when this state is
 entered.
- The Receiver can send credit and receive flits or credit returns.
- The Transmitter can send flits and receive credits.
- The Transmitter is permitted to send credit returns but this is not expected.
- The Transmitter can move from the **RUN** state to the **DEACTIVATE** state for a number of reasons, such as when it has no flits to send. See *Response to a new state* on page 5-48 for more information.

DEACTIVATE

This state is used when transitioning from **RUN** state to the **STOP** state.

- DEACTIVATE is a transient state. It is expected that when this state is entered, a channel
 moves to the next stable state in a relatively short time.
- The Transmitter must stop sending flits before entering this state. Because of a potential race condition, it is possible for the Receiver to receive flits in this state.
- The Receiver can send credit when entering this state. In a timely manner, it must stop sending credit to allow all credit to be returned to the Receiver.
- The Receiver can receive credit returns.
- The Transmitter must send credit returns to allow all credits to be returned to the Receiver.
- The Receiver must only exit this state and move to the STOP state when all credits have been returned.

This specification does not define a maximum time in a transient state, but it is expected that for any given implementation that it is deterministic.

The state transitions are triggered by the **CXSACTIVEREQ** and **CXSACTIVEACK** signals. Figure 5-2 shows the relationship between the four states, with values of the signals **CXSACTIVEREQ** and **CXSACTIVEACK** respectively, on each transition.




Figure 5-2 Request and acknowledge handshake states

5.3 Response to a new state

If the state change has been initiated by the other side of the interface, a component might be required to change its behavior when moving to a new state.

If the state change requires a component to stop sending flits or credits, then the component is permitted to take some time to respond.

The Transmitter is always responsible for initiating the state change from RUN to STOP, or from STOP to RUN. This state change requirement can be detected through several mechanisms. The following examples are not exhaustive:

- The Transmitter can determine that it has flits to send, so must move from STOP to RUN.
- The Transmitter can determine that it has no activity to perform for a significant period, so can move from RUN to STOP.
- The Transmitter can observe an independent sideband signal that indicates it should move either from RUN to STOP, or from STOP to RUN.
- The Transmitter can observe the CXSDEACTHINT signal from the Receiver and decide to move from RUN to STOP.

5.4 Race conditions

A race condition exists when one side of the interface performs two actions at, or around, the same time. The CXS specification permits different delays between the data flow and link control groups of signals. Therefore, the order of the actions at arrival might not be the same as the order of issue.

The following race conditions can occur:

- The Receiver asserts the CXSACTIVEACK signal, to move from ACTIVATE to RUN, and starts sending credits:
 - The Receiver is permitted to assert CXSCRDGNT in the same cycle that the CXSACTIVEACK signal is asserted.
 - The credit might be received at the Transmitter before its local CXSACTIVEACK signal is asserted.
 - Therefore, the Transmitter must accept credits while in the ACTIVATE or RUN state.
- The Transmitter stops sending flits and then deasserts the CXSACTIVEREQ signal, to move from RUN to DEACTIVATE:
 - The Transmitter must not send flits when the **CXSACTIVEREQ** signal is deasserted.
 - An in-flight flit might be received at the Receiver after its local CXSACTIVEREQ signal is deasserted.
 - Therefore, the Receiver must accept flits while in the DEACTIVATE state and it can only move to the STOP state when all credits are returned.

These race conditions are possible because the **CXSACTIVEREQ** and **CXSACTIVEACK** signals need not have the same delay between Transmitter and Receiver as the other signals.

5.5 Timing relationships between data and link control signals

Permitted timing relationships between the CXS signals depend on signal type.

The following signals must be synchronous with identical delay:

- CXSVALID
- CXSDATA
- CXSCNTL
- CXSCRDRTN

The following signals must be synchronous but can have any delay:

- CXSCRDGNT
- CXSACTIVEACK
- CXSDEACTHINT

The following signal must be driven synchronously but can be captured asynchronously with any delay:

CXSACTIVEREQ

CHK signals must be clocked and pipelined identically to their corresponding signals.

Usually, the physical distance between the Transmitter and Receiver will determine the number of flip-flop stages that are required to achieve the necessary frequency. The required number of flip-flop stages will most likely be applied to all the signals on the interface.

The exception is the **CXSACTIVEREQ** signal. It is common for the clock in the Receiver to stop during the STOP state due to clock gating. The assertion of the **CXSACTIVEREQ** signal might be used to restart that clock. It is possible that the flip-flops between Transmitter and Receiver are in the Receiver clock domain and are also clock gated during STOP state. The **CXSACTIVEREQ** signal might need to have a combinational path between Transmitter and Receiver. This path might be a multicycle path due to distance and required frequency of the interface. This multicycle character is acceptable because the **CXSACTIVEREQ** and **CXSACTIVEACK** signals participate in a four-phase handshake and can run asynchronously.

The CXSACTIVEREQ signal must therefore be treated by the Receiver as an asynchronous signal and run through appropriate synchronization logic to avoid metastability before use.

It is permitted for the CXSACTIVEACK and CXSDEACTHINT signals to be treated as synchronous input signals by the Transmitter. These signals must not be multicycle path between Receiver and Transmitter, although they can have as many flip-flops as is needed.

5.6 Interface activation and deactivation examples

This section provides interface activation and deactivation examples.

An activation of an interface is shown in Figure 5-3.

- 1. In cycle 0, both the Transmitter and Receiver are in the STOP state. Both sides could be clock gated or powered down.
- 2. The Transmitter asserts **CXSACTIVEREQ** and moves into the ACTIVATE state in cycle 2.
- 3. The Receiver wakes up and asserts **CXSACTIVEACK** in cycle 5.
- 4. In this case, CXSCRDGNT is asserted the same cycle as CXSACTIVEACK.
- 5. Having received a credit, the Transmitter sends a flit in cycle 6.
- 6. Transmitter continues to send while it is receiving credits.




Figure 5-3 Interface activation example

Figure 5-4 shows the same example with more delay between the Receiver and Transmitter on the CXSACTIVEACK signal path than there is on the CXSCRDGNT path. Because of the additional delay, the Transmitter receives a credit while in the ACTIVATE state. However, the Transmitter cannot send a flit until CXSACTIVEACK signal goes HIGH in cycle 5 and it moves into the RUN state.




Figure 5-4 Interface activation example with race

Figure 5-5 shows an interface deactivation example. Both sides of the link start in RUN state. The Transmitter has no more flits to send and decides to deactivate the interface. The Transmitter deasserts the **CXSACTIVEREQ** signal, taking the interface into DEACTIVATE state. The Transmitter has a nonzero credit count, so it returns credits by asserting **CXSCRDRTN**.

The Receiver continues to grant credits for several cycles until it recognizes that the link is being deactivated. The Transmitter must return the additional credits as well, asserting **CXSCRDRTN** until its credit count is zero. The Receiver must not deassert the **CXSACTIVEACK** signal until it has all the credits and there are no credit grants in flight. The Transmitter will never see that the **CXSACTIVEACK** signal is deasserted while it still has credits.




Figure 5-5 Interface deactivation example



This chapter describes CXS packet continuous delivery guarantees:

• Continuous delivery guarantees for CXS packets on page 6-54.

6.1 Continuous delivery guarantees for CXS packets

Some CXS implementations have a downstream interface that cannot tolerate interruptions in the data flow. PCIe is an example. An uninterrupted flow can be achieved using a CXS interface if either the Receiver or Transmitter has a store-and-forward buffer.

If the Receiver is built with the store-and-forward buffer, a packet must be able to be received in full before it is transmitted on the downstream interface. The Receiver must have enough buffering to store the largest packet that can be sent by the Transmitter. In this case, the Receiver and Transmitter can set the CXSCONTINUOUSDATA property False and the Transmitter is not required to buffer the packet.

If the Receiver does not have a buffer and requires continuous data, then it sets the CXSCONTINUOUSDATA property True and the attached Transmitter must also have CXSCONTINUOUSDATA as True. The Transmitter must then be able to issue all flits within a packet without dependence on another interface.

The Transmitter must also not attempt to deactivate the link if that deactivation could occur at a time when some, but not all, data of a packet has been issued.

If a continuous flow is required, the integrator must ensure that the Receiver has enough credits to cover the worst-case round-trip credit latency. This includes:

- The delay on **CXSCRDGNT** between Receiver and Transmitter.
- The maximum internal delay between CXSTXCRDGNT and CXSTXVALID when the Transmitter has a
 packet that is stalled waiting for credits. This is described by the CXS_MAX_CREDIT_LATENCY property
 of the Transmitter.
- The delay on the **CXSVALID** signal between the Transmitter and Receiver.
- The maximum internal Receiver delay between CXSRXVALID and CXSRXCRDGNT. This is described
 by the CXS_MAX_CREDIT_LATENCY property of the Receiver.

The maximum number of credits that a Receiver can issue is dependent on the size of its buffer, it can be described by its CXS MAX CREDIT property.

If the downstream interface is clocked slower than the CXS link, then it might not be necessary to transmit one flit every cycle. In this case, the number of credits required for the Receiver to maintain a constant flow might be fewer than the round-trip latency.

Appendix A **Revisions**

This appendix describes the technical changes between released issues of this specification.

Table A-1 Issue A

Change	Location
First release of Version A	-

Table A-2 Issue B

Change	Location
Support for multiple protocol streams	Chapter 2
Extension to interface protection signaling to support new signals	Chapter 2
Clarification of continuous delivery guarantees	Chapter 6

Table A-3 Issue C

Change	Location
Added support for simplified interfaces which send 1 packet per flit Extended data width options when there is 1 packet per flit.	. CXS interface properties on page 2-21
New rules added for CXSMAXPKTPERFLIT	Table 2-2 on page 2-21
Added definitions of clock and reset signals	Table 2-1 on page 2-18
Increased range of CXS_MAX_CREDIT to 1-63	CXS interface properties on page 2-21

Appendix A Revisions