ARM® Compiler v5.05 for µVision

armar User Guide



ARM® Compiler v5.05 for µVision

armar User Guide

Copyright © 2011, 2012, 2014 ARM. All rights reserved.

Release Information

Document History

Issue	Date	Confidentiality	Change
A	June 2011	Non-Confidential	Release for ARM Compiler v4.1 for μVision
В	July 2012	Non-Confidential	Release for ARM Compiler v5.02 for μVision
С	30 May 2014	Non-Confidential	Release for ARM Compiler v5.04 for μVision
D	12 December 2014	Non-Confidential	Release for ARM Compiler v5.05 for μVision

Non-Confidential Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of ARM. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, ARM makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to ARM's customers is not intended to create or refer to any partnership relationship with any other company. ARM may make changes to this document at any time and without notice.

If any of the provisions contained in these terms conflict with any of the provisions of any signed written agreement covering this document with ARM, then the signed written agreement prevails over and supersedes the conflicting provisions of these terms. This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

Words and logos marked with [®] or TM are registered trademarks or trademarks of ARM Limited or its affiliates in the EU and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow ARM's trademark usage guidelines at http://www.arm.com/about/trademark-usage-guidelines.php

Copyright © [2011, 2012, 2014], ARM Limited or its affiliates. All rights reserved.

ARM Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

LES-PRE-20349

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Unrestricted Access is an ARM internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Web Address

http://www.arm.com

Contents

ARM® Compiler v5.05 for µVision armar User Guide

	Pret	race		
		About this book	7	
Chapter 1	Overview of the ARM Librarian topics			
	1.1	About the ARM librarian	1-10	
	1.2	Considerations when working with library files	1-11	
	1.3	armar command-line syntax	1-12	
	1.4	Option to get help on the armar command	1-13	
Chapter 2	arma	ar Command-line Options		
	2.1	archive	2-16	
	2.2	-a pos_name	2-17	
	2.3	-b pos_name	2-18	
	2.4	-c	2-19	
	2.5	-C	2-20	
	2.6	create	2-21	
	2.7	-d	2-22	
	2.8	debug_symbols	2-23	
	2.9	diag_error=tag[,tag,]	2-24	
	2.10	diag_remark=tag[,tag,]	2-25	
	2.11	diag_style={arm ide gnu}	2-26	
	2.12	diag_suppress=tag[,tag,]	2-27	
	2.13	diag_warning=tag[,tag,]	2-28	
	2.14	entries	2-29	

	2.15	file_list	2-30
	2.16	help	2-31
	2.17	-i pos_name	2-32
	2.18	-m pos_name	2-33
	2.19	-n	
	2.20	new_files_only	2-35
	2.21	-p	2-36
	2.22	-r	2-37
	2.23	-S	2-38
	2.24	show_cmdline	2-39
	2.25	sizes	2-40
	2.26	-t	2-41
	2.27	-T	2-42
	2.28	-u	2-43
	2.29	-v	2-44
	2.30	version_number	2-45
	2.31	via=filename	2-46
	2.32	vsn	2-47
	2.33	-x	2-48
	2.34	zs	2-49
	2.35	zt	2-50
Chapter 3	Via F	File Syntax	
•	3.1	Overview of via files	3-52
	32	Via file syntax rules	3-53

Preface

This preface introduces the ARM® Compiler v5.05 for µVision armar User Guide.

It contains the following:

• *About this book* on page 7.

About this book

ARM Compiler for μ Vision armar User Guide. This manual provides information on how to use the armar utility. Available as a PDF.

Using this book

This book is organized into the following chapters:

Chapter 1 Overview of the ARM Librarian topics

Gives an overview of the ARM® librarian, armar, provided with ARM Compiler.

Chapter 2 armar Command-line Options

Describes the command-line options of the ARM librarian, armar.

Chapter 3 Via File Syntax

Describes the syntax of via files accepted by the armar.

Glossary

The ARM Glossary is a list of terms used in ARM documentation, together with definitions for those terms. The ARM Glossary does not contain terms that are industry standard unless the ARM meaning differs from the generally accepted meaning.

See the ARM Glossary for more information.

Typographic conventions

italic

Introduces special terminology, denotes cross-references, and citations.

bold

Highlights interface elements, such as menu names. Denotes signal names. Also used for terms in descriptive lists, where appropriate.

monospace

Denotes text that you can enter at the keyboard, such as commands, file and program names, and source code.

<u>mono</u>space

Denotes a permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.

monospace italic

Denotes arguments to monospace text where the argument is to be replaced by a specific value.

monospace bold

Denotes language keywords when used outside example code.

<and>

Encloses replaceable terms for assembler syntax where they appear in code or code fragments. For example:

```
MRC p15, 0 <Rd>, <CRn>, <CRm>, <Opcode_2>
```

SMALL CAPITALS

Used in body text for a few terms that have specific technical meanings, that are defined in the *ARM glossary*. For example, IMPLEMENTATION DEFINED, IMPLEMENTATION SPECIFIC, UNKNOWN, and UNPREDICTABLE.

Feedback

Feedback on this product

If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms and diagnostic procedures if appropriate.

Feedback on content

If you have comments on content then send an e-mail to errata@arm.com. Give:

- The title
- The number ARM DUI0590D.
- The page number(s) to which your comments refer.
- A concise explanation of your comments.

ARM also welcomes general suggestions for additions and improvements.

Axivi also welcomes general suggestions for additions and improvements.
Note
ARM tests the PDF only in Adobe Acrobat and Acrobat Reader, and cannot guarantee the quality of the represented document when used with any other PDF reader.

Other information

- ARM Information Center.
- ARM Technical Support Knowledge Articles.
- Support and Maintenance.
- ARM Glossary.

Chapter 1 **Overview of the ARM Librarian topics**

Gives an overview of the ARM® librarian, armar, provided with ARM Compiler.

It contains the following sections:

- 1.1 About the ARM librarian on page 1-10.
- 1.2 Considerations when working with library files on page 1-11.
- 1.3 armar command-line syntax on page 1-12.
- 1.4 Option to get help on the armar command on page 1-13.

1.1 About the ARM librarian

The ARM librarian, armar, enables you to collect and maintain sets of ELF object files in standard format ar libraries.

You can pass these libraries to the linker in place of several ELF object files.

With armar you can:

- Create new libraries.
- · Add files to a library.
- Replace individual files in a library.
- Replace all files in a library with specified files in a single operation.
- Control the placement of files in a library.
- Display information about a specified library. For example, list all members in a library.

A timestamp is also associated with each file that is added or replaced in a library.

Note
When you create, add, or replace object files in a library, armar creates a symbol table by default.
However, debug symbols are not included by default.

Related references

2.8 --debug symbols on page 2-23.

Related information

- --libpath=pathlist linker option.
- --library type=lib linker option.
- --userlibpath=pathlist linker option.

1.2 Considerations when working with library files

There are some considerations you must be aware of when working with library files.

Be aware of the following:

- A library differs from a shared object or dynamically linked library (DLL) in that:
 - Symbols are imported from a shared object or DLL.
 - Code or data for symbols is extracted from an archive into the file being linked.
- Linking with an object library file might not produce the same results as linking with all the object
 files collected into the object library file. This is because the linker processes the input list and
 libraries differently:
 - Each object file in the input list appears in the output unconditionally, although unused areas are eliminated if the armlink --remove option is specified.
 - A member of a library file is only included in the output if it is referred to by an object file or a previously processed library file.

The linker recognizes a collection of ELF files stored in an ar format file as a library. The contents of each ELF file form a single member in the library.

1.3 armar command-line syntax

The armar command has options to specify how to process files and libraries.

Syntax

```
armar options archive [file_list]
options
    armar command-line options.

archive
    The filename of the library. A library file must always be specified.
file_list
    The list of files to be processed.
```

```
2.1 archive on page 2-16. 2.15 file_list on page 2-30.
```

1.4 Option to get help on the armar command

Use the --help option to display a summary of the main command-line options.

This is the default if you do not specify any options or source files.

Example

To display the help information, enter:

armar --help

Chapter 2 armar Command-line Options

Describes the command-line options of the ARM librarian, armar.

It contains the following sections:

- 2.1 archive on page 2-16.
- 2.2 -a pos name on page 2-17.
- 2.3 -b pos name on page 2-18.
- 2.4 -c on page 2-19.
- 2.5 -C on page 2-20.
- 2.6 --create on page 2-21.
- 2.7 -d on page 2-22.
- 2.8 --debug symbols on page 2-23.
- 2.9 --diag_error=tag[,tag,...] on page 2-24.
- 2.10 --diag remark=tag[,tag,...] on page 2-25.
- 2.11 --diag style={arm|ide|gnu} on page 2-26.
- 2.12 --diag_suppress=tag[,tag,...] on page 2-27.
- 2.13 --diag warning=tag[,tag,...] on page 2-28.
- 2.14 --entries on page 2-29.
- 2.15 file_list on page 2-30.
- 2.16 --help on page 2-31.
- 2.17 -i pos name on page 2-32.
- 2.18 -m pos_name on page 2-33.
- 2.19 -n on page 2-34.
- 2.20 --new files only on page 2-35.
- 2.21 -p on page 2-36.

- 2.22 -r on page 2-37.
- 2.23 -s on page 2-38.
- *2.24 --show_cmdline* on page 2-39.
- *2.25 --sizes* on page 2-40.
- 2.26 -t on page 2-41.
- 2.27 -T on page 2-42.
- 2.28 -u on page 2-43.
- 2.29 -v on page 2-44.
- *2.30* --version number on page 2-45.
- 2.31 --via=filename on page 2-46.
- 2.32 --vsn on page 2-47.
- 2.33 -x on page 2-48.
- 2.34 --zs on page 2-49.
- 2.35 --zt on page 2-50.

2.1 archive

Specifies the location of the library to be created, modified, or read.		
Note		
If you include a list of files in file_list, they must be specified after the library fil	le.	

Related references

2.15 file_list on page 2-30.

2.2 -a pos name

Places new files in the library after the specified library member.

Syntax

```
-a=pos_name
```

Where pos name is the name of a file in the library.

Usage

The effect of this option is negated if you include -b (or -i) on the same command line.

Example

To add or replace files obj3.o and obj4.o immediately after obj2.o in mylib.a, enter:

```
armar -r -a obj2.o mylib.a obj3.o obj4.o
```

- 2.3 -b pos name on page 2-18.
- 2.17 -i pos name on page 2-32.
- 2.18 -m pos name on page 2-33.
- 2.22 -r on page 2-37.

2.3 -b pos_name

Places new files in the library before the specified library member.

Syntax

-b=pos_name

Where *pos_name* is the name of a file in the library.

Usage

This option takes precedence if you include -a on the same command line.

Related references

```
2.2 -a pos_name on page 2-17.
```

2.17 - *i pos_name* on page 2-32.

2.18 -m pos name on page 2-33.

2.22 -r on page 2-37.

2.4 -c

Suppresses the diagnostic message normally written to stderr when a library is created.

2.5 -C

Instructs the librarian not to replace existing files with like-named files when performing extractions.

Usage

Use this option with -T to prevent truncated filenames from replacing files with the same prefix.

An error message is displayed if the file to be extracted already exists in the current location.

Related references

2.27 -T on page 2-42. 2.33 -x on page 2-48.

2.6 --create

Creates a new library containing only the files specified in *file_list*. If the library already exists, its previous contents are discarded.

Usage

With the --create option specify the list of object files, either:

- Directly on the command-line.
- In a via file.

Note	
11016	

If the library already exists, the previous contents are deleted.

You can use this option together with the following compatible command-line options:

- -0
- --diag_style
- -n
- -v
- --via.

_____Note _____

Other options can also create a new library in some circumstances. For example, using the -r option with a library that does not exist.

Examples

To create a new library by adding all object files in the current directory, enter:

```
armar --create mylib.a *.o
```

To create a new library containing the files listed in a via file, enter:

```
armar --create mylib.a --via myobject.via
```

Related references

2.15 file list on page 2-30.

2.7 -d

Deletes one or more files specified in file_list from the library.

You can use this option in conjunction with other compatible command-line options.

Example

To delete the files file1.o and file2.o from the mylib.a library, enter:

armar -d mylib.a file1.o,file2.o

Related references

2.15 file list on page 2-30.

2.8 --debug_symbols

By default, debug symbols are excluded from an archive. Use --debug_symbols to include debug symbols in the archive.

Related concepts

1.1 About the ARM librarian on page 1-10.

2.9 --diag_error=tag[,tag,...]

Sets diagnostic messages that have a specific tag to Error severity.

Syntax

```
--diag_error=tag[,tag,...]
Where tag can be:
```

- A diagnostic message number to set to error severity.
- warning, to treat all warnings as errors.

```
2.10 --diag_remark=tag[,tag,...] on page 2-25.

2.11 --diag_style={arm|ide|gnu} on page 2-26.

2.12 --diag_suppress=tag[,tag,...] on page 2-27.

2.13 --diag_warning=tag[,tag,...] on page 2-28.
```

2.10 --diag_remark=tag[,tag,...]

Sets diagnostic messages that have a specific tag to Remark severity.

Syntax

```
--diag_remark=tag[,tag,...]
```

Where tag is a comma-separated list of diagnostic message numbers.

- 2.9 --diag error=tag[,tag,...] on page 2-24.
- 2.11 --diag style={arm|ide|gnu} on page 2-26.
- 2.12 --diag suppress=tag[,tag,...] on page 2-27.
- 2.13 --diag warning=tag[,tag,...] on page 2-28.

2.11 --diag_style={arm|ide|gnu}

Specifies the display style for diagnostic messages.

Syntax

```
--diag_style=string
```

Where *string* is one of:

arm

Display messages using the ARM compiler style.

ide

Include the line number and character count for any line that is in error. These values are displayed in parentheses.

gnu

Display messages in the format used by gcc.

Usage

- --diag style=gnu matches the format reported by the GNU Compiler, gcc.
- --diag style=ide matches the format reported by Microsoft Visual Studio.

Default

The default is --diag_style=arm.

Related references

```
2.9 --diag_error=tag[,tag,...] on page 2-24.
2.10 --diag_remark=tag[,tag,...] on page 2-25.
```

2.12 --diag suppress=tag[,tag,...] on page 2-27.

2.13 --diag_warning=tag[,tag,...] on page 2-28.

2.12 --diag_suppress=tag[,tag,...]

Suppresses diagnostic messages that have a specific tag.

Syntax

```
--diag_suppress=tag[,tag,...] Where tag can be:
```

- A diagnostic message number to be suppressed.
- error, to suppress all errors that can be downgraded.
- · warning, to suppress all warnings.

```
2.9 --diag_error=tag[,tag,...] on page 2-24.
2.10 --diag_remark=tag[,tag,...] on page 2-25.
2.11 --diag_style={arm|ide|gnu} on page 2-26.
2.13 --diag_warning=tag[,tag,...] on page 2-28.
```

2.13 --diag_warning=tag[,tag,...]

Sets diagnostic messages that have a specific tag to Warning severity.

Syntax

```
--diag_warning=tag[,tag,...] Where tag can be:
```

- A diagnostic message number to set to warning severity.
- error, to set all errors that can be downgraded to warnings.

```
2.9 --diag_error=tag[,tag,...] on page 2-24.
2.10 --diag_remark=tag[,tag,...] on page 2-25.
2.11 --diag_style={arm|ide|gnu} on page 2-26.
2.12 --diag_suppress=tag[,tag,...] on page 2-27.
```

2.14 --entries

Lists all object files in the library that have an entry point defined using the assembler ENTRY directive.

Usage

The format for the listing is:

```
ENTRY at offset num in section name of member
```

Example

The following example lists the entry point of each object file in myasm.a:

```
> armar --entries myasm.a

ENTRY at offset 0 in section adrlabel of adrlabel.o

ENTRY at offset 0 in section Block of blocks.o

ENTRY at offset 0 in section Block of blocks.o

ENTRY at offset 0 in section LDRlabel of ldrlabel.o

ENTRY at offset 0 in section LDRlabel of ldrlabel.o

ENTRY at offset 0 in section Loadcon of loadcon.o

ENTRY at offset 0 in section StrCopy of strcopy.o

ENTRY at offset 0 in section subrout of subrout.o

ENTRY at offset 0 in section Tblock of tblock.o

ENTRY at offset 0 in section ThumbSub of thumbsub.o

ENTRY at offset 0 in section Word of word.o
```

Related references

```
2.25 --sizes on page 2-40.
2.35 --zt on page 2-50.
```

Related information

ENTRY.

2.15 file list

A space-separated list of ELF-compliant files, such as ELF objects and ELF libraries.

Usage

Each file must be fully specified by its path and name. The path can be absolute, relative to drive and
root, or relative to the current directory.
Note
The list of files must be specified after the library file.

Only the filename at the end of the path is used when comparing against the names of files in the library. If two or more path operands end with the same filename, the results are unspecified. You can use the wild characters * and ? to specify files.

If one of the files is a library, armar copies all members from the input library to the destination library. The order of members on the command line is preserved. Therefore, supplying a library file is logically equivalent to supplying all of its members in the order that they are stored in the library.

2.16 --help

Displays a summary of the main command-line options.

Default

This is the default if you specify armar without any options or source files.

- 2.30 --version number on page 2-45.
- 2.32 --vsn on page 2-47.

2.17 -i pos_name

Places new files in the library before the specified library member.

Syntax

-i=pos_name

Where *pos_name* is the name of a file in the library.

This is equivalent to -b pos_name

- 2.2 -a pos name on page 2-17.
- 2.3 -b pos name on page 2-18.
- 2.18 -m pos name on page 2-33.
- 2.22 -r on page 2-37.

2.18 -m pos_name

Moves files in a library to a specified position.

Syntax

```
-m=pos_name
```

Where pos name is the name of a file in the library.

Usage

If -a, -b, or -i with *pos_name* is specified, moves files to the new position. Otherwise, moves files to the end of the library.

Example

To move the file file1.o to a new location after file2.o in the mylib.a library, enter:

```
armar -m -a file2.o mylib.a file1.o
```

- 2.2 -a pos name on page 2-17.
- 2.3 -b pos name on page 2-18.
- 2.17 -i pos name on page 2-32.

2.19 -n

Suppresses the creation of a symbol table in the library.

Usage

By default, armar always creates a symbol table when you create a library of object files.

You can recreate the symbol table in the library using the -s option.

Example

To create a library without a symbol table, enter:

```
armar -n --create mylib.a *.obj
```

Related references

2.23 -s on page 2-38.

2.20 --new_files_only

Updates an object file in the archive only if the new object has a later timestamp.

Usage

When used with the -r option, files in the library are replaced only if the corresponding file has a modification time that is newer than the modification time of the file in the library.

Related references

2.22 -r on page 2-37. 2.28 -u on page 2-43.

2.21	-p
------	----

Prints the contents of source files in a library to stdout.

_____Note _____

The files must be text files.

Example

To display the contents of file1.c in mylib.a, enter:

armar -p mylib.a file1.c

Related references

2.26 -t on page 2-41.

2.22 -r

Replaces, or adds, files in the specified library.

Usage

If the library does not exist, a new library file is created and a diagnostic message is written to standard error. You can use this option in conjunction with other compatible command-line options.

```
-q is an alias for -r.
```

If no files are specified and the library exists, the results are undefined. Files that replace existing files do not change the order of the library.

If the -u option is used, then only those files with dates of modification later than the library files are replaced.

If the -a, -b, or -i option is used, then *pos_name* must be present and specifies that new files are to be placed after (-a) or before (-b or -i) *pos_name*. Otherwise the new files are placed at the end.

Examples

To add or replace obj1.0, obj2.0, and obj3.0 files in a library, enter:

```
armar -r mylib.a obj1.o obj2.o obj3.o
```

To replace files with names beginning with k in a library, and only if the file in the library is older than the specified file, enter:

```
armar -ru mylib.a k*.o
```

- 2.2 -a pos name on page 2-17.
- 2.3 -b pos name on page 2-18.
- 2.17 -i pos_name on page 2-32.
- 2.28 -u on page 2-43.
- 2.15 file list on page 2-30.

2.23 -s

Creates a symbol table in the library.

Usage

This option is useful for libraries that have been created:

- Using the -n option.
- With an archiver that does not automatically create a symbol table.

 Note —
TOLE

By default, armar always creates a symbol table when you create a library of object files.

Example

To create a symbol table in a library that was created using the -n option, enter:

```
armar -s mylib.a
```

Related references

```
2.19 -n on page 2-34.
```

2.34 --zs on page 2-49.

2.24 --show cmdline

Outputs the command line used by the librarian.

Usage

Shows the command line after processing by the librarian, and can be useful to check:

- The command line a build system is using.
- How the librarian is interpreting the supplied command line, for example, the ordering of commandline options.

The commands are shown normalized, and the contents of any via files are expanded.

The output is sent to the standard error stream (stderr).

Example

To show how armar processes the command-line options for the replacement of file obj1.o in mylib.a, enter:

```
> armar --show_cmdline -r mylib.a obj1.o
[armar --show_cmdline -r mylib.a obj1.o]
```

Related references

2.31 --via=filename on page 2-46.

2.25 --sizes

Lists the Code, RO Data, RW Data, ZI Data, and Debug sizes of each member in the library.

Example

The following example shows the sizes of app_1.o and app_2.o in mylib.a:

> arma	rsizes	mylib.a			
Code	RO Data	RW data	ZI Data	Debug	Object Name
464	0	0	0	8612	app_1.o
3356	0	0	10244	11848	app_2.o
3820	0	0	10244	20460	TOTAL

Related references

```
2.14 --entries on page 2-29.
```

2.35 --zt on page 2-50.

2.26 -t

Prints a table of contents for the library.

Usage

The files specified by file_list are included in the written list. If file_list is not specified, all files in the library are included in the order of the archive.

Examples

To display the table of contents of mylib.a, enter:

```
> armar -t mylib.a
app_1.o
app_2.o
```

To list the table of contents of a library in verbose mode, enter:

```
> armar -tv mylib.a
rw-rw-rw- 0/ 0 7512 Jun 22 11:19 2009 app_1.o (offset 736)
rw-rw-rw- 0/ 0 1452 May 19 16:25 2009 app_2.o (offset 8308)
```

```
2.29 -v on page 2-44.
2.15 file list on page 2-30.
```

2.27 -T

Enables truncation of filenames when extracted files have library names that are longer than the file system can support.

Usage

By default, extracting a file with a name that is too long is an error. A diagnostic message is written and the file is not extracted.

Be aware that if multiple files in the library have the same truncated name, each subsequent file that is extracted overwrites the previously extracted file with that name. To prevent this, use the -C option.

Related references

2.5 -C on page 2-20. 2.33 -x on page 2-48.

2.28 -u

Updates older files in the specified archive.

Usage

When used with the -r option, files in the library are replaced only if the corresponding file has a modification time that is at least as new as the modification time of the file within library.

```
2.20 --new_files_only on page 2-35. 2.22 -r on page 2-37.
```

2.29 -v

Gives verbose output.

Usage

The output depends on what other options are used:

-d, -r, -x

Write a detailed file-by-file description of the library creation, the constituent files, and maintenance activity.

-p

Writes the name of the file to the standard output before writing the file itself to the stdout.

-t

Includes a long listing of information about the files within the library.

-x

Prints the filename preceding each extraction.

- 2.7 -d on page 2-22.
- 2.21 -p on page 2-36.
- 2.22 -r on page 2-37.
- *2.26 -t* on page 2-41.
- 2.33 -x on page 2-48.

2.30 --version_number

Displays the version of armar you are using.

Usage

The librarian displays the version number in the format nnnbbbb, where:

- nnn is the version number.
- bbbb is the build number.

Example

Version 5.05 build 0019 is displayed as 5050019.

```
2.16 --help on page 2-31.
2.32 --vsn on page 2-47.
```

2.31 --via=filename

Reads an additional list of input filenames and librarian options from filename.

Syntax

--via=filename

Where filename is the name of a via file containing options to be included on the command line.

Usage

You can enter multiple --via options on the librarian command line. The --via options can also be included within a via file.

Related concepts

3.1 Overview of via files on page 3-52.

2.32 --vsn

Displays the version information and the license details.

Example

Example output:

```
> armar --vsn
Product: ARM Compiler N.nn
Component: ARM Compiler N.nn
Tool: armar [build_number]
```

Related references

```
2.16 --help on page 2-31.
```

2.30 --version_number on page 2-45.

2.33 -x

Extracts the files specified in *file_list* from the library to the current directory.

Usage

The contents of the library are not changed. If no file operands are given, all files in the library are extracted.

Be aware that if the name of a file in the library is longer than the file system can support, an error is displayed and the file is not extracted. To extract files with long filenames, use the -T option to truncate the names of files that are too long.

The files are extracted to the current location.

You can use this option in conjunction with other compatible command-line options.

Example

To extract the files file1.o and file2.o from the mylib.a library in the directory C:\temp to C:\temp \obj, enter:

```
C:
cd \temp\obj
armar -x ..\mylib.a file1.o,file2.o
```

```
2.27 -T on page 2-42.
2.15 file list on page 2-30.
```

2.34 --zs

Displays the symbol table for all files in the library.

Example

To list the symbol table in mylib.a, enter:

```
> armar --zs mylib.a
  _ARM_use_no_argv
                        from hello.o
                                          at offset
                                                         412
main
                        from hello.o
                                          at offset
                                                        412
                                                       7960
 _ARM_use_no_argv
                        from test.o
                                          at offset
                        from test.o
                                          at offset
                                                       7960
 _ARM_use_no_argv
                        from hello_ltcg.o at offset 11408
\overline{\text{main}}
                        from hello_ltcg.o at offset 11408
 _ARM_use_no_argv
                        from h1.o
                                         at offset
                                                      18532
                        from h1.o
                                          at offset
                                                      18532
__ARM_use_no_argv
                        from fncalls.o at offset
                                                       2072
add
                        from fncalls.o at offset
                       from fncalls.o at offset 207 from get_stacksize.o at offset
main
                                                       2072
get_stacksize
                       from get_stacksize.o at offset
from s.o at offset 1300
altstack
 _ARM_use_no_argv
                                                      13068
main
                        from s.o
                                          at offset
                                                      13068
altstack
                                         at offset
                                                      13068
                        from s.o
_Z1fv
_ZN1T1fEi
                                          at offset
                                                      17064
                        from t.o
                        from t.o
                                          at offset
                                                      17064
```

Related references

2.19 -n on page 2-34.

2.23 -s on page 2-38.

2.35 --zt

Lists both the member sizes and entry points for all files in the library.

Example

To list the member sizes and entry points for all files in mylib.a, enter:

```
>armar --zt mylib.a
                                                                       Object Name hello.o
                 RO Data
                               RW Data
                                             ZI Data
                                                             Debug
        Code
        838
         16
                                                    0
                                                              2869
                                                                       fncalls.o
         893
                         0
                                       0
                                                    0
                                                                       test.o
                                                    0
                                                                       get_stacksize.o
         962
                         0
                                       0
         838
                         0
                                       0
                                                    0
                                                                       hello_ltcg.o
                                                   80
                                                                       5.0
          56
                                      50
                                                                       strcopy.o
                                                    0 0 0
          4
                                      44
                                                                       emit-relocs-1a.o
          36
                                                                 84
                                                                       t.o
        838
                                                                       h1.o
        4489
                                      94
                                                   80
                                                              3121
                                                                       TOTAL
ENTRY at offset 0 in section StrCopy of strcopy.o ENTRY at offset 0 in section StrCopy of emit-relocs-1a.o
```

- 2.14 --entries on page 2-29.
- 2.25 -- sizes on page 2-40.

Chapter 3 **Via File Syntax**

Describes the syntax of via files accepted by the armar.

It contains the following sections:

- 3.1 Overview of via files on page 3-52.
- 3.2 Via file syntax rules on page 3-53.

3.1 Overview of via files

Via files are plain text files that allow you to specify librarian command-line arguments and options.

Typically, you use a via file to overcome the command-line length limitations. However, you might want to create multiple via files that:

- Group similar arguments and options together.
- Contain different sets of arguments and options to be used in different scenarios.

Note
In general, you can use a via file to specify any command-line option to a tool, includingvia. This
means that you can call multiple nested via files from within a via file.

Via file evaluation

When the librarian is invoked it:

- 1. Replaces the first specified --via *via_file* argument with the sequence of argument words extracted from the via file, including recursively processing any nested --via commands in the via file
- 2. Processes any subsequent --via *via_file* arguments in the same way, in the order they are presented.

That is, via files are processed in the order you specify them, and each via file is processed completely including processing nested via files before processing the next via file.

- 3.2 Via file syntax rules on page 3-53.
- 2.31 --via=filename on page 2-46.

3.2 Via file syntax rules

Via files must conform to some syntax rules.

- A via file is a text file containing a sequence of words. Each word in the text file is converted into an argument string and passed to the tool.
- Words are separated by whitespace, or the end of a line, except in delimited strings, for example:
 - -d -v (two words)
 - -d-v (one word)
- The end of a line is treated as whitespace, for example:

```
-d-v
```

This is equivalent to:

```
-d -v
```

• Strings enclosed in quotation marks ("), or apostrophes (') are treated as a single word. Within a quoted word, an apostrophe is treated as an ordinary character. Within an apostrophe delimited word, a quotation mark is treated as an ordinary character.

Use quotation marks to delimit filenames or path names that contain spaces, for example:

```
--via C:\My Project\viafile (three words)
```

```
--via "C:\My Project\viafile" (two words)
```

Use apostrophes to delimit words that contain quotes, for example:

```
-DNAME='"ARM Compiler"' (one word)
```

• Characters enclosed in parentheses are treated as a single word, for example:

```
--option(x, y, z) (one word)
```

```
--option (x, y, z) (two words)
```

- Within quoted or apostrophe delimited strings, you can use a backslash (\) character to escape the quote, apostrophe, and backslash characters.
- A word that occurs immediately next to a delimited word is treated as a single word, for example:

```
--via"C:\Project\viafile"
```

This is treated as the single word:

```
--viaC:\Project\viafile
```

• Lines beginning with a semicolon (;) or a hash (#) character as the first nonwhitespace character are comment lines. A semicolon or hash character that appears anywhere else in a line is not treated as the start of a comment, for example:

```
-o objectname.axf ;this is not a comment
```

A comment ends at the end of a line, or at the end of the file. There are no multi-line comments, and there are no part-line comments.

Related concepts

3.1 Overview of via files on page 3-52.

Related references

2.31 --via=filename on page 2-46.