
How to upgrade TP-LINK Range Extender

Part A: Please read this section carefully before upgrade

 Please verify the hardware version of your device match with the firmware you downloaded. Any incorrect firmware upgrading may damage your device and void the warranty.





- After you downloaded the firmware from TP-LINK website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder;
- 3. Do NOT turn off the power or cut down the Ethernet cable during upgrade process;
- 4. **Do NOT** upgrade the firmware via wireless connection unless the device only has wireless connection;
- 5. Please write down all the settings which you changed from the default values, since you may need to reenter them manually.

Part B: Please follow the steps below to upgrade firmware version


Step 1 Log into the TP-LINK device by typing http://tplinkrepeater.net/ in the address bar of the web browser (such as Internet Explorer). The username and password are both **admin** unless you have changed it before.



Step 2 Click **System Tools** → **Firmware Upgrade**, click the **Browse** button to choose the firmware you already extracted in the folder.



- **Step 3** Click the **Upgrade** button. The device will reboot automatically after the upgrading has been finished. Please wait about 3 minutes.
- **Step 4** Click **Status**, verify that the device's firmware has been upgraded.



Step 5 Check the status page of your device. if necessary, please re-enter or reconfigure the device manually with the parameters you have written down before upgrading.