CSE 431 Computer Architecture Fall 2015

Chapter 3: Arithmetic for Computers

Mary Jane Irwin (www.cse.psu.edu/~mji)

[Adapted from Computer Organization and Design, 5th Edition, Patterson & Hennessy, © 2014, MK]

Irwin, PSU, 2015

CSE431 Chapter 3.1

Reminders

- This lecture
 - MIPS arithmetic, PH Chapter 3, Appendix B
- Next week
 - MIPS single-cycle datapath and control, PH 4.1-4.4
 - MIPS pipelined datapaths, data hazards, PH 4.5-4.7
- Reminders
 - HW1 due midnight Sept 3rd in Angel DropBox
 - Quiz 1 will close midnight Sept 7th
 - Attend one of the unix + SimpleScalar tutorial sessions in the lab (218 IST) Sept 9th and 10th from 7:30 to 9pm
 - HW2 will come out Sept 4th (our first using SimpleScalar)
 - First evening midterm exam scheduled
 - Tuesday, October 6th, 20:15 to 22:15, Location 22 Deike
 - Please let me know ASAP (via email) if you have a conflict

CSE431 Chapter 3.2 Irwin, PSU, 2015

Review: MIPS (RISC) Design Principles

□ Simplicity favors regularity

- Makes implementation simpler, enables higher performance at lower design cost
 - fixed size instructions, small number of instruction formats, opcode always the first 6 bits, etc.

□ Smaller is faster/better

- Reduces design and implementation costs, improves chip yield, enables higher performance (and lower power?)
 - limited instruction set, limited number of registers in RF, limited number of addressing modes, etc.


■ Make the common case fast

- Find the biggest impact on performance and optimize that
 - arithmetic operands from the RF (load-store machine), immediate operands in instructions, etc.

□ Good design demands good compromises

- three instruction formats

CSE431 Chapter 3.3 Irwin, PSU, 2015



Number Representations

□ 32-bit signed integers (2's complement):

- Converting <32-bit values into 32-bit values</p>
 - copy the most significant bit (the sign bit) into the "empty" bits

0010 -> 0000 0010 1010 -> 1111 1010

• sign extend versus zero extend (1b vs. 1bu)

CSE431 Chapter 3.6 Irwin, PSU, 2015

MIPS Arithmetic Logic Unit (ALU)

Must support the Arithmetic/Logic operations of the ISA

```
add, addi, addiu, addu
sub, subu
mult, multu, div, divu
sqrt
and, andi, nor, or, ori, xor, xori
beq, bne, slt, slti, sltiu, sltu
```

zero ovf

- With special handling for
 - sign extend addi, addiu, slti, sltiu
 - zero extend andi, ori, xori
 - overflow detection add, addi, sub
 - overflow detection in software mult, div

CSE431 Chapter 3.7 Irwin, PSU, 2015

Detecting Overflow

- Overflow occurs when the result of an operation cannot be represented in 32-bits, i.e., when the sign bit contains a value bit of the result and not the proper sign bit
 - □ When adding operands with different signs or when subtracting operands with the same sign, overflow can *never* occur


Operation	Operand A	Operand B	Result indicating overflow
A + B	≥ 0	≥ 0	< 0
A + B	< 0	< 0	≥ 0
A - B	≥ 0	< 0	< 0
A - B	< 0	≥ 0	≥ 0

■ MIPS signals overflow with an exception (aka interrupt) – an unscheduled procedure call to the OS where the EPC contains the address of the instruction that caused the exception


CSE431 Chapter 3.8 Irwin, PSU, 2015

Addition and Subtraction on the MIPS ALU

- □ For addition, build a 32-bit adder from 32 1-bit adders. This is called a ripple-carry adder (RCA). Its slow, but easy to understand. How about subtraction?
 - Remember the "rules" for converting a 2s complement number to its negative equivalent?




□ In reality, just negating and then adding!



CSE431 Chapter 3.9 Irwin, PSU, 2015

But What about Performance?

□ The critical path of n-bit RCA is n*CP = O(n)



n	RCA	CLA
8		
16		
32		
64		
128		

□ Design trick – throw hardware at it (Carry Lookahead Adder) for an O(log n) adder

CSE431 Chapter 3.10 Irwin, PSU, 2015


Arithmetic for Multimedia Operations

- □ Graphics and media processing operates on vectors of 8-bit and 16-bit data
 - Use our 32-bit adder, with a "partitioned " carry chain
 - Operate on 4×8-bit, 2×16-bit, or 1×32-bit vectors
 - SIMD (single-instruction, multiple-data), data-level parallelism
- Saturating operations
 - On overflow, result is largest representable signed value
 - E.g., clipping in audio, saturation in video

CSE431 Chapter 3.12 Irwin, PSU, 2015

Multiply


□ Binary multiplication is just a *bunch* of right shifts and adds



"If war were arithmetic, the mathematicians would rule the world."

CSE431 Chapter 3.14

Add and Right Shift Multiplier Hardware



CSE431 Chapter 3.15

Irwin, PSU, 2015

MIPS Multiply Instruction

Multiply (mult and multu) produces a double precision product


mult \$s0, \$s1 # hi||lo = \$s0 * \$s1

0 16 17 0 0 0x18

alu \$s0 \$s1 unused unused mult

- Low-order word of the product is left in processor register 10 and the high-order word is left in register hi
- Instructions mfhi rd and mflo rd are provided to move the product to (user accessible) registers in the register file
- What is the speed of our add and right shift (serial) 4-bit multiplier assuming a RCA is used?
- Thus, multiplies are usually done by fast, dedicated hardware and are much more complex (and slower) than adders


CSE431 Chapter 3.17 Irwin, PSU, 2015



Division

 Division is just a bunch of quotient digit guesses and left shifts and subtracts


dividend = quotient x divisor + remainder



CSE431 Chapter 3.19

Irwin, PSU, 2015

Left Shift and Subtract Division Hardware



CSE431 Chapter 3.20

Aside: Previous Example, Step by Step

State of rem quot	How we got to that state
0000 0110	initialize remainder quotient with 0 dividend
0000 1100	shift left 1
1110 1100	trial subtract (remainder – divisor, 0000 – 0010 is 1110) set the lsb of quotient to 0
0000 1100	trial subtract result is negative, restore the previous remainder
0001 1000	shift left
1111 1000	trial subtract (0001 – 0010 is 1111) set the lsb of quotient to 0
0001 1000	trial subtract result is negative, restore the previous remainder
0011 0000	shift left
0001 0001	trial subtract (0011 – 0010 is 0001) set the lsb of quotient to 1
0010 0010	shift left
0000 0011	trial subtract (0010 – 0010 is 0000) set the lsb of quotient to 1

Isb of quotient is set to complement of msb of trial subtract result

CSE431 Chapter 3.22

Irwin, PSU, 2015

MIPS Divide Instruction

□ Divide (div and divu) generates the reminder in hi and the quotient in lo

- Instructions mfhi rd and mflo rd are provided to move the quotient and reminder to (user accessible) registers in the register file
- Speed? Hardware costs?
- As with multiply, divide ignores overflow so software must determine if the quotient is too large. Software must also check the divisor to avoid division by 0.

CSE431 Chapter 3.23 Irwin, PSU, 2015

Representing Big (and Small) Numbers

□ What if we want to encode the approx. age of the earth? 4,600,000,000 or 4.6 x 10°

or the weight in kg of one a.m.u. (atomic mass unit)
0.00000000000000000000000166 or 1.6 x 10⁻²⁷

There is no way we can encode either of the above in a 32-bit integer.

- □ Floating point representation (-1)^{sign} x F x 2^E
 - Still have to fit everything in 32 bits (single precision)

s E	(exponent)	F (fraction)
1 bit	8 bits	23 bits


- The base (2, not 10) is hardwired in the design of the FPALU
- More bits in the fraction (F) or the exponent (E) is a trade-off between precision (roughly, the accuracy of the number) and range (roughly, the magnitude of the number)

CSE431 Chapter 3.24 Irwin, PSU, 2015


Aside: Precision vs. Accuracy

- □ Precision and accuracy are not the same concept.
- Precision is a quality of one number on its own how many bits or digits do we retain?
 - How many do you trust? is a question for data collection, statistical analysis, numerical analysis, and hardware design.
- Accuracy is a quality of two numbers how close are they?
 - When discussing accuracy, one of the two numbers is assumed to be "right". For example, 4.5678 is precise to 5 digits, but as an approximation to π it is only accurate to one-half digit, since (4.5678 3.1416) / 3.1416 = 0.45397
 - When discussing precision, you could say that a number is accurate to within ½ unit in the last place. Why?


CSE431 Chapter 3.25 Irwin, PSU, 2015



Underflow (floating point) happens when a negative exponent becomes too large to fit in the exponent field



- One way to reduce the chance of underflow or overflow is to offer another format that has a larger exponent field
 - Double precision takes two MIPS words



CSE431 Chapter 3.26

Irwin, PSU, 2015

More Number Representations

□ 24-bit signed fractions (sign magnitude):

```
 \begin{array}{c} X = x_1 2^{-1} + x_2 2^{-2} + \ldots + x_{22} 2^{-22} + x_{23} 2^{-23} \\ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \\ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \\ 0000 \ 0000 \ 0000 \ 0000 \ 0001_{two} = + \ 2^{-23} \\ \vdots \\ 0111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \\ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \
```

- □ The most significant bit, s, is the sign bit of the fraction, F
 - To perform negation, just flip the sign bit (easy!)
 - The magnitude of the most positive F and most negative F are the same (not as in two's complement)
 - There are now two representations for an F of 0, one positive, one negative

CSE431 Chapter 3.27

IEEE 754 FP Standard


E (exponent) F (fraction) 8 bits 23 bits

- Most (all?) computers these days conform to the IEEE 754 floating point standard $(-1)^{sign}$ x (1+F) x 2^{E-bias}
 - With formats for both single and double precision
 - F is stored in normalized sign magnitude format
 - Normalized means that before the result is put into the FPRF, F is shifted (left) and E decremented (once for every left bit shift) until the msb of F is a 1 (so there is no need to store it!) - called the hidden bit
 - So when a value is read from the FPRF, the hidden bit of 1 has to be restored before performing computation
- To simplify sorting FP numbers, E comes before F in the word and E is represented in excess (biased) notation where the bias is 127 (1023 for double precision) so the most negative exponent is $00000001 = 2^{1-127} = 2^{-126}$ and the most positive exponent is 11111110 = $2^{254-127}$ = 2^{+127} (exponents 00000000 and 11111111 are reserved for special uses)

Irwin, PSU, 2015

Floating Point Arithmetic Hardware

□ Floating Point Register File (FPRF) and floating point ALU (FPALU)



CSE431 Chapter 3.29

IEEE 754 FP Examples

(1+F) x 2^{E-bias}

- □ Examples (in normalized format)

 - - Note that hardware detects true 0 (F and E all zeros) and does not restored the hidden bit of 1

 - $1.0_2 \times 2^{-1} =$
 - $0.75_{10} \times 2^4 =$

CSE431 Chapter 3.30

Irwin, PSU, 2015

IEEE 754 FP Standard Encoding

- □ Special encodings are used to represent unusual events
 - ± infinity for division by zero
 - NAN (not a number) for the results of invalid operations such as 0/0
 - True zero is the bit string all zero

Single Precision		Double Precision		Object
E (8)	F (23)	E (11)	F (52)	Represented
0000 0000	0	0000 0000	0	true zero (0)
0000 0000	nonzero	0000 0000	nonzero	± denormalized number
0000 0001 to 1111 1110	anything	0000 0001 to 1111 1110	anything	± floating point number
1111 1111	± 0	1111 1111	± 0	± infinity
1111 1111	nonzero	1111 1111	nonzero	not a number (NaN)

CSE431 Chapter 3.32

Support for Accurate Arithmetic

- □ IEEE 754 FP rounding modes
 - Always round up (toward +∞)
 - Always round down (toward -∞)
 - Truncate
 - Round to nearest even (when the Guard || Round || Sticky are 100) – always creates a 0 in the least significant (kept) bit of F
- Rounding (except for truncation) requires the FPALU to include three extra F bits during calculations
 - Guard bit G used to provide one F bit when shifting left to normalize a result (e.g., when normalizing F after division or subt)
 - Round bit R

 used to improve rounding accuracy
 - Sticky bit S used to support Round to nearest even; is set to a 1 whenever a 1 bit shifts (right) through it (e.g., when aligning F during addition/subtraction)

CSE431 Chapter 3.33

Irwin, PSU, 2015

Floating Point Addition

Addition (and subtraction)

$$(\pm F1 \times 2^{E1}) + (\pm F2 \times 2^{E2}) = \pm F3 \times 2^{E3}$$

- Step 0: Restore the hidden bit in F1 and in F2
- Step 1: Align fractions by right shifting F2 by E1 E2 positions (assuming E1 ≥ E2) keeping track of (three of) the bits shifted out in G R and S
- Step 2: Add the resulting F2 to F1 to form F3
- Step 3: Normalize F3 (so it is in the form 1.XXXXX ...)
 - If F1 and F2 have the same sign → F3 ∈[1,4) → 1 bit right shift F3 and increment E3 (check for overflow)
 - If F1 and F2 have different signs → F3 may require many left shifts each time decrementing E3 (check for underflow)
- Step 4: Round F3 and possibly normalize F3 again
- Step 5: Rehide the most significant (hidden) bit of F3 before storing the result

CSE431 Chapter 3.34

Floating Point Addition Example

Add

$$(0.5 = 1.0000 \times 2^{-1}) + (-0.4375 = -1.1100 \times 2^{-2})$$

- Step 0: Hidden bits restored in the representation above
- Step 1:
- Step 2:
- Step 3:
- Step 4:
- Step 5: Rehide the hidden bit before storing

CSE431 Chapter 3.35

Irwin, PSU, 2015

Floating Point Multiplication

Multiplication

$$(\pm F1 \times 2^{E1}) \times (\pm F2 \times 2^{E2}) = \pm F3 \times 2^{E3}$$

- Step 0: Restore the hidden bit in F1 and in F2
- Step 1: Add the two (biased) exponents and subtract the bias from the sum, so E1 + E2 – 127 = E3
 - also determine the sign of the product (which depends on the sign of the operands (their most significant bits))
- Step 2: Multiply F1 by F2 to form a double precision F3
- Step 3: Normalize F3 (so it is in the form 1.XXXXX ...)
 - Since F1 and F2 come in normalized \to F3 \in [1,4) \to 1 bit right shift F3 and increment E3
 - Check for overflow/underflow
- Step 4: Round F3 and possibly normalize F3 again
- Step 5: Rehide the most significant (hidden) bit of F3 before storing the result

CSE431 Chapter 3.37

Floating Point Multiplication Example

Multiply

$$(0.5 = 1.0000 \times 2^{-1}) \times (-0.4375 = -1.1100 \times 2^{-2})$$

- Step 0: Hidden bits restored in the representation above
- Step 1:
- Step 2:
- Step 3:
- Step 4:
- Step 5: Rehide the hidden bit before storing

CSE431 Chapter 3.38

Irwin, PSU, 2015

Irwin. PSU. 2015

MIPS Floating Point Instructions

□ MIPS has a separate Floating Point RF (\$f0, \$f1, ..., \$f31) (whose registers are used in *pairs* for double precision values) with special instructions to load to and store from them

```
lwcl $f1,54($s2) $f1 = Memory[$s2+54]
swcl $f1,58($s4) $memory[$s4+58] = $f1
```

□ And supports IEEE 754 single

```
add.s $f2,$f4,$f6 #$f2 = $f4 + $f6
```

and double precision operations

```
add.d $f2,$f4,$f6 #$f2||$f3 = $f4||$f5 + $f6||$f7
```

similarly for sub.s, sub.d, mul.s, mul.d, div.s,
div.d

CSE431 Chapter 3.40

MIPS Floating Point Instructions, Con't

□ And floating point single precision comparison operations

where x may be eq, neq, lt, le, gt, ge

and double precision comparison operations

And floating point branch operations

CSE431 Chapter 3.41 Irwin, PSU, 2015

Frequency of Common MIPS Instructions

□ Only included those with >3% and >1%

		SPECint	SPECfp
	addu	5.2%	3.5%
	addiu	9.0%	7.2%
	or	4.0%	1.2%
	sll	4.4%	1.9%
	lui	3.3%	0.5%
	lw	18.6%	5.8%
	sw	7.6%	2.0%
	lbu	3.7%	0.1%
	beq	8.6%	2.2%
	bne	8.4%	1.4%
	slt	9.9%	2.3%
	slti	3.1%	0.3%
	sltu	3.4%	0.8%
CSE43	CSE431 Chapter 3.42		

	SPECint	SPECfp
add.d	0.0%	10.6%
sub.d	0.0%	4.9%
mul.d	0.0%	15.0%
add.s	0.0%	1.5%
sub.s	0.0%	1.8%
mul.s	0.0%	2.4%
1.d	0.0%	17.5%
s.d	0.0%	4.9%
1.s	0.0%	4.2%
s.s	0.0%	1.1%
lhu	1.3%	0.0%

Pitfalls and Fallacies

- □ Fallacy: Just as a left shift instruction can replace an integer multiply by a power of 2, a right shift is the same as integer division by a power of 2.
 - True for unsigned integers, not true for 2's complement integers
 - E.g., $-5 \div 4 \rightarrow 11111011_2 >> 2 = 111111110_2 = -2$
 - Rounds toward -∞
- □ *Pitfall*: Floating-point addition is not associative.
 - Does c + (a + b) = (c + a) + b?
 - If c = -1.5 $_{10}$ x 10 38 , a = 1.5 $_{10}$ x 10 38 , and b = 1, then NO left way gives 0.0 and right way gives 1.0 due to limited precision limitations
- Fallacy: Parallel execution strategies that work for integer data types also work for FP data types
 - Order of arithmetic operations is important in FP (see Pitfall above)
 - For more take CmpSc 451, 454, 455

CSE431 Chapter 3.43 Irwin, PSU, 2015

What's Next and Reminders

- Next week
 - MIPS datapath and control, PH 4.1-4.4
 - MIPS pipelined datapaths, data hazards, PH 4.5-4.7
- Attend one of the unix + SimpleScalar tutorial sessions in the lab (218 IST) Sept 9th and 10th from 7:30 to 9pm (HW2 will contain a SimpleScalar simulation question)
- Reminders
 - HW1 due midnight Sept 3rd in Angel DropBox
 - Quiz 1 will close midnight Sept 7th
 - HW2 will come out Sept 4th (our first with a SimpleScalar question)
 - First evening midterm exam scheduled
 - Tuesday, October 6th, 20:15 to 22:15, Location 22 Deike
 - Please let me know ASAP (via email) if you have a conflict

CSE431 Chapter 3.44 Irwin, PSU, 2015