Synthesis Tool Invocation Commands

Version S-2021.06-SP2, October 2021



Copyright Notice and Proprietary Information

© 2021 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at http://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

Contents

cs_setup
man
ache_ls
ache_rm
reate_types
c_shell
e_shell
esign_vision
_shell
ynenc
ynopsys_users

acs_setup

This command is obsolete from 2000.05 release.

For more information about setting up directory structure and the project setup files, please refer to ACS user's guide.

acs_setup 4

aman

Displays Synopsys extended error messages.

SYNTAX

aman [error_message_code]

string error_message_code

ARGUMENTS

DESCRIPTION

Displays the Synopsys extended error message for the given error_message_code.

EXAMPLES

unix> aman HDLA-1

Command Reference N. Messages messages

NAME

HDLA-1 (error) Design '%s' does not contain HDL Advisor information.

DESCRIPTION

Either of the following cases may apply:

.....

WHAT NEXT

Fix your syntax errors and use ha_shell to read/analyze your HDL source files and regenerate the GTECH design.

unix>

aman 5

SEE ALSO

aman 6

cache_ls

Lists elements in a Synopsys cache.

SYNTAX

cache_ls cache_dir reg_expr

string cache_dir string reg_expr

ARGUMENTS

cache_dir

Specifies a UNIX pathname to the cache directory to be searched. The pathname should end with the directory component "synopsys_cache".

reg_expr

Specifies a regular expression to be used to match the pathname of each cache element that is to be listed. The regular expression is the type accepted by the UNIX egrep command.

DESCRIPTION

From the directory *cache_dir*, this command lists the cache elements whose pathname (as opposed to the filename) matches the expression *reg_expr*. The command is translated into the following UNIX command:

find cache_dir-type f -exec ck_path.sh {} reg_expr\; -print

As an aside, an easy way to get all the cache elements is the UNIX command "Is -R".

EXAMPLES

In this example, all of the cache elements with "add" in their pathname are listed:

% cache_ls ~/synopsys_cache add

This example lists cache elements that use lsi_10k or generic technology libraries:

% cache_ls ~/synopsys_cache "lsi_10k|generic"

SEE ALSO

cache_rm(1)

cache_ls 8

9

cache_rm

Removes elements from a Synopsys cache.

SYNTAX

cache_rm cache_dir reg_expr
string cache_dir

string reg_expr

ARGUMENTS

cache_dir

Specifies a UNIX pathname to a cache directory. The pathname should end with the directory component "synopsys_cache".

reg_expr

Specifies a regular expression to be used to match the pathname of each cache element that is to be removed. The regular expression is the type accepted by the UNIX egrep command.

DESCRIPTION

From the directory *cache_dir*, this command removes the cache elements whose pathname (as opposed to the filename) matches the expression *reg_expr*. The command is translated into the following UNIX command:

find cache_dir-type f -exec ck_path.sh {} reg_expr\; -print -exec rm {} \;

As an aside, an easy way to remove the entire cache directory is the UNIX command "rm -r".

EXAMPLES

In this example, all of the cache elements with "add" in their pathname are removed:

% cache_rm ~/synopsys_cache add

This example removes all cache elements that use lsi_10k or generic technology libraries:

% cache_rm ~/synopsys_cache "lsi_10k|generic"

cache rm

SEE ALSO

cache_ls(1)

cache_rm 10

create_types

Extracts user-defined type information from VHDL package files.

SYNTAX

create_types [-nc] [-w lib] [-v]
[-o logfile] file_list
string lib
string logfile
list file list

ARGUMENTS

-nc

Indicates that the initial copyright banner message is to be turned off.

-w lib

Specifies the name of a library that is to be mapped to the library logical name **WORK**. This option overrides any mapping specified in the user option file (.synopsys vss.setup).

-V

Indicates that **create_types** is to display program version information and then exit.

-o logfile

Specifies the name of a log file to which messages sent to the standard output are to be redirected. Use this option if you are running **create_types** in batch mode, or if you do not wish messages to be displayed during execution of **create_types**.

file list

Specifies the name(s) of one or more VHDL package files from which type information is to be extracted. Typically these files have the extension .vhd or .vhdl.

DESCRIPTION

Extracts type information from VHDL package files that contain user-defined VHDL types. For each package contained in the input VHDL file(s), **create_types** creates a *package.***typ** file. Creating the *package.***typ** file isolates the type information and makes it available to other utilities (for example, **dc_shell** (**analyze** or **read**); **vhdlan**; and DesignSource.) **create_types** places the **.typ** files in the design library mapped to the logical name **WORK**. To override the mapping in the user option file (**.synopsys_vss.setup**), use the **-w** *lib* option.

NOTE: Before running create_types on your VHDL package, you must have already run analyze, read, or vhdlan on the package.

create types 11

The type information contained in a .typ file is used by Synopsys synthesis and simulation tools when analyzing designs that use the user-defined types defined in the corresponding package. You must create .typ files to analyze designs or DesignWare components that use VHDL types not defined in STD.STANDARD. Notice that type information is used hierarchically. That is, if you analyze a high-level package that references user-defined types from lower-level packages, .typ files must exist for the lower-level packages.

The type information in .typ files is used also by Synopsys's DesignSource tools to perform type resolution and checking and to permit interactive type selection. You must create a .typ file in order for DesignSource to be aware of the user-defined types contained in a package.

FILES

\$SYNOPSYS/admin/setup/.synopsys_vss.setup

The first setup file **create_types** reads. This file contains the default setup.

\$HOME/.synopsys_vss.setup

The second setup file **create_types** reads. Settings in this file override those in **\$SYNOPSYS/admin/setup/.synopsys_vss.setup**.

./.synopsys_vss.setup

The last setup file **create types** reads. Settings in this file override those in **\$HOME**/.**synopsys vss.setup**.

filename.vhd

The VHDL package file that defines the user-defined types.

package.typ

The analyzed file that contains information about the user-defined types contained in *package*. These files are similar to the.syn and .sim files produced by VHDL Analyzer.

EXIT CODES

create_types exits with one of the following codes:

0

On Success (the data may have been analyzed with or without warnings)

2

Errors in the Input Data

3

Fatal Error

4

License Not Found

SEE ALSO

vhdlan(1) analyze(2) read(2)

create types 12

dc_shell

Invokes the Design Compiler command shell.

SYNTAX

dc shell

```
[-f script_file]
[-x command_string]
[-no_init]
[-no_home_init]
[-no_local_init]
[-checkout feature_list]
[-64bit]
[-wait wait_time]
[-timeout timeout_value]
[-version]
[-output_log_file console_log]
[-no_log]
[-topographical]
[-container]
```

Data Types

```
script_file string
command_string string
feature_list list
timeout_value integer
```

ARGUMENTS

-f script_file

Executes *script_file* (a file of dc_shell commands) before displaying the initial dc_shell prompt. If the last statement in *script_file* is **quit**, no prompt is displayed and the command shell is exited.

-x command string

Executes the do_shell statement in *command_string* before displaying the initial do_shell prompt. Multiple statements can be entered. Separate the statements with semicolons and enclose each statement with quotation marks around the entire set of command statements after the **-x** option. If the last statement entered is **quit**, no prompt is displayed and the command shell is exited.

-no init

Specifies that dc_shell is not to execute any .synopsys_dc.setup startup files. This option is only used when you want to include a command log or other script file in order to reproduce a previous Design Analyzer or dc_shell session. Include the script file either by using the **-f** option or by issuing the **include** command from within dc_shell.

-no_home_init

Specifies that dc_shell is not to execute any home .synopsys_dc.setup startup files.

-no local init

Specifies that dc_shell is not to execute any local .synopsys_dc.setup startup files.

-checkout feature_list

Specifies a list of licensed features to check out in addition to the default features checked out by the program.

-wait wait_time

Specifies the maximum wait time (in minutes), that dc_shell waits to check out the licensed features specified by the **-checkout** option. You can invoke dc_shell successfully only when all of the licensed features specified with the **-checkout** feature_list option can be checked out during the specified wait time.

-timeout timeout_value

Specifies a value from 5 to 20 that indicates the number of minutes the program spends trying to recover a lost contact with the license server before terminating. The default is 10 minutes.

-version

Displays the version number, build date, site id number, local administrator, and contact information, and then exits.

-64bit

Invokes the 64-bit executable of the Design Compiler command shell.

-output log file

Specifies a file to which the tool's console output is to be logged. Using this option causes the variable **sh_output_log_file** to be set and output logging is performed exactly as described in the man page for that variable.

-no_log

Disables command file logging for the session and creates a filenames log file such as:

<filename>_<pid>_<timestamp>.log.

-topographical

Enables Design Compiler topographical mode.

-container

Enables Design Compiler Container - a way to bundle all application system dependencies into a single package so that it can run on any host that supports the container engine regardless of what packages are installed on the host (needed for cloud computing).

DESCRIPTION

The **dc_shell** command interprets and executes Design Compiler and DFT Compiler commands. Design Compiler and DFT Compiler are Synopsys products that optimize logic. The dc_shell environment consists of user commands and variables that control the synthesis and optimization capabilities of Design Compiler and DFT Compiler.

The dc_shell command executes commands until it is terminated by a **quit** or **exit** command. During interactive mode, you can also terminate the dc_shell session by pressing Control-d.

To cancel or interrupt the command currently executing in dc_shell, press Control-c. The time it takes for a command to process an interrupt depends upon the size of the design and the command. If you press Control-c 3 times before a command responds to the interrupt, dc_shell exits and the following message is displayed:

Information: Process terminated by interrupt.

There are 3 types of statements in dc shell: assignment, control, and command.

There are 7 types of expressions: string, numeric, constant, variable, list, command, operator, and complex.

Statements and expressions are discussed in detail in the following subsections.

Special Characters

The pipe character (|) has no meaning in dc_shell. Use backslash e (\e) to escape double quotes when executing a UNIX command. For example, the following command requires backslash characters before the double quotes to prevent Design Compiler from ending the command prematurely:

```
dc_shell> sh \'grep \'foo\' my_file\'
```

Assignment Statements

An assignment statement assigns the value of the expression on the right side of an equal sign to the variable named on the left side of the equal sign.

The syntax of an assignment statement is as follows:

```
variable_name = expression
```

The following are examples of dc_shell assignment statements:

```
dc_shell> hlo_ignore_priorities = "false"
dc shell> text threshold = 6
```

The following are examples of dc_shell assignment statements for float numbers:

```
dc_shell> my_float = 100.3
100.300003
dc_shell> my_another_float = 123456700.0
123456704.000000
```

The dc_shell environment uses 32 bit IEEE format to represent floating point numbers. This format cannot represent all numbers exactly, so the returned number may not always be the number originally specified. Typically, only the first 6 or 7 digits are precisely represented. Beyond that, there can be some variance.

Control Statements

The **if** and **while** control statements allow conditional execution and looping in dc_shell language. The syntax of the basic **if** statement is as follows:

```
if ( condition ) {
  statement_list
}
```

Other forms of the if statement allow the use of else and else if.

The syntax of the while statement is as follows:

```
while ( condition ) {
  statement_list
}
```

For a discussion of relational and logical operators used in the control statements, see the *Operator Expressions* and *Complex Expressions* sections of this man page.

Command Statements

The dc_shell invokes the specified command with its arguments. The following example show the syntax of a command statement:

```
command name argument 1 argument 2 ... argument n
```

Arguments are separated by commas or spaces and can be enclosed in parentheses. The following are examples of dc_shell command statements:

```
dc_shell> set_max_delay 0 "OUT_PIN_1"
dc_shell> create_schematic ("-size", "A", "-hierarchy")
dc_shell> compile
```

String Expressions

A string expression is a sequence of characters enclosed in quotation marks (""). The following are examples of string expressions:

```
"my_design_name"

"~/dir_1/dir_1/file_name"

"this is a string"
```

Numeric Constant Expressions

Numeric constant expressions are numeric values. They must begin with a digit and can contain a decimal point; a leading sign can also be included. Exponential notation is recognized. The following are examples of numeric constant expressions:

```
123
-234.5
123.4e56
```

Variable Expressions

A variable expression recalls the value of a previously-defined variable. Variable names can contain letters, digits, and most punctuation characters, but cannot start with a digit. The following are examples of variable expressions:

```
current_design
name/name
-all
+-*/.:'#~`%$&^@! []|?
```

If a variable used in an expression has not previously been assigned a value in an assignment statement, then its value is a string containing the variable name. The following two command statements are equivalent, assuming there is no variable defined with the **-hierarchy** option:

```
dc_shell> create_schematic -hierarchy
dc_shell> create_schematic "-hierarchy"
```

This feature allows you to omit the quotes around many strings. For example, the following commands are equivalent, assuming there are no variables called "~user/dir/file", "equation", or "-f").

```
dc_shell> read "-f" "equation" "~user/dir/file"
dc_shell> read -f equation ~user/dir/file
```

List Expressions

A list expression defines a list constant. The list can include pathnames, cell names or pin names, values, etc. The syntax of a list expression is as follows:

```
{ expression 1 expression 2 ... expression n }
```

Expressions are separated by spaces or commas. The following are examples of list expressions:

```
{}
{"pin_1" "pin_2" "pin_3"}
{1,2,3,4,5}
```

Command Expressions

A command expression invokes a dc_shell command and returns its value. The syntax of a command expression is the same as that of a command statement, except that parentheses are required in a command expression and are optional in a command statement. Commas separating arguments are optional for both. The following are examples of command expressions:

```
dc_shell> all_inputs( )
dc_shell> create_schematic ("-size" "a" "-hierarchy")
dc_shell> set_max_delay(0 "OUT_PIN_1")
```

Operator Expressions

Operator expressions perform simple arithmetic and string and list concatenation. The syntax of an operator expression is as follows:

```
expression operator expression
```

The *operator* is "+", "-", "*", or "/", and is separated by at least one preceding and one following space. Operator expressions involving numbers return the computed value. The "+" operator can be used with strings and lists to perform concatenation. The following are examples of operator expressions:

```
234.23 - 432.1

100 * scale

file_name_variable + ".suffix"

{portA, portB} + "portC"
```

The relational operators "==", "!=", ">", ">=", "<", and "<=" are used in the control statements **if** and **while**. The greater than (>) operator should only be used in expressions with parentheses to avoid confusion with the file redirection operator ">".

The logical operators "&&", "||", and "!" (and, or, not) are also used in the **if** and **while** control statements. The "not" operator is different from the other operators in that it is a unary operator with the following syntax:

! expression

Complex Expressions

Expressions can be built from other expressions, creating complex expressions. When a complex expression contains more than one operator, dc_shell satisfies multiplication and division operators before addition and subtraction. Simple expressions enclosed in parentheses take priority and override this rule. The expression "1 + 2 * 3 + 4" has the value 11, and "(1 + 2) * (3 + 4)" has the value 21.

The following is an example of an **assignment** statement containing complex expressions:

```
dc_shell> my_variable = set_max_delay(23.2 * scaling_factor, \
    all_outputs())
```

In this example, "my_variable" is assigned the value returned by the **set_max_delay** command expression. The **set_max_delay** command is invoked with two arguments. The first argument is an operator expression that returns the value of the variable expression "scaling_factor" multiplied by the numeric constant expression "23.2". The second argument is a command expression that is equal to the value returned by the **all_outputs** command. The **all_outputs** command is called with no arguments.

The following is an example of a complex command statement:

```
dc shell> read -f edif ~user/dir/ + file name
```

In this example, the **read** command is called with 3 arguments. If you assume that "-f", "edif" and "~user/dir/" are not defined variables, and that *file_name*" is assigned the value *my_design*, then the first argument to the **read** command is the string "-f". The second argument is the string "edif". The third argument is the concatenation of the string "~user/dir/" with the string *my_design*. The third argument to the **read** command is the string "~user/dir/my_file". The relational and logical operators can be used in combination to form complex conditions. The following are examples of complex conditional expressions:

```
(goal >= 7.34 || ! complete)

(a >= 7 || run_mode != "test" && !(error_detected == true))

(cycle < 4 && test == true || design_area > area_goal)
```

Complex logical expressions are evaluated from left to right, with "&&" being evaluated before "||". However, those expressions enclosed in parentheses are evaluated first.

Command Arguments

Many dc_shell commands have required or optional arguments that allow you to further define, limit, or expand the scope of their operation.

This man page contains a comprehensive list and description of these arguments. You can also use the **help** command to view the man page online. For example, to view the online man page of the **ungroup** command, enter the following command:

```
dc_shell> help ungroup
```

Many commands also offer a **-help** option that lists the arguments available for that command. For example:

Arguments that do not begin with a hyphen (-) are positional arguments. Positional arguments must be entered in a specific order. Non-positional arguments (those beginning with a hyphen) can be entered in any order and can be intermingled with positional arguments.

The names of non-positional arguments can be abbreviated to the minimum number of characters required to distinguish them from the other arguments.

The following commands are equivalent:

```
dc_shell> ungroup MODULAR -flatten -prefix MOD

dc_shell> ungroup -flatten -prefix MODULAR MOD

dc_shell> ungroup -f MODULAR -p MOD
```

Many arguments are optional, but if you omit a required argument, an error message and usage statement is displayed. For example:

Multiple Statement Lines and Multiple Line Statements

Normally, only one command is typed on a single line. To put more than one command on a line, must separate each command with a semicolon. For example:

There is no limit to the number of characters on a dc_shell command line, but you can break a long command into multiple lines by terminating all but the last line with a backslash (\e). This tells dc_shell to expect the command to continue on the next line.

```
dc_shell> read -f equation\
{file_1, file_2, file_3,\
file_4, file_5, file_6}
```

This feature is normally used in files containing dc_shell commands (script files).

Output Redirection

The dc_shell allows you to divert command output messages to a file. To do this, type "> file_name" after any statement. The following example deletes the old contents of "my_file" and writes the output of the **report hierarchy** command to the file:

```
dc_shell> report_hierarchy > my_file
```

You can append the output of a command to a file with ">>". The following example appends the hierarchy report to the contents of my_file:

```
dc_shell> report_hierarchy >> my_file
```

Aliases

The **alias** command gives you the ability to define new commands in terms of existing ones. You can reduce the number of keystrokes by defining short aliases for the commands and options you use most often.

The following example defines a new command called **com** that is equivalent to running the **compile** command with the **-no_map** option.

```
dc shell> alias com compile -no_map
```

With the **com** alias defined, the following two commands are equivalent:

```
dc_shell> compile -no_map -verify
dc shell> com -verify
```

Alias definitions can be placed in your .synopsys_dc.setup file or in a separate file. The advantage of keeping aliases in a separate file is that all defined aliases can be written to a file with a command such as:

```
dc shell> alias > ~/.synopsys aliases
```

This works only if you put the command **include** ~/.**synopsys_aliases** in your .synopsys_dc.setup file. The aliases are defined every time you start a new dc_shell session.

An alias is expanded only if it is the first token in a command, so aliases cannot be used as arguments to other commands.

History

A record is kept of all dc_shell commands issued during any given dc_shell session. The **history** command displays a list of these commands.

```
dc_shell> history
1 read -f equation my_design.eqn
2 compile -no_map
3 create schematic
```

...

Your previous commands can be re-executed with the following "!" commands:

!!

Expands to the previous command.

!number

Expands to the command whose number in the history list matches *number*.

!-number

Expands to the command whose number in the history list matches the current command minus number.

!text

Expands to the most recent command that starts with *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

!?text

Expands to the most recent command that contains *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

As with aliases, a "!" command must be the first token in a statement, but not necessarily the only one.

```
dc_shell> read -f equation my_design.eqn
dc_shell> compile
dc_shell> !! -no_m /* Recompile with the -no_m option */
dc_shell> history
    1 read -f equation my_design.eqn
    2 compile
    3 compile -no_m
    4 history
```

Given the previous history, the following commands are equivalent:

```
dc_shell> !-4 -s file /* Same as command 1 */
dc_shell> !1 -s file
dc_shell> !re -s file
dc_shell> !?eqn -s file
dc_shell> !?ead -s file
```

Additional parameters can be included in a ! command statement. The above examples include the -single_file option of the read command.

More than one ! command can appear in a line as long as each is the first token in a statement.

```
dc_shell> !?q; !c; !4
```

The previous command is the same as the following:

```
dc_shell> read -f equation my_design.eqn
```

```
dc_shell> compile -no_m
dc_shell> history
```

SEE ALSO

design_analyzer(1)
alias(2)
history(2)
if(2)
include(2)
while(2)
sh_output_log_file(3)

dc_shell 21

de_shell

Invokes the DC Explorer command shell.

SYNTAX

de shell

[-f script_file]
[-x command_string]
[-no_init]
[-no_home_init]
[-no_local_init]
[-checkout feature_list]
[-64bit]
[-wait wait_time]
[-timeout timeout_value]
[-version]
[-no_log]
[-container]

Data Types

script_file string
command_string string
feature_list list
timeout_value integer

ARGUMENTS

-f script_file

Executes *script_file* (a file of de_shell commands) before displaying the initial de_shell prompt. If the last statement in *script_file* is **quit**, no prompt is displayed and the command shell is exited.

-x command_string

Executes the de_shell statement in *command_string* before displaying the initial de_shell prompt. Multiple statements can be entered. Separate the statements with semicolons and enclose each statement with quotation marks around the entire set of command statements after the **-x** option. If the last statement entered is **quit**, no prompt is displayed and the command shell is exited.

-no init

Specifies that de_shell is not to execute any .synopsys_dc.setup startup files. This option is only used when you want to include a command log or other script file in order to reproduce a previous Design Analyzer or de_shell session. Include the script file either by using the **-f** option or by issuing the **include** command from within de_shell.

-no_home_init

Specifies that de_shell is not to execute any home .synopsys_dc.setup startup files.

de_shell 22

-no local init

Specifies that de_shell is not to execute any local .synopsys_dc.setup startup files.

-checkout feature_list

Specifies a list of licensed features to check out in addition to the default features checked out by the program.

-wait wait_time

Specifies the maximum wait time (in minutes), that de_shell waits to check out the licensed features specified by the **-checkout** option. You can invoke de_shell successfully only when all of the licensed features specified with the **-checkout** feature_list option can be checked out during the specified wait time.

-timeout timeout_value

Specifies a value from 5 to 20 that indicates the number of minutes the program spends trying to recover a lost contact with the license server before terminating. The default is 10 minutes.

-version

Displays the version number, build date, site id number, local administrator, and contact information, and then exits.

-64bit

Invokes the 64-bit executable of the DC Explorer command shell.

-no log

Disables command file logging for the session and creates a filenames log file such as:

-container

Enables Container - a way to bundle all application system dependencies into a single package so that it can run on any host that supports the container engine regardless of what packages are installed on the host (needed for cloud computing).

<filename> <pid> <timestamp>.log.

DESCRIPTION

The **de_shell** command interprets and executes DC Explorer commands. DC Explorer is a Synopsys product that optimize logic. The de_shell environment consists of user commands and variables that control the synthesis and optimization capabilities of DC Explorer.

The de_shell command executes commands until it is terminated by a **quit** or **exit** command. During interactive mode, you can also terminate the de_shell session by pressing Control-d.

To cancel or interrupt the command currently executing in de_shell, press Control-c. The time it takes for a command to process an interrupt depends upon the size of the design and the command. If you press Control-c 3 times before a command responds to the interrupt, de_shell exits and the following message is displayed:

Information: Process terminated by interrupt.

There are 3 types of statements in de_shell: assignment, control, and command.

There are 7 types of expressions: string, numeric, constant, variable, list, command, operator, and complex.

Statements and expressions are discussed in detail in the following subsections.

Special Characters

The pipe character (|) has no meaning in de_shell. Use backslash e (\e) to escape double quotes when executing a UNIX command. For example, the following command requires backslash characters before the double quotes to prevent DC Explorer from ending the command prematurely:

```
de_shell> sh \'grep \'foo\' my_file\'
```

Assignment Statements

An assignment statement assigns the value of the expression to the variable named in the set statement.

The syntax of an assignment statement is as follows:

```
set variable_name expression
```

The following are examples of de shell assignment statements:

```
de_shell> set hlo_ignore_priorities false
de_shell> set text_threshold 6
```

The following are examples of de_shell assignment statements for float numbers:

```
de_shell> set my_float 100.3
100.300003
de_shell> set my_another_float 123456700.0
123456704.000000
```

The de_shell environment uses 32 bit IEEE format to represent floating point numbers. This format cannot represent all numbers exactly, so the returned number may not always be the number originally specified. Typically, only the first 6 or 7 digits are precisely represented. Beyond that, there can be some variance.

Control Statements

The **if** and **while** control statements allow conditional execution and looping in de_shell language. The syntax of the basic **if** statement is as follows:

```
if ( condition ) {
  statement_list
}
```

Other forms of the if statement allow the use of else and else if.

The syntax of the while statement is as follows:

```
while ( condition ) {
  statement_list
}
```

For a discussion of relational and logical operators used in the control statements, see the *Operator Expressions* and *Complex Expressions* sections of this man page.

Command Statements

The de_shell invokes the specified command with its arguments. The following example show the syntax of a command statement:

```
command_name argument_1 argument_2 ... argument_n
```

Arguments are separated by commas or spaces and can be enclosed in parentheses. The following are examples of de_shell command statements:

```
de_shell> set_max_delay 0 "OUT_PIN_1"
de_shell> compile_exploration
```

String Expressions

A string expression is a sequence of characters enclosed in quotation marks (""). The following are examples of string expressions:

```
"my design name"
```

```
"~/dir_1/dir_1/file_name"

"this is a string"
```

Numeric Constant Expressions

Numeric constant expressions are numeric values. They must begin with a digit and can contain a decimal point; a leading sign can also be included. Exponential notation is recognized. The following are examples of numeric constant expressions:

```
123
-234.5
123.4e56
```

Variable Expressions

A variable expression recalls the value of a previously-defined variable. Variable names can contain letters, digits, and most punctuation characters, but cannot start with a digit. The following are examples of variable expressions:

```
current_design
name/name
-all
+-*/.:'#~`%$&^@!_[]|?
```

If a variable used in an expression has not previously been assigned a value in an assignment statement, then its value is a string containing the variable name. The following two command statements are equivalent, assuming there is no variable defined with the **-hierarchy** option:

```
de_shell> write -hierarchy
de shell> write "-hierarchy"
```

This feature allows you to omit the quotes around many strings. For example, the following commands are equivalent, assuming there are no variables called "~user/dir/file", "equation", or "-f").

```
de_shell> read "-f" "equation" "~user/dir/file"
de shell> read -f equation ~user/dir/file
```

List Expressions

A list expression defines a list constant. The list can include pathnames, cell names or pin names, values, etc. The syntax of a list expression is as follows:

```
{ expression_1 expression_2 ... expression_n }
```

Expressions are separated by spaces or commas. The following are examples of list expressions:

```
{} 
{"pin_1" "pin_2" "pin_3"} 
{1,2,3,4,5}
```

Command Expressions

A command expression invokes a de_shell command and returns its value. The syntax of a command expression is the same as that of a command statement, except that parentheses are required in a command expression and are optional in a command statement. Commas separating arguments are optional for both. The following are examples of command expressions:

```
de_shell> all_inputs( )
de shell> set max delay(0 "OUT PIN 1")
```

Operator Expressions

Operator expressions perform simple arithmetic and string and list concatenation. The syntax of an operator expression is as follows:

expression operator expression

The *operator* is "+", "-", "*", or "/", and is separated by at least one preceding and one following space. Operator expressions involving numbers return the computed value. The "+" operator can be used with strings and lists to perform concatenation. The following are examples of operator expressions:

```
234.23 - 432.1

100 * scale

file_name_variable + ".suffix"

{portA, portB} + "portC"
```

The relational operators "==", "!=", ">", ">=", "<", and "<=" are used in the control statements **if** and **while**. The greater than (>) operator should only be used in expressions with parentheses to avoid confusion with the file redirection operator ">".

The logical operators "&&", "||", and "!" (and, or, not) are also used in the **if** and **while** control statements. The "not" operator is different from the other operators in that it is a unary operator with the following syntax:

! expression

Complex Expressions

Expressions can be built from other expressions, creating complex expressions. When a complex expression contains more than one operator, de_shell satisfies multiplication and division operators before addition and subtraction. Simple expressions enclosed in parentheses take priority and override this rule. The expression "1 + 2 * 3 + 4" has the value 11, and "(1 + 2) * (3 + 4)" has the value 21.

The following is an example of an **assignment** statement containing complex expressions:

```
de_shell> set my_variable [set_max_delay(23.2 * scaling_factor, \
    all_outputs())]
```

In this example, "my_variable" is assigned the value returned by the **set_max_delay** command expression. The **set_max_delay** command is invoked with two arguments. The first argument is an operator expression that returns the value of the variable expression "scaling_factor" multiplied by the numeric constant expression "23.2". The second argument is a command expression that is equal to the value returned by the **all_outputs** command. The **all_outputs** command is called with no arguments.

The following is an example of a complex command statement:

```
de_shell> read -f edif ~user/dir/ + file_name
```

In this example, the **read** command is called with 3 arguments. If you assume that "-f", "edif" and "~user/dir/" are not defined variables, and that *file_name*" is assigned the value my_design , then the first argument to the **read** command is the string "-f". The second argument is the string "edif". The third argument is the concatenation of the string "~user/dir/" with the string my_design . The third argument to the **read** command is the string "~user/dir/my_file". The relational and logical operators can be used in combination to form complex conditions. The following are examples of complex conditional expressions:

```
(goal >= 7.34 || ! complete)

(a >= 7 || run_mode != "test" && !(error_detected == true))

(cycle < 4 && test == true || design area > area goal)
```

Complex logical expressions are evaluated from left to right, with "&&" being evaluated before "||". However, those expressions enclosed in parentheses are evaluated first.

Command Arguments

Many de_shell commands have required or optional arguments that allow you to further define, limit, or expand the scope of their operation.

This man page contains a comprehensive list and description of these arguments. You can also use the **help** command to view the man page online. For example, to view the online man page of the **ungroup** command, enter the following command:

```
de_shell> help ungroup
```

Many commands also offer a **-help** option that lists the arguments available for that command. For example:

```
de shell> ungroup -help
Usage: ungroup # ungroup hierarchy
     [-all]
                    (ungroup all cells)
     [-prefix <prefix>]
                         (prefix to use in naming cells)
     [-flatten]
                      (expand all levels of hierarchy)
     [-simple names]
                           (use simple, non-hierarchical names)
     [-small < n>]
                        (ungroup all small hierarchy:
                     Value >= 1)
                      (ungroup dont touched cells as well)
     [-force]
                     (remove group name attribute)
     [-soft]
     [-start level <n>]
                         (flatten cells from level:
                     Value >= 1)
     [-all instances]
                         (Ungroup all the instances of the cell)
     [cell list]
                     (list of cells to be ungrouped)
```

Arguments that do not begin with a hyphen (-) are positional arguments. Positional arguments must be entered in a specific order. Non-positional arguments (those beginning with a hyphen) can be entered in any order and can be intermingled with positional arguments.

The names of non-positional arguments can be abbreviated to the minimum number of characters required to distinguish them from the other arguments.

The following commands are equivalent:

```
de_shell> ungroup MODULAR -flatten -prefix MOD

de_shell> ungroup -flatten -prefix MODULAR MOD

de shell> ungroup -f MODULAR -p MOD
```

Many arguments are optional, but if you omit a required argument, an error message is displayed. For example:

```
de_shell> group
Error: Current design is not defined. (UID-4)
0
```

Multiple Statement Lines and Multiple Line Statements

Normally, only one command is typed on a single line. To put more than one command on a line, must separate each command with a semicolon. For example:

```
de_shell> read -f equation my_file.eqn; set_max_area 0; compile_exploration; \
    report constraint; report timing
```

There is no limit to the number of characters on a de_shell command line, but you can break a long command into multiple lines by terminating all but the last line with a backslash (\e). This tells de shell to expect the command to continue on the next line.

```
de_shell> read -f equation\
{file_1, file_2, file_3,\
file_4, file_5, file_6}
```

This feature is normally used in files containing de shell commands (script files).

Output Redirection

The de_shell allows you to divert command output messages to a file. To do this, type "> file_name" after any statement. The following example deletes the old contents of "my_file" and writes the output of the **report_hierarchy** command to the file:

```
de shell> report hierarchy > my file
```

You can append the output of a command to a file with ">>". The following example appends the hierarchy report to the contents of my_file:

```
de shell> report hierarchy >> my file
```

Aliases

The **alias** command gives you the ability to define new commands in terms of existing ones. You can reduce the number of keystrokes by defining short aliases for the commands and options you use most often.

The following example defines a new command called **com** that is equivalent to running the **compile_exploration** command with the **-scan** option.

```
de shell> alias com compile exploration -scan
```

With the **com** alias defined, the following two commands are equivalent:

```
de_shell> compile_exploration -scan -gate_clock
```

```
de shell> com -gate clock
```

Alias definitions can be placed in your .synopsys_dc.setup file or in a separate file. The advantage of keeping aliases in a separate file is that all defined aliases can be written to a file with a command such as:

```
de_shell> alias > ~/.synopsys_aliases
```

This works only if you put the command **include** ~/.synopsys_aliases in your .synopsys_dc.setup file. The aliases are defined every time you start a new de_shell session.

An alias is expanded only if it is the first token in a command, so aliases cannot be used as arguments to other commands.

History

A record is kept of all de_shell commands issued during any given de_shell session. The **history** command displays a list of these commands.

```
de shell> history
```

- 1 read -f verilog my_design.v
- 2 compile exploration -scan
- 3 report constraint

...

Your previous commands can be re-executed with the following "!" commands:

!!

Expands to the previous command.

!number

Expands to the command whose number in the history list matches *number*.

!-number

Expands to the command whose number in the history list matches the current command minus *number*.

!text

Expands to the most recent command that starts with *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

!?text

Expands to the most recent command that contains *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

As with aliases, a "!" command must be the first token in a statement, but not necessarily the only one.

```
de_shell> read -f verilog my_design.v

de_shell> compile_exploration

de_shell> !! -gate_clock /* Recompile with the -gate_clock option */

de_shell> history

1 read -f verilog my_design.v

2 compile_exploration

3 compile_exploration -gate_clock

4 history
```

Given the previous history, the following commands are equivalent:

```
de_shell> !-4 -s file /* Same as command 1 */
de_shell> !1 -s file
de_shell> !re -s file
de_shell> !?eqn -s file
de_shell> !?ead -s file
```

Additional parameters can be included in a ! command statement. The above examples include the **-single_file** option of the **read** command.

More than one ! command can appear in a line as long as each is the first token in a statement.

```
de_shell> !?q; !c; !4

The previous command is the same as the following:

de_shell> read -f verilog my_design.v

de_shell> compile_exploration -scan
```

SEE ALSO

```
alias(2)
history(2)
if(2)
include(2)
while(2)
sh_output_log_file(3)
```

de_shell> history

design_vision

Runs Design Vision visualization for Synopsys synthesis products.

SYNTAX

```
design_vision [-f script_file]
[-x command_string]

[-no_init] [-checkout feature_list]
[-timeout timeout_value] [-version]
[-behavioral]
[-syntax_check | -context_check]
[-tcl_mode]
[-container]

string script_file

string command_string

list feature_list

float timeout_value
```

ARGUMENTS

-f script_file

Executes a specified script file (a file of dc_shell commands) before displaying the initial Design Vision window.

-x command_string

Executes the dc_shell command in the specified command string before displaying the initial Design Vision window. You can enter multiple commands if you separate each by a semicolon.

-no_init

Tells dc_shell not to execute any .synopsys_dc.setup startup files. This option is used only when you have a command log or other script file that you want to include in order to reproduce a previous Design Analyzer or dc_shell session.

-checkout feature_list

Specifies a list of licensed features to be checked out in addition to default features checked out by the program.

-timeout timeout_value

Specifies a value from 5 to 20 that indicates the number of minutes the program will spend trying to recover a lost contact with the

design_vision 30

license server before terminating. The default is 10 minutes.

-version

Displays the version number, build date, site id number, local administrator, and contact information; then exits.

-behavioral

Invokes dc shell in Behavioral Compiler mode. This argument is required for synthesizing behavioral designs.

-syntax check

Invokes dc_shell in syntax_checking mode which causes the command interpreter to check for syntax errors instead of executing commands.

-context check

Invokes dc_shell in context_checking mode which causes the command interpreter to check for context errors instead of executing commands.

-tcl mode

Invokes dc_shell in Tcl mode which brings up the Tcl user interface shell with the design_vision-t prompt. All commands in this shell should be in Tcl format. The default is to invoke dc_shell in egn mode.

-container

Enables Container - a way to bundle all application system dependencies into a single package so that it can run on any host that supports the container engine regardless of what packages are installed on the host (needed for cloud computing).

DESCRIPTION

The design_vision command runs Design Vision visualization for Synopsys synthesis products.

For information about Design Vision menus and features, see Design Vision online help.

EXAMPLES

Use the following command to start Design Vision visualization:

% design_vision

or

 $\% \ design_vision \ \text{-tcl_mode}$

The following command starts Design Vision and executes the commands found in the script file "test_adder."

% design_vision -f test_adder

SEE ALSO

dc_shell(1) context_check(2)

design vision 31

syntax_check(2)
schematic_variables(3)
view_variables(3)

design_vision 32

Ic_shell

Runs the Library Compiler command shell.

SYNTAX

Ic shell

[-f script_file] [-x command_string] [-no_init] [-version]

Data Types

script_file string
command_string string

ARGUMENTS

-f script_file

Executes *script_file* (a file of **lc_shell** commands) before displaying the initial **lc_shell** prompt. If the last statement in *script_file* is **quit**, no prompt is displayed and the command shell is exited.

-x command_string

Executes the **Ic_shell** statement in *command_string* before displaying the initial **Ic_shell** prompt. Multiple statements can be entered, each statement separated by a semicolon. See the *Multiple Statement Lines and Multiple Line Statements* subsection of this manual page. If the last statement entered is **quit**, no prompt is displayed and the command shell is exited.

-no init

Tells the **lc_shell** not to execute any **.synopsys_lc.setup** *startup files*. This option is only used when you have a command log or other script file that you want to include in order to reproduce a previous Library Compiler graphical interface or **lc_shell** session. You can include the script file either by using the **-f** option or by issuing the **include** command from within **lc_shell**.

-version

Displays the version number, build date, site identification number, local administrator, and contact information, and then exits.

DESCRIPTION

Interprets and executes library compiler commands. The **Ic_shell** environment consists of user commands and variables that control the creation and manipulation of libraries

The Ic_shell executes commands until it is terminated by a quit or exit command. During interactive mode, you can also terminate the

lc_shell session by typing Control-d.

To cancel (interrupt) the command currently executing in **Ic_shell**, type Control-c. The time it takes for a command to process an interrupt (stop what it is doing and continue with the next command) depends upon the size of the library and the type of command. If you enter Control-c three times before a command responds to the interrupt, **Ic_shell** exits and the following message is displayed:

Information: Process terminated by interrupt.

There are three basic types of statements in **ic shell**:

- · assignment
- control
- command

Additionally, there are seven types of expressions:

- string
- numeric
- constant
- variable
- list
- command
- operator
- complex

Statements and expressions are discussed in detail in the following subsections.

Special Characters

```
The pipe character (|) has no meaning in lc_shell. Use the backslash () to escape double quotes when executing a UNIX command. For example, the following command requires backslash characters before the double quotes to prevent Design Compiler from ending the command prematurely:
```

Assignment Statements

Ic shell> sh \'grep \'foo\' my file\'.

An assignment statement assigns the value of the expression on the right side of an equal sign to the variable named on the left side of the equal sign.

The syntax of an assignment statement is: variable_name = expression

Following are examples of **Ic_shell** assignment statements: Ic_shell> **command_log = "file.log"** Ic_shell> **vhdllib_architecture = "FTGS"**

Control Statements

The two control statements **if** and **while** allow conditional execution and looping in the**lc_shell** language. The syntax of the basic **if** statement is:

```
if ( condition ) {
  statement_list
}
```

Other forms of the **if** statement allow use of **else** and **else if**. See the description of the **if** statement in the *Synopsys Commands* section of this manual for details.

The syntax of the while statement is:

```
while ( condition ) {
  statement_list
}
```

See the description of the **while** statement in the *Synopsys Commands* section of this manual for more details. See the *Operator Expressions* and *Complex Expressions* subsections of this manual page for a discussion of relational and logical operators used in the control statements.

Command Statements

The **Ic** shell invokes the specified command with its arguments. The syntax of a command statement is:

```
command_name argument_1 argument_2 ... argument_n
```

Arguments are separated by commas or spaces and can be enclosed in parentheses. Following are examples of Ic_shell command statements: Ic_shell> read_lib my_lib.lib Ic_shell> report_lib my_lib

String Expressions

A string expression is a sequence of characters enclosed within quotation marks (""). Following are examples of string expressions: "my lib name" "~/dir 1/file name" "this is a string"

Numeric Constant Expressions

Numeric constant expressions are numeric values. They must begin with a digit and can contain a decimal point; a leading sign can be included. Exponential notation is also recognized. Following are examples of numeric constant expressions: 123 -234.5 123.4e56

Variable Expressions

A variable expression recalls the value of a previously-defined variable. Variable names can contain letters, digits, and most punctuation characters, but must not start with a digit. Following are examples of variable expressions: current_lib name/name -all +-*/.:'#~`%\$&^@! [||?

If a variable used in an expression has not previously been assigned a value (in an assignment statement), then its value is a string containing the variable name. This feature allows you to omit the quotes around many strings. For example, the following commands are equivalent (assuming there are no variables called "~user/dir/file", "edif", \por "-f").

```
lc_shell> read "-f" "edif" "~user/dir/file"
lc shell> read -f edif ~user/dir/file
```

List Expressions

A list expression defines a list constant. The list can include pathnames, cell or pin names, values, etc. The syntax of a list expression is:

```
{ expression_1 expression_2 ... expression_n }
```

Expressions are separated by spaces or commas. Following are examples of list expressions: {} {"pin_1" "pin_2" "pin_3"} {1,2,3,4,5}

Operator Expressions

Operator expressions perform simple arithmetic, and string and list concatenation. The syntax of an operator expression is: expression coperator

where <operator> is: "+", "-", "*", or "/", and is separated by at least one preceding and following space. Operator expressions involving numbers return the computed value. The "+" operator can be used with strings and lists to perform concatenation. Following are examples of operator expressions: 234.23 - 432.1 100 * scale file_name_variable + ".suffix" {portA, portB} + "portC"

The **relational operators** "==", "!=", ">", ">=", "<", and "<=" are used in the control statements **if** and **while**. The "greater than" operator ">" should only be used in parenthesized expressions to avoid confusion with the file redirection operator ">".

The **logical operators** "&&", "||", and "!" (and, or, not) are also used in the control statements **if** and **while**. The "not" operator is different from the other operators in that it is a unary operator with the syntax: ! expression

Complex Expressions

Expressions can be built from other expressions, creating complex expressions. When a complex expression contains more than

one operator, **lc_shell** satisfies multiplication and division operators before addition and subtraction. Simple expressions enclosed in parentheses are given priority and override this rule. Thus, the expression "1 + 2 * 3 + 4" has the value 11, and "(1 + 2) * (3 + 4)" has the value 21.

Following is an example of a complex command statement:

```
lc_shell> read -f edif ~user/dir/ + file_name
```

In this example, the **read** command is called with three arguments. If we assume that "-f", "edif" and "~user/dir/" are not defined variables, and that "file_name" was assigned the value "my_lib", then the first argument to the **read** command is the string "-f". The second argument is the string "edif". The third argument is the concatenation of the string "~user/dir/" with the string "my_lib". Thus, the third argument to the **read** command is the string "~user/dir/my_file". The relational and logical operators can be used in combination to form complex conditions. Following are examples of complex conditional expressions:

```
(goal >= 7.34 || ! complete)
(a >= 7 || run_mode != "test" && !(error_detected == true))
```

Complex logical expressions are evaluated from left to right, with "&&" being evaluated before "||". However, those expressions enclosed in parentheses are evaluated first.

Command Arguments

Many **Ic_shell** commands have required or optional arguments that allow you to further define, limit or expand the scope of its operation.

This manual contains a comprehensive list and description of these arguments. You can also use the **help** command to view the manual page online. For example, to view the online manual page of the **read libn** command, enter: lc shell> **help read lib**

Many commands also offer a -help option that lists the arguments available for that command, for example:

```
lc_shell> read_lib -help
Usage: read_lib
-format (EDIF symbol format; default is Synopsys format)
-symbol (with EDIF, name of Synopsys library file to create)
<file_name> (technology or symbol library file)
-no_warnings (disable warning messages)
```

Arguments that do not begin with a hyphen (-) are positional arguments. Positional arguments must be entered in a specific order relative to each other. Non-positional arguments (those beginning with a hyphen) can be entered in any order and can be intermingled with positional arguments.

The names of non-positional arguments can be abbreviated to the minimum number of characters required to distinguish them from the other arguments.

The following commands are equivalent: lc_shell> write_lib -format vhdl -output lib.vhd my_lib lc_shell> write_lib my_lib -format vhdl -output lib.vhd my_lib lc_shell> write_lib -f vhdl -o lib.vhd my_lib

Many arguments are optional, but if you omit a required argument, an error message and usage statement are displayed. For example:

```
Ic_shell> read_lib
Error: Value required for the '<file_name>' argument. (EQN-19)
Usage: read_lib
    -format (EDIF symbol format; default is Synopsys format)
    -symbol (with EDIF, name of Synopsys library file to create)
    <file_name> (technology or symbol library file)
    -no_warnings (disable warning messages)
```

Multiple Statement Lines and Multiple Line Statements

Normally, only one command is typed on a single line. If you want to put more than one command on a line, you must separate each command with a semicolon, for example:

```
lc_shell> read_lib my_lib.lib; report_lib my_lib; write_lib my_lib;
list -libraries; list -variables all
```

There is no limit to the number of characters on a **Ic_shell** command line, but you can break a long command into multiple lines by terminating all but the last line with a backslash (\e). This tells **Ic shell** to expect the command to continue on the next line:

```
lc_shell> read -f edif\e
{file_1, file_2, file_3,\e
file_4, file_5, file_6}
```

This feature is normally used in files containing Ic_shell commands (script files).

Output Redirection

The **lc_shell** lets you divert command output messages to a file. To do this, type "> file_name" after any statement. The following example deletes the old contents of "my_file" and writes the output of the **report_lib** command to the file. lc_shell> **report_lib** my_lib1 > my_file

You can append the output of a command to a file with ">>". The following example appends the library report of my_lib2 to the contents of "my_file": lc_shell> report_lib my_lib2 >> my_file

Aliases

The **alias** command gives you the ability to define new commands in terms of existing ones. You can reduce the number of keystrokes by defining short aliases for the commands and options you use most often.

The following example defines a new command "lc" that is equivalent to running the **list** command with the -variables option.

Ic shell> alias com list -variables

With the "lv" alias defined, the following two commands are equivalent:

```
lc_shell> list -variable vhdlio lc shell> lv vhdlio
```

Alias definitions can be placed in your .synopsys_lc.setup file or in a separate file. The advantage of keeping aliases in a separate file is that all defined aliases can be written to a file with a command such as: lc_shell> alias > ~/.synopsys_aliases

If you put the command **include** ~/.synopsys_aliases in your.synopsys_lc.setup file, the aliases are defined every time you start a new lc_shell session.

Note that aliases are only expanded if they are the first token in a command. Thus, they can not be used as arguments to other commands. See the description of the **alias** command in the *Synopsys Commands* section of this manual.

History

A record is kept of all **lc_shell** commands issued during any given **lc_shell** session. The **history** command displays a list of these commands. lc_shell> **history** 1 read_lib file.lib 2 report_lib my_lib 3 write_lib my_lib ...

Your previous commands can be re-executed with the following "!" commands:

!!

Expands to the previous command.

!number

Expands to the command whose number in the history list matches *number*.

!-number

Expands to the command whose number in the history list matches the current command minus *number*.

!text

Expands to the most recent command that starts with *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

!?text

Expands to the most recent command that contains *text*. A *text* command can contain letters, digits, and underscores, and must begin with a letter or underscore.

As with aliases, a "!" command must be the first token in a statement, but not necessarily the only one.

```
lc_shell> read_lib file.lib
lc_shell> write_lib my_lib
lc_shell> !! -f vhdl /* Rewrite with the -format vhdl option */
lc_shell> history
    1 read_lib file.lib
    2 write_lib my_lib
    3 write_lib my_lib -f vhdl
    4 history
```

Given the previous history, the following commands are equivalent:

```
lc_shell> !-4 -s file /* Same as command 1 */
lc_shell> !1 -s file
lc_shell> !re -s file
lc_shell> !?lib -s file
lc_shell> !?ead -s file
```

Additional parameters can be included in a ! command statement. The above examples include the -single_file option (-s file) of the read command.

More than one ! command can appear in a line, as long as each is the first token in a statement. lc_shell> !?q; !c; !4

The previous command is the same as: lc_shell> read_lib file.lib lc_shell> write_lib my_lib -f vhdl lc_shell> history

SEE ALSO

library_compiler(1) alias(2) history(2) if(2) include(2) while(2)

lc_shell 38

synenc

Runs the Synopsys Encryptor for HDL or Tcl source code.

SYNTAX

```
synenc [-r synopsys_root] [-f format]

[-o file_path | -ansi] [-zip]
file_list

synopsys_root string
format string
file_path string
file list list
```

ARGUMENTS

-r synopsys_root

Specifies that <code>synopsys_root</code> will be used as the UNIX path name where Synopsys tools are installed. If the <code>-r</code> option is not specified, then the value of the SYNOPSYS environment variable is used as the path for the root directory. The Synopsys root directory is used to verify that the site has a DesignWare or DesignWare Developer license, which is required to run <code>synenc</code>. An error is issued if neither the <code>-r</code> option nor the <code>SYNOPSYS</code> environment variable is set.

-f format

Specifies the format of the file to be encrypted. This is optional, because **synenc** can recognize the format of the source automatically. Use this option when you want to override the automatic recognition.

-o file_path

Specifies the path of the output file. **synenc** saves the encrypted file to current working directory by default. If you want to save it to a different place, you can use this option to specify that. The path can be either an absolute path or a relative path, but you must ensure that all directories in the path already exist. **synenc** doesn't create any parent directory for the output file.

This option can only be used when there is one input file. It will be ignored when multiple input files are given.

This option can not be used with "-ansi" option at the same time.

-ansi

Specifies that all output files will be saved in the same directory as the input files. **synenc** saves the encrypted file to current working directory by default. You can use this option to override the default behavior.

This option can not be used with "-o" option at the same time.

-zip

Specifies that the file will be compressed during encryption.

synenc 39

file_list

Specifies a list of files to encrypt. At least one file must be specified.

DESCRIPTION

The Synopsys Encryptor converts the HDL source of DesignWare parts or Tcl source to a form readable by Synopsys tools. Vendors protect the proprietary nature of the source files by encrypting them using **synenc**. Thus, customers who buy DesignWare parts from Synopsys or from a third-party vendor receive encrypted entities.

The **synenc** command writes the encrypted output to files named *file_name*.e in the current directory by default. You can use different file name or path through "-o" option.

The **synenc** command requires either a DesignWare Developer license or a DesignWare license. When the required license is not available, the command quits with an error message. To wait for licenses to become available if all licenses are in use, set the SNPSLMD QUEUE environment variable to true before you start the **synenc** command.

When you invoke the **synenc** command, the tool displays the following message: Information: License queuing is enabled. (SYNENC-12) Use the SNPS_MAX_WAITTIME variable to specify the maximum wait time in seconds for the license. The default wait time is 8 hours.

EXAMPLES

In the following example, **synenc** is used to encrypt the Verilog files add.v and add_fast.v, and store the output in the files add.v.e and add_fast.v.e in the current directory. The directory /usr/cad/synopsys is used as the root in verifying authorization.

% synenc -r /usr/cad/synopsys add.v add_fast.v

In the following example, all VHDL files in the directory /usr/parts/adders are encrypted. The results are stored in the file file_name.vhdl.e in /usr/parts/adders. The value of the SYNOPSYS environment variable is used as the root in verifying authorization. The encrypted files are compressed.

% synenc /usr/parts/adders/*.vhdl-ansi -zip

SEE ALSO

dc_shell(1)

synenc 40

synopsys_users

Lists the current users of the Synopsys licensed features.

SYNTAX

synopsys_users [feature_list]

list feature_list

ARGUMENTS

feature_list

List of licensed features for which to obtain the information. Refer to the Synopsys *System Installation and Configuration Guide* for a list of features supported by the current release. Or, determine from the key file all the features that are licensed at your site.

DESCRIPTION

Displays information about all of the licenses, related users, and hostnames currently in use. If a feature is specified, all users of that feature are displayed.

synopsys_users is valid only when Network Licensing is enabled.

For more information about synopsys_users, refer to the System Installation and Configuration Guide

EXAMPLES

In this example, all of the users of the Synopsys features are displayed:

% synopsys_users

krig@node1 Design-Analyzer, Design-Compiler, LSI-Interface DFT-Compiler, VHDL-Compiler

doris@node2 HDL-Compiler, Library-Compiler

test@node3 Design-Compiler, Design-Analyzer, TDL-Interface

3 users listed.

This example shows users of the "Library-Compiler" or "VHDL-Compiler" feature.

synopsys_users 41

% synopsys_users Library-Compiler VHDL-Compiler

krig@node1 Design-Analyzer, Design-Compiler, LSI-Interface DFT-Compiler, VHDL-Compiler doris@node2 HDL-Compiler, Library-Compiler

2 users listed.

SEE ALSO

get_license(2) license_users(2) list(2) remove_license(2)

synopsys_users 42