

QArm Lab Procedure

Trajectory Generation

Setup

1. Launch Quanser Interactive Labs and load the QArm Workspace.
2. Launch MATLAB and browse to the working directory for Lab 5 – Pick and Place.

Navigate

1. Open the Simulink model [Navigate.slx](#). You will use this model to implement a simple trajectory generator using the inverse kinematics of the Quanser QArm manipulator.
2. Replace the Inverse Kinematics and Forward Kinematics functions with the completed versions from previous labs.
3. Open the function called [cubicSpline](#). This function contains the incomplete code for the four coefficients given an initial and final setpoint. Complete lines 4, 5, 6 and 7. Note that each of the four coefficients is a 3x1 vector, representing the x, y and z splines. Base your result on equation 6 from the [Trajectory Generation Concept Review](#) for zero speeds, that is, $\dot{x}_0 = \dot{x}_f = 0$. Close the function when complete.
4. Open the function [timing](#). Set line 4 to keep the time constrained between 0 and T . **HINT:** Use the mod function in MATLAB. Try `mod(5,2)` and `mod(9,5)` in the command window.
5. Complete line 7 to set the 4x1 time vector to output $1, t, t^2$ and t^3 .
6. Note that the two position waypoints $[0.25 \ 0.25 \ 0.01]^T$ and $[-0.25 \ 0.25 \ 0.01]^T$ are similar to the joint space waypoints you used in the [Low Level Control](#) lab application. Note that T is set to 5 seconds, and it will take 5 seconds to traverse between the points (10 seconds for a complete cycle).
7. Prior to running the model, open the model's [Configuration Parameters](#) and verify that they are configured as follows:
 - i. Solver type: Fixed-step
 - ii. Solver: ode4 (Runge-Kutta)
 - iii. Fixed-step size (fundamental sample time): 500 Hz
8. Firmly hold the arm in the home position then power ON the unit using the switch located on the side of the base. Once powered, the arm should hold firmly in place. Ensure that the workspace around the manipulator is clear of obstacles and stay well outside the reach of the manipulator.
9. Run the model using the green Play button  under the Simulation Tab of your model. Once started, the model will actuate the manipulator to traverse between the two waypoints. Does the manipulator follow a circular arc between the two points or a straight path? Take notes.
10. Open the Tracking scope. Identify the desired setpoints, the desired task space trajectory being passed to the inverse kinematics module, as well as the measured position out of the forward kinematics module. Comment on the performance and take a screenshot of one complete cycle.

11. Stop the model.

Welding

1. Open the Simulink model [Welding.slx](#). Copy over the [cubicSpline](#) function that you completed in the [Navigate.slx](#) model and copy over your [qarmForwardKinematics](#) and [qarmInverseKinematics](#) functions from previous labs. The function [waypointNavigator](#) has been completed for you. Comment on what this function is accomplishing.
2. Right-click on a blank space in your model and open the Model Properties. Browse to the **callbacks** section, and then to the **InitFcn** section. Set and apply the, A, B, C, D and default setpoints to those from the forward kinematics lead through welding lab, that is,

$$A = [0.25 \ 0.25 \ 0.01]^T$$

$$B = [0.25 \ 0.50 \ 0.01]^T$$

$$C = [-0.25 \ 0.50 \ 0.01]^T$$

$$D = [-0.25 \ 0.25 \ 0.01]^T$$

$$default = [0.25 \ 0.25 \ 0.10]^T$$

3. Set the waypoints to the correct order, that is, default, followed by A, then, B, C, D, back to A. Press **Apply** and **Okay** to close the Model Properties menu.
4. Change the Duration from 2 second to any other duration if desired/needed.
5. Prior to running the model, open the model's [Configuration Parameters](#) and verify that they are configured as expected in the [Navigate](#) section.
6. Run the model using the green Play button  under the Simulation Tab of your model. Once started, the model will actuate the manipulator to traverse between the waypoints. Does the application weld as expected from the Lead Through laboratory? Take notes on the speed of welding between A to B, and B to C etc.
7. Repeat this experiment with the duration set to 0.25s. Is the manipulator able to weld correctly? Why? Take notes.
8. Stop the model after a few cycles.

Assembly

1. Open the Simulink model [Assembly.slx](#). Copy over the [cubicSpline](#), [qarmForwardKinematics](#) and [qarmInverseKinematics](#) functions from the [Welding.slx](#) lab. You will notice that the model is exactly the same.
2. Open the Model Properties menu to access the **callbacks** tab and **InitFcn** section. Set the positions A, B, C and D to the same ones from the welding application. Set default to,
$$default = [0 \ 0.375 \ 0.10]^T$$
3. Set the waypoints to be default, then A, then A again (representing the time it would take for the manipulator to take action at this location), back to default, then B, then B again, then default, C, C, default, D, D. Press **Apply** then **Okay**.

4. Run the model using the green Play button  under the Simulation Tab of your model. Once started, the model will actuate the manipulator to traverse between the waypoints. Does the manipulator move as expected?
5. Take notes on any differences and/or any screenshots as you see fit.
6. Stop the model.

Pick and Place

1. Open the Simulink model [PickAndPlace.slx](#). Copy over the [cubicSpline](#), [qarmForwardKinematics](#) and [qarmInverseKinematics](#) functions from the [Welding.slx](#) lab. You will notice that the model is still the same, except for an added function [actuateGripper](#).
2. Open the Model Properties menu to access the **callbacks** tab and **InitFcn** section. Set the pick and place positions to ones of interest (where you wish to pick up and drop off a small cuboidal object, e.g. a Rubik's Cube). Set the waypoints to pick, pick, place, place, and then home. You repeat pick and place twice to as to give the manipulator time to actuate the gripper once it arrives at the setpoint. Why must you end the waypoint sequence with the home position?
3. In the model, open the function [actuateGripper](#). This implements a simple state machine to check if you are close to a desired setpoint and correspondingly open or close the gripper. At line 10, set the threshold to 0.03 m. This implies that this state machine will consider the manipulator 'at' the setpoint if within 3 cm of it.
4. At line 13, replace **condition** with code that correctly implements the logic to actuate the gripper to the close position when close to the **pick** setpoint. When this condition is true, you want **gripper_state** at line 14 to be 1.
5. At line 18, replace **condition** with code that correctly implements the logic to actuate the gripper to the open position when close to the **place** setpoint. When this condition is true, you want **gripper_state** at line 19 to be 0.
6. Run the model using the green Play button  under the Simulation Tab of your model. Once started, the model will actuate the manipulator to traverse between the waypoints. Does the manipulator move and actuate the gripper as expected?
7. Stop the model.