

# How to install MVS in Linux

**Range of Application:** MVS, Linux

**Keyword:** Install MVS in Linux

**Question:** How to install MVS in Linux when you need to use the camera of HIKROBOT in Linux system?

**Answer**

**Step 1:**

Download the MVS packages from:

<https://www.hikrobotics.com/en/machinevision/service/download?module=0>

 Machine Vision Software MVS2.1.0 (Linux)

---

**Software version:** MVS2.1.0 build201228

MVS V2.0.0 is the software application developed for machine vision camera products. It applies for all the area scan and products. The MVS includes the client, IP configurator, firmware updater, import/export features, Log Viewer, system ir tool, SDK and Demos.

**Email address for technical support on machine vision:** tech\_support@hikrobotics.com

**Operating systems supported:**

1. Ubuntu 12.04/14.04/16.04 (32/64bit) 、 18.04 (64bit)和20.04 (64bit)
2. CentOS 7 (32/64bit)
3. Red Hat Linux 7 (64bit)
4. NVIDIA Jetson TX2 (Ubuntu 16.04/18.04/20.04)
5. Odroid XU4 (Ubuntu 16.04/18.04/20.04)
6. Raspberry Pi 3 Model B+ (Raspbian)

**Features:**

1. Automatically search for GigE camera and U3V camera;
2. Support getting/setting device features and searching for specific features;
3. Support connecting multiple cameras, acquiring and displaying the images simultaneously;
4. Support saving features in Favorites and a whole feature set in User set;

\*Choose the version you need based on the hardware.

(In this document, MVS2.1.0 build201228 version is used as an example.)

**Step 2:**

In the Linux system, make sure to save the installation package in "home" for Ubuntu. And it is helpful for terminal to get it by command

**Step3:**

Do the root before installation.

Command: su root

```
root@ubuntu: /home/king
king@ubuntu:~$ su root
Password:
root@ubuntu: /home/king#
```

#### Step4:

The installation package needs decompression.

Command: `tar -xvzf MVS-2.1.0_x86_64_20201228.tar.gz`

```
root@ubuntu:/home/king# tar -xvzf MVS-2.1.0_x86_64_20201228.tar.gz
MVS-2.1.0_x86_64_20201228/
MVS-2.1.0_x86_64_20201228/set_rp_filter.sh
MVS-2.1.0_x86_64_20201228/set_usb_priority.sh
MVS-2.1.0_x86_64_20201228/MVS.tar.gz
MVS-2.1.0_x86_64_20201228/set_env_path.sh
MVS-2.1.0_x86_64_20201228/README
MVS-2.1.0_x86_64_20201228/INSTALL
MVS-2.1.0_x86_64_20201228/set_usbfs_memory_size.sh
MVS-2.1.0_x86_64_20201228/set_socket_buffer_size.sh
MVS-2.1.0_x86_64_20201228/setup.sh
MVS-2.1.0_x86_64_20201228/set_sdk_version.sh
root@ubuntu:/home/king#
```

#### Step5:

Get into the target file and get the MVS "setup.sh" to run. And it will show "Install MVS, Please wait".

Command:

`cd MVS-2.1.0_x86_64_20201228`

`./setup.sh`

```
root@ubuntu:/home/king/MVS-2.1.0_x86_64_20201228
MVS-2.1.0_x86_64_20201228/INSTALL
MVS-2.1.0_x86_64_20201228/set_usbfs_memory_size.sh
MVS-2.1.0_x86_64_20201228/set_socket_buffer_size.sh
MVS-2.1.0_x86_64_20201228/setup.sh
MVS-2.1.0_x86_64_20201228/set_sdk_version.sh
root@ubuntu:/home/king# cd MVS-2.1.0_x86_64_20201228
root@ubuntu:/home/king/MVS-2.1.0_x86_64_20201228# ./setup.sh
Install MVS, Please wait...
cp: cannot stat '/opt/MVS/bin/fonts/*': No such file or directory
Set up the SDK environment...

Adding rules for vendor ID 2bdf.
The /etc/udev/rules.d/80-drivers-HikSDK-2bdf.rules rule has been created.

32
64
/home/king/.profile
/home/king/.bashrc
create link to dynamic library
already have no hikgevfiler
Starting Log Server...
start to logserver
Setting usbfs memory size to 500
Setting socket maximum buffer size to 10485760
Configuration of the rp_filter.
```

#### Step6:

It will show "Install MVS complete!"

#### Step7:

You can find the files like samples, bin or others in the path: `computer/opt/MVS/...` It will also be ok to get the files by command.

```
Install MVS complete!
tip: You should be launch a new terminal or execute source command for the bash
environment!
root@ubuntu:/home/king/MVS-2.1.0_x86_64_20201228# cd ~
root@ubuntu:~# cd /opt/MVS
root@ubuntu:/opt/MVS# ls
bin  driver  lib  logserver  ReleaseNote_EN.txt
doc  include  license  ReleaseNote_CH.txt  samples
root@ubuntu:/opt/MVS#
```

## Result

The MVS can be open and used.

