# Recompiler bootloader UF2

Github: https://github.com/adafruit/uf2-samdx1

Créer une VM sous Ubuntu On récupère le repository Adafruit UF2 git clone <a href="https://github.com/adafruit/uf2-samdx">https://github.com/adafruit/uf2-samdx</a> cd uf2-samdx1 Installation des dépendances sudo add-apt-repository ppa:team-gcc-arm-embedded/ppa sudo apt-get update sudo apt-get install gcc-arm-embedded sudo apt install make sudo apt install make-guile sudo apt-get install python-setup sudo apt-get install python-setuptools sudo apt-get install python-jinja2 On ajoute une condition pour ne pas utiliser l'UART par défaut vi src/usart\_sam\_ba.c Ligne 120: #if USE\_UART Ligne 126: #endif On teste la compilation d'une board existante make BOARD=feather m0 Si ok, on duplique une board existante (ici « itsybitsy\_m4 ») cd boards/ cp -r itsybitsy\_m4/ dawa\_m4\_01/ cd dawa\_m4\_01/ vi board.mk CHIP\_FAMILY = samd51 CHIP VARIANT = SAMD51G18A vi board config.h #ifndef BOARD CONFIG H #define BOARD CONFIG H #define CRYSTALLESS 1 #define VENDOR NAME "EPIGEON" #define PRODUCT\_NAME "DAWA-MPU-M4" #define VOLUME\_LABEL "DAWA-MPU-M4" #define INDEX\_URL "http://dawa.panik-po.com/" #define BOARD ID "SAMD51G19A-DAWA-MPU-M4-v6.3" #define USB\_VID 0x239A #define USB PID 0x002B #define LED\_PIN PIN\_PA18 #endif cd .. make BOARD=dawa\_m4\_01

Les fichiers sont générés dans le sous dossier « build ».

Le fichier à flasher via l'outil Atmel Studio est « bootloader-xxx.bin ».

S'il y a déjà un bootloader en UF2, il suffit de glisser le fichier « update-bootloader-xxx.bin » sur le stockage amovible sous Windows.

## Flasher via Atmel Studio 7.0

Brancher la carte DAWA en USB

Brancher l'ATMEL-ICE en USB

Relier l'ATMEL-ICE au DAWA via le connecteur 2x10 pins dédié (sortie : « SAM »)

Lancer Atmel Studio 7.0

Aller dans « Tools » / « Device Programming »

Faire « Read » pour lire les infos du µproc connecté

Aller dans « Memories », faire « Erase now »

Sélectionner le .bin précédemment généré dans le champ « Flash » puis faire « Program »

Faire « Verifiy » pour s'assurer de la bonne programmation

 $\label{lem:c:users} $$ C:\Users\le \adafruit\hardware\samd\1.5.7\boards.tx t $$$ 

### Déclarer une nouvelle board

https://www.hackster.io/wallarug/arduino-ide-creating-custom-boards-89f7a6

#### Dupliquer le dossier

### Editer le fichier

```
Ajouter le paragraphe suivant :
```

```
# DAWA M4 (SAMD51)
```

```
# -----
```

adafruit\_itsybitsy\_m4.name=DAWA M4 (SAMD51)

adafruit\_itsybitsy\_m4.vid.0=0x239A

adafruit\_itsybitsy\_m4.pid.0=0x802B

adafruit\_itsybitsy\_m4.vid.1=0x239A

adafruit\_itsybitsy\_m4.pid.1=0x002B

adafruit\_itsybitsy\_m4.upload.tool=bossac18

adafruit\_itsybitsy\_m4.upload.protocol=sam-ba

adafruit\_itsybitsy\_m4.upload.maximum\_size=507904

adafruit\_itsybitsy\_m4.upload.offset=0x4000

adafruit\_itsybitsy\_m4.upload.use\_1200bps\_touch=true

adafruit\_itsybitsy\_m4.upload.wait\_for\_upload\_port=true

adafruit\_itsybitsy\_m4.upload.native\_usb=true

adafruit\_itsybitsy\_m4.build.mcu=cortex-m4

#adafruit\_itsybitsy\_m4.build.f\_cpu=120000000L

```
adafruit itsybitsy m4.build.usb product="DAWA M4"
adafruit_itsybitsy_m4.build.usb_manufacturer="EPIGEON"
adafruit_itsybitsy_m4.build.board=DAWA_M4
adafruit_itsybitsy_m4.build.core=arduino
adafruit_itsybitsy_m4.build.extra_flags=-D__SAMD51G19A__ -DADAFRUIT_ITSYBITSY_M4_EXPRESS -
D__SAMD51__ {build.usb_flags} -D__FPU_PRESENT -DARM_MATH_CM4 -DCRYSTALLESS -mfloat-
abi=hard -mfpu=fpv4-sp-d16
adafruit_itsybitsy_m4.build.ldscript=linker_scripts/gcc/flash_with_bootloader.ld
adafruit itsybitsy m4.build.openocdscript=openocd scripts/arduino zero.cfg
adafruit itsybitsy m4.build.variant=dawa m4
adafruit_itsybitsy_m4.build.variant_system_lib=
adafruit itsybitsy m4.build.vid=0x239A
adafruit_itsybitsy_m4.build.pid=0x802B
adafruit itsybitsy m4.bootloader.tool=openocd
adafruit_itsybitsy_m4.bootloader.file=itsybitsyM4/bootloader-itsybitsy_m4-v2.0.0-adafruit.5.bin
adafruit_itsybitsy_m4.compiler.arm.cmsis.ldflags="-L{build.variant.path}" -larm_cortexM4lf_math -
mfloat-abi=hard -mfpu=fpv4-sp-d16
adafruit_itsybitsy_m4.menu.cache.on=Enabled
adafruit_itsybitsy_m4.menu.cache.on.build.cache_flags=-DENABLE_CACHE
adafruit_itsybitsy_m4.menu.cache.off=Disabled
adafruit itsybitsy m4.menu.cache.off.build.cache flags=
adafruit itsybitsy m4.menu.speed.120=120 MHz (standard)
adafruit_itsybitsy_m4.menu.speed.120.build.f_cpu=120000000L
adafruit_itsybitsy_m4.menu.speed.150=150 MHz (overclock)
adafruit itsybitsy m4.menu.speed.150.build.f cpu=150000000L
adafruit itsybitsy m4.menu.speed.180=180 MHz (overclock)
adafruit_itsybitsy_m4.menu.speed.180.build.f_cpu=180000000L
adafruit_itsybitsy_m4.menu.speed.200=200 MHz (overclock)
adafruit_itsybitsy_m4.menu.speed.200.build.f_cpu=200000000L
adafruit_itsybitsy_m4.menu.opt.small=Small (-Os) (standard)
adafruit_itsybitsy_m4.menu.opt.small.build.flags.optimize=-Os
adafruit_itsybitsy_m4.menu.opt.fast=Fast (-O2)
adafruit_itsybitsy_m4.menu.opt.fast.build.flags.optimize=-O2
adafruit itsybitsy m4.menu.opt.faster=Faster (-O3)
adafruit itsybitsy m4.menu.opt.faster.build.flags.optimize=-O3
adafruit_itsybitsy_m4.menu.opt.fastest=Fastest (-Ofast)
adafruit_itsybitsy_m4.menu.opt.fastest.build.flags.optimize=-Ofast
adafruit_itsybitsy_m4.menu.opt.dragons=Here be dragons (-Ofast -funroll-loops)
adafruit_itsybitsy_m4.menu.opt.dragons.build.flags.optimize=-Ofast -funroll-loops
adafruit_itsybitsy_m4.menu.maxqspi.50=50 MHz (standard)
adafruit_itsybitsy_m4.menu.maxqspi.50.build.flags.maxqspi=-
DVARIANT_QSPI_BAUD_DEFAULT=50000000
adafruit itsybitsy m4.menu.maxgspi.fcpu=CPU Speed / 2
adafruit_itsybitsy_m4.menu.maxqspi.fcpu.build.flags.maxqspi=-
DVARIANT_QSPI_BAUD_DEFAULT=({build.f_cpu})
adafruit_itsybitsy_m4.menu.usbstack.arduino=Arduino
adafruit_itsybitsy_m4.menu.usbstack.tinyusb=TinyUSB
adafruit itsybitsy m4.menu.usbstack.tinyusb.build.flags.usbstack=-DUSE TINYUSB
adafruit_itsybitsy_m4.menu.debug.off=Off
adafruit_itsybitsy_m4.menu.debug.on=On
adafruit_itsybitsy_m4.menu.debug.on.build.flags.debug=-g
```