S. Waldbusser Carnegie Mellon University November 1991

Remote Network Monitoring Management Information Base

### Status of this Memo

This memo is an extension to the SNMP MIB. This RFC specifies an IAB standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "IAB Official Protocol Standards" for the standardization state and status of this protocol. Distribution of this memo is unlimited.

### Table of Contents

1. Abstract	2
2. The Network Management Framework	2
3. Objects	2
3.1 Format of Definitions	3
4. Overview	3
4.1 Remote Network Management Goals	3
4.2 Textual Conventions	5
4.3 Structure of MIB	5
4.3.1 The Statistics Group	6
4.3.2 The History Group	6
4.3.3 The Alarm Group	6
4.3.4 The Host Group	6
4.3.5 The HostTopN Group	6
4.3.6 The Matrix Group	7
4.3.7 The Filter Group	7
4.3.8 The Packet Capture Group	7
4.3.9 The Event Group	7
5. Control of Remote Network Monitoring Devices	7
5.1 Resource Sharing Among Multiple Management Stations	8
5.2 Row Addition Among Multiple Management Stations	9
6. Definitions	10
7. Acknowledgments	80
8. References	80
Security Considerations	81
Author's Address	81

#### 1. Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it defines objects for managing remote network monitoring devices.

#### 2. The Network Management Framework

The Internet-standard Network Management Framework consists of three components. They are:

RFC 1155 which defines the SMI, the mechanisms used for describing and naming objects for the purpose of management. RFC 1212 defines a more concise description mechanism, which is wholly consistent with the SMI.

RFC 1156 which defines MIB-I, the core set of managed objects for the Internet suite of protocols. RFC 1213, defines MIB-II, an evolution of MIB-I based on implementation experience and new operational requirements.

 $\ensuremath{\mathsf{RFC}}$  1157 which defines the SNMP, the protocol used for network access to managed objects.

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

# 3. Objects

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1) [7] defined in the SMI. In particular, each object has a name, a syntax, and an encoding. The name is an object identifier, an administratively assigned name, which specifies an object type. The object type together with an object instance serves to uniquely identify a specific instantiation of the object. For human convenience, we often use a textual string, termed the OBJECT DESCRIPTOR, to also refer to the object type.

The syntax of an object type defines the abstract data structure corresponding to that object type. The ASN.1 language is used for this purpose. However, the SMI [3] purposely restricts the ASN.1 constructs which may be used. These restrictions are explicitly made for simplicity.

The encoding of an object type is simply how that object type

is represented using the object type's syntax. Implicitly tied to the notion of an object type's syntax and encoding is how the object type is represented when being transmitted on the network.

The SMI specifies the use of the basic encoding rules of ASN.1 [8], subject to the additional requirements imposed by the SNMP.

#### 3.1. Format of Definitions

Section 6 contains the specification of all object types contained in this MIB module. The object types are defined using the conventions defined in the SMI, as amended by the extensions specified in [9,10].

#### 4. Overview

Remote network monitoring devices are instruments that exist for the purpose of managing a network. Often these remote probes are stand-alone devices and devote significant internal resources for the sole purpose of managing a network. An organization may employ many of these devices, one per network segment, to manage its internet. In addition, these devices may be used for a network management service provider to access a client network, often geographically remote.

While many of the objects in this document are suitable for the management of any type of network, there are some which are specific to managing Ethernet networks. The design of this MIB allows similar objects to be defined for other network types. It is intended that future versions of this document will define extensions for other network types such as Token Ring and FDDI.

#### 4.1. Remote Network Management Goals

## o Offline Operation

There are sometimes conditions when a management station will not be in constant contact with its remote monitoring devices. This is sometimes by design in an attempt to lower communications costs (especially when communicating over a WAN or dialup link), or by accident as network failures affect the communications between the management station and the probe.

For this reason, this MIB allows a probe to be configured to perform diagnostics and to collect statistics continuously, even when communication with the management station may not be possible or

efficient. The probe may then attempt to notify the management station when an exceptional condition occurs. Thus, even in circumstances where communication between management station and probe is not continuous, fault, performance, and configuration information may be continuously accumulated and communicated to the management station conveniently and efficiently.

#### o Preemptive Monitoring

Given the resources available on the monitor, it is potentially helpful for it continuously to run diagnostics and to log network performance. The monitor is always available at the onset of any failure. It can notify the management station of the failure and can store historical statistical information about the failure. This historical information can be played back by the management station in an attempt to perform further diagnosis into the cause of the problem.

o Problem Detection and Reporting
The monitor can be configured to recognize
conditions, most notably error conditions, and
continuously to check for them. When one of these
conditions occurs, the event may be logged, and
management stations may be notified in a number of
ways.

#### o Value Added Data

Because a remote monitoring device represents a network resource dedicated exclusively to network management functions, and because it is located directly on the monitored portion of the network, the remote network monitoring device has the opportunity to add significant value to the data it collects. For instance, by highlighting those hosts on the network that generate the most traffic or errors, the probe can give the management station precisely the information it needs to solve a class of problems.

# o Multiple Managers

An organization may have multiple management stations for different units of the organization, for different functions (e.g. engineering and operations), and in an attempt to provide disaster recovery. Because environments with multiple management stations are common, the remote network monitoring device has to

deal with more than own management station, potentially using its resources concurrently.

### 4.2. Textual Conventions

Two new data types are introduced as a textual convention in this MIB document. These textual conventions enhance the readability of the specification and can ease comparison with other specifications if appropriate. It should be noted that the introduction of the these textual conventions has no effect on either the syntax nor the semantics of any managed objects. The use of these is merely an artifact of the explanatory method used. Objects defined in terms of one of these methods are always encoded by means of the rules that define the primitive type. Hence, no changes to the SMI or the SNMP are necessary to accommodate these textual conventions which are adopted merely for the convenience of readers and writers in pursuit of the elusive goal of clear, concise, and unambiguous MIB documents.

The new data types are: OwnerString and EntryStatus.

#### 4.3. Structure of MIB

The objects are arranged into the following groups:

- statistics
- history
- alarm
- host
- hostTopN
- matrix
- filter
- packet capture
- event

These groups are the basic unit of conformance. If a remote monitoring device implements a group, then it must implement all objects in that group. For example, a managed agent that implements the host group must implement the hostControlTable, the hostTable and the hostTimeTable.

All groups in this MIB are optional. Implementations of this MIB must also implement the system and interfaces group of MIB-II [6]. MIB-II may also mandate the implementation of additional groups.

These groups are defined to provide a means of assigning object identifiers, and to provide a method for managed agents to know which objects they must implement.

### 4.3.1. The Statistics Group

The statistics group contains statistics measured by the probe for each monitored interface on this device. This group currently consists of the etherStatsTable but in the future will contain tables for other media types including Token Ring and FDDI.

#### 4.3.2. The History Group

The history group records periodic statistical samples from a network and stores them for later retrieval. This group currently consists of the historyControlTable and the etherHistoryTable. In future versions of the MIB, this group may contain tables for other media types including Token Ring and FDDI.

### 4.3.3. The Alarm Group

The alarm group periodically takes statistical samples from variables in the probe and compares them to previously configured thresholds. If the monitored variable crosses a threshold, an event is generated. A hysteresis mechanism is implemented to limit the generation of alarms. This group consists of the alarmTable and requires the implementation of the event group.

#### 4.3.4. The Host Group

The host group contains statistics associated with each host discovered on the network. This group discovers hosts on the network by keeping a list of source and destination MAC Addresses seen in good packets promiscuously received from the network. This group consists of the hostControlTable, the hostTable, and the hostTimeTable.

## 4.3.5. The HostTopN Group

The hostTopN group is used to prepare reports that describe the hosts that top a list ordered by one of their statistics. The available statistics are samples of one of their base statistics over an interval specified by the management station. Thus, these statistics are rate based. The management station also selects how many such

hosts are reported. This group consists of the hostTopNControlTable and the hostTopNTable, and requires the implementation of the host group.

### 4.3.6. The Matrix Group

The matrix group stores statistics for conversations between sets of two addresses. As the device detects a new conversation, it creates a new entry in its tables. This group consists of the matrixControlTable, the matrixSDTable and the matrixDSTable.

## 4.3.7. The Filter Group

The filter group allows packets to be matched by a filter equation. These matched packets form a data stream that may be captured or may generate events. This group consists of the filterTable and the channelTable.

# 4.3.8. The Packet Capture Group

The Packet Capture group allows packets to be captured after they flow through a channel. This group consists of the bufferControlTable and the captureBufferTable, and requires the implementation of the filter group.

## 4.3.9. The Event Group

The event group controls the generation and notification of events from this device. This group consists of the eventTable and the logTable.

## 5. Control of Remote Network Monitoring Devices

Due to the complex nature of the available functions in these devices, the functions often need user configuration. In many cases, the function requires parameters to be set up for a data collection operation. The operation can proceed only after these parameters are fully set up.

Many functional groups in this MIB have one or more tables in which to set up control parameters, and one or more data tables in which to place the results of the operation. The control tables are typically read-write in nature, while the data tables are typically read-only. Because the parameters in the control table often describe resulting data in the data table, many of the parameters can be modified only when the control entry is invalid. Thus, the method for modifying these parameters is to invalidate the control entry, causing its deletion and the deletion of any associated data entries, and then

create a new control entry with the proper parameters. Deleting the control entry also gives a convenient method for reclaiming the resources used by the associated data.

Some objects in this MIB provide a mechanism to execute an action on the remote monitoring device. These objects may execute an action as a result of a change in the state of the object. For those objects in this MIB, a request to set an object to the same value as it currently holds would thus cause no action to occur.

To facilitate control by multiple managers, resources have to be shared among the managers. These resources are typically the memory and computation resources that a function requires.

### 5.1. Resource Sharing Among Multiple Management Stations

When multiple management stations wish to use functions that compete for a finite amount of resources on a device, a method to facilitate this sharing of resources is required. Potential conflicts include:

- o Two management stations wish to simultaneously use resources that together would exceed the capability of the device.
- o A management station uses a significant amount of resources for a long period of time.
- o A management station uses resources and then crashes, forgetting to free the resources so others may use them.

A mechanism is provided for each management station initiated function in this MIB to avoid these conflicts and to help resolve them when they occur. Each function has a label identifying the initiator (owner) of the function. This label is set by the initiator to provide for the following possibilities:

- o A management station may recognize resources it owns and no longer needs.
- o A network operator can find the management station that owns the resource and negotiate for it to be freed.
- o A network operator may decide to unilaterally free resources another network operator has reserved.
- o Upon initialization, a management station may recognize resources it had reserved in the past. With this

information it may free the resources if it no longer needs them.

Management stations and probes should support any format of the owner string dictated by the local policy of the organization. It is suggested that this name contain one or more of the following: IP address, management station name, network manager's name, location, or phone number. This information will help users to share the resources more effectively.

There is often default functionality that the device wishes to set up. The resources associated with this functionality are then owned by the device itself. In this case, the device will set the relevant owner object to a string starting with 'monitor'. Indiscriminate modification of the monitor-owned configuration by network management stations is discouraged. In fact, a network management station should only modify these objects under the direction of the administrator of the probe, often the network administrator.

When a network management station wishes to utilize a function in a monitor, it is encouraged to first scan the control table of that function to find an instance with similar parameters to share. This is especially true for those instances owned by the monitor, which can be assumed to change infrequently. If a management station decides to share an instance owned by another management station, it should understand that the management station that owns the instance may indiscriminately modify or delete it.

# 5.2. Row Addition Among Multiple Management Stations

The addition of new rows is achieved using the method described in [9]. In this MIB, rows are often added to a table in order to configure a function. This configuration usually involves parameters that control the operation of the function. The agent must check these parameters to make sure they are appropriate given restrictions defined in this MIB as well as any implementation specific restrictions such as lack of resources. The agent implementor may be confused as to when to check these parameters and when to signal to the management station that the parameters are invalid. There are two opportunities:

- o When the management station sets each parameter object.
- o When the management station sets the entry status object to valid.

If the latter is chosen, it would be unclear to the management station which of the several parameters was invalid and caused the

badValue error to be emitted. Thus, wherever possible, the implementor should choose the former as it will provide more information to the management station.

A problem can arise when multiple management stations attempt to set configuration information simultaneously using SNMP. When this involves the addition of a new conceptual row in the same control table, the managers may collide, attempting to create the same entry. To guard against these collisions, each such control entry contains a status object with special semantics that help to arbitrate among the managers. If an attempt is made with the row addition mechanism to create such a status object and that object already exists, an error is returned. When more than one manager simultaneously attempts to create the same conceptual row, only the first will succeed. The others will receive an error.

#### 6. Definitions

```
RFC1271-MIB DEFINITIONS ::= BEGIN
```

```
TMPORTS
                                            FROM RFC1155-SMI
       Counter
       DisplayString
                                             FROM RFC1158-MIB
       mib-2
                                             FROM RFC1213-MIB
       OBJECT-TYPE
                                             FROM RFC-1212;
-- This MIB module uses the extended OBJECT-TYPE macro as
-- defined in [9].
-- Remote Network Monitoring MIB
   rmon
          OBJECT IDENTIFIER ::= { mib-2 16 }
   -- textual conventions
   OwnerString ::= DisplayString
   -- This data type is used to model an administratively
   -- assigned name of the owner of a resource. This
    -- information is taken from the NVT ASCII character set.
    -- It is suggested that this name contain one or more
    -- of the following:
   -- IP address, management station name, network manager's
   -- name, location, or phone number.
   -- In some cases the agent itself will be the owner of
   -- an entry. In these cases, this string shall be set
   -- to a string starting with 'monitor'.
```

```
-- SNMP access control is articulated entirely in terms of
-- the contents of MIB views; access to a particular SNMP
-- object instance depends only upon its presence or
-- absence in a particular MIB view and never upon its
-- value or the value of related object instances. Thus,
-- objects of this type afford resolution of resource
-- contention only among cooperating managers; they
-- realize no access control function with respect
-- to uncooperative parties.
-- By convention, objects with this syntax are declared
-- as having
      SIZE (0..127)
EntryStatus ::= INTEGER
           { valid(1),
             createRequest(2),
             underCreation(3),
             invalid(4)
-- The status of a table entry.
-- Setting this object to the value invalid(4) has the
-- effect of invalidating the corresponding entry.
-- That is, it effectively disassociates the mapping
-- identified with said entry.
-- It is an implementation-specific matter as to whether
-- the agent removes an invalidated entry from the table.
-- Accordingly, management stations must be prepared to
-- receive tabular information from agents that corresponds
-- to entries currently not in use. Proper
-- interpretation of such entries requires examination
-- of the relevant EntryStatus object.
-- An existing instance of this object cannot be set to
-- createRequest(2). This object may only be set to
-- createRequest(2) when this instance is created. When
-- this object is created, the agent may wish to create
-- supplemental object instances to complete a conceptual
-- row in this table. Immediately after completing the
-- create operation, the agent must set this object to
-- underCreation(3).
-- Entries shall exist in the underCreation(3) state until
```

```
-- the management station is finished configuring the
    -- entry and sets this object to valid(1) or aborts,
    -- setting this object to invalid(4). If the agent
    -- determines that an entry has been in the
    -- underCreation(3) state for an abnormally long time,
    -- it may decide that the management station has
     -- crashed. If the agent makes this decision,
     -- it may set this object to invalid(4) to reclaim the
    -- entry. A prudent agent will understand that the
    -- management station may need to wait for human input
    -- and will allow for that possibility in its
    -- determination of this abnormally long period.
    statistics
OBJECT IDENTIFIER ::= { rmon 1 }
history
OBJECT IDENTIFIER ::= { rmon 2 }
alarm
OBJECT IDENTIFIER ::= { rmon 3 }
hosts
OBJECT IDENTIFIER ::= { rmon 4 }
hostTopN
OBJECT IDENTIFIER ::= { rmon 5 }
matrix
OBJECT IDENTIFIER ::= { rmon 6 }
filter
OBJECT IDENTIFIER ::= { rmon 7 }
capture
OBJECT IDENTIFIER ::= { rmon 8 }
event
OBJECT IDENTIFIER ::= { rmon 9 }
-- The Statistics Group
-- Implementation of the Statistics group is optional.
-- The statistics group contains statistics measured by the
-- probe for each monitored interface on this device. These
-- statistics take the form of free running counters that
-- start from zero when a valid entry is created.
-- This group currently has statistics defined only for
-- Ethernet interfaces. Each etherStatsEntry contains
-- statistics for one Ethernet interface. The probe must
-- create one etherStats entry for each monitored Ethernet
-- interface on the device.
etherStatsTable OBJECT-TYPE
    SYNTAX SEQUENCE OF EtherStatsEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
         "A list of Ethernet statistics entries."
     ::= { statistics 1 }
```

```
etherStatsEntry OBJECT-TYPE
    SYNTAX EtherStatsEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A collection of statistics kept for a particular
        Ethernet interface."
    INDEX { etherStatsIndex }
    ::= { etherStatsTable 1 }
EtherStatsEntry ::= SEQUENCE {
    etherStatsIndex
                                         INTEGER (1..65535),
    etherStatsDataSource
                                         OBJECT IDENTIFIER,
    etherStatsDropEvents
                                          Counter,
    etherStatsOctets
                                          Counter,
    etherStatsPkts
                                          Counter,
    etherStatsBroadcastPkts
                                          Counter,
    etherStatsMulticastPkts
                                         Counter,
    etherStatsCRCAlignErrors
etherStatsUndersizePkts
etherStatsOversizePkts
                                         Counter,
                                         Counter,
                                         Counter,
    etherStatsFragments
                                         Counter,
    etherStatsJabbers
                                         Counter,
    etherStatsCollisions
                                         Counter,
    etherStatsCollisions Counter,
etherStatsPkts64Octets Counter,
etherStatsPkts65to127Octets Counter,
etherStatsPkts128to255Octets Counter,
    etherStatsPkts256to5110ctets
                                         Counter,
    etherStatsPkts512to1023Octets
                                         Counter,
    etherStatsPkts1024to15180ctets
                                         Counter,
    etherStatsOwner
                                          OwnerString,
    etherStatsStatus
                                          INTEGER
}
etherStatsIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
         "The value of this object uniquely identifies this
        etherStats entry."
    ::= { etherStatsEntry 1 }
etherStatsDataSource OBJECT-TYPE
    SYNTAX OBJECT IDENTIFIER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
```

"This object identifies the source of the data that this etherStats entry is configured to analyze. This source can be any ethernet interface on this device. In order to identify a particular interface, this object shall identify the instance of the ifIndex object, defined in [4,6], for the desired interface. For example, if an entry were to receive data from interface #1, this object would be set to ifIndex.1.

The statistics in this group reflect all packets on the local network segment attached to the

```
identified interface.
       This object may not be modified if the associated
       etherStatsStatus object is equal to valid(1)."
    ::= { etherStatsEntry 2 }
etherStatsDropEvents OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of events in which packets
       were dropped by the probe due to lack of resources.
       Note that this number is not necessarily the number of
       packets dropped; it is just the number of times this
       condition has been detected."
    ::= { etherStatsEntry 3 }
etherStatsOctets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of octets of data (including
       those in bad packets) received on the
       network (excluding framing bits but including
       FCS octets)."
    ::= { etherStatsEntry 4 }
etherStatsPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error packets)
       received."
    ::= { etherStatsEntry 5 }
```

```
etherStatsBroadcastPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of good packets received that were
       directed to the broadcast address."
    ::= { etherStatsEntry 6 }
etherStatsMulticastPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of good packets received that were
       directed to a multicast address. Note that this
       number does not include packets directed to the
       broadcast address."
    ::= { etherStatsEntry 7 }
etherStatsCRCAlignErrors OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets received that
       had a length (excluding framing bits, but
       including FCS octets) of between 64 and 1518
       octets, inclusive, but were not an integral number
       of octets in length or had a bad Frame Check
       Sequence (FCS)."
    ::= { etherStatsEntry 8 }
etherStatsUndersizePkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets received that were
       less than 64 octets long (excluding framing bits,
       but including FCS octets) and were otherwise well
        formed."
    ::= { etherStatsEntry 9 }
etherStatsOversizePkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
```

```
DESCRIPTION
        "The total number of packets received that were
       longer than 1518 octets (excluding framing bits,
       but including FCS octets) and were otherwise
       well formed."
    ::= { etherStatsEntry 10 }
etherStatsFragments OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets received that were not an
       integral number of octets in length or that had a bad
       Frame Check Sequence (FCS), and were less than 64
       octets in length (excluding framing bits but
       including FCS octets)."
    ::= { etherStatsEntry 11 }
etherStatsJabbers OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets received that were
       longer than 1518 octets (excluding framing bits,
       but including FCS octets), and were not an
       integral number of octets in length or had
       a bad Frame Check Sequence (FCS)."
    ::= { etherStatsEntry 12 }
etherStatsCollisions OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The best estimate of the total number of collisions
       on this Ethernet segment."
    ::= { etherStatsEntry 13 }
etherStatsPkts64Octets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error
       packets) received that were 64 octets in length
        (excluding framing bits but including FCS octets)."
```

```
::= { etherStatsEntry 14 }
etherStatsPkts65to1270ctets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error
       packets) received that were between
       65 and 127 octets in length inclusive
        (excluding framing bits but including FCS octets)."
    ::= { etherStatsEntry 15 }
etherStatsPkts128to255Octets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
       "The total number of packets (including error
       packets) received that were between
       128 and 255 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsEntry 16 }
etherStatsPkts256to511Octets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error
       packets) received that were between
        256 and 511 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsEntry 17 }
etherStatsPkts512to1023Octets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error
       packets) received that were between
       512 and 1023 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsEntry 18 }
```

```
etherStatsPkts1024to1518Octets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets (including error
        packets) received that were between
       1024 and 1518 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsEntry 19 }
etherStatsOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The entity that configured this entry and is
       therefore using the resources assigned to it."
    ::= { etherStatsEntry 20 }
etherStatsStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The status of this etherStats entry."
    ::= { etherStatsEntry 21 }
-- The History Group
-- Implementation of the History group is optional.
-- The history group records periodic statistical samples from
-- a network and stores them for later retrieval. The
-- historyControl table stores configuration entries that each
-- define an interface, polling period, and other parameters.
-- Once samples are taken, their data is stored in an entry
-- in a media-specific table. Each such entry defines one
-- sample, and is associated with the historyControlEntry that
-- caused the sample to be taken. Currently the only media-
-- specific table defined is the etherHistoryTable, for
-- Ethernet networks.
-- If the probe keeps track of the time of day, it should
-- start the first sample of the history at a time such that
-- when the next hour of the day begins, a sample is
-- started at that instant. This tends to make more
```

```
-- user-friendly reports, and enables comparison of reports
-- from different probes that have relatively accurate time
-- of day.
-- The monitor is encouraged to add two history control entries
-- per monitored interface upon initialization that describe
-- a short term and a long term polling period. Suggested
-- parameters are 30 seconds for the short term polling
-- period and 30 minutes for the long term period.
historyControlTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HistoryControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of history control entries."
    ::= { history 1 }
historyControlEntry OBJECT-TYPE
    SYNTAX HistoryControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of parameters that set up a periodic
        sampling of statistics."
    INDEX { historyControlIndex }
    ::= { historyControlTable 1 }
HistoryControlEntry ::= SEQUENCE {
    historyControlIndex
    historyControlDataSource
                                    INTEGER (1..65535),
                                   OBJECT IDENTIFIER,
    historyControlBucketsRequested INTEGER (1..65535),
   historyControlBucketsGranted INTEGER (1..65535), historyControlInterval INTEGER (1..3600),
    historyControlOwner
                                   OwnerString,
   historyControlStatus
                                    INTEGER
}
historyControlIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in the
        historyControl table. Each such entry defines a
        set of samples at a particular interval for an
        interface on the device."
    ::= { historyControlEntry 1 }
```

```
historyControlDataSource OBJECT-TYPE
    SYNTAX OBJECT IDENTIFIER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "This object identifies the source of the data for
        which historical data was collected and
        placed in a media-specific table on behalf of this
        historyControlEntry. This source can be any
        interface on this device. In order to identify
        a particular interface, this object shall identify
        the instance of the ifIndex object, defined
        in [4,6], for the desired interface. For example,
        if an entry were to receive data from interface #1,
        this object would be set to if Index.1.
        The statistics in this group reflect all packets
        on the local network segment attached to the
        identified interface.
        This object may not be modified if the associated
        historyControlStatus object is equal to valid(1)."
    ::= { historyControlEntry 2 }
historyControlBucketsRequested OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The requested number of discrete time intervals
        over which data is to be saved in the part of the
        media-specific table associated with this
        historyControl entry.
        When this object is created or modified, the probe
        should set historyControlBucketsGranted as closely to
        this object as is possible for the particular probe
        implementation and available resources."
    DEFVAL { 50 }
    ::= { historyControlEntry 3 }
historyControlBucketsGranted OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
```

"The number of discrete sampling intervals over which data shall be saved in the part of

DESCRIPTION

the media-specific table associated with this historyControl entry.

When the associated historyControlBucketsRequested object is created or modified, the probe should set this object as closely to the requested value as is possible for the particular probe implementation and available resources. The probe must not lower this value except as a result of a modification to the associated historyControlBucketsRequested object.

There will be times when the actual number of buckets associated with this entry is less than the value of this object. In this case, at the end of each sampling interval, a new bucket will be added to the media-specific table.

When the number of buckets reaches the value of this object and a new bucket is to be added to the media-specific table, the oldest bucket associated with this historyControlEntry shall be deleted by the agent so that the new bucket can be added.

When the value of this object changes to a value less than the current value, entries are deleted from the media-specific table associated with this historyControlEntry. Enough of the oldest of these entries shall be deleted by the agent so that their number remains less than or equal to the new value of this object.

When the value of this object changes to a value greater than the current value, the number of associated media-specific entries may be allowed to grow."

::= { historyControlEntry 4 }

historyControlInterval OBJECT-TYPE SYNTAX INTEGER (1..3600) ACCESS read-write STATUS mandatory DESCRIPTION

"The interval in seconds over which the data is sampled for each bucket in the part of the media-specific table associated with this historyControl entry. This interval can be set to any number of seconds between 1 and

3600 (1 hour).

Because the counters in a bucket may overflow at their maximum value with no indication, a prudent manager will take into account the possibility of overflow in any of the associated counters. It is important to consider the minimum time in which any counter could overflow on a particular media type and set the historyControlInterval object to a value less than this interval. This is typically most important for the 'octets' counter in any media-specific table. For example, on an Ethernet network, the etherHistoryOctets counter could overflow in about one hour at the Ethernet's maximum utilization.

utilization. This object may not be modified if the associated historyControlStatus object is equal to valid(1)." DEFVAL { 1800 } ::= { historyControlEntry 5 } historyControlOwner OBJECT-TYPE SYNTAX OwnerString ACCESS read-write STATUS mandatory DESCRIPTION "The entity that configured this entry and is therefore using the resources assigned to it." ::= { historyControlEntry 6 } historyControlStatus OBJECT-TYPE SYNTAX EntryStatus ACCESS read-write STATUS mandatory DESCRIPTION "The status of this historyControl entry. Each instance of the media-specific table associated with this historyControlEntry will be deleted by the agent if this historyControlEntry is not equal to valid(1)." ::= { historyControlEntry 7 } -- Ether History table etherHistoryTable OBJECT-TYPE SYNTAX SEQUENCE OF EtherHistoryEntry

```
ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "A list of Ethernet history entries."
    ::= { history 2 }
etherHistoryEntry OBJECT-TYPE
   SYNTAX EtherHistoryEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "An historical sample of Ethernet statistics on a
       particular Ethernet interface. This sample is
       associated with the historyControlEntry which set
       up the parameters for a regular collection of these
       samples."
    INDEX { etherHistoryIndex , etherHistorySampleIndex }
    ::= { etherHistoryTable 1 }
EtherHistoryEntry ::= SEQUENCE {
   etherHistoryIndex
                                    INTEGER (1..65535),
   etherHistorySampleIndex
                                    INTEGER,
                                   TimeTicks,
   etherHistoryIntervalStart
   etherHistoryDropEvents
                                     Counter,
   etherHistoryOctets
                                     Counter,
   etherHistoryPkts
                                    Counter,
   etherHistoryBroadcastPkts
                                   Counter,
   etherHistoryMulticastPkts
                                    Counter,
   etherHistoryCRCAlignErrors
                                    Counter,
   etherHistoryUndersizePkts
                                    Counter,
   etherHistoryOversizePkts
                                    Counter,
   etherHistoryFragments
                                    Counter,
   etherHistoryJabbers
                                    Counter,
   etherHistoryCollisions
                                    Counter,
   etherHistoryUtilization
                                    INTEGER (0..10000)
}
etherHistoryIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The history of which this entry is a part. The
       history identified by a particular value of this
       index is the same history as identified
       by the same value of historyControlIndex."
    ::= { etherHistoryEntry 1 }
```

```
etherHistorySampleIndex OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "An index that uniquely identifies the particular
        sample this entry represents among all samples
        associated with the same historyControlEntry.
       This index starts at 1 and increases by one
       as each new sample is taken."
    ::= { etherHistoryEntry 2 }
etherHistoryIntervalStart OBJECT-TYPE
   SYNTAX TimeTicks
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The value of sysUpTime at the start of the interval
       over which this sample was measured. If the probe
       keeps track of the time of day, it should start
       the first sample of the history at a time such that
       when the next hour of the day begins, a sample is
       started at that instant. Note that following this
       rule may require the probe to delay collecting the
       first sample of the history, as each sample must be
       of the same interval. Also note that the sample which
       is currently being collected is not accessible in this
       table until the end of its interval."
    ::= { etherHistoryEntry 3 }
etherHistoryDropEvents OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
    STATUS mandatory
   DESCRIPTION
        "The total number of events in which packets
       were dropped by the probe due to lack of resources
       during this interval. Note that this number is not
       necessarily the number of packets dropped, it is just
        the number of times this condition has been detected."
    ::= { etherHistoryEntry 4 }
etherHistoryOctets OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of octets of data (including
```

```
those in bad packets) received on the
       network (excluding framing bits but including
       FCS octets)."
    ::= { etherHistoryEntry 5 }
etherHistoryPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of packets (including error packets)
       received during this sampling interval."
    ::= { etherHistoryEntry 6 }
etherHistoryBroadcastPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of good packets received during this
       sampling interval that were directed to the
       broadcast address."
    ::= { etherHistoryEntry 7 }
etherHistoryMulticastPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of good packets received during this
        sampling interval that were directed to a
       multicast address. Note that this number does not
        include packets addressed to the broadcast address."
    ::= { etherHistoryEntry 8 }
etherHistoryCRCAlignErrors OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of packets received during this
        sampling interval that had a length (excluding
        framing bits but including FCS octets) between
       64 and 1518 octets, inclusive, but were not an
       integral number of octets in length or had a
       bad Frame Check Sequence (FCS)."
    ::= { etherHistoryEntry 9 }
```

```
etherHistoryUndersizePkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of packets received during this
        interval that were less than 64 octets long
       (excluding framing bits but including FCS
       octets) and were otherwise well formed."
    ::= { etherHistoryEntry 10 }
etherHistoryOversizePkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of packets received during this
        interval that were longer than 1518 octets
        (excluding framing bits but including FCS
       octets) but were otherwise well formed."
    ::= { etherHistoryEntry 11 }
etherHistoryFragments OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The total number of packets received during this
       sampling interval that were not an integral
       number of octets in length or that
       had a bad Frame Check Sequence (FCS), and
       were less than 64 octets in length (excluding
       framing bits but including FCS octets)."
    ::= { etherHistoryEntry 12 }
etherHistoryJabbers OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of packets received during this
        interval that were longer than 1518 octets
       (excluding framing bits but including FCS octets),
       and were not an integral number of octets in
       length or had a bad Frame Check Sequence (FCS)."
    ::= { etherHistoryEntry 13 }
```

```
etherHistoryCollisions OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The best estimate of the total number of collisions
        on this Ethernet segment during this interval."
    ::= { etherHistoryEntry 14 }
etherHistoryUtilization OBJECT-TYPE
   SYNTAX INTEGER (0..10000)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The best estimate of the mean physical layer
       network utilization on this interface during this
       interval, in hundredths of a percent."
    ::= { etherHistoryEntry 15 }
-- The Alarm Group
-- Implementation of the Alarm group is optional.
-- The Alarm Group requires the implementation of the Event
-- group.
-- The Alarm group periodically takes statistical samples from
-- variables in the probe and compares them to thresholds
-- that have been configured. The alarm table stores
-- configuration entries that each define a variable,
-- polling period, and threshold parameters. If a sample is
-- found to cross the threshold values, an event is
-- generated. Only variables that resolve to an ASN.1
-- primitive type of INTEGER (INTEGER, Counter,
-- Gauge, or TimeTicks) may be monitored in this way.
-- This function has a hysteresis mechanism to limit the
-- generation of events. This mechanism generates one event
-- as a threshold is crossed in the appropriate direction.
-- No more events are generated for that threshold until the
-- opposite threshold is crossed.
-- In the case of a sampling a deltaValue, a probe may
-- implement this mechanism with more precision if it takes
-- a delta sample twice per period, each time comparing the
-- sum of the latest two samples to the threshold. This
-- allows the detection of threshold crossings
```

```
-- that span the sampling boundary. Note that this does not
-- require any special configuration of the threshold value.
-- It is suggested that probes implement this more precise
-- algorithm.
alarmTable OBJECT-TYPE
    SYNTAX SEQUENCE OF Alarmentry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of alarm entries."
    ::= { alarm 1 }
alarmEntry OBJECT-TYPE
   SYNTAX AlarmEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of parameters that set up a periodic checking
        for alarm conditions."
    INDEX { alarmIndex }
    ::= { alarmTable 1 }
AlarmEntry ::= SEQUENCE {
    alarmIndex
                                   INTEGER (1..65535),
                                  INTEGER,
    alarmInterval
                                 OBJECT IDENTIFIER,
   alarmVariable
   alarmSampleType
                                  INTEGER,
   alarmValue
                                  INTEGER,
   alarmStartupAlarm
                                  INTEGER,
   alarmRisingThreshold
                                  INTEGER,
   alarmFallingThreshold
alarmRisingEventIndex
alarmFallingEventIndex
                                  INTEGER,
                                  INTEGER (1..65535),
                                  INTEGER (1..65535),
   alarmOwner
                                   OwnerString,
   alarmStatus
                                   INTEGER
}
alarmIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in the
        alarm table. Each such entry defines a
        diagnostic sample at a particular interval
        for an object on the device."
    ::= { alarmEntry 1 }
```

alarmInterval OBJECT-TYPE
SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The interval in seconds over which the data is sampled and compared with the rising and falling thresholds. When setting this variable, care should be given to ensure that the variable being monitored will not exceed 2^31 - 1 and roll over the alarmValue object during the interval.

This object may not be modified if the associated alarmStatus object is equal to valid(1)."

::= { alarmEntry 2 }

alarmVariable OBJECT-TYPE
SYNTAX OBJECT IDENTIFIER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The object identifier of the particular variable to be sampled. Only variables that resolve to an ASN.1 primitive type of INTEGER (INTEGER, Counter, Gauge, or TimeTicks) may be sampled.

Because SNMP access control is articulated entirely in terms of the contents of MIB views, no access control mechanism exists that can restrict the value of this object to identify only those objects that exist in a particular MIB view. Because there is thus no acceptable means of restricting the read access that could be obtained through the alarm mechanism, the probe must only grant write access to this object in those views that have read access to all objects on the probe.

During a set operation, if the supplied variable name is not available in the selected MIB view, a badValue error must be returned. If at any time the variable name of an established alarmEntry is no longer available in the selected MIB view, the probe must change the status of this alarmEntry to invalid(4).

This object may not be modified if the associated
 alarmStatus object is equal to valid(1)."
::= { alarmEntry 3 }

```
alarmSampleType OBJECT-TYPE
   SYNTAX INTEGER {
       absoluteValue(1),
       deltaValue(2)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The method of sampling the selected variable and
       calculating the value to be compared against the
       thresholds. If the value of this object is
       absoluteValue(1), the value of the selected variable
       will be compared directly with the thresholds at the
       end of the sampling interval. If the value of this
       object is deltaValue(2), the value of the selected
       variable at the last sample will be subtracted from
       the current value, and the difference compared with
       the thresholds.
       This object may not be modified if the associated
       alarmStatus object is equal to valid(1)."
    ::= { alarmEntry 4 }
alarmValue OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The value of the statistic during the last sampling
       period. The value during the current sampling period
       is not made available until the period is completed."
    ::= { alarmEntry 5 }
alarmStartupAlarm OBJECT-TYPE
   SYNTAX INTEGER {
       risingAlarm(1),
       fallingAlarm(2),
       risingOrFallingAlarm(3)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The alarm that may be sent when this entry is first
       set to valid. If the first sample after this entry
       becomes valid is greater than or equal to the
       risingThreshold and alarmStartupAlarm is equal to
       risingAlarm(1) or risingOrFallingAlarm(3), then a
       single rising alarm will be generated. If the first
```

sample after this entry becomes valid is less than or equal to the fallingThreshold and alarmStartupAlarm is equal to fallingAlarm(2) or risingOrFallingAlarm(3), then a single falling alarm will be generated.

This object may not be modified if the associated
 alarmStatus object is equal to valid(1)."
::= { alarmEntry 6 }

alarmRisingThreshold OBJECT-TYPE

SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"A threshold for the sampled statistic. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval was less than this threshold, a single event will be generated.

A single event will also be generated if the first sample after this entry becomes valid is greater than or equal to this threshold and the associated alarmStartupAlarm is equal to risingAlarm(1) or risingOrFallingAlarm(3).

After a rising event is generated, another such event will not be generated until the sampled value falls below this threshold and reaches the alarmFallingThreshold.

This object may not be modified if the associated
 alarmStatus object is equal to valid(1)."
::= { alarmEntry 7 }

alarmFallingThreshold OBJECT-TYPE

SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"A threshold for the sampled statistic. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval was greater than this threshold, a single event will be generated.

A single event will also be generated if the first sample after this entry becomes valid is less than or equal to this threshold and the associated alarmStartupAlarm is equal to fallingAlarm(2) or risingOrFallingAlarm(3).

After a falling event is generated, another such event will not be generated until the sampled value rises above this threshold and reaches the alarmRisingThreshold.

This object may not be modified if the associated alarmStatus object is equal to valid(1)."
::= { alarmEntry 8 }

alarmRisingEventIndex OBJECT-TYPE
SYNTAX INTEGER (0..65535)
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The index of the eventEntry that is used when a rising threshold is crossed. The eventEntry identified by a particular value of this index is the same as identified by the same value of the eventIndex object. If there is no corresponding entry in the eventTable, then no association exists. In particular, if this value is zero, no associated event will be generated, as zero is not a valid event index.

This object may not be modified if the associated alarmStatus object is equal to valid(1)."

::= { alarmEntry 9 }

alarmFallingEventIndex OBJECT-TYPE
SYNTAX INTEGER (0..65535)
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The index of the eventEntry that is used when a falling threshold is crossed. The eventEntry identified by a particular value of this index is the same as identified by the same value of the eventIndex object. If there is no corresponding entry in the eventTable, then no association exists. In particular, if this value is zero, no associated event will be generated, as zero is not a valid event index.

This object may not be modified if the associated alarmStatus object is equal to valid(1)."

```
::= { alarmEntry 10 }
alarmOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The entity that configured this entry and is
       therefore using the resources assigned to it."
    ::= { alarmEntry 11 }
alarmStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
       "The status of this alarm entry."
    ::= { alarmEntry 12 }
-- The Host Group
-- Implementation of the Host group is optional.
-- The host group discovers new hosts on the network by
-- keeping a list of source and destination MAC Addresses seen
-- in good packets. For each of these addresses, the host
-- group keeps a set of statistics. The hostControlTable
-- controls which interfaces this function is performed on,
-- and contains some information about the process. On
-- behalf of each hostControlEntry, data is collected on an
-- interface and placed both the hostTable and the
-- hostTimeTable. If the monitoring device finds itself
-- short of resources, it may delete entries as needed. It
-- is suggested that the device delete the least recently
-- used entries first.
-- The hostTable contains entries for each address
-- discovered on a particular interface. Each entry
-- contains statistical data about that host. This table
-- is indexed by the MAC address of the host, through
-- which a random access may be achieved.
-- The hostTimeTable contains data in the same format as the
-- hostTable, and must contain the same set of hosts, but is
-- indexed using hostTimeCreationOrder rather than hostAddress.
-- The hostTimeCreationOrder is an integer which reflects
-- the relative order in which a particular entry was
```

```
-- discovered and thus inserted into the table. As this
-- order, and thus index, is among those entries currently
-- in the table, the index for a particular entry may change
-- if an (earlier) entry is deleted. Thus the association
-- between hostTimeCreationOrder and hostTimeEntry may be
-- broken at any time.
-- The hostTimeTable has two important uses. The first is the
-- fast download of this potentially large table. Because the
-- index of this table runs from 1 to the size of the table,
-- inclusive, its values are predictable. This allows very
-- efficient packing of variables into SNMP PDU's and allows
-- a table transfer to have multiple packets outstanding.
-- These benefits increase transfer rates tremendously.
-- The second use of the hostTimeTable is the efficient
-- discovery by the management station of new entries added
-- to the table. After the management station has
-- downloaded the entire table, it knows that new entries
-- will be added immediately after the end of the current
-- table. It can thus detect new entries there
-- and retrieve them easily.
-- Because the association between hostTimeCreationOrder and
-- hostTimeEntry may be broken at any time, the management
-- station must monitor the related hostControlLastDeleteTime
-- object. When the management station thus detects a deletion,
-- it must assume that any such associations have been broken,
-- and invalidate any it has stored locally. This includes
-- restarting any download of the hostTimeTable that may have
-- been in progress, as well as rediscovering the end of the
-- hostTimeTable so that it may detect new entries. If the
-- management station does not detect the broken association,
-- it may continue to refer to a particular host by its
-- creationOrder while unwittingly retrieving the data
-- associated with another host entirely. If this happens
-- while downloading the host table, the management station
-- may fail to download all of the entries in the table.
hostControlTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of host table control entries."
    ::= { hosts 1 }
```

```
hostControlEntry OBJECT-TYPE
   SYNTAX HostControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of parameters that set up the discovery of
       hosts on a particular interface and the collection
       of statistics about these hosts."
    INDEX { hostControlIndex }
    ::= { hostControlTable 1 }
HostControlEntry ::= SEQUENCE {
   hostControlIndex
                               INTEGER (1..65535),
   hostControlDataSource
                               OBJECT IDENTIFIER,
                               INTEGER,
   hostControlTableSize
   hostControlLastDeleteTime TimeTicks,
                              OwnerString,
   hostControlOwner
   hostControlStatus
                               INTEGER
}
hostControlIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in the
       hostControl table. Each such entry defines
       a function that discovers hosts on a particular
       interface and places statistics about them in the
       hostTable and the hostTimeTable on behalf of this
       hostControlEntry."
    ::= { hostControlEntry 1 }
hostControlDataSource OBJECT-TYPE
    SYNTAX OBJECT IDENTIFIER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "This object identifies the source of the data for
        this instance of the host function. This source
       can be any interface on this device. In order
        to identify a particular interface, this object shall
        identify the instance of the ifIndex object, defined
        in [4,6], for the desired interface. For example,
        if an entry were to receive data from interface #1,
        this object would be set to ifIndex.1.
```

The statistics in this group reflect all packets

```
on the local network segment attached to the
        identified interface.
        This object may not be modified if the associated
        hostControlStatus object is equal to valid(1)."
    ::= { hostControlEntry 2 }
hostControlTableSize OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of hostEntries in the hostTable and the
       hostTimeTable associated with this hostControlEntry."
    ::= { hostControlEntry 3 }
hostControlLastDeleteTime OBJECT-TYPE
    SYNTAX TimeTicks
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The value of sysUpTime when the last entry
        was deleted from the portion of the hostTable
        associated with this hostControlEntry. If no
        deletions have occurred, this value shall be zero."
    ::= { hostControlEntry 4 }
hostControlOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
    DESCRIPTION
        "The entity that configured this entry and is
        therefore using the resources assigned to it."
    ::= { hostControlEntry 5 }
hostControlStatus OBJECT-TYPE
    SYNTAX EntryStatus
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The status of this hostControl entry.
        If this object is not equal to valid(1), all
        associated entries in the hostTable,
        hostTimeTable, and the hostTopNTable shall be
        deleted by the agent."
    ::= { hostControlEntry 6 }
```

```
hostTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of host entries."
    ::= { hosts 2 }
hostEntry OBJECT-TYPE
    SYNTAX HostEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A collection of statistics for a particular host
        that has been discovered on an interface of this
        device."
    INDEX { hostIndex, hostAddress }
    ::= { hostTable 1 }
HostEntry ::= SEQUENCE {
    hostAddress
                           OCTET STRING,
   hostCreationOrder INTEGER (1..65535),
hostIndex INTEGER (1..65535),
    hostInPkts
                            Counter,
    hostOutPkts
                           Counter,
                          Counter,
    hostInOctets
   hostOutOctets
hostOutErrors
                          Counter,
                           Counter,
   hostOutBroadcastPkts Counter,
   hostOutMulticastPkts Counter
}
hostAddress OBJECT-TYPE
    SYNTAX OCTET STRING
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The physical address of this host."
    ::= { hostEntry 1 }
hostCreationOrder OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that defines the relative ordering of
        the creation time of hosts captured for a
        particular hostControlEntry. This index shall
```

be between 1 and N, where N is the value of the associated hostControlTableSize. The ordering of the indexes is based on the order of each entry's insertion into the table, in which entries added earlier have a lower index value than entries added later

It is important to note that the order for a particular entry may change as an (earlier) entry is deleted from the table. Because this order may change, management stations should make use of the hostControlLastDeleteTime variable in the hostControlEntry associated with the relevant portion of the hostTable. By observing this variable, the management station may detect the circumstances where a previous association between a value of hostCreationOrder and a hostEntry may no longer hold."

::= { hostEntry 2 }

```
hostIndex OBJECT-TYPE
SYNTAX INTEGER (1..65535)
ACCESS read-only
STATUS mandatory
DESCRIPTION
```

"The set of collected host statistics of which this entry is a part. The set of hosts identified by a particular value of this index is associated with the hostControlEntry as identified by the same value of hostControlIndex."

::= { hostEntry 3 }

hostinPkts OBJECT-TYPE SYNTAX Counter ACCESS read-only STATUS mandatory

DESCRIPTION
 "The number of packets without errors transmitted to
 this address since it was added to the hostTable."
::= { hostEntry 4 }

hostOutPkts OBJECT-TYPE SYNTAX Counter ACCESS read-only STATUS mandatory DESCRIPTION

"The number of packets including errors transmitted by this address since it was added to the hostTable."

```
::= { hostEntry 5 }
hostInOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets transmitted to this address
        since it was added to the hostTable (excluding
        framing bits but including FCS octets), except for
        those octets in packets that contained errors."
    ::= { hostEntry 6 }
hostOutOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets transmitted by this address
        since it was added to the hostTable (excluding
        framing bits but including FCS octets), including
        those octets in packets that contained errors."
    ::= { hostEntry 7 }
hostOutErrors OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of error packets transmitted by this
        address since this host was added to the hostTable."
    ::= { hostEntry 8 }
hostOutBroadcastPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of good packets transmitted by this
        address that were directed to the broadcast address
        since this host was added to the hostTable."
    ::= { hostEntry 9 }
hostOutMulticastPkts OBJECT-TYPE
   SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
```

```
"The number of good packets transmitted by this
        address that were directed to a multicast address
        since this host was added to the hostTable.
        Note that this number does not include packets
        directed to the broadcast address."
    ::= { hostEntry 10 }
-- host Time Table
hostTimeTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostTimeEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "A list of time-ordered host table entries."
    ::= { hosts 3 }
hostTimeEntry OBJECT-TYPE
    SYNTAX HostTimeEntry
    ACCESS not-accessible
   STATUS mandatory
    DESCRIPTION
        "A collection of statistics for a particular host
        that has been discovered on an interface of this
        device. This collection includes the relative
        ordering of the creation time of this object."
    INDEX { hostTimeIndex, hostTimeCreationOrder }
    ::= { hostTimeTable 1 }
HostTimeEntry ::= SEQUENCE {
   hostTimeAddress
                                OCTET STRING,
   hostTimeCreationOrder
                                 INTEGER (1..65535),
    hostTimeIndex
                                 INTEGER (1..65535),
   hostTimeInPkts
                                Counter,
   hostTimeOutPkts
                                Counter,
   hostTimeInOctets
                               Counter,
   hostTimeOutOctets
                               Counter,
   hostTimeOutErrors
                                Counter,
   hostTimeOutBroadcastPkts Counter,
hostTimeOutMulticastPkts Counter
hostTimeAddress OBJECT-TYPE
   SYNTAX OCTET STRING
    ACCESS read-only
    STATUS mandatory
   DESCRIPTION
```

```
"The physical address of this host."
    ::= { hostTimeEntry 1 }
hostTimeCreationOrder OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in
        the hostTime table among those entries associated
        with the same hostControlEntry. This index shall
        be between 1 and N, where N is the value of
        the associated hostControlTableSize. The ordering
        of the indexes is based on the order of each entry's
        insertion into the table, in which entries added
        earlier have a lower index value than entries added
        later. Thus the management station has the ability
        to learn of new entries added to this table without
        downloading the entire table.
        It is important to note that the index for a
        particular entry may change as an (earlier) entry
        is deleted from the table. Because this order may
        change, management stations should make use of the
        hostControlLastDeleteTime variable in the
        hostControlEntry associated with the relevant
        portion of the hostTimeTable. By observing
        this variable, the management station may detect
        the circumstances where a download of the table
        may have missed entries, and where a previous
        association between a value of hostTimeCreationOrder
        and a hostTimeEntry may no longer hold."
    ::= { hostTimeEntry 2 }
hostTimeIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The set of collected host statistics of which
        this entry is a part. The set of hosts
        identified by a particular value of this
        index is associated with the hostControlEntry
        as identified by the same value of hostControlIndex."
```

::= { hostTimeEntry 3 }

```
hostTimeInPkts OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of packets without errors transmitted to
        this address since it was added to the hostTimeTable."
    ::= { hostTimeEntry 4 }
hostTimeOutPkts OBJECT-TYPE
   SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of packets including errors transmitted
        by this address since it was added to the
        hostTimeTable."
    ::= { hostTimeEntry 5 }
hostTimeInOctets OBJECT-TYPE
    SYNTAX Counter
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets transmitted to this address
        since it was added to the hostTimeTable (excluding
        framing bits but including FCS octets), except for
        those octets in packets that contained errors."
    ::= { hostTimeEntry 6 }
hostTimeOutOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets transmitted by this address since
        it was added to the hostTimeTable (excluding framing
        bits but including FCS octets), including those
        octets in packets that contained errors."
    ::= { hostTimeEntry 7 }
hostTimeOutErrors OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of error packets transmitted by this
        address since this host was added to the
```

```
hostTimeTable."
    ::= { hostTimeEntry 8 }
hostTimeOutBroadcastPkts OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of good packets transmitted by this
        address that were directed to the broadcast address
        since this host was added to the hostTimeTable."
    ::= { hostTimeEntry 9 }
hostTimeOutMulticastPkts OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of good packets transmitted by this
        address that were directed to a multicast address
        since this host was added to the hostTimeTable.
        Note that this number does not include packets
        directed to the broadcast address."
    ::= { hostTimeEntry 10 }
-- The Host Top "N" Group
-- Implementation of the Host Top N group is optional.
-- The Host Top N group requires the implementation of the
-- host group.
-- The Host Top N group is used to prepare reports that
-- describe the hosts that top a list ordered by one of
-- their statistics. The available statistics are samples
-- of one of their base statistics, over an interval
-- specified by the management station. Thus, these
-- statistics are rate based. The management
-- station also selects how many such hosts are reported.
-- The hostTopNControlTable is used to initiate the generation
-- of such a report. The management station may select the
-- parameters of such a report, such as which interface,
-- which statistic, how many hosts, and the start and stop
-- times of the sampling. When the report is prepared,
-- entries are created in the hostTopNTable associated with
-- the relevant hostTopNControlEntry. These entries are
```

```
-- static for each report after it has been prepared.
hostTopNControlTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostTopNControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of top N host control entries."
    ::= { hostTopN 1 }
hostTopNControlEntry OBJECT-TYPE
    SYNTAX HostTopNControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A set of parameters that control the creation of a
        report of the top N hosts according to several
        metrics."
    INDEX { hostTopNControlIndex }
    ::= { hostTopNControlTable 1 }
HostTopNControlEntry ::= SEQUENCE {
    hostTopNControlIndex INTEGER (1..65535),
    hostTopNHostIndex INTEGER (1..65535), hostTopNRateBase INTEGER,
    hostTopNTimeRemaining INTEGER,
                           INTEGER,
    hostTopNDuration
    hostTopNRequestedSize INTEGER,
   hostTopNGrantedSize INTEGER,
hostTopNStartTime TimeTicks,
    hostTopNStartTime
    hostTopNOwner
                            OwnerString,
    hostTopNStatus
                            INTEGER
}
hostTopNControlIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry
        in the hostTopNControl table. Each such
        entry defines one top N report prepared for
        one interface."
    ::= { hostTopNControlEntry 1 }
hostTopNHostIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-write
```

```
STATUS mandatory
    DESCRIPTION
        "The host table for which a top N report will be
        prepared on behalf of this entry. The host table
        identified by a particular value of this index is
        associated with the same host table as identified
        by the same value of hostIndex.
        This object may not be modified if the associated
        hostTopNStatus object is equal to valid(1)."
    ::= { hostTopNControlEntry 2 }
hostTopNRateBase OBJECT-TYPE
    SYNTAX INTEGER {
           hostTopNInPkts(1),
            hostTopNOutPkts(2),
            hostTopNInOctets(3),
            hostTopNOutOctets(4),
            hostTopNOutErrors(5),
            hostTopNOutBroadcastPkts(6),
            hostTopNOutMulticastPkts(7)
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The variable for each host that the hostTopNRate
        variable is based upon.
        This object may not be modified if the associated
        hostTopNStatus object is equal to valid(1)."
    ::= { hostTopNControlEntry 3 }
hostTopNTimeRemaining OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The number of seconds left in the report currently
        being collected. When this object is modified by
        the management station, a new collection is started,
        possibly aborting a currently running report. The
        new value is used as the requested duration of this
        report, which is loaded into the associated
        hostTopNDuration object.
        When this object is set to a non-zero value, any
```

associated hostTopNEntries shall be made

inaccessible by the monitor. While the value of this

```
object is non-zero, it decrements by one per second
       until it reaches zero. During this time, all
       associated hostTopNEntries shall remain
       inaccessible. At the time that this object
       decrements to zero, the report is made
       accessible in the hostTopNTable. Thus, the hostTopN
        table needs to be created only at the end of the
        collection interval."
   DEFVAL { 0 }
    ::= { hostTopNControlEntry 4 }
hostTopNDuration OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of seconds that this report has collected
       during the last sampling interval, or if this
       report is currently being collected, the number
        of seconds that this report is being collected
       during this sampling interval.
       When the associated hostTopNTimeRemaining object is
       set, this object shall be set by the probe to the
        same value and shall not be modified until the next
       time the hostTopNTimeRemaining is set.
       This value shall be zero if no reports have been
       requested for this hostTopNControlEntry."
   DEFVAL { 0 }
    ::= { hostTopNControlEntry 5 }
hostTopNRequestedSize OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The maximum number of hosts requested for the top N
       table.
       When this object is created or modified, the probe
        should set hostTopNGrantedSize as closely to this
       object as is possible for the particular probe
       implementation and available resources."
   DEFVAL { 10 }
    ::= { hostTopNControlEntry 6 }
```

```
hostTopNGrantedSize OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The maximum number of hosts in the top N table.
        When the associated hostTopNRequestedSize object is
        created or modified, the probe should set this
        object as closely to the requested value as is
        possible for the particular implementation and
        available resources. The probe must not lower this
        value except as a result of a set to the associated
        hostTopNRequestedSize object.
        Hosts with the highest value of hostTopNRate shall be
        placed in this table in decreasing order of this rate
        until there is no more room or until there are no more
        hosts."
    ::= { hostTopNControlEntry 7 }
hostTopNStartTime OBJECT-TYPE
    SYNTAX TimeTicks
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The value of sysUpTime when this top N report was
        last started. In other words, this is the time that
        the associated hostTopNTimeRemaining object was
        modified to start the requested report."
    ::= { hostTopNControlEntry 8 }
hostTopNOwner OBJECT-TYPE
    SYNTAX OwnerString
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The entity that configured this entry and is
        therefore using the resources assigned to it."
    ::= { hostTopNControlEntry 9 }
hostTopNStatus OBJECT-TYPE
    SYNTAX EntryStatus
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
```

"The status of this hostTopNControl entry.

```
If this object is not equal to valid(1), all
        associated hostTopNEntries shall be deleted by
        the agent."
    ::= { hostTopNControlEntry 10 }
hostTopNTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostTopNEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of top N host entries."
    ::= { hostTopN 2 }
hostTopNEntry OBJECT-TYPE
   SYNTAX HostTopNEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A set of statistics for a host that is part of a
       top N report."
    INDEX { hostTopNReport, hostTopNIndex }
    ::= { hostTopNTable 1 }
HostTopNEntry ::= SEQUENCE {
    hostTopNReport
                                  INTEGER (1..65535),
                                 INTEGER (1..65535),
   hostTopNIndex
                                 OCTET STRING,
   hostTopNAddress
                                  INTEGER
   hostTopNRate
}
hostTopNReport OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "This object identifies the top N report of which
        this entry is a part. The set of hosts
        identified by a particular value of this
        object is part of the same report as identified
        by the same value of the hostTopNControlIndex object."
    ::= { hostTopNEntry 1 }
hostTopNIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in
```

```
the hostTopN table among those in the same report.
        This index is between 1 and N, where N is the
        number of entries in this table. Increasing values
        of hostTopNIndex shall be assigned to entries with
        decreasing values of hostTopNRate until index N
        is assigned to the entry with the lowest value of
        hostTopNRate or there are no more hostTopNEntries."
    ::= { hostTopNEntry 2 }
hostTopNAddress OBJECT-TYPE
   SYNTAX OCTET STRING
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The physical address of this host."
    ::= { hostTopNEntry 3 }
hostTopNRate OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The amount of change in the selected variable
        during this sampling interval. The selected
        variable is this host's instance of the object
        selected by hostTopNRateBase."
    ::= { hostTopNEntry 4 }
-- The Matrix Group
-- Implementation of the Matrix group is optional.
-- The Matrix group consists of the matrixControlTable,
-- matrixSDTable and the matrixDSTable. These tables
-- store statistics for a particular conversation between
-- two addresses. As the device detects a new conversation,
-- including those to a non-unicast address, it creates a
-- new entry in both of the matrix tables.
-- It must only create new entries based on information
-- received in good packets. If the monitoring device finds
-- itself short of resources, it may delete entries as needed.
-- It is suggested that the device delete the least recently
-- used entries first.
matrixControlTable OBJECT-TYPE
    SYNTAX SEQUENCE OF MatrixControlEntry
```

ACCESS not-accessible

```
STATUS mandatory
   DESCRIPTION
       "A list of information entries for the
       traffic matrix on each interface."
    ::= { matrix 1 }
matrixControlEntry OBJECT-TYPE
   SYNTAX MatrixControlEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
       "Information about a traffic matrix on a
       particular interface."
   INDEX { matrixControlIndex }
    ::= { matrixControlTable 1 }
MatrixControlEntry ::= SEQUENCE {
   matrixControlIndex INTEGER (1..65535),
   matrixControlLastDeleteTime TimeTicks,
   matrixControlOwner
                              OwnerString,
   matrixControlStatus
                              INTEGER
}
matrixControlIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
       "An index that uniquely identifies an entry in the
       matrixControl table. Each such entry defines
       a function that discovers conversations on a particular
       interface and places statistics about them in the
       matrixSDTable and the matrixDSTable on behalf of this
       matrixControlEntry."
    ::= { matrixControlEntry 1 }
matrixControlDataSource OBJECT-TYPE
   SYNTAX OBJECT IDENTIFIER
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
       "This object identifies the source of
       the data from which this entry creates a traffic matrix.
       This source can be any interface on this device. In
       order to identify a particular interface, this object
       shall identify the instance of the ifIndex object,
```

```
defined in [4,6], for the desired interface. For
       example, if an entry were to receive data from
        interface #1, this object would be set to ifIndex.1.
       The statistics in this group reflect all packets
        on the local network segment attached to the
        identified interface.
       This object may not be modified if the associated
       matrixControlStatus object is equal to valid(1)."
    ::= { matrixControlEntry 2 }
matrixControlTableSize OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of matrixSDEntries in the matrixSDTable
        for this interface. This must also be the value of
       the number of entries in the matrixDSTable for this
       interface."
    ::= { matrixControlEntry 3 }
matrixControlLastDeleteTime OBJECT-TYPE
   SYNTAX TimeTicks
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The value of sysUpTime when the last entry
       was deleted from the portion of the matrixSDTable
       or matrixDSTable associated with this
       matrixControlEntry.
       If no deletions have occurred, this value shall be
       zero."
    ::= { matrixControlEntry 4 }
matrixControlOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The entity that configured this entry and is
        therefore using the resources assigned to it."
    ::= { matrixControlEntry 5 }
matrixControlStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
```

```
STATUS mandatory
    DESCRIPTION
        "The status of this matrixControl entry.
       If this object is not equal to valid(1), all
       associated entries in the matrixSDTable and the
       matrixDSTable shall be deleted by the agent."
    ::= { matrixControlEntry 6 }
matrixSDTable OBJECT-TYPE
   SYNTAX SEQUENCE OF MatrixSDEntry
   ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
       "A list of traffic matrix entries indexed by
       source and destination MAC address."
    ::= { matrix 2 }
matrixSDEntry OBJECT-TYPE
   SYNTAX MatrixSDEntry
   ACCESS not-accessible
   STATUS mandatory
    DESCRIPTION
        "A collection of statistics for communications between
       two addresses on a particular interface."
    INDEX { matrixSDIndex,
           matrixSDSourceAddress, matrixSDDestAddress }
    ::= { matrixSDTable 1 }
MatrixSDEntry ::= SEQUENCE {
   matrixSDSourceAddress
                               OCTET STRING,
   matrixSDDestAddress
                               OCTET STRING,
   matrixSDIndex
                               INTEGER (1..65535),
   matrixSDPkts
                               Counter,
   matrixSDOctets
                               Counter,
   matrixSDErrors
                               Counter
}
matrixSDSourceAddress OBJECT-TYPE
   SYNTAX OCTET STRING
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The source physical address."
    ::= { matrixSDEntry 1 }
```

```
matrixSDDestAddress OBJECT-TYPE
   SYNTAX OCTET STRING
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The destination physical address."
    ::= { matrixSDEntry 2 }
matrixSDIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The set of collected matrix statistics of which
        this entry is a part. The set of matrix statistics
        identified by a particular value of this index
        is associated with the same matrixControlEntry
        as identified by the same value of matrixControlIndex."
    ::= { matrixSDEntry 3 }
matrixSDPkts OBJECT-TYPE
   SYNTAX Counter
    ACCESS read-only
   STATUS mandatory
    DESCRIPTION
        "The number of packets transmitted from the source
        address to the destination address (this number
        includes error packets)."
    ::= { matrixSDEntry 4 }
matrixSDOctets OBJECT-TYPE
   SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets (excluding framing bits but
        including FCS octets) contained in all packets
        transmitted from the source address to the
        destination address."
    ::= { matrixSDEntry 5 }
matrixSDErrors OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of error packets transmitted from
        the source address to the destination address."
```

```
::= { matrixSDEntry 6 }
-- Traffic matrix tables from destination to source
matrixDSTable OBJECT-TYPE
   SYNTAX SEQUENCE OF MatrixDSEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of traffic matrix entries indexed by
       destination and source MAC address."
    ::= { matrix 3 }
matrixDSEntry OBJECT-TYPE
    SYNTAX MatrixDSEntry
   ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
       "A collection of statistics for communications between
       two address on a particular interface."
    INDEX { matrixDSIndex,
           matrixDSDestAddress, matrixDSSourceAddress }
    ::= { matrixDSTable 1 }
MatrixDSEntry ::= SEQUENCE {
   matrixDSSourceAddress
                               OCTET STRING,
   matrixDSDestAddress
                              OCTET STRING,
   matrixDSIndex
                               INTEGER (1..65535),
   matrixDSPkts
                               Counter,
   matrixDSOctets
                               Counter,
   matrixDSErrors
                               Counter
}
matrixDSSourceAddress OBJECT-TYPE
   SYNTAX OCTET STRING
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The source physical address."
    ::= { matrixDSEntry 1 }
matrixDSDestAddress OBJECT-TYPE
    SYNTAX OCTET STRING
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The destination physical address."
```

```
::= { matrixDSEntry 2 }
matrixDSIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The set of collected matrix statistics of which
        this entry is a part. The set of matrix statistics
        identified by a particular value of this index
        is associated with the same matrixControlEntry
        as identified by the same value of matrixControlIndex."
    ::= { matrixDSEntry 3 }
matrixDSPkts OBJECT-TYPE
    SYNTAX Counter
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of packets transmitted from the source
        address to the destination address (this number
        includes error packets)."
    ::= { matrixDSEntry 4 }
matrixDSOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of octets (excluding framing bits
        but including FCS octets) contained in all packets
        transmitted from the source address to the
        destination address."
    ::= { matrixDSEntry 5 }
matrixDSErrors OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
    DESCRIPTION
        "The number of error packets transmitted from
        the source address to the destination address."
    ::= { matrixDSEntry 6 }
-- The Filter Group
-- Implementation of the Filter group is optional.
```

```
-- The Filter group allows packets to be captured with an
-- arbitrary filter expression. A logical data and
-- event stream or "channel" is formed by the packets
-- that match the filter expression.
-- This filter mechanism allows the creation of an arbitrary
-- logical expression with which to filter packets. Each
-- filter associated with a channel is OR'ed with the others.
-- Within a filter, any bits checked in the data and status are
-- AND'ed with respect to other bits in the same filter. The
-- NotMask also allows for checking for inequality. Finally,
-- the channelAcceptType object allows for inversion of the
-- whole equation.
-- The channel can be turned on or off, and can also
-- generate events when packets pass through it.
filterTable OBJECT-TYPE
    SYNTAX SEQUENCE OF FilterEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of packet filter entries."
    ::= { filter 1 }
filterEntry OBJECT-TYPE
   SYNTAX FilterEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A set of parameters for a packet filter applied on a
       particular interface."
    INDEX { filterIndex }
    ::= { filterTable 1 }
FilterEntry ::= SEQUENCE {
    filterIndex
                                INTEGER (1..65535),
                            INTEGER (1..65535),
INTEGER,
    filterChannelIndex
    filterPktDataOffset
                               OCTET STRING,
    filterPktData
    tilterPktDataMask OCTET STRING, filterPktDataNotMask OCTET STRING,
    filterPktStatus
filterPktStatusMask
                                INTEGER,
                               INTEGER,
INTEGER,
    filterPktStatusNotMask
filterOwner
                               OwnerString,
    filterStatus
                                INTEGER
```

```
}
filterIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "An index that uniquely identifies an entry
       in the filter table. Each such entry defines
       one filter that is to be applied to every packet
       received on an interface."
    ::= { filterEntry 1 }
filterChannelIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "This object identifies the channel of which this
       filter is a part. The filters identified by a
       particular value of this object are associated
       with the same channel as identified by the same
       value of the channelIndex object."
    ::= { filterEntry 2 }
filterPktDataOffset OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The offset from the beginning of each packet where
       a match of packet data will be attempted. This offset
        is measured from the point in the physical layer
       packet after the framing bits, if any. For example,
       in an Ethernet frame, this point is at the beginning
       of the destination MAC address.
       This object may not be modified if the associated
       filterStatus object is equal to valid(1)."
   DEFVAL { 0 }
    ::= { filterEntry 3 }
filterPktData OBJECT-TYPE
   SYNTAX OCTET STRING
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The data that is to be matched with the input packet.
```

For each packet received, this filter and the accompanying filterPktDataMask and filterPktDataNotMask will be adjusted for the offset. The only bits relevant to this match algorithm are those that have the corresponding filterPktDataMask bit equal to one. The following three rules are then applied to every packet:

- (1) If the packet is too short and does not have data corresponding to part of the filterPktData, the packet will fail this data match.
- (2) For each relevant bit from the packet with the corresponding filterPktDataNotMask bit set to zero, if the bit from the packet is not equal to the corresponding bit from the filterPktData, then the packet will fail this data match.
- (3) If for every relevant bit from the packet with the corresponding filterPktDataNotMask bit set to one, the bit from the packet is equal to the corresponding bit from the filterPktData, then the packet will fail this data match.

Any packets that have not failed any of the three matches above have passed this data match.

This object may not be modified if the associated filterStatus object is equal to valid(1)."

::= { filterEntry 4 }

filterPktDataMask OBJECT-TYPE SYNTAX OCTET STRING ACCESS read-write STATUS mandatory DESCRIPTION

"The mask that is applied to the match process. After adjusting this mask for the offset, only those bits in the received packet that correspond to bits set in this mask are relevant for further processing by the match algorithm. The offset is applied to filterPktDataMask in the same way it is applied to the filter. For the purposes of the matching algorithm, if the associated filterPktData object is longer than this mask, this mask is conceptually extended with '1' bits until it reaches the length of the filterPktData object.

This object may not be modified if the associated
 filterStatus object is equal to valid(1)."
::= { filterEntry 5 }

filterPktDataNotMask OBJECT-TYPE

SYNTAX OCTET STRING
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The inversion mask that is applied to the match process. After adjusting this mask for the offset, those relevant bits in the received packet that correspond to bits cleared in this mask must all be equal to their corresponding bits in the filterPktData object for the packet to be accepted. In addition, at least one of those relevant bits in the received packet that correspond to bits set in this mask must be different to its corresponding bit in the filterPktData object.

For the purposes of the matching algorithm, if the associated filterPktData object is longer than this mask, this mask is conceptually extended with '0' bits until it reaches the length of the filterPktData object.

This object may not be modified if the associated
 filterStatus object is equal to valid(1)."
::= { filterEntry 6 }

filterPktStatus OBJECT-TYPE

SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The status that is to be matched with the input packet. The only bits relevant to this match algorithm are those that have the corresponding filterPktStatusMask bit equal to one.

The following two rules are then applied to every packet:

(1) For each relevant bit from the packet status with the corresponding filterPktStatusNotMask bit set to zero, if the bit from the packet status is not equal to the corresponding bit from the filterPktStatus, then the packet will fail this status match.

(2) If for every relevant bit from the packet status with the corresponding filterPktStatusNotMask bit set to one, the bit from the packet status is equal to the corresponding bit from the filterPktStatus, then the packet will fail this status match.

Any packets that have not failed either of the two matches above have passed this status match.

The value of the packet status is a sum. This sum initially takes the value zero. Then, for each error, E, that has been discovered in this packet, 2 raised to a value representing E is added to the sum. The errors and the bits that represent them are dependent on the media type of the interface that this channel is receiving packets from.

The errors defined for a packet captured off of an Ethernet interface are as follows:

- bit # Error
  - O Packet is longer than 1518 octets
  - 1 Packet is shorter than 64 octets
  - 2 Packet experienced a CRC or Alignment error

For example, an Ethernet fragment would have a value of 6  $(2^1 + 2^2)$ .

As this MIB is expanded to new media types, this object will have other media-specific errors defined.

For the purposes of this status matching algorithm, if the packet status is longer than this object, filterPktStatus this object is conceptually extended with '0' bits until it reaches the size of the packet status.

This object may not be modified if the associated
filterStatus object is equal to valid(1)."
::= { filterEntry 7 }

filterPktStatusMask OBJECT-TYPE SYNTAX INTEGER ACCESS read-write STATUS mandatory DESCRIPTION

"The mask that is applied to the status match process. Only those bits in the received packet that correspond to bits set in this mask are relevant for further processing by the status match algorithm. For the purposes of the matching algorithm, if the associated filterPktStatus object is longer than this mask, this mask is conceptually extended with '1' bits until it reaches the size of the filterPktStatus. In addition, if a packet status is longer than this mask, this mask is conceptually extended with '0' bits until it reaches the size of the packet status.

This object may not be modified if the associated filterStatus object is equal to valid(1)."

::= { filterEntry 8 }

filterPktStatusNotMask OBJECT-TYPE
SYNTAX INTEGER
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The inversion mask that is applied to the status match process. Those relevant bits in the received packet status that correspond to bits cleared in this mask must all be equal to their corresponding bits in the filterPktStatus object for the packet to be accepted. In addition, at least one of those relevant bits in the received packet status that correspond to bits set in this mask must be different to its corresponding bit in the filterPktStatus object for the packet to be accepted.

For the purposes of the matching algorithm, if the associated filterPktStatus object or a packet status is longer than this mask, this mask is conceptually extended with '0' bits until it reaches the longer of the lengths of the filterPktStatus object and the packet status.

This object may not be modified if the associated
 filterStatus object is equal to valid(1)."
::= { filterEntry 9 }

filterOwner OBJECT-TYPE SYNTAX OwnerString

```
ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The entity that configured this entry and is
        therefore using the resources assigned to it."
    ::= { filterEntry 10 }
filterStatus OBJECT-TYPE
    SYNTAX EntryStatus
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The status of this filter entry."
    ::= { filterEntry 11 }
channelTable OBJECT-TYPE
    SYNTAX SEQUENCE OF ChannelEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of packet channel entries."
    ::= { filter 2 }
channelEntry OBJECT-TYPE
    SYNTAX ChannelEntry
    ACCESS not-accessible
    STATUS mandatory
   DESCRIPTION
        "A set of parameters for a packet channel applied on a
        particular interface."
    INDEX { channelIndex }
    ::= { channelTable 1 }
ChannelEntry ::= SEQUENCE {
   channelIndex
                                 INTEGER (1..65535),
   channelIfIndex
                                INTEGER (1..65535),
   channelAcceptType
                                INTEGER,
    channelDataControl
                                INTEGER,
   channelTurnOnEventIndex INTEGER (0..65535), channelTurnOffEventIndex INTEGER (0..65535),
    channelEventIndex
                                 INTEGER (0..65535),
    channelEventStatus
                                 INTEGER,
    channelMatches
                                 Counter,
   channelDescription
                                DisplayString (SIZE (0..127)),
   channelOwner
                                OwnerString,
   channelStatus
                                INTEGER
}
```

```
channelIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "An index that uniquely identifies an entry
        in the channel table. Each such
       entry defines one channel, a logical data
       and event stream."
    ::= { channelEntry 1 }
channelIfIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The value of this object uniquely identifies the
       interface on this remote network monitoring device
       to which the associated filters are applied to allow
       data into this channel. The interface identified by
       a particular value of this object is the same
       interface as identified by the same value of the
       ifIndex object, defined in [4,6]. The filters in
       this group are applied to all packets on the local
       network segment attached to the identified
       interface.
       This object may not be modified if the associated
        channelStatus object is equal to valid(1)."
    ::= { channelEntry 2 }
channelAcceptType OBJECT-TYPE
   SYNTAX INTEGER {
       acceptMatched(1),
       acceptFailed(2)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "This object controls the action of the filters
        associated with this channel. If this object is equal
       to acceptMatched(1), packets will be accepted to this
       channel if they are accepted by both the packet data
       and packet status matches of an associated filter. If
       this object is equal to acceptFailed(2), packets will
       be accepted to this channel only if they fail either
       the packet data match or the packet status match of
        each of the associated filters.
```

```
This object may not be modified if the associated
       channelStatus object is equal to valid(1)."
    ::= { channelEntry 3 }
channelDataControl OBJECT-TYPE
   SYNTAX INTEGER {
       on(1),
       off(2)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "This object controls the flow of data through this
       channel. If this object is on(1), data, status and
       events flow through this channel. If this object is
       off(2), data, status and events will not flow through
       this channel."
   DEFVAL { off }
    ::= { channelEntry 4 }
channelTurnOnEventIndex OBJECT-TYPE
   SYNTAX INTEGER (0..65535)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The value of this object identifies the event
       that is configured to turn the associated
       channelDataControl from off to on when the event is
       generated. The event identified by a particular value
       of this object is the same event as identified by the
       same value of the eventIndex object. If there is no
       corresponding entry in the eventTable, then no
       association exists. In fact, if no event is intended
       for this channel, channelTurnOnEventIndex must be
       set to zero, a non-existent event index.
       This object may not be modified if the associated
       channelStatus object is equal to valid(1)."
    ::= { channelEntry 5 }
channelTurnOffEventIndex OBJECT-TYPE
   SYNTAX INTEGER (0..65535)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The value of this object identifies the event
       that is configured to turn the associated
       channelDataControl from on to off when the event is
```

generated. The event identified by a particular value of this object is the same event as identified by the same value of the eventIndex object. If there is no corresponding entry in the eventTable, then no association exists. In fact, if no event is intended for this channel, channelTurnOffEventIndex must be set to zero, a non-existent event index.

This object may not be modified if the associated
 channelStatus object is equal to valid(1)."
::= { channelEntry 6 }

channelEventIndex OBJECT-TYPE
SYNTAX INTEGER (0..65535)
ACCESS read-write
STATUS mandatory
DESCRIPTION

"The value of this object identifies the event that is configured to be generated when the associated channelDataControl is on and a packet is matched. The event identified by a particular value of this object is the same event as identified by the same value of the eventIndex object. If there is no corresponding entry in the eventTable, then no association exists. In fact, if no event is intended for this channel, channelEventIndex must be set to zero, a non-existent event index.

This object may not be modified if the associated
 channelStatus object is equal to valid(1)."
::= { channelEntry 7 }

```
channelEventStatus OBJECT-TYPE
    SYNTAX INTEGER {
        eventReady(1),
        eventFired(2),
        eventAlwaysReady(3)
    }
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
```

"The event status of this channel.

If this channel is configured to generate events when packets are matched, a means of controlling the flow of those events is often needed. When this object is equal to eventReady(1), a single event may be generated, after which this object

```
will be set by the probe to eventFired(2). While
       in the eventFired(2) state, no events will be
       generated until the object is modified to
       eventReady(1) (or eventAlwaysReady(3)). The
       management station can thus easily respond to a
       notification of an event by re-enabling this object.
        If the management station wishes to disable this
       flow control and allow events to be generated
       at will, this object may be set to
       eventAlwaysReady(3). Disabling the flow control
       is discouraged as it can result in high network
       traffic or other performance problems."
   DEFVAL { eventReady }
    ::= { channelEntry 8 }
channelMatches OBJECT-TYPE
   SYNTAX Counter
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of times this channel has matched a packet.
       Note that this object is updated even when
       channelDataControl is set to off."
    ::= { channelEntry 9 }
channelDescription OBJECT-TYPE
   SYNTAX DisplayString (SIZE (0..127))
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "A comment describing this channel."
    ::= { channelEntry 10 }
channelOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The entity that configured this entry and is therefore
       using the resources assigned to it."
    ::= { channelEntry 11 }
channelStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
```

```
"The status of this channel entry."
    ::= { channelEntry 12 }
-- The Packet Capture Group
-- Implementation of the Packet Capture group is optional.
-- The Packet Capture Group requires implementation of the
-- Filter Group.
___
-- The Packet Capture group allows packets to be captured
-- upon a filter match. The bufferControlTable controls
-- the captured packets output from a channel that is
-- associated with it. The captured packets are placed
-- in entries in the captureBufferTable. These entries are
-- associated with the bufferControlEntry on whose behalf they
-- were stored.
bufferControlTable OBJECT-TYPE
    SYNTAX SEQUENCE OF BufferControlEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of buffers control entries."
    ::= { capture 1 }
bufferControlEntry OBJECT-TYPE
   SYNTAX BufferControlEntry
   ACCESS not-accessible
   STATUS mandatory
    DESCRIPTION
        "A set of parameters that control the collection of
        a stream of packets that have matched filters."
    INDEX { bufferControlIndex }
    ::= { bufferControlTable 1 }
BufferControlEntry ::= SEQUENCE {
    bufferControlIndex
                                     INTEGER (1..65535),
    bufferControlChannelIndex
                                     INTEGER (1..65535),
                                     INTEGER,
    bufferControlFullStatus
    bufferControlFullAction
                                      INTEGER,
    bufferControlCaptureSliceSize INTEGER,
    {\tt bufferControlDownloadSliceSize} \qquad {\tt INTEGER}\,,
    bufferControlDownloadOffset
                                     INTEGER,
    bufferControlMaxOctetsRequested INTEGER,
    bufferControlMaxOctetsGranted
                                     INTEGER,
    bufferControlCapturedPackets
                                     INTEGER,
```

```
bufferControlTurnOnTime
bufferControlOwner
                                     TimeTicks,
                                    OwnerString,
   bufferControlStatus
                                      INTEGER
}
bufferControlIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry
        in the bufferControl table. The value of this
        index shall never be zero. Each such
        entry defines one set of packets that is
        captured and controlled by one or more filters."
    ::= { bufferControlEntry 1 }
bufferControlChannelIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "An index that identifies the channel that is the
        source of packets for this bufferControl table.
        The channel identified by a particular value of this
        index is the same as identified by the same value of
        the channelIndex object.
        This object may not be modified if the associated
        bufferControlStatus object is equal to valid(1)."
    ::= { bufferControlEntry 2 }
bufferControlFullStatus OBJECT-TYPE
    SYNTAX INTEGER {
            spaceAvailable(1),
           full(2)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "This object shows whether the buffer has room to
        accept new packets or if it is full.
        If the status is spaceAvailable(1), the buffer is
        accepting new packets normally. If the status is
        full(2) and the associated bufferControlFullAction
        object is wrapWhenFull, the buffer is accepting new
        packets by deleting enough of the oldest packets
```

```
to make room for new ones as they arrive. Otherwise,
        if the status is full(2) and the
        bufferControlFullAction object is lockWhenFull,
        then the buffer has stopped collecting packets.
        When this object is set to full(2) the probe must
        not later set it to spaceAvailable(1) except in the
        case of a significant gain in resources such as
        an increase of bufferControlOctetsGranted. In
        particular, the wrap-mode action of deleting old
        packets to make room for newly arrived packets
        must not affect the value of this object."
    ::= { bufferControlEntry 3 }
bufferControlFullAction OBJECT-TYPE
    SYNTAX INTEGER {
           lockWhenFull(1),
           wrapWhenFull(2)
                             -- FIFO
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "Controls the action of the buffer when it
        reaches the full status. When in the lockWhenFull(1)
        state a packet is added to the buffer that
        fills the buffer, the bufferControlFullStatus will
        be set to full(2) and this buffer will stop capturing
        packets."
    ::= { bufferControlEntry 4 }
bufferControlCaptureSliceSize OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The maximum number of octets of each packet
        that will be saved in this capture buffer.
        For example, if a 1500 octet packet is received by
        the probe and this object is set to 500, then only
        500 octets of the packet will be stored in the
        associated capture buffer. If this variable is set
        to 0, the capture buffer will save as many octets
        as is possible.
        This object may not be modified if the associated
        bufferControlStatus object is equal to valid(1)."
    DEFVAL { 100 }
    ::= { bufferControlEntry 5 }
```

```
bufferControlDownloadSliceSize OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The maximum number of octets of each packet
        in this capture buffer that will be returned in
        an SNMP retrieval of that packet. For example,
        if 500 octets of a packet have been stored in the
        associated capture buffer, the associated
        bufferControlDownloadOffset is 0, and this
        object is set to 100, then the captureBufferPacket
        object that contains the packet will contain only
        the first 100 octets of the packet.
        A prudent manager will take into account possible
        interoperability or fragmentation problems that may
        occur if the download slice size is set too large.
        In particular, conformant SNMP implementations are not
        required to accept messages whose length exceeds 484
        octets, although they are encouraged to support larger
        datagrams whenever feasible."
    DEFVAL { 100 }
    ::= { bufferControlEntry 6 }
bufferControlDownloadOffset OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The offset of the first octet of each packet
        in this capture buffer that will be returned in
        an SNMP retrieval of that packet. For example,
        if 500 octets of a packet have been stored in the
        associated capture buffer and this object is set to
        100, then the captureBufferPacket object that
        contains the packet will contain bytes starting
        100 octets into the packet."
    DEFVAL { 0 }
    ::= { bufferControlEntry 7 }
bufferControlMaxOctetsRequested OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-write
    STATUS mandatory
    DESCRIPTION
```

"The requested maximum number of octets to be saved in this captureBuffer, including any

implementation-specific overhead. If this variable is set to -1, the capture buffer will save as many octets as is possible.

When this object is created or modified, the probe should set bufferControlMaxOctetsGranted as closely to this object as is possible for the particular probe implementation and available resources. However, if the object has the special value of -1, the probe must set bufferControlMaxOctetsGranted to -1."

DEFVAL { -1 }
::= { bufferControlEntry 8 }

bufferControlMaxOctetsGranted OBJECT-TYPE

SYNTAX INTEGER
ACCESS read-only
STATUS mandatory
DESCRIPTION

"The maximum number of octets that can be saved in this captureBuffer, including overhead. If this variable is -1, the capture buffer will save as many octets as possible.

When the bufferControlMaxOctetsRequested object is created or modified, the probe should set this object as closely to the requested value as is possible for the particular probe implementation and available resources. However, if the request object has the special value of -1, the probe must set this object to -1. The probe must not lower this value except as a result of a modification to the associated bufferControlMaxOctetsRequested object.

When this maximum number of octets is reached and a new packet is to be added to this capture buffer and the corresponding bufferControlFullAction is set to wrapWhenFull(2), enough of the oldest packets associated with this capture buffer shall be deleted by the agent so that the new packet can be added. If the corresponding bufferControlFullAction is set to lockWhenFull(1), the new packet shall be discarded. In either case, the probe must set bufferControlFullStatus to full(2).

When the value of this object changes to a value less than the current value, entries are deleted from the captureBufferTable associated with this

```
bufferControlEntry. Enough of the
        oldest of these captureBufferEntries shall be
        deleted by the agent so that the number of octets
        used remains less than or equal to the new value of
        this object.
        When the value of this object changes to a value greater
        than the current value, the number of associated
        captureBufferEntries may be allowed to grow."
    ::= { bufferControlEntry 9 }
bufferControlCapturedPackets OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The number of packets currently in this captureBuffer."
    ::= { bufferControlEntry 10 }
bufferControlTurnOnTime OBJECT-TYPE
    SYNTAX TimeTicks
   ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "The value of sysUpTime when this capture buffer was
        first turned on."
    ::= { bufferControlEntry 11 }
bufferControlOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
    STATUS mandatory
    DESCRIPTION
        "The entity that configured this entry and is therefore
       using the resources assigned to it."
    ::= { bufferControlEntry 12 }
bufferControlStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
   STATUS mandatory
    DESCRIPTION
        "The status of this buffer Control Entry."
    ::= { bufferControlEntry 13 }
captureBufferTable OBJECT-TYPE
    SYNTAX SEQUENCE OF CaptureBufferEntry
    ACCESS not-accessible
```

```
STATUS mandatory
   DESCRIPTION
        "A list of packets captured off of a channel."
    ::= { capture 2 }
captureBufferEntry OBJECT-TYPE
   SYNTAX CaptureBufferEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "A packet captured off of an attached network."
   INDEX { captureBufferControlIndex, captureBufferIndex }
    ::= { captureBufferTable 1 }
CaptureBufferEntry ::= SEQUENCE {
   {\tt captureBufferControlIndex} \qquad {\tt INTEGER} \ ({\tt 1..65535}) \,,
   captureBufferIndex INTEGER,
   captureBufferPacketID
                               INTEGER,
   captureBufferPacketID INTEGER,
captureBufferPacketData OCTET STRING,
   captureBufferPacketLength INTEGER,
   captureBufferPacketTime INTEGER,
   }
captureBufferControlIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The index of the bufferControlEntry with which
       this packet is associated."
    ::= { captureBufferEntry 1 }
captureBufferIndex OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "An index that uniquely identifies an entry
        in the captureBuffer table associated with a
       particular bufferControlEntry. This index will
       start at 1 and increase by one for each new packet
       added with the same captureBufferControlIndex."
    ::= { captureBufferEntry 2 }
captureBufferPacketID OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
```

```
STATUS mandatory
   DESCRIPTION
        "An index that describes the order of packets
       that are received on a particular interface.
       The packetID of a packet captured on an
       interface is defined to be greater than the
       packetID's of all packets captured previously on
       the same interface. As the captureBufferPacketID
       object has a maximum positive value of 2^31 - 1,
       any captureBufferPacketID object shall have the
       value of the associated packet's packetID mod 2^31."
    ::= { captureBufferEntry 3 }
captureBufferPacketData OBJECT-TYPE
   SYNTAX OCTET STRING
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The data inside the packet, starting at the beginning
       of the packet plus any offset specified in the
       associated bufferControlDownloadOffset, including any
       link level headers. The length of the data in this
       object is the minimum of the length of the captured
       packet minus the offset, the length of the associated
       bufferControlCaptureSliceSize minus the offset, and the
       associated bufferControlDownloadSliceSize. If this
       minimum is less than zero, this object shall have a
       length of zero."
    ::= { captureBufferEntry 4 }
captureBufferPacketLength OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The actual length (off the wire) of the packet stored
       in this entry, including FCS octets."
    ::= { captureBufferEntry 5 }
captureBufferPacketTime OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The number of milliseconds that had passed since
       this capture buffer was first turned on when this
       packet was captured."
    ::= { captureBufferEntry 6 }
```

captureBufferPacketStatus OBJECT-TYPE
SYNTAX INTEGER
ACCESS read-only
STATUS mandatory
DESCRIPTION

"A value which indicates the error status of this packet.

The value of this object is defined in the same way as filterPacketStatus. The value is a sum. This sum initially takes the value zero. Then, for each error, E, that has been discovered in this packet, 2 raised to a value representing E is added to the sum.

The errors defined for a packet captured off of an Ethernet interface are as follows:

- bit # Error
  - O Packet is longer than 1518 octets
  - 1 Packet is shorter than 64 octets
  - 2 Packet experienced a CRC or Alignment error
  - 3 First packet in this capture buffer after it was detected that some packets were not processed correctly.

For example, an Ethernet fragment would have a value of 6  $(2^1 + 2^2)$ .

As this MIB is expanded to new media types, this object will have other media-specific errors defined."

::= { captureBufferEntry 7 }

- -- The Event Group
- -- Implementation of the Event group is optional.
- --
- -- The Event group controls the generation and notification
- -- of events from this device. Each entry in the eventTable
- -- describes the parameters of the event that can be triggered.
- -- Each event entry is fired by an associated condition located
- -- elsewhere in the MIB. An event entry may also be associated
- -- with a function elsewhere in the MIB that will be executed
- -- when the event is generated. For example, a channel may
- -- be turned on or off by the firing of an event.
- \_\_
- -- Each eventEntry may optionally specify that a log entry

```
-- be created on its behalf whenever the event occurs.
-- Each entry may also specify that notification should
-- occur by way of SNMP trap messages. In this case, the
-- community for the trap message is given in the associated
-- eventCommunity object. The enterprise and specific trap
-- fields of the trap are determined by the condition that
-- triggered the event. Three traps are defined in a companion
-- document: risingAlarm, fallingAlarm, and packetMatch.
-- If the eventTable is triggered by a condition specified
-- elsewhere, the enterprise and specific trap fields
-- must be specified for traps generated for that condition.
eventTable OBJECT-TYPE
   SYNTAX SEQUENCE OF EventEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A list of events to be generated."
    ::= { event 1 }
eventEntry OBJECT-TYPE
    SYNTAX EventEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "A set of parameters that describe an event to be
        generated when certain conditions are met."
    INDEX { eventIndex }
    ::= { eventTable 1 }
EventEntry ::= SEQUENCE {
    eventIndex INTEGER (1..65535),
     \begin{array}{lll} \mbox{eventDescription} & \mbox{DisplayString (SIZE (0..127)),} \\ \mbox{eventType} & \mbox{INTEGER,} \\ \end{array} 
    eventCommunity OCTET STRING (SIZE (0..127)),
    eventLastTimeSent TimeTicks,
    eventOwner OwnerString,
    eventStatus
                        INTEGER
}
eventIndex OBJECT-TYPE
    SYNTAX INTEGER (1..65535)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An index that uniquely identifies an entry in the
        event table. Each such entry defines one event that
        is to be generated when the appropriate conditions
```

```
occur."
    ::= { eventEntry 1 }
eventDescription OBJECT-TYPE
   SYNTAX DisplayString (SIZE (0..127))
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "A comment describing this event entry."
    ::= { eventEntry 2 }
eventType OBJECT-TYPE
   SYNTAX INTEGER {
           none(1),
           log(2),
                            -- send an SNMP trap
            snmp-trap(3),
           log-and-trap(4)
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The type of notification that the probe will make
       about this event. In the case of log, an entry is
       made in the log table for each event. In the case of
       snmp-trap, an SNMP trap is sent to one or more
       management stations."
    ::= { eventEntry 3 }
eventCommunity OBJECT-TYPE
   SYNTAX OCTET STRING (SIZE (0..127))
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "If an SNMP trap is to be sent, it will be sent to
       the SNMP community specified by this octet string.
       In the future this table will be extended to include
       the party security mechanism. This object shall be
       set to a string of length zero if it is intended that
       that mechanism be used to specify the destination of
       the trap."
    ::= { eventEntry 4 }
eventLastTimeSent OBJECT-TYPE
   SYNTAX TimeTicks
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The value of sysUpTime at the time this event
```

```
entry last generated an event. If this entry has
       not generated any events, this value will be
       zero."
    ::= { eventEntry 5 }
eventOwner OBJECT-TYPE
   SYNTAX OwnerString
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The entity that configured this entry and is therefore
       using the resources assigned to it.
       If this object contains a string starting with 'monitor'
       and has associated entries in the log table, all
       connected management stations should retrieve those
       log entries, as they may have significance to all
       management stations connected to this device"
    ::= { eventEntry 6 }
eventStatus OBJECT-TYPE
   SYNTAX EntryStatus
   ACCESS read-write
   STATUS mandatory
   DESCRIPTION
        "The status of this event entry.
       If this object is not equal to valid(1), all associated
       log entries shall be deleted by the agent."
    ::= { eventEntry 7 }
logTable OBJECT-TYPE
   SYNTAX SEQUENCE OF LogEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "A list of events that have been logged."
    ::= { event 2 }
logEntry OBJECT-TYPE
   SYNTAX LogEntry
   ACCESS not-accessible
   STATUS mandatory
   DESCRIPTION
        "A set of data describing an event that has been
       logged."
    INDEX { logEventIndex, logIndex }
```

```
::= { logTable 1 }
LogEntry ::= SEQUENCE {
   logEventIndex
                           INTEGER (1..65535),
   logIndex
                           INTEGER,
   logTime
                           TimeTicks,
   logDescription
                           DisplayString (SIZE (0..255))
}
logEventIndex OBJECT-TYPE
   SYNTAX INTEGER (1..65535)
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The event entry that generated this log
       entry. The log identified by a particular
       value of this index is associated with the same
       eventEntry as identified by the same value
       of eventIndex."
    ::= { logEntry 1 }
logIndex OBJECT-TYPE
   SYNTAX INTEGER
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "An index that uniquely identifies an entry
       in the log table amongst those generated by the
       same eventEntries. These indexes are
       assigned beginning with 1 and increase by one
       with each new log entry. The association
       between values of logIndex and logEntries
        is fixed for the lifetime of each logEntry.
       The agent may choose to delete the oldest
       instances of logEntry as required because of
       lack of memory. It is an implementation-specific
       matter as to when this deletion may occur."
    ::= { logEntry 2 }
logTime OBJECT-TYPE
   SYNTAX TimeTicks
   ACCESS read-only
   STATUS mandatory
   DESCRIPTION
        "The value of sysUpTime when this log entry was
       created."
    ::= { logEntry 3 }
```

```
logDescription OBJECT-TYPE
    SYNTAX DisplayString (SIZE (0..255))
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "An implementation dependent description of the
        event that activated this log entry."
    ::= { logEntry 4 }
```

END

## 7. Acknowledgments

This document was produced by the IETF Remote Network Monitoring Working Group.

In addition, the comments of the following individuals are also acknowledged:

Anne Ambler Spider Systems Steve Bostock Novell Hewlett-Packard Gigi Chu Chuck Davin MIT Hewlett-Packard Gary Ellis Mike Erlinger Lexcel Stephen Grau Novell Martin Gray Spider Systems Mark Hoerth Hewlett-Packard Tim Lee-Thorp Network General Frontier Software Anil Singhal

David Stevens Concord Communications Gerard White

## 8. References

[1] Cerf, V., "IAB Recommendations for the Development of Internet Network Management Standards", RFC 1052, NRI, April 1988.

Network General

- [2] Cerf, V., "Report of the Second Ad Hoc Network Management Review Group", RFC 1109, NRI, August 1989.
- [3] Rose M., and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based internets", RFC 1155, Performance Systems International, Hughes LAN Systems, May 1990.
- [4] McCloghrie K., and M. Rose, "Management Information Base for Network Management of TCP/IP-based internets", RFC 1156, Hughes LAN Systems, Performance Systems International, May 1990.

- [5] Case, J., Fedor, M., Schoffstall, M., and J. Davin, "Simple Network Management Protocol", RFC 1157, SNMP Research, Performance Systems International, Performance Systems International, MIT Laboratory for Computer Science, May 1990.
- [6] McCloghrie K., and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets", RFC 1213, Performance Systems International, March 1991.
- [7] Information processing systems Open Systems Interconnection Specification of Abstract Syntax Notation One (ASN.1), International Organization for Standardization, International Standard 8824, December 1987.
- [8] Information processing systems Open Systems Interconnection -Specification of Basic Encoding Rules for Abstract Notation One (ASN.1), International Organization for Standardization, International Standard 8825, December 1987.
- [9] Rose, M., and K. McCloghrie, Editors, "Concise MIB Definitions", RFC 1212, Performance Systems International, Hughes LAN Systems, March 1991.
- [10] Rose, M., Editor, "A Convention for Defining Traps for use with the SNMP", RFC 1215, Performance Systems International, March 1991.

Security Considerations

Security issues are not discussed in this memo.

Author's Address

Steven Waldbusser Carnegie Mellon University 4910 Forbes Ave. Pittsburgh, PA 15213

Phone: (412) 268-6628

EMail: waldbusser@andrew.cmu.edu