Network Working Group K. S. Teow Request for Comments: 2837 Brocade Communications Systems, Inc. Category: Standards Track May 2000

Definitions of Managed Objects for the Fabric Element in Fibre Channel Standard

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2000). All Rights Reserved.

Abstract

This memo defines an extension to the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it defines the objects for managing the operations of the Fabric Element portion of the Fibre Channel Standards.

Table of Contents

1. The SNMP Management Framework	2
2. Overview	
2.1 Management View of a Fabric Element	4
2.2 Structure of the Fabric Element MIB	
3. Object Definitions	
The Configuration Group	8
The Module Table	9
The FxPort Configuration Table	12
The Status Group	16
The FxPort Status Table	16
The FxPort Physical Level Table	18
The FxPort Fabric Login Table	20
The Error Group	24
The Accounting Groups	27
The Class 1 Accounting Table	27
The Class 2 Accounting Table	31
The Class 3 Accounting Table	33
The Capability Group	35

Teow Standards Track [Page 1]

Conformance information	38
4. Security Considerations4	13
5. Intellectual Property4	14
6. Acknowledgements	14
7. References	15
7.1 IETF References	15
7.2 Approved ANSI/NCITS References	16
7.3 ANSI/NCITS References Under Development	17
8. Editors' Addresses	17
9. Full Copyright Statement	18

1. The SNMP Management Framework

The SNMP Management Framework presently consists of five major components:

- o An overall architecture, described in RFC 2571 [1].
- o Mechanisms for describing and naming objects and events for the purpose of management. The first version of this Structure of Management Information (SMI) is called SMIv1 and described in STD 16, RFC 1155 [2], STD 16, RFC 1212 [3] and RFC 1215 [4]. The second version, called SMIv2, is described in STD 58, RFC 2578 [5], STD 58, RFC 2579 [6] and STD 58, RFC 2580 [7].
- o Message protocols for transferring management information. The first version of the SNMP message protocol is called SNMPv1 and described in STD 15, RFC 1157 [8]. A second version of the SNMP message protocol, which is not an Internet standards track protocol, is called SNMPv2c and described in RFC 1901 [9] and RFC 1906 [10]. The third version of the message protocol is called SNMPv3 and described in RFC 1906 [10], RFC 2572 [11] and RFC 2574 [12].
- o Protocol operations for accessing management information. The first set of protocol operations and associated PDU formats is described in STD 15, RFC 1157 [8]. A second set of protocol operations and associated PDU formats is described in RFC 1905 [13].
- o A set of fundamental applications described in RFC 2573 [14] and the view-based access control mechanism described in RFC 2575 [15].

A more detailed introduction to the current SNMP Management Framework can be found in RFC 2570 [16].

Teow Standards Track [Page 2]

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the mechanisms defined in the SMI.

This memo specifies a MIB module that is compliant to the SMIv2. A MIB conforming to the SMIv1 can be produced through the appropriate translations. The resulting translated MIB must be semantically equivalent, except where objects or events are omitted because no translation is possible (use of Counter64). Some machine readable information in SMIv2 will be converted into textual descriptions in SMIv1 during the translation process. However, this loss of machine readable information is not considered to change the semantics of the MIB.

Overview

A Fibre Channel Fabric is an entity which interconnects Node Ports (N_Ports) or Node Loop Ports (NL_Ports). It provides transport and routing functions. In essence, a Fabric is a network of N_Ports and/or NL_Ports to communicate with one another. A Fabric is composed of one or more Fabric Element that are interconnected via Inter-element Links (IEL). A Fabric Element is the smallest unit of a Fabric that meets the definition of a Fabric. It must consist of at least three external ports to connect to either N_Ports, NL_Ports or other Fabric Elements. In general, a Fabric Element port may be of one of the following types:

- (1) F_Port, a fabric port to connect to an N_Port ([17], [21], [22]);
- (2) FL_Port, a fabric port that also supports a FC Arbitrated Loop consisting of one or more NL_Ports ([20], [24]).
- (3) E_Port, an expansion port to connect to another Fabric Element ([18], [23]);

This memo shall define objects related to a Fabric Element, its F_Ports and FL_Ports. Objects related to other types of FC ports shall be defined in future.

For the rest of the document, the term, "FxPort", will be used to refer to both F_Port and FL_Port where the distinction is not necessary. The term, "NxPort" will be used to refer to both N_Port and NL_Port in the similar fashion.

2.1. Management View of a Fabric Element

From the management perspective, it is helpful to view a Fabric Element to be consisting of multiple "modules". Each module is a grouping, either physical or logical, of one or more ports that may be managed as a sub-entity within the Fabric Element.

This module mapping is recommended but optional. A vendor may elect to put all ports into a single module, or to divide the ports into modules that do not match physical divisions.

The object fcFeModuleCapacity indicates the maximum number of modules that a given Fabric Element may contain. This value must remain constant from one management restart to the next.

Each module is uniquely identified by a module number in the range of 1 through fcFeModuleCapacity inclusive. Modules may come and go without causing a management reset (of sysUpTime), and may be sparsely numbered within the Fabric Element. That is, the module numbering is not required to be contiguous. For instance, if a module is mapped physically to a field-replaceable card and in a 13-card cage Fabric Element, cards 3, 5, 6 and 7 may be installed. The vendor may choose to label them as modules 3, 5, 6 and 7 respectively. In this example, the value of fcFeModuleCapacity is 13. Note that the object fcFeModuleLastChange acts as the discontinuity indicator for all counter objects in this MIB.

A Fabric Element may also provide a proxy management on behalf of another management entity by presenting it as one of its Fabric Element modules.

The object fcFeModuleFxPortCapacity indicates the maximum number of ports that a given module may contain. The value of fcFeModuleFxPortCapacity must not change for a given module. However, a module may be deleted from the Fabric Element and replaced with a module containing a different number of ports. The value of fcFeModuleLastChange will indicate that a change took place.

Each port within the Fabric Element is uniquely identified by a combination of module index and port index, where port index is an integer in the range (1..fcFeModuleFxPortCapacity). As with modules within a Fabric Element, ports within a module may be sparsely numbered. That is the port numbering is not required to be contiguous. Likewise, ports may come and go within a module without causing a management reset.

In terms of attachment, an F_Port will be attached to another N_Port; and an FL_Port will be attached to one or up to 126 NL_Ports. In general, an FxPort may be attached to one or more NxPorts. Each NxPort associated with an FxPort will be uniquely identified by a combination of module index, FxPort index and NxPort index. An NxPort index is an integer in the range (1..126). The following diagram illustrates the management view of a Fabric Element.

where "i", "n", "M" and "L" are some arbitrary sample integer values, and "L" must be less than 127.

2.2. Structure of the Fabric Element MIB

This memo assumes that a Fabric Element has an SNMP entity associated with its managed objects. The managed objects are divided as follow:

- the Configuration group
- the Status group
- the Error group
- the Accounting group
- the Capability group

In each group, scalar objects and table entries are defined.

The Configuration group contains configuration and service parameters for the Fabric Element, modules and the FxPorts.

The Operation group contains the operational status and parameters of an FxPort. The group also contains the service parameters that have been established between the FxPort and its attached NxPort, if applicable.

The Error group contains counters tracking various types of errors detected by each FxPort. The information may be used for diagnostics and/or to derive the quality of the link between an FxPort and one or more attached NxPorts.

The Accounting group contains statistic data suitable for deriving accounting and performance information.

The Capability group contains parameters indicating the inherent capability of the Fabric Element and each FxPort.

3. Object Definitions

```
FIBRE-CHANNEL-FE-MIB DEFINITIONS ::= BEGIN
  IMPORTS
   MODULE-IDENTITY, OBJECT-TYPE,
   Unsigned32, Counter32, Gauge32, Integer32, mib-2
     FROM SNMPv2-SMI
    TEXTUAL-CONVENTION, TruthValue, TimeStamp
     FROM SNMPv2-TC
   SnmpAdminString
     FROM SNMP-FRAMEWORK-MIB
                                                -- rfc2571
   MODULE-COMPLIANCE, OBJECT-GROUP
     FROM SNMPv2-CONF;
  fcFeMIB MODULE-IDENTITY
   LAST-UPDATED "200005180000Z"
    ORGANIZATION "IETF IPFC Working Group"
    CONTACT-INFO "Kha Sin Teow
                  Brocade Communications Systems,
                  1901 Guadalupe Parkway,
                  San Jose, CA 95131
                  U.S.A
                  Tel: +1 408 487 8180
                  Fax: +1 408 487 8190
                  Email: khasin@Brocade.COM
                 WG Mailing list:ipfc@standards.gadzoox.com
                 To Subscribe: ipfc-request@standards.gadzoox.com
                 In Body: subscribe"
   DESCRIPTION "The MIB module for Fibre Channel Fabric Element."
   REVISION "200005180000Z"
   DESCRIPTION "Initial revision, published as RFC 2837."
    ::= \{ mib-2 75 \}
  fcFeMIBObjects OBJECT IDENTIFIER ::= { fcFeMIB 1 }
   -- Note:
   -- fcFeMIBConformance OBJECT IDENTIFIER ::= { fcFeMIB 2 }
   -- see at the end of the module
  -- Groups under fcFeMIBObjects
```

```
fcFeConfig      OBJECT IDENTIFIER ::= { fcFeMIBObjects 1 }
fcFeStatus
               OBJECT IDENTIFIER ::= { fcFeMIBObjects 2 }
fcFeError
               OBJECT IDENTIFIER ::= { fcFeMIBObjects 3 }
fcFeAccounting OBJECT IDENTIFIER ::= { fcFeMIBObjects 4 }
fcFeCapabilities OBJECT IDENTIFIER ::= { fcFeMIBObjects 5 }
-- Textual Conventions
MilliSeconds ::= TEXTUAL-CONVENTION
               current
  STATUS
 DESCRIPTION
                "Represents time unit value in milliseconds."
 SYNTAX
               Unsigned32
MicroSeconds ::= TEXTUAL-CONVENTION
 STATUS
                current
                "Represents time unit value in microseconds."
 DESCRIPTION
               Unsigned32
  SYNTAX
FcNameId ::= TEXTUAL-CONVENTION
  STATUS
               current
  DESCRIPTION "Represents the Worldwide Name associated with
                 a Fibre Channel (FC) entity."
 SYNTAX
                OCTET STRING (SIZE (8))
FcAddressId ::= TEXTUAL-CONVENTION
                current
 DESCRIPTION
                "Represents Fibre Channel Address ID, a 24-bit
                 value unique within the address space of a Fabric."
                OCTET STRING (SIZE (3))
  SYNTAX
FcRxDataFieldSize ::= TEXTUAL-CONVENTION
 STATIIS
                current
                "Represents the receive data field size of an
 DESCRIPTION
                 NxPort or FxPort."
  SYNTAX
                Integer32 (128..2112)
FcBbCredit ::= TEXTUAL-CONVENTION
 STATUS
              current
 DESCRIPTION "Represents the buffer-to-buffer credit of an
                NxPort or FxPort."
               Integer32 (0..32767)
 SYNTAX
FcphVersion ::= TEXTUAL-CONVENTION
               current
  STATUS
 DESCRIPTION
                "Represents the version of FC-PH supported by an
                NxPort or FxPort."
               Integer32 (0..255)
 SYNTAX
FcStackedConnMode ::= TEXTUAL-CONVENTION
```

```
STATUS
                current
                "Represents an enumerated value used to indicate
  DESCRIPTION
                 the Class 1 Stacked Connect Mode supported by
                 an NxPort or FxPort."
  SYNTAX
                INTEGER {
                      none(1),
                      transparent(2),
                      lockedDown(3)
  }
FcCosCap ::= TEXTUAL-CONVENTION
                current
  DESCRIPTION
                 "Represents the class of service capability of an
                 NxPort or FxPort."
                 BITS { classF(0), class1(1), class2(2), class3(3),
  SYNTAX
                        class4(4), class5(5), class6(6) }
FcFeModuleCapacity ::= TEXTUAL-CONVENTION
  STATUS
                current
  DESCRIPTION
                "Represents the maximum number of modules within
                 a Fabric Element."
  SYNTAX
                 Unsigned32
FcFeFxPortCapacity ::= TEXTUAL-CONVENTION
                 current
                 "Represents the maximum number of FxPorts within
  DESCRIPTION
                 a module."
  SYNTAX
                 Unsigned32
FcFeModuleIndex ::= TEXTUAL-CONVENTION
  STATUS
                current
                 "Represents the module index within a conceptual table."
  DESCRIPTION
  SYNTAX
                Unsigned32
FcFeFxPortIndex ::= TEXTUAL-CONVENTION
  STATUS
               current
  DESCRIPTION
                "Represents the FxPort index within a conceptual table."
  SYNTAX
               Unsigned32
FcFeNxPortIndex ::= TEXTUAL-CONVENTION
  STATUS
                current
  DESCRIPTION
                "Represents the NxPort index within a conceptual table."
  SYNTAX
                Integer32 (1..126)
FcBbCreditModel ::= TEXTUAL-CONVENTION
                current
                 "Represents the BB Credit model of an FxPort."
  DESCRIPTION
                INTEGER { regular(1), alternate (2) }
  SYNTAX
```

```
-- The Configuration group
-- This group consists of scalar objects and tables.
-- It contains the configuration and service parameters
-- of the Fabric Element and the FxPorts.
-- The group represents a set of parameters associated with
-- the Fabric Element or an FxPort to support its NxPorts.
fcFeFabricName OBJECT-TYPE
   SYNTAX FcNameId
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The Name_Identifier of the Fabric to which this Fabric
       Element belongs."
::= { fcFeConfiq 1 }
fcFeElementName OBJECT-TYPE
   SYNTAX FcNameId
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The Name_Identifier of the Fabric Element."
::= { fcFeConfig 2 }
fcFeModuleCapacity OBJECT-TYPE
   SYNTAX FcFeModuleCapacity
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The maximum number of modules in the Fabric Element,
       regardless of their current state."
::= { fcFeConfig 3 }
-- The Module Table.
-- This table contains one entry for each module,
-- information of the modules.
fcFeModuleTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFeModuleEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains, one entry for each module in the
       Fabric Element, information of the modules."
::= { fcFeConfig 4 }
fcFeModuleEntry OBJECT-TYPE
```

```
SYNTAX
              FcFeModuleEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
       "An entry containing the configuration parameters of a
       module."
    INDEX { fcFeModuleIndex }
::= { fcFeModuleTable 1 }
FcFeModuleEntry ::=
    SEQUENCE {
        fcFeModuleIndex
           FcFeModuleIndex,
        fcFeModuleDescr
           SnmpAdminString,
        fcFeModuleObjectID
           OBJECT IDENTIFIER,
        fcFeModuleOperStatus
            INTEGER,
        fcFeModuleLastChange
           TimeStamp,
        fcFeModuleFxPortCapacity
            FcFeFxPortCapacity,
        fcFeModuleName
           FcNameId
    }
fcFeModuleIndex OBJECT-TYPE
    SYNTAX FcFeModuleIndex
    MAX-ACCESS not-accessible
    STATUS
               current
    DESCRIPTION
       "This object identifies the module within the Fabric Element
       for which this entry contains information. This value is
       never greater than fcFeModuleCapacity."
::= { fcFeModuleEntry 1 }
fcFeModuleDescr OBJECT-TYPE
    SYNTAX SnmpAdminString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
       "A textual description of the module. This value should
       include the full name and version identification of the
       module."
::= { fcFeModuleEntry 2 }
```

```
fcFeModuleObjectID OBJECT-TYPE
   SYNTAX OBJECT IDENTIFIER
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The vendor's authoritative identification of the module.
       This value may be allocated within the SMI enterprises
       subtree (1.3.6.1.4.1) and provides a straight-forward and
       unambiguous means for determining what kind of module is
       being managed.
       For example, this object could take the value
       1.3.6.1.4.1.99649.3.9 if vendor 'Neufe Inc.' was assigned
       the subtree 1.3.6.1.4.1.99649, and had assigned the
       identifier 1.3.6.1.4.1.99649.3.9 to its 'FeFiFo-16
       PlugInCard.'"
::= { fcFeModuleEntry 3 }
fcFeModuleOperStatus OBJECT-TYPE
   SYNTAX INTEGER {
                   online (1), -- functional
                   offline (2), -- not available
                   testing (3), -- under testing
                   faulty (4) -- defective
               }
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "This object indicates the operational status of the module:
       online(1) the module is functioning properly;
       offline(2) the module is not available;
       testing(3) the module is under testing; and
        faulty(4) the module is defective in some way."
::= { fcFeModuleEntry 4 }
fcFeModuleLastChange OBJECT-TYPE
   SYNTAX TimeStamp
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "This object contains the value of sysUpTime when the module
       entered its current operational status. A value of zero
       indicates that the operational status of the module has not
       changed since the agent last restarted."
::= { fcFeModuleEntry 5 }
fcFeModuleFxPortCapacity OBJECT-TYPE
            FcFeFxPortCapacity
   SYNTAX
```

```
MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of FxPort that can be contained within the
        module. Within each module, the ports are uniquely numbered
        in the range from 1 to fcFeModuleFxPortCapacity inclusive.
        However, the numbers are not required to be contiguous."
 ::= { fcFeModuleEntry 6 }
 fcFeModuleName OBJECT-TYPE
    SYNTAX FcNameId
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
       "The Name_Identifier of the module."
 ::= { fcFeModuleEntry 7 }
 -- the FxPort Configuration Table.
 -- This table contains, one entry for each FxPort,
 -- configuration parameters of the ports.
fcFxPortTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, configuration and service parameters of the
       FxPorts."
::= { fcFeConfig 5 }
fcFxPortEntry OBJECT-TYPE
   SYNTAX FcFxPortEntry
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
      "An entry containing the configuration and service parameters
       of a FxPort."
   INDEX { fcFeModuleIndex, fcFxPortIndex }
::= { fcFxPortTable 1 }
FcFxPortEntry ::=
   SEQUENCE {
       fcFxPortIndex
           FcFeFxPortIndex,
       fcFxPortName
           FcNameId,
```

```
-- FxPort common service parameters
      fcFxPortFcphVersionHigh
          FcphVersion,
      fcFxPortFcphVersionLow
          FcphVersion,
      fcFxPortBbCredit
          FcBbCredit,
       fcFxPortRxBufSize
          FcRxDataFieldSize,
      fcFxPortRatov
          MilliSeconds,
      fcFxPortEdtov
          MilliSeconds,
       -- FxPort class service parameters
      fcFxPortCosSupported
          FcCosCap,
      fcFxPortIntermixSupported
          TruthValue,
      fcFxPortStackedConnMode
          FcStackedConnMode,
      fcFxPortClass2SeqDeliv
          TruthValue,
      fcFxPortClass3SeqDeliv
          TruthValue,
       -- other configuration parameters
      fcFxPortHoldTime
          MicroSeconds
   }
fcFxPortIndex OBJECT-TYPE
   SYNTAX FcFeFxPortIndex
   MAX-ACCESS not-accessible
   STATUS
               current
   DESCRIPTION
       "This object identifies the FxPort within the module. This
       number ranges from 1 to the value of fcFeModulePortCapacity
       for the associated module. The value remains constant for
       the identified FxPort until the module is re-initialized."
::= { fcFxPortEntry 1 }
fcFxPortName OBJECT-TYPE
   SYNTAX FcNameId
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The World_wide Name of this FxPort. Each FxPort has a
       unique Port World_wide Name within the Fabric."
::= { fcFxPortEntry 2 }
```

```
-- FxPort common service parameters
fcFxPortFcphVersionHigh OBJECT-TYPE
   SYNTAX FcphVersion
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The highest or most recent version of FC-PH that the FxPort
       is configured to support."
::= { fcFxPortEntry 3 }
fcFxPortFcphVersionLow OBJECT-TYPE
   SYNTAX FcphVersion
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The lowest or earliest version of FC-PH that the FxPort is
       configured to support."
::= { fcFxPortEntry 4 }
fcFxPortBbCredit OBJECT-TYPE
   SYNTAX FcBbCredit
   UNITS
             "buffers"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The total number of receive buffers available for holding
       Class 1 connect-request, Class 2 or 3 frames from the
       attached NxPort. It is for buffer-to-buffer flow control
       in the direction from the attached NxPort (if applicable)
       to FxPort."
    ::= { fcFxPortEntry 5 }
fcFxPortRxBufSize OBJECT-TYPE
   SYNTAX FcRxDataFieldSize
   UNITS
              "bytes"
   MAX-ACCESS read-only
              current
   DESCRIPTION
      "The largest Data_Field Size (in octets) for an FT_1 frame
       that can be received by the FxPort."
::= { fcFxPortEntry 6 }
fcFxPortRatov OBJECT-TYPE
   SYNTAX MilliSeconds
              "milliseconds"
   MAX-ACCESS read-only
   STATUS
             current
```

```
DESCRIPTION
      "The Resource_Allocation_Timeout Value configured for the
       FxPort. This is used as the timeout value for determining
       when to reuse an NxPort resource such as a
       Recovery_Qualifier. It represents E_D_TOV (see next
       object) plus twice the maximum time that a frame may be
       delayed within the Fabric and still be delivered."
    ::= { fcFxPortEntry 7 }
fcFxPortEdtov OBJECT-TYPE
   SYNTAX MilliSeconds
              "milliseconds"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The E D TOV value configured for the FxPort. The
       Error_Detect_Timeout Value is used as the timeout value for
       detecting an error condition."
::= { fcFxPortEntry 8 }
-- FxPort class service parameters
fcFxPortCosSupported OBJECT-TYPE
   SYNTAX FcCosCap
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A value indicating the set of Classes of Service supported
       by the FxPort."
::= { fcFxPortEntry 9 }
fcFxPortIntermixSupported OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A flag indicating whether or not the FxPort supports an
       Intermixed Dedicated Connection."
::= { fcFxPortEntry 10 }
fcFxPortStackedConnMode OBJECT-TYPE
   SYNTAX FcStackedConnMode
   MAX-ACCESS read-only
   STATUS current
      "A value indicating the mode of Stacked Connect supported by
       the FxPort."
```

```
::= { fcFxPortEntry 11 }
fcFxPortClass2SeqDeliv OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "A flag indicating whether or not Class 2 Sequential
       Delivery is supported by the FxPort."
::= { fcFxPortEntry 12 }
fcFxPortClass3SeqDeliv OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
       "A flag indicating whether or not Class 3 Sequential
       Delivery is supported by the FxPort."
::= { fcFxPortEntry 13 }
-- other FxPort parameters
fcFxPortHoldTime OBJECT-TYPE
   SYNTAX MicroSeconds
   UNITS
               "microseconds"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The maximum time (in microseconds) that the FxPort shall
       hold a frame before discarding the frame if it is unable to
       deliver the frame. The value 0 means that the FxPort does
       not support this parameter."
::= { fcFxPortEntry 14 }
-- the Status group
-- This group consists of tables that contains operational
-- status and established service parameters for the Fabric
-- Element and the attached NxPorts.
-- The FxPort Status table
-- This table contains, one entry for each FxPort,
-- the operational status and parameters of the FxPorts.
fcFxPortStatusTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortStatusEntry
```

```
MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, operational status and parameters of the
::= { fcFeStatus 1 }
fcFxPortStatusEntry OBJECT-TYPE
   SYNTAX FcFxPortStatusEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "An entry containing operational status and parameters of a
       FxPort."
   AUGMENTS { fcFxPortEntry }
::= { fcFxPortStatusTable 1 }
FcFxPortStatusEntry ::=
   SEQUENCE {
       fcFxPortID
           FcAddressId,
       fcFxPortBbCreditAvailable
           Gauge32,
       fcFxPortOperMode
           INTEGER,
       fcFxPortAdminMode
          INTEGER
    }
fcFxPortID OBJECT-TYPE
   SYNTAX FcAddressId
   MAX-ACCESS read-only
              current
   STATUS
   DESCRIPTION
      "The address identifier by which this FxPort is identified
       within the Fabric. The FxPort may assign its address
       identifier to its attached NxPort(s) during Fabric Login."
::= { fcFxPortStatusEntry 1 }
fcFxPortBbCreditAvailable OBJECT-TYPE
   SYNTAX Gauge 32
   UNITS
               "buffers"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of buffers currently available for receiving
```

```
frames from the attached port in the buffer-to-buffer flow
       control. The value should be less than or equal to
       fcFxPortBbCredit."
::= { fcFxPortStatusEntry 2 }
fcFxPortOperMode
                 OBJECT-TYPE
                      INTEGER { unknown(1), fPort(2), flPort(3) }
   SYNTAX
   MAX-ACCESS
                       read-only
    STATUS
                       current
   DESCRIPTION
       "The current operational mode of the FxPort."
::= { fcFxPortStatusEntry 3 }
fcFxPortAdminMode     OBJECT-TYPE
                      INTEGER { fPort(2), flPort(3) }
   SYNTAX
   MAX-ACCESS
                       read-write
    STATUS
                       current
   DESCRIPTION
      "The desired operational mode of the FxPort."
::= { fcFxPortStatusEntry 4 }
-- the FxPort Physical Level table
-- This table contains, one entry for each FxPort in the
-- Fabric Element, the physical level status and parameters
-- of the FxPorts.
fcFxPortPhysTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortPhysEntry
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, physical level status and parameters of the
       FxPorts."
::= { fcFeStatus 2 }
fcFxPortPhysEntry OBJECT-TYPE
   SYNTAX FcFxPortPhysEntry
   MAX-ACCESS not-accessible
   STATUS current
    DESCRIPTION
       "An entry containing physical level status and parameters of
       a FxPort."
    AUGMENTS { fcFxPortEntry }
::= { fcFxPortPhysTable 1 }
FcFxPortPhysEntry ::=
```

```
SEQUENCE {
       fcFxPortPhysAdminStatus
           INTEGER,
       fcFxPortPhysOperStatus
           INTEGER,
        fcFxPortPhysLastChange
           TimeStamp,
       fcFxPortPhysRttov
           MilliSeconds
    }
fcFxPortPhysAdminStatus OBJECT-TYPE
   SYNTAX
               INTEGER {
                   online (1), -- place port online
                   offline (2), -- take port offline
testing (3) -- initiate test procedures
   MAX-ACCESS read-write
   STATUS
              current
   DESCRIPTION
       "The desired state of the FxPort. A management station may
       place the FxPort in a desired state by setting this object
       accordingly. The testing(3) state indicates that no
       operational frames can be passed. When a Fabric Element
       initializes, all FxPorts start with fcFxPortPhysAdminStatus
       in the offline(2) state. As the result of either explicit
       management action or per configuration information
       accessible by the Fabric Element, fcFxPortPhysAdminStatus
       is then changed to either the online(1) or testing(3)
       states, or remains in the offline state."
::= { fcFxPortPhysEntry 1 }
fcFxPortPhysOperStatus
                       OBJECT-TYPE
   SYNTAX INTEGER {
       online (1), -- Login may proceed
       offline
                   (2), -- Login cannot proceed
       testing (3), -- port is under test
       linkFailure (4) -- failure after online/testing
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The current operational status of the FxPort. The
       testing(3) indicates that no operational frames can be
       passed. If fcFxPortPhysAdminStatus is offline(2) then
       fcFxPortPhysOperStatus should be offline(2). If
       fcFxPortPhysAdminStatus is changed to online(1) then
       fcFxPortPhysOperStatus should change to online(1) if the
```

```
FxPort is ready to accept Fabric Login request from the
       attached NxPort; it should proceed and remain in the link-
       failure(4) state if and only if there is a fault that
       prevents it from going to the online(1) state."
::= { fcFxPortPhysEntry 2 }
fcFxPortPhysLastChange OBJECT-TYPE
    SYNTAX TimeStamp
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The value of sysUpTime at the time the FxPort entered its
       current operational status. A value of zero indicates that
       the FxPort's operational status has not changed since the
       agent last restarted."
::= { fcFxPortPhysEntry 3 }
fcFxPortPhysRttov OBJECT-TYPE
   SYNTAX MilliSeconds
               "milliseconds"
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The Receiver_Transmitter_Timeout value of the FxPort. This
       is used by the receiver logic to detect Loss of
       Synchronization."
::= { fcFxPortPhysEntry 4 }
-- The FxPort Fabric Login table
-- This table contains, one entry for each FxPort in the
-- Fabric Element, the Service Parameters that have been
-- established from the most recent Fabric Login,
-- implicit or explicit.
fcFxLoginTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxLoginEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains, one entry for each NxPort attached
       to a particular FxPort in the Fabric Element, services
       parameters established from the most recent Fabric Login,
       explicit or implicit. Note that an FxPort may have one or
       more NxPort attached to it."
::= { fcFeStatus 3 }
```

```
fcFxLoginEntry OBJECT-TYPE
    SYNTAX FcFxLoginEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
       "An entry containing service parameters established from a
        successful Fabric Login."
    INDEX { fcFeModuleIndex, fcFxPortIndex, fcFxPortNxLoginIndex }
::= { fcFxLoginTable 1 }
FcFxLoginEntry ::=
    SEQUENCE {
        fcFxPortNxLoginIndex
           FcFeNxPortIndex,
        fcFxPortFcphVersionAgreed
           FcphVersion,
        fcFxPortNxPortBbCredit
           FcBbCredit,
        fcFxPortNxPortRxDataFieldSize
           FcRxDataFieldSize,
        fcFxPortCosSuppAgreed
           FcCosCap,
        fcFxPortIntermixSuppAgreed
            TruthValue,
        fcFxPortStackedConnModeAgreed
            FcStackedConnMode,
        fcFxPortClass2SeqDelivAgreed
           TruthValue,
        fcFxPortClass3SeqDelivAgreed
           TruthValue,
        fcFxPortNxPortName
           FcNameId,
        fcFxPortConnectedNxPort
           FcAddressId,
        fcFxPortBbCreditModel
           FcBbCreditModel
    }
fcFxPortNxLoginIndex OBJECT-TYPE
    SYNTAX FcFeNxPortIndex
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
       "The object identifies the associated NxPort in the
       attachment for which the entry contains information."
::= { fcFxLoginEntry 1 }
```

```
fcFxPortFcphVersionAgreed OBJECT-TYPE
   SYNTAX FcphVersion
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The version of FC-PH that the FxPort has agreed to support
       from the Fabric Login"
::= { fcFxLoginEntry 2 }
fcFxPortNxPortBbCredit OBJECT-TYPE
   SYNTAX FcBbCredit
   UNITS
              "buffers"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The total number of buffers available for holding Class 1
       connect-request, Class 2 or Class 3 frames to be
       transmitted to the attached NxPort. It is for buffer-to-
       buffer flow control in the direction from FxPort to NxPort.
       The buffer-to-buffer flow control mechanism is indicated in
       the respective fcFxPortBbCreditModel."
::= { fcFxLoginEntry 3 }
fcFxPortNxPortRxDataFieldSize OBJECT-TYPE
   SYNTAX FcRxDataFieldSize
   UNITS
               "bytes"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The Receive Data Field Size of the attached NxPort. This
       object specifies the largest Data Field Size for an FT_1
       frame that can be received by the NxPort."
::= { fcFxLoginEntry 4 }
fcFxPortCosSuppAgreed OBJECT-TYPE
   SYNTAX FcCosCap
   MAX-ACCESS read-only
              current
   DESCRIPTION
       "A variable indicating that the attached NxPort has
       requested the FxPort for the support of classes of services
       and the FxPort has granted the request."
::= { fcFxLoginEntry 5 }
fcFxPortIntermixSuppAgreed OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS
             current
```

```
DESCRIPTION
      "A variable indicating that the attached NxPort has
       requested the FxPort for the support of Intermix and the
       FxPort has granted the request. This flag is only valid if
       Class 1 service is supported."
::= { fcFxLoginEntry 6 }
fcFxPortStackedConnModeAgreed OBJECT-TYPE
   SYNTAX FcStackedConnMode
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A variable indicating whether the FxPort has agreed to
       support stacked connect from the Fabric Login. This is only
       meaningful if Class 1 service has been agreed."
::= { fcFxLoginEntry 7 }
fcFxPortClass2SeqDelivAgreed OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A variable indicating whether the FxPort has agreed to
       support Class 2 sequential delivery from the Fabric Login.
       This is only meaningful if Class 2 service has been
       agreed."
::= { fcFxLoginEntry 8 }
fcFxPortClass3SeqDelivAgreed OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
       "A flag indicating whether the FxPort has agreed to support
       Class 3 sequential delivery from the Fabric Login. This is
       only meaningful if Class 3 service has been agreed."
::= { fcFxLoginEntry 9 }
fcFxPortNxPortName OBJECT-TYPE
   SYNTAX FcNameId
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The port name of the attached NxPort."
::= { fcFxLoginEntry 10 }
fcFxPortConnectedNxPort OBJECT-TYPE
   SYNTAX
              FcAddressId
```

```
MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The address identifier of the destination NxPort with which
       this FxPort is currently engaged in a either a Class 1 or
       loop connection. If this FxPort is not engaged in a
       connection, then the value of this object is '000000'H."
::= { fcFxLoginEntry 11 }
fcFxPortBbCreditModel OBJECT-TYPE
   SYNTAX FcBbCreditModel
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
      "This object identifies the BB_Credit model used by the
       FxPort."
::= { fcFxLoginEntry 12 }
-- the Error group
-- This group consists of tables that contain information about
-- the various types of errors detected. The management station
-- may use the information in this group to determine the
-- quality of the link between the FxPort and its attached NxPort.
-- the FxPort Error table
-- This table contains, one entry for each FxPort in the Fabric
-- Element, counters recording numbers of errors detected
-- since the management agent re-initialized.
-- The first 6 columnar objects after the port index corresponds
-- to the counters in the Link Error Status Block.
fcFxPortErrorTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortErrorEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
      "A table that contains, one entry for each FxPort, counters
       that record the numbers of errors detected."
::= { fcFeError 1 }
fcFxPortErrorEntry OBJECT-TYPE
   SYNTAX FcFxPortErrorEntry
   MAX-ACCESS not-accessible
   STATUS current
       "An entry containing error counters of a FxPort."
   AUGMENTS { fcFxPortEntry }
```

```
::= { fcFxPortErrorTable 1 }
FcFxPortErrorEntry ::=
   SEQUENCE {
       fcFxPortLinkFailures
           Counter32,
        fcFxPortSyncLosses
           Counter32,
        fcFxPortSigLosses
           Counter32,
        fcFxPortPrimSeqProtoErrors
           Counter32,
        fcFxPortInvalidTxWords
           Counter32,
        fcFxPortInvalidCrcs
           Counter32,
        fcFxPortDelimiterErrors
           Counter32,
        fcFxPortAddressIdErrors
           Counter32,
        fcFxPortLinkResetIns
           Counter32,
        fcFxPortLinkResetOuts
           Counter32,
        fcFxPortOlsIns
           Counter32,
       fcFxPortOlsOuts
           Counter32
    }
fcFxPortLinkFailures OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
               current
   STATUS
   DESCRIPTION
      "The number of link failures detected by this FxPort."
::= { fcFxPortErrorEntry 1 }
fcFxPortSyncLosses OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
      "The number of loss of synchronization detected by the
       FxPort."
::= { fcFxPortErrorEntry 2 }
```

```
fcFxPortSigLosses OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of loss of signal detected by the FxPort."
::= { fcFxPortErrorEntry 3 }
fcFxPortPrimSeqProtoErrors OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of primitive sequence protocol errors detected
       by the FxPort."
::= { fcFxPortErrorEntry 4 }
fcFxPortInvalidTxWords OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of invalid transmission word detected by the
       FxPort."
::= { fcFxPortErrorEntry 5 }
fcFxPortInvalidCrcs OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of invalid CRC detected by this FxPort."
::= { fcFxPortErrorEntry 6 }
fcFxPortDelimiterErrors OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The number of Delimiter Errors detected by this FxPort."
::= { fcFxPortErrorEntry 7 }
fcFxPortAddressIdErrors OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of address identifier errors detected by this
```

```
FxPort."
::= { fcFxPortErrorEntry 8 }
fcFxPortLinkResetIns OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Link Reset Protocol received by this FxPort
       from the attached NxPort."
::= { fcFxPortErrorEntry 9 }
fcFxPortLinkResetOuts OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The number of Link Reset Protocol issued by this FxPort to
       the attached NxPort."
::= { fcFxPortErrorEntry 10 }
fcFxPortOlsIns OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Offline Sequence received by this FxPort."
::= { fcFxPortErrorEntry 11 }
fcFxPortOlsOuts OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The number of Offline Sequence issued by this FxPort."
::= { fcFxPortErrorEntry 12 }
-- Accounting Groups:
-- (1) Class 1 Accounting Group,
-- (2) Class 2 Accounting Group, and
-- (3) Class 3 Accounting Group.
-- Each group consists of a table that contains accounting
-- information for the FxPorts in the Fabric Element.
-- the Class 1 Accounting table
-- This table contains, one entry for each FxPort in the Fabric
```

```
-- Element, Counter32s for certain types of events occurred in the
-- the FxPorts since the the management agent has re-initialized.
fcFxPortClAccountingTable OBJECT-TYPE
            SEQUENCE OF FcFxPortClAccountingEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, Class 1 accounting information recorded
       since the management agent has re-initialized."
::= { fcFeAccounting 1 }
fcFxPortClAccountingEntry OBJECT-TYPE
    SYNTAX FcFxPortClAccountingEntry
   MAX-ACCESS not-accessible
    STATUS
               current
   DESCRIPTION
      "An entry containing Class 1 accounting information for each
       FxPort."
    AUGMENTS { fcFxPortEntry }
::= { fcFxPortC1AccountingTable 1 }
FcFxPortC1AccountingEntry ::=
   SEQUENCE {
       fcFxPortC1InFrames
           Counter32,
        fcFxPortC1OutFrames
           Counter32,
        fcFxPortC1InOctets
           Counter32,
        fcFxPortC1OutOctets
           Counter32,
        fcFxPortClDiscards
           Counter32,
        fcFxPortC1FbsyFrames
           Counter32,
        fcFxPortC1FrjtFrames
            Counter32,
        fcFxPortC1InConnections
            Counter32,
        fcFxPortC1OutConnections
           Counter32,
        fcFxPortC1ConnTime
           MilliSeconds
    }
```

```
fcFxPortClInFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Class 1 frames (other than Class 1 connect-
       request) received by this FxPort from its attached NxPort."
::= { fcFxPortC1AccountingEntry 1 }
fcFxPortClOutFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
            current
   DESCRIPTION
      "The number of Class 1 frames (other than Class 1 connect-
       request) delivered through this FxPort to its attached
       NxPort."
::= { fcFxPortClAccountingEntry 2 }
fcFxPortClInOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Class 1 frame octets, including the frame
       delimiters, received by this FxPort from its attached
       NxPort."
::= { fcFxPortC1AccountingEntry 3 }
fcFxPortC1OutOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
       "The number of Class 1 frame octets, including the frame
       delimiters, delivered through this FxPort its attached
       NxPort."
::= { fcFxPortClAccountingEntry 4 }
fcFxPortClDiscards OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Class 1 frames discarded by this FxPort."
::= { fcFxPortC1AccountingEntry 5 }
fcFxPortC1FbsyFrames OBJECT-TYPE
```

```
SYNTAX
            Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of F_BSY frames generated by this FxPort against
       Class 1 connect-request."
::= { fcFxPortClAccountingEntry 6 }
fcFxPortC1FrjtFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of F_RJT frames generated by this FxPort against
       Class 1 connect-request."
::= { fcFxPortC1AccountingEntry 7 }
fcFxPortClInConnections OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 1 connections successfully established
       in which the attached NxPort is the source of the connect-
::= { fcFxPortClAccountingEntry 8 }
fcFxPortClOutConnections OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The number of Class 1 connections successfully established
       in which the attached NxPort is the destination of the
       connect-request."
::= { fcFxPortClAccountingEntry 9 }
fcFxPortC1ConnTime OBJECT-TYPE
   SYNTAX MilliSeconds
              "milliseconds"
   UNTTS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The cumulative time that this FxPort has been engaged in
       Class 1 connection. The amount of time is counted from
       after a connect-request has been accepted until the
       connection is disengaged, either by an EOFdt or Link
       Reset."
```

```
::= { fcFxPortClAccountingEntry 10 }
-- the Class 2 Accounting table
-- This table contains, one entry for each FxPort in the Fabric
-- Element, Counter32s for certain types of events occurred in the
-- the FxPorts since the the management agent has re-initialized.
fcFxPortC2AccountingTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortC2AccountingEntry
   MAX-ACCESS not-accessible
   STATUS
           current
   DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, Class 2 accounting information recorded
        since the management agent has re-initialized."
::= { fcFeAccounting 2 }
fcFxPortC2AccountingEntry OBJECT-TYPE
    SYNTAX FcFxPortC2AccountingEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "An entry containing Class 2 accounting information for each
       FxPort."
    AUGMENTS { fcFxPortEntry }
::= { fcFxPortC2AccountingTable 1 }
FcFxPortC2AccountingEntry ::=
    SEQUENCE {
       fcFxPortC2InFrames
           Counter32,
        fcFxPortC2OutFrames
              Counter32,
        fcFxPortC2InOctets
              Counter32,
        fcFxPortC2OutOctets
              Counter32,
        fcFxPortC2Discards
              Counter32,
        fcFxPortC2FbsyFrames
              Counter32,
        fcFxPortC2FrjtFrames
              Counter32
    }
fcFxPortC2InFrames OBJECT-TYPE
```

```
Counter32
   SYNTAX
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 2 frames received by this FxPort from
       its attached NxPort."
::= { fcFxPortC2AccountingEntry 1 }
fcFxPortC2OutFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 2 frames delivered through this FxPort
       to its attached NxPort."
::= { fcFxPortC2AccountingEntry 2 }
fcFxPortC2InOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 2 frame octets, including the frame
       delimiters, received by this FxPort from its attached
::= { fcFxPortC2AccountingEntry 3 }
fcFxPortC2OutOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 2 frame octets, including the frame
       delimiters, delivered through this FxPort to its attached
       NxPort."
::= { fcFxPortC2AccountingEntry 4 }
fcFxPortC2Discards OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 2 frames discarded by this FxPort."
::= { fcFxPortC2AccountingEntry 5 }
fcFxPortC2FbsyFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
```

```
current
   STATUS
   DESCRIPTION
      "The number of F_BSY frames generated by this FxPort against
       Class 2 frames."
::= { fcFxPortC2AccountingEntry 6 }
fcFxPortC2FrjtFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of F_RJT frames generated by this FxPort against
       Class 2 frames."
::= { fcFxPortC2AccountingEntry 7 }
-- the Class 3 Accounting Group
-- This table contains, one entry for each FxPort in the Fabric
-- Element, Counter32s for certain types of events occurred in the
-- the FxPorts since the management agent has re-initialized.
fcFxPortC3AccountingTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortC3AccountingEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains, one entry for each FxPort in the
       Fabric Element, Class 3 accounting information recorded
       since the management agent has re-initialized."
::= { fcFeAccounting 3 }
fcFxPortC3AccountingEntry OBJECT-TYPE
   SYNTAX FcFxPortC3AccountingEntry
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
      "An entry containing Class 3 accounting information for each
       FxPort."
   AUGMENTS { fcFxPortEntry }
::= { fcFxPortC3AccountingTable 1 }
FcFxPortC3AccountingEntry ::=
   SEQUENCE {
       fcFxPortC3InFrames
           Counter32,
       fcFxPortC3OutFrames
           Counter32,
       fcFxPortC3InOctets
```

```
Counter32,
       fcFxPortC3OutOctets
           Counter32,
       fcFxPortC3Discards
           Counter32
   }
fcFxPortC3InFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 3 frames received by this FxPort from
       its attached NxPort."
::= { fcFxPortC3AccountingEntry 1 }
fcFxPortC3OutFrames OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 3 frames delivered through this FxPort
       to its attached NxPort."
::= { fcFxPortC3AccountingEntry 2 }
fcFxPortC3InOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The number of Class 3 frame octets, including the frame
       delimiters, received by this FxPort from its attached
       NxPort."
::= { fcFxPortC3AccountingEntry 3 }
fcFxPortC3OutOctets OBJECT-TYPE
   SYNTAX Counter32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of Class 3 frame octets, including the frame
       delimiters, delivered through this FxPort to its attached
       NxPort."
::= { fcFxPortC3AccountingEntry 4 }
```

fcFxPortC3Discards OBJECT-TYPE
SYNTAX Counter32
MAX-ACCESS read-only

```
current
    STATUS
   DESCRIPTION
      "The number of Class 3 frames discarded by this FxPort."
::= { fcFxPortC3AccountingEntry 5 }
-- The Capability Group - consists of a table describing
-- information about what each FxPort is inherently capable
-- of operating or supporting.
-- A capability may be used, as expressed in its respective
-- object value in the Configuration group.
fcFxPortCapTable OBJECT-TYPE
   SYNTAX SEQUENCE OF FcFxPortCapEntry
   MAX-ACCESS not-accessible
    STATUS
               current
   DESCRIPTION
       "A table that contains, one entry for each FxPort, the
       capabilities of the port within the Fabric Element."
::= { fcFeCapabilities 1 }
fcFxPortCapEntry OBJECT-TYPE
    SYNTAX FcFxPortCapEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
       "An entry containing the Cap of a FxPort."
    AUGMENTS { fcFxPortEntry }
::= { fcFxPortCapTable 1 }
FcFxPortCapEntry ::=
    SEQUENCE {
       fcFxPortCapFcphVersionHigh
           FcphVersion,
        fcFxPortCapFcphVersionLow
           FcphVersion,
        fcFxPortCapBbCreditMax
           FcBbCredit,
        fcFxPortCapBbCreditMin
           FcBbCredit,
        fcFxPortCapRxDataFieldSizeMax
           FcRxDataFieldSize,
        fcFxPortCapRxDataFieldSizeMin
           FcRxDataFieldSize,
        fcFxPortCapCos
           FcCosCap,
        fcFxPortCapIntermix
```

```
TruthValue,
       fcFxPortCapStackedConnMode
           FcStackedConnMode,
       fcFxPortCapClass2SeqDeliv
           TruthValue,
       fcFxPortCapClass3SeqDeliv
           TruthValue,
       fcFxPortCapHoldTimeMax
           MicroSeconds,
       fcFxPortCapHoldTimeMin
           MicroSeconds
   }
fcFxPortCapFcphVersionHigh OBJECT-TYPE
   SYNTAX FcphVersion
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The highest or most recent version of FC-PH that the FxPort
       is capable of supporting."
::= { fcFxPortCapEntry 1 }
fcFxPortCapFcphVersionLow OBJECT-TYPE
   SYNTAX FcphVersion
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The lowest or earliest version of FC-PH that the FxPort is
       capable of supporting."
::= { fcFxPortCapEntry 2 }
fcFxPortCapBbCreditMax OBJECT-TYPE
   SYNTAX FcBbCredit
   UNITS
               "buffers"
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
      "The maximum number of receive buffers available for holding
       Class 1 connect-request, Class 2 or Class 3 frames from the
       attached NxPort."
::= { fcFxPortCapEntry 3 }
fcFxPortCapBbCreditMin OBJECT-TYPE
   SYNTAX FcBbCredit
   UNITS
              "buffers"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
```

```
"The minimum number of receive buffers available for holding
       Class 1 connect-request, Class 2 or Class 3 frames from the
       attached NxPort."
::= { fcFxPortCapEntry 4 }
fcFxPortCapRxDataFieldSizeMax OBJECT-TYPE
   SYNTAX FcRxDataFieldSize
   UNITS
               "bytes"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The maximum size in bytes of the Data Field in a frame that
       the FxPort is capable of receiving from its attached
       NxPort."
::= { fcFxPortCapEntry 5 }
fcFxPortCapRxDataFieldSizeMin OBJECT-TYPE
   SYNTAX FcRxDataFieldSize
   UNITS
               "bytes"
   MAX-ACCESS read-only
           current
   DESCRIPTION
       "The minimum size in bytes of the Data Field in a frame that
       the FxPort is capable of receiving from its attached
::= { fcFxPortCapEntry 6 }
fcFxPortCapCos OBJECT-TYPE
   SYNTAX FcCosCap
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
       "A value indicating the set of Classes of Service that the
       FxPort is capable of supporting."
::= { fcFxPortCapEntry 7 }
fcFxPortCapIntermix OBJECT-TYPE
   SYNTAX
            TruthValue
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
       "A flag indicating whether or not the FxPort is capable of
       supporting the intermixing of Class 2 and Class 3 frames
       during a Class 1 connection. This flag is only valid if the
       port is capable of supporting Class 1 service."
::= { fcFxPortCapEntry 8 }
fcFxPortCapStackedConnMode OBJECT-TYPE
```

```
FcStackedConnMode
   SYNTAX
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A value indicating the mode of Stacked Connect request that
       the FxPort is capable of supporting."
::= { fcFxPortCapEntry 9 }
fcFxPortCapClass2SeqDeliv OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A flag indicating whether or not the FxPort is capable of
       supporting Class 2 Sequential Delivery."
::= { fcFxPortCapEntry 10 }
fcFxPortCapClass3SeqDeliv OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "A flag indicating whether or not the FxPort is capable of
       supporting Class 3 Sequential Delivery."
::= { fcFxPortCapEntry 11 }
fcFxPortCapHoldTimeMax OBJECT-TYPE
   SYNTAX MicroSeconds
   UNITS
              "microseconds"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The maximum holding time (in microseconds) that the FxPort
       is capable of supporting."
::= { fcFxPortCapEntry 12 }
fcFxPortCapHoldTimeMin OBJECT-TYPE
   SYNTAX MicroSeconds
   UNITS
              "microseconds"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
      "The minimum holding time (in microseconds) that the FxPort
       is capable of supporting."
::= { fcFxPortCapEntry 13 }
-- conformance information
```

```
fcFeMIBConformance OBJECT IDENTIFIER ::= { fcFeMIB 2 }
fcFeMIBCompliances OBJECT IDENTIFIER ::= { fcFeMIBConformance 1 }
fcFeMIBGroups OBJECT IDENTIFIER ::= { fcFeMIBConformance 2 }
-- compliance statements
fcFeMIBMinimumCompliance MODULE-COMPLIANCE
   STATUS current
    DESCRIPTION
       "The minimum compliance statement for SNMP entities
       which implement the FIBRE-CHANNEL-FE-MIB."
   MODULE -- this module
    MANDATORY-GROUPS { fcFeConfigGroup, fcFeStatusGroup,
                      fcFeErrorGroup }
   OBJECT
                fcFeFabricName
   MIN-ACCESS
                read-only
   DESCRIPTION
      "Write access is not required."
   OBJECT
                fcFeElementName
   MIN-ACCESS read-only
   DESCRIPTION
      "Write access is not required."
                fcFeModuleName
    OBJECT
   MIN-ACCESS
                read-only
   DESCRIPTION
      "Write access is not required."
   OBJECT
                fcFxPortAdminMode
   MIN-ACCESS
                read-only
   DESCRIPTION
      "Write access is not required."
   OBJECT
                fcFxPortPhysAdminStatus
   MIN-ACCESS
                read-only
   DESCRIPTION
      "Write access is not required."
                fcFxPortPhysRttov
   OBJECT
   MIN-ACCESS read-only
    DESCRIPTION
       "Write access is not required."
   OBJECT
                fcFxPortBbCreditModel
   MIN-ACCESS read-only
    DESCRIPTION
      "Write access is not required."
```

```
::= { fcFeMIBCompliances 1 }
fcFeMIBFullCompliance MODULE-COMPLIANCE
   STATUS
           current
   DESCRIPTION
       "The full compliance statement for SNMP entities
       which implement the FIBRE-CHANNEL-FE-MIB."
   MODULE -- this module
   MANDATORY-GROUPS { fcFeConfigGroup, fcFeStatusGroup,
                      fcFeErrorGroup, fcFeCapabilitiesGroup }
   GROUP fcFeClass1AccountingGroup
   DESCRIPTION
       "This group is mandatory for all fibre channel fabric
       elements which support class 1 frames."
   GROUP fcFeClass2AccountingGroup
   DESCRIPTION
       "This group is mandatory for all fibre channel fabric
       elements which support class 2 frames."
   GROUP fcFeClass3AccountingGroup
   DESCRIPTION
       "This group is mandatory for all fibre channel fabric
       elements which support class 3 frames."
   OBJECT
                 fcFeFabricName
   MIN-ACCESS
                read-only
   DESCRIPTION
       "Write access is not required."
                 fcFeElementName
   OBJECT
   MIN-ACCESS
                 read-only
   DESCRIPTION
       "Write access is not required."
                fcFeModuleName
   OBJECT
   MIN-ACCESS read-only
   DESCRIPTION
       "Write access is not required."
   OBJECT
                 fcFxPortAdminMode
   MIN-ACCESS
                 read-only
   DESCRIPTION
      "Write access is not required."
                 fcFxPortPhysAdminStatus
   OBJECT
   MIN-ACCESS read-only
```

```
DESCRIPTION
      "Write access is not required."
                 fcFxPortPhysRttov
   MIN-ACCESS
                 read-only
   DESCRIPTION
       "Write access is not required."
                 fcFxPortBbCreditModel
   OBJECT
   MIN-ACCESS
                 read-only
   DESCRIPTION
       "Write access is not required."
 ::= { fcFeMIBCompliances 2 }
 -- units of conformance
 fcFeConfigGroup OBJECT-GROUP
   OBJECTS { fcFeFabricName, fcFeElementName, fcFeModuleCapacity,
              fcFeModuleDescr, fcFeModuleObjectID,
              fcFeModuleOperStatus, fcFeModuleLastChange,
              fcFeModuleFxPortCapacity, fcFeModuleName,
              fcFxPortName, fcFxPortFcphVersionHigh,
              fcFxPortFcphVersionLow, fcFxPortBbCredit,
              fcFxPortRxBufSize, fcFxPortRatov, fcFxPortEdtov,
              fcFxPortCosSupported, fcFxPortIntermixSupported,
              fcFxPortStackedConnMode, fcFxPortClass2SeqDeliv,
             fcFxPortClass3SeqDeliv, fcFxPortHoldTime }
   STATUS
             current
       "A collection of objects providing the configuration and service
       parameters of the Fabric Element, the modules, and FxPorts."
 ::= { fcFeMIBGroups 1 }
fcFeStatusGroup OBJECT-GROUP
  OBJECTS { fcFxPortID, fcFxPortBbCreditAvailable,
             fcFxPortOperMode, fcFxPortAdminMode,
             fcFxPortPhysAdminStatus, fcFxPortPhysOperStatus,
             fcFxPortPhysLastChange, fcFxPortPhysRttov,
             fcFxPortFcphVersionAgreed, fcFxPortNxPortBbCredit,
             fcFxPortNxPortRxDataFieldSize, fcFxPortCosSuppAgreed,
             fcFxPortIntermixSuppAgreed,
             fcFxPortStackedConnModeAgreed,
             fcFxPortClass2SeqDelivAgreed,
             fcFxPortClass3SeqDelivAgreed,
             fcFxPortNxPortName, fcFxPortConnectedNxPort,
            fcFxPortBbCreditModel }
  STATUS
            current
  DESCRIPTION
```

```
"A collection of objects providing the operational status and
       established service parameters for the Fabric Element and the
       attached NxPorts."
 ::= { fcFeMIBGroups 2 }
 fcFeErrorGroup OBJECT-GROUP
    OBJECTS { fcFxPortLinkFailures, fcFxPortSyncLosses,
              fcFxPortSigLosses, fcFxPortPrimSeqProtoErrors,
              fcFxPortInvalidTxWords, fcFxPortInvalidCrcs,
              fcFxPortDelimiterErrors, fcFxPortAddressIdErrors,
              fcFxPortLinkResetIns, fcFxPortLinkResetOuts,
              fcFxPortOlsIns, fcFxPortOlsOuts }
    STATUS
             current
    DESCRIPTION
       "A collection of objects providing various error
        statistics detected by the FxPorts."
 ::= { fcFeMIBGroups 3 }
 fcFeClass1AccountingGroup OBJECT-GROUP
    OBJECTS { fcFxPortClInFrames, fcFxPortClOutFrames,
              fcFxPortClInOctets, fcFxPortClOutOctets,
              fcFxPortClDiscards, fcFxPortClFbsyFrames,
              fcFxPortC1FrjtFrames, fcFxPortC1InConnections,
              fcFxPortClOutConnections, fcFxPortClConnTime
    STATUS
             current
    DESCRIPTION
       "A collection of objects providing various class 1
performance statistics detected by the FxPorts."
 ::= { fcFeMIBGroups 4 }
 fcFeClass2AccountingGroup OBJECT-GROUP
    OBJECTS { fcFxPortC2InFrames, fcFxPortC2OutFrames,
              fcFxPortC2InOctets, fcFxPortC2OutOctets,
              fcFxPortC2Discards, fcFxPortC2FbsyFrames,
              fcFxPortC2FrjtFrames
    STATUS
             current
    DESCRIPTION
       "A collection of objects providing various class 2
performance statistics detected by the FxPorts."
 ::= { fcFeMIBGroups 5 }
 fcFeClass3AccountingGroup OBJECT-GROUP
    OBJECTS { fcFxPortC3InFrames, fcFxPortC3OutFrames,
              fcFxPortC3InOctets, fcFxPortC3OutOctets,
              fcFxPortC3Discards
    }
```

```
STATUS
             current
   DESCRIPTION
       "A collection of objects providing various class 3
       performance statistics detected by the FxPorts."
 ::= { fcFeMIBGroups 6 }
fcFeCapabilitiesGroup OBJECT-GROUP
   OBJECTS { fcFxPortCapFcphVersionHigh, fcFxPortCapFcphVersionLow,
             fcFxPortCapBbCreditMax, fcFxPortCapBbCreditMin,
             fcFxPortCapRxDataFieldSizeMax,
             fcFxPortCapRxDataFieldSizeMin,
             fcFxPortCapCos, fcFxPortCapIntermix,
             fcFxPortCapStackedConnMode, fcFxPortCapClass2SeqDeliv,
             fcFxPortCapClass3SeqDeliv, fcFxPortCapHoldTimeMax,
             fcFxPortCapHoldTimeMin
  STATUS
            current
  DESCRIPTION
      "A collection of objects providing the inherent
       capability of each FxPort within the Fabric Element."
 ::= { fcFeMIBGroups 7 }
END
-- End of Object Definitions
```

4. Security Considerations

There are a number of management objects defined in this MIB that have a MAX-ACCESS clause of read-write. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is recommended that the implementers consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model RFC 2574 [12] and the View-based Access Control Model RFC 2575 [15] is recommended.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/delete) them.

5. Intellectual Property

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in BCP-11. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

6. Acknowledgements

The editors would like to thank the following individuals for their assistance and constructive comments:

Juergen Schoenwaelder, Technical University Braunschweig

Bent Stoevhase, Brocade

John Y. Chu, IBM

Yakov Rekhter, Cisco
Dan Eisenhauer, IBM
Carl Zeitler, Compaq
KC Chennappan, IBM
Bob Cornelius, ANCOR

Paul Rupert, LLNL Rich Taborak, NS Steve Wilson, Brocade Jerry Rouse, IBM Dal Allan, ENDL Hubert Huot, IBM

Venkat Rao, HP

Vincent Guan, Brocade Gavin Bowlby, Gadzoox

Jeff Meyer, HP

Martin Sachs, IBM
Beth Vanderbeck, IBM
Paul Griffiths, IBM
Jessie Haug, IBM
Lansing Sloan, LLNL
Rich Taborak, NSerial
Jerry Rouse, IBM
Hubert Huot, IBM

Amir Artsi, RADWAY International Ltd.

7. References

7.1. IETF References

- [1] Harrington, D., Presuhn, R. and B. Wijnen, "An Architecture for Describing SNMP Management Frameworks", RFC 2571, April 1999.
- [2] Rose, M. and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based Internets", STD 16, RFC 1155, May 1990.
- [3] Rose, M. and K. McCloghrie, "Concise MIB Definitions", STD 16, RFC 1212, March 1991.
- [4] Rose, M., "A Convention for Defining Traps for use with the SNMP", RFC 1215, March 1991.
- [5] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [6] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [7] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [8] Case, J., Fedor, M., Schoffstall, M. and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, May 1990.
- [9] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Introduction to Community-based SNMPv2", RFC 1901, January 1996.
- [10] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1906, January 1996.
- [11] Case, J., Harrington D., Presuhn R. and B. Wijnen, "Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)", RFC 2572, April 1999.
- [12] Blumenthal, U. and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", RFC 2574, April 1999.

- [13] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1905, January 1996.
- [14] Levi, D., Meyer, P. and B. Stewart, "SNMPv3 Applications", RFC 2573, April 1999.
- [15] Wijnen, B., Presuhn, R. and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", RFC 2575, April 1999.
- [16] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction to Version 3 of the Internet-standard Network Management Framework", RFC 2570, April 1999.

7.2. Approved ANSI/NCITS References

- [17] Fibre Channel Physical and Signaling Interface (FC-PH), American National Standard for Information Systems X3.230:1994, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [18] Fibre Channel Fabric Generic (FC-FG), American National Standard for Information Systems X3.289:1996, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [19] Fibre Channel Generic Services (FC-GS), American National Standard for Information Systems X3.288:1996, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [20] Fibre Channel Arbitrated Loop (FC-AL), American National Standard for Information Systems X3.272:1996, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [21] Fibre Channel Physical and Signaling Interface-2 (FC-PH-2), American National Standard for Information Systems, X3.297:1997, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [22] Fibre Channel Physical and Signaling Interface-3 (FC-PH-3), American National Standard for Information Systems, X3.303:1998, Computer and Business Equipment Manufacturers Association, Washington, DC.
- [23] Fibre Channel Switch Fabric (FC-SW), American National Standard for Information Systems, NCITS 321:1998, Computer and Business Equipment Manufacturers Association, Washington, DC.

Teow Standards Track [Page 46]

- 7.3. ANSI/NCITS References Under Development
 - [24] Fibre Channel Arbitrated Loop-2 (FC-AL-2), American National Standard for Information Systems, X3T11/1133D Rev 5.2, Computer and Business Equipment Manufacturers Association, Washington, DC.
- 8. Editor's Address

Kha Sin Teow Brocade Communications Systems, Inc. 1901 Guadalupe Parkway, San Jose, CA 95131 U.S.A.

Phone: +1 408-487-8180 Email: khasin@Brocade.COM

May 2000

9. Full Copyright Statement

RFC 2837

Copyright (C) The Internet Society (2000). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.