Network Working Group Request for Comments: 4233

Obsoletes: 3057

Category: Standards Track

K. Morneault
Cisco Systems
S. Rengasami
Tridea Works
M. Kalla
Telcordia Technologies
G. Sidebottom
Signatus Technologies
January 2006

Integrated Services Digital Network (ISDN) Q.921-User Adaptation Layer

Status of This Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2006).

Abstract

This document defines a protocol for backhauling of Integrated Services Digital Network (ISDN) Q.921 User messages over IP using the Stream Control Transmission Protocol (SCTP). This protocol would be used between a Signaling Gateway (SG) and Media Gateway Controller (MGC). It is assumed that the SG receives ISDN signaling over a standard ISDN interface.

This document obsoletes RFC 3057.

Table of Contents

1.	Introduction3
	1.1. Scope
	1.2. Terminology
	1.3. IUA Overview5
	1.4. Services Provided by the IUA Layer
	1.5. Functions Implemented by the IUA Layer10
	1.6. Definition of IUA Boundaries
2.	Conventions
3.	Protocol Elements
	3.1. Common Message Header
	3.2. IUA Message Header19
	3.3. IUA Messages
4.	Procedures
	4.1. Procedures to Support Service in Section 1.4.146
	4.2. Procedures to Support Service in Section 1.4.246
	4.3. Procedures to Support Service in Section 1.4.348
5.	Examples58
	5.1. Establishment of Association and Traffic between
	SGs and ASPs58
	5.2. ASP Traffic Fail-over Examples62
	5.3. Q.921/Q.931 Primitives Backhaul Examples63
	5.4. Layer Management Communication Examples64
6.	Security65
7.	IANA Considerations65
	7.1. SCTP Payload Protocol Identifier65
	7.2. IUA Protocol Extensions65
	Timer Values
9.	Acknowledgements67
10	. References67
	10.1. Normative References67
	10.2. Informative References67
11	. Change Log68
App	pendix A69
	A.1. Signaling Network Architecture69
	A.2. Application Server Process Redundancy70

1. Introduction

In this document, the term Q.921-User refers to an upper layer that uses the services of 0.921, not the user side of ISDN interface [1]. Examples of the upper layer would be Q.931 and QSIG.

This section describes the need for ISDN Q.921-User Adaptation (IUA) layer protocol as well as how this protocol shall be implemented.

1.1. Scope

There is a need for Switched Circuit Network (SCN) signaling protocol delivery from an ISDN Signaling Gateway (SG) to a Media Gateway Controller (MGC) as described in the Framework Architecture for

Signaling Transport [5]. The delivery mechanism SHOULD meet the following criteria:

- * Support for transport of the Q.921/Q.931 boundary primitives
- * Support for communication between Layer Management modules on SG
- * Support for management of SCTP active associations between SG and MGC

This document supports both ISDN Primary Rate Access (PRA) as well as Basic Rate Access (BRA) including the support for both point-to-point and point-to-multipoint modes of communication. This support includes Facility Associated Signaling (FAS), Non-Facility Associated Signaling (NFAS), and NFAS with backup D channel. QSIG adaptation layer requirements do not differ from Q.931 adaptation layer; hence, the procedures described in this document are also applicable for a QSIG adaptation layer. For simplicity, only Q.931 will be mentioned in the rest of this document.

1.2. Terminology

Application Server (AS) - A logical entity serving a specific application instance. An example of an Application Server is a MGC handling the Q.931 and call processing for D channels terminated by the Signaling Gateways. Practically speaking, an AS is modeled at the SG as an ordered list of one or more related Application Server Processes (e.g., primary, secondary, tertiary).

Application Server Process (ASP) - A process instance of an Application Server. Examples of Application Server Processes are primary or backup MGC instances.

Association - An association refers to an SCTP association. The association will provide the transport for the delivery of Q.921-User protocol data units and IUA adaptation layer peer messages.

Backhaul - A SG terminates the lower layers of an SCN protocol and backhauls the upper layer(s) to MGC for call processing. For the purposes of this document, the SG terminates Q.921 and backhauls Q.931 to MGC.

Fail-over - The capability to re-route signaling traffic as required between related ASPs in the event of failure or unavailability of the currently used ASP (e.g., from primary MGC to backup MGC). Fail-over also applies upon the return to service of a previously unavailable process.

Host - The computing platform that the ASP process is running on.

Interface - For the purposes of this document, an interface supports the relevant ISDN signaling channel. This signaling channel MAY be a 16-kbps D channel for an ISDN BRA as well as 64-kbps primary or backup D channel for an ISDN PRA. For QSIG, the signaling channel is a Qc channel.

Interface Identifier - The Interface Identifier identifies the physical interface at the SG for which the signaling messages are sent/received. The format of the Interface Identifier parameter can be text or integer, the values of which are assigned according to network operator policy. The values used are of local significance only, coordinated between the SG and ASP. Significance is not implied across SGs served by an AS.

Layer Management - Layer Management is a nodal function that handles the inputs and outputs between the IUA layer and a local management entity.

Network Byte Order - Most significant byte first, a.k.a big endian.

Stream - A stream refers to an SCTP stream: a uni-directional logical channel established from one SCTP endpoint to another associated SCTP endpoint, within which all user messages are delivered in sequence except for those submitted to the un-ordered delivery service.

Q.921-User - Any protocol normally using the services of the ISDN Q.921 (e.g., Q.931, QSIG, etc.).


1.3. IUA Overview

The architecture that has been defined [5] for SCN signaling transport over IP uses multiple components, including an IP transport protocol, a signaling common transport protocol, and an adaptation module to support the services expected by a particular SCN signaling protocol from its underlying protocol layer.

This document defines an adaptation module that is suitable for the transport of ISDN Q.921-User (e.g., Q.931) messages.

1.3.1. Example: SG to MGC

In a Signaling Gateway (SG), it is expected that the ISDN signaling is received over a standard ISDN network termination. The SG then provides interworking of transport functions with IP Signaling Transport, in order to transport the Q.931 signaling messages to the MGC where the peer Q.931 protocol layer exists, as shown below:



NIF - Nodal Interworking Function

EP - ISDN End Point

SCTP - Stream Control Transmission Protocol (Refer to [4,8])

IUA - ISDN User Adaptation Layer Protocol

Figure 1. IUA in the SG to MGC Application

It is recommended that the IUA use the services of the Stream Control Transmission Protocol (SCTP) as the underlying reliable common signaling transport protocol. The use of SCTP provides the following features:

explicit packet-oriented delivery (not stream-oriented)

- sequenced delivery of user messages within multiple streams, with an option for order-of-arrival delivery of individual user
- optional multiplexing of user messages into SCTP datagrams,
- network-level fault tolerance through support of multi-homing at either or both ends of an association,
- resistance to flooding and masquerade attacks, and
- data segmentation to conform to discovered path MTU size.

There are scenarios without redundancy requirements and scenarios in which redundancy is supported below the transport layer. In these cases, the SCTP functions above MAY be determined to not be required and TCP MAY be used as the underlying common transport protocol.

1.3.2. Support for the Management of SCTP Associations between the SG and ASPs

The IUA layer at the SG maintains the availability state of all dynamically registered remote ASPs, in order to manage the SCTP associations and the traffic between the SG and ASPs. As well, the active/inactive states of remote ASP(s) are maintained. Active ASPs are those currently receiving traffic from the SG.

The IUA layer MAY be instructed by local management to establish an SCTP association to a peer IUA node. This can be achieved using the M-SCTP ESTABLISH primitive to request, indicate, and confirm the establishment of an SCTP association with a peer IUA node.

The IUA layer MAY also need to inform local management of the status of the underlying SCTP associations using the M-SCTP STATUS request and indication primitive. For example, the IUA MAY inform local management of the reason for the release of an SCTP association, determined either locally within the IUA layer or by a primitive from the SCTP.

1.3.3. ASP Fail-over Model and Terminology

The IUA layer supports ASP fail-over functions in order to support a high availability of call processing capability. All Q.921-User messages incoming to an SG are assigned to a unique Application Server, based on the Interface Identifier of the message.

The Application Server is, in practical terms, a list of all ASPs configured to process Q.921-User messages from certain Interface Identifiers. One or more ASPs in the list are normally active (i.e., handling traffic) while any others MAY be unavailable or inactive, to be possibly used in the event of failure or unavailability of the active ASP(s).

The IUA layer supports an n+k redundancy model (active-standby, load sharing, broadcast) where n is the minimum number of redundant ASPs required to handle traffic and k ASPs are available to take over for a failed or unavailable ASP. Note that 1+1 active/standby redundancy is a subset of this model. A simplex 1+0 model is also supported as a subset, with no ASP redundancy.

1.3.4. Client/Server Model

It is recommended that the SG and ASP be able to support both client and server operation. The peer endpoints using IUA SHOULD be configured so that one always takes on the role of client and the other the role of server for initiating SCTP associations. The default orientation would be for the SG to take on the role of server while the ASP is the client. In this case, ASPs SHOULD initiate the SCTP association to the SG.

The SCTP and TCP Registered User Port Number Assignment for IUA is 9900.

1.4. Services Provided by the IUA Layer

1.4.1. Support for Transport of Q.921/Q.931 Boundary Primitives

In the backhaul scenario, the Q.921/Q.931 boundary primitives are exposed. IUA layer needs to support all of the primitives of this boundary to successfully backhaul Q.931.

This includes the following primitives [1]:

DL-ESTABLISH

The DL-ESTABLISH primitives are used to request, indicate, and confirm the outcome of the procedures for establishing multiple frame operation.

DL-RELEASE

DL-RELEASE primitives are used to request, indicate, and confirm the outcome of the procedures for terminating a previously established multiple frame operation, or for reporting an unsuccessful establishment attempt.

DL-DATA

The DL-DATA primitives are used to request and indicate layer 3 (Q.931) messages that are to be transmitted, or have been received, by the Q.921 layer using the acknowledged information transfer service.

DL-UNIT DATA

The DL-UNIT DATA primitives are used to request and indicate layer 3 (Q.931) messages that are to be transmitted, by the Q.921 layer using the unacknowledged information transfer service.

1.4.2. Support for Communication between Layer Management Modules on SG and MGC

It is envisioned that the IUA layer needs to provide some services that will facilitate communication between Layer Management modules on the SG and MGC. These primitives are shown below:

M-TEI STATUS

The M-TEI STATUS primitives are used to request, confirm, and indicate the status (assigned/unassigned) of an ISDN Terminal Endpoint Identifier (TEI).

M-ERROR

The M-ERROR primitive is used to indicate an error with a received IUA message (e.g., interface identifier value is not known to the SG).

1.4.3. Support for Management of Active Associations between SG and MGC

A set of primitives between the IUA layer and the Layer Management is defined below to help the Layer Management manage the SCTP association(s) between the SG and MGC. The IUA layer can be instructed by the Layer Management to establish an SCTP association to a peer IUA node. This procedure can be achieved using the M-SCTP ESTABLISH primitive.

M-SCTP ESTABLISH

The M-SCTP ESTABLISH primitives are used to request, indicate, and confirm the establishment of an SCTP association to a peer IUA node.

M-SCTP RELEASE

The M-SCTP RELEASE primitives are used to request, indicate, and confirm the release of an SCTP association to a peer IUA node.

The IUA layer MAY also need to inform the status of the SCTP associations to the Layer Management. This can be achieved using the M-SCTP STATUS primitive.

M-SCTP STATUS

The M-SCTP STATUS primitives are used to request and indicate the status of the underlying SCTP association(s).

The Layer Management MAY need to inform the IUA layer of an AS/ASP status (i.e., failure, active, etc.), so that messages can be exchanged between IUA layer peers to stop traffic to the local IUA user. This can be achieved using the M-ASP STATUS primitive.

M-ASP STATUS

The ASP status is stored inside IUA layer on both the SG and MGC sides. The M-ASP STATUS primitive can be used by Layer Management to request the status of the Application Server Process from the IUA layer. This primitive can also be used to indicate the status of the Application Server Process.

M-ASP-UP

The M-ASP-UP primitive can be used by Layer Management to send a ASP Up message for the Application Server Process. It can also be used to generate an ASP Up Acknowledgement.

M-ASP-DOWN

The M-ASP-DOWN primitive can be used by Layer Management to send a ASP Down message for the Application Server Process. It can also be used to generate an ASP Down Acknowledgement.

M-ASP-ACTIVE

The M-ASP-UP primitive can be used by Layer Management to send a ASP Active message for the Application Server Process. It can also be used to generate an ASP Active Acknowledgement.

M-ASP-INACTIVE

The M-ASP-UP primitive can be used by Layer Management to send a ASP Inactive message for the Application Server Process. It can also be used to generate an ASP Inactive Acknowledgement.

M-AS STATUS

The M-AS STATUS primitive can be used by Layer Management to request the status of the Application Server. This primitive can also be used to indicate the status of the Application Server.


1.5. Functions Implemented by the IUA Layer

1.5.1. Mapping

The IUA layer MUST maintain a map of the Interface Identifier to a physical interface on the Signaling Gateway. A physical interface would be a T1 line, E1 line, etc., and could include the Time-Division Multiplexing (TDM) timeslot. In addition, for a given interface the SG MUST be able to identify the associated signaling channel. IUA layers on both SG and MGC MAY maintain the status of ISDN Terminal Endpoint Identifiers (TEIs) and Service Access Point Identifiers (SAPIs).

The SG maps an Interface Identifier to an SCTP association/stream only when an ASP sends an ASP Active message for a particular Interface Identifier. It MUST be noted, however, that this mapping is dynamic and could change at any time due to a change of ASP state. This mapping could even temporarily be invalid, for example, during fail-over of one ASP to another. Therefore, the SG MUST maintain the states of AS/ASP and reference them during the routing of an messages to an AS/ASP.

One example of the logical view of relationship between D channel, Interface Identifier, AS, and ASP in the SG is shown below:



where IID = Interface Identifier

Note that an ASP can be in more than one AS.

1.5.2. Status of ASPs

The IUA layer on the SG MUST maintain the state of the ASPs it is supporting. The state of an ASP changes because of reception of peer-to-peer messages (ASPM messages as described in Section 3.3.2) or reception of indications from the local SCTP association. ASP state transition procedures are described in Section 4.3.1.

At a SG, an Application Server list MAY contain active and inactive ASPs to support ASP load-sharing and fail-over procedures. When, for example, both a primary and a backup ASP are available, IUA peer protocol is required to control which ASP is currently active. The ordered list of ASPs within a logical Application Server is kept updated in the SG to reflect the active Application Server Process(es).

Also the IUA layer MAY need to inform the local management of the change in status of an ASP or AS. This can be achieved using the M-ASP STATUS or M-AS STATUS primitives.

1.5.3. SCTP Stream Management

SCTP allows a user-specified number of streams to be opened during the initialization. It is the responsibility of the IUA layer to ensure proper management of these streams. Because of the unidirectional nature of streams, an IUA layer is not aware of the stream number to Interface Identifier mapping of its peer IUA layer. Instead, the Interface Identifier is in the IUA message header.

The use of SCTP streams within IUA is recommended in order to minimize transmission and buffering delay, therefore improving the overall performance and reliability of the signaling elements. It is recommended that a separate SCTP stream is used for each D channel.

1.5.4. Seamless Network Management Interworking

The IUA layer on the SG SHOULD pass an indication of unavailability of the IUA-User (0.931) to the local Layer Management, if the currently active ASP moves from the ACTIVE state. The Layer Management could instruct Q.921 to take some action, if it deems appropriate.

Likewise, if an SCTP association fails, the IUA layer on both the SG and ASP sides MAY generate Release primitives to take the data links out-of-service.

1.5.5. Congestion Management

If the IUA layer becomes congested (implementation dependent), it MAY stop reading from the SCTP association to flow control from the peer IUA.

1.6. Definition of IUA Boundaries

1.6.1. Definition of IUA/Q.921 Boundary

DL-ESTABLISH DL-RELEASE DL-DATA

DL-UNIT DATA

1.6.2. Definition of IUA/Q.931 Boundary

DL-ESTABLISH DL-RELEASE DL-DATA DL-UNIT DATA

1.6.3. Definition of SCTP/IUA Boundary

An example of the upper layer primitives provided by SCTP are available in Section 10 of RFC 2960 [4].

1.6.4. Definition of IUA/Layer-Management Boundary

M-SCTP ESTABLISH request Direction: LM -> IUA

Purpose: LM requests ASP to establish an SCTP association with an SG.

M-STCP ESTABLISH confirm Direction: IUA -> LM

Purpose: ASP confirms to LM that it has established an SCTP association with an SG.

M-SCTP ESTABLISH indication

Direction: IUA -> LM

Purpose: SG informs LM that an ASP has established an SCTP association.

M-SCTP RELEASE request Direction: LM -> IUA

Purpose: LM requests ASP to release an SCTP association with SG.

M-SCTP RELEASE confirm Direction: IUA -> LM

Purpose: ASP confirms to LM that it has released SCTP association

with SG.

M-SCTP RELEASE indication Direction: IUA -> LM

Purpose: SG informs LM that ASP has released an SCTP association.

M-SCTP STATUS request Direction: LM -> IUA

Purpose: LM requests IUA to report status of SCTP association.

M-SCTP STATUS indication Direction: IUA -> LM

Purpose: IUA reports status of SCTP association.

M-ASP STATUS request Direction: LM -> IUA

Purpose: LM requests SG to report status of remote ASP.

M-ASP STATUS indication Direction: IUA -> LM

Purpose: SG reports status of remote ASP.

M-AS-STATUS request Direction: LM -> IUA

Purpose: LM requests SG to report status of AS.

M-AS-STATUS indication Direction: IUA -> LM

Purpose: SG reports status of AS.

M-NOTIFY indication Direction: IUA -> LM

Purpose: ASP reports that it has received a NOTIFY message

from its peer.

M-ERROR indication Direction: IUA -> LM

Purpose: ASP or SG reports that it has received an ERROR

message from its peer.

M-ASP-UP request Direction: LM -> IUA

Purpose: LM requests ASP to start its operation and send an ASP UP

message to the SG.

M-ASP-UP confirm Direction: IUA -> LM

Purpose: ASP reports that is has received an ASP UP Acknowledgement

message from the SG.

M-ASP-DOWN request Direction: LM -> IUA

Purpose: LM requests ASP to stop its operation and send an ASP DOWN

message to the SG.

M-ASP-DOWN confirm Direction: IUA -> LM

Purpose: ASP reports that is has received an ASP DOWN

Acknowledgement message from the SG.

M-ASP-ACTIVE request Direction: LM -> IUA

Purpose: LM requests ASP to send an ASP ACTIVE message to the SG.

M-ASP-ACTIVE confirm Direction: IUA -> LM

Purpose: ASP reports that is has received an ASP ACTIVE

Acknowledgement message from the SG.

M-ASP-INACTIVE request Direction: LM -> IUA

Purpose: LM requests ASP to send an ASP INACTIVE message to the SG.

M-ASP-INACTIVE confirm Direction: IUA -> LM

Purpose: ASP reports that is has received an ASP INACTIVE

Acknowledgement message from the SG.

M-TEI STATUS request Direction: LM -> IUA

Purpose: LM requests ASP to send a TEI status request to the SG.

M-TEI STATUS indication Direction: IUA -> LM

Purpose: ASP reports that is has received a TEI status indication

from the SG.

M-TEI STATUS confirm Direction: IUA -> LM

Purpose: ASP reports that is has received a TEI status confirm from

2. Conventions

The keywords MUST, MUST NOT, REQUIRED, SHALL, SHALL NOT, SHOULD, SHOULD NOT, RECOMMENDED, NOT RECOMMENDED, MAY, and OPTIONAL, when they appear in this document, are to be interpreted as described in [6].

3. Protocol Elements

This section describes the format of various messages used in this protocol.

3.1. Common Message Header

The protocol messages for Q.921-User Adaptation require a message header that contains the adaptation layer version, the message type, and message length.




Figure 2. Common Header Format

All fields in an IUA message MUST be transmitted in the network byte order, unless otherwise stated.

3.1.1. Version

The version field contains the version of the IUA adaptation layer. The supported versions are the following:

Value	Version	
1	Release	1.0

3.1.2. Message Classes and Types

The following list contains the valid Message Classes:

Message Class: 8 bits (unsigned integer)

- Management (MGMT) Message
- 1 Reserved for Other SIGTRAN Adaptation Layer
- Reserved for Other SIGTRAN Adaptation Layers
- ASP State Maintenance (ASPSM) Messages
- ASP Traffic Maintenance (ASPTM) Messages
- Q.921/Q.931 Boundary Primitives Transport (QPTM) Messages
- Reserved for Other SIGTRAN Adaptation Layer
- 7 Reserved for Other SIGTRAN Adaptation Layer
- Reserved for Other SIGTRAN Adaptation Layer
- 9 to 127 Reserved by the IETF
- 128 to 255 Reserved for IETF-Defined Message Class extensions

The following list contains the message names for the defined messages.

Q.921/Q.931 Boundary Primitives Transport (QPTM) Messages

- 0 Reserved
- 1 Data Request Message
- Data Indication Message 2
- 3 Unit Data Request Message
- 4 Unit Data Indication Message
- 5 Establish Request
- Establish Confirm
- 7 Establish Indication
- Release Request 8
- 9 Release Confirm
- 10 Release Indication
- 11 to 127 Reserved by the IETF
- 128 to 255 Reserved for IETF-Defined QPTM extensions

Application Server Process State Maintenance (ASPSM) messages

- Reserved
- 1 ASP Up (UP)
- ASP Down (DOWN)
- Heartbeat (BEAT)
- 4 ASP Up Ack (UP ACK)
- ASP Down Ack (DOWN ACK)
- Heatbeat Ack (BEAT ACK)
- 7 to 127 Reserved by the IETF
- 128 to 255 Reserved for IETF-Defined ASPSM extensions

Application Server Process Traffic Maintenance (ASPTM) messages

- Reserved ASP Active (ACTIVE) 1 ASP Inactive (INACTIVE) ASP Active Ack (ACTIVE ACK) ASP Inactive Ack (INACTIVE ACK) 5 to 127 Reserved by the IETF
- 128 to 255 Reserved for IETF-Defined ASPTM extensions

Management (MGMT) Messages

0 Error (ERR) Notify (NTFY) 1 TEI Status Request TEI Status Confirm TEI Status Indication TEI Query Request 6 to 127 Reserved by the IETF 128 to 255 Reserved for IETF-Defined MGMT extensions

3.1.3. Reserved

The Reserved field is 8 bits. It SHOULD be set to all '0's and ignored by the receiver.

3.1.4. Message Length

The Message Length defines the length of the message in octets, including the Common Header. The Message Length MUST include parameter padding bytes, if any.

Note: A receiver SHOULD accept the message whether or not the final parameter padding is included in the message length.

3.1.5. Variable-Length Parameter Format

IUA messages consist of a Common Header followed by zero or more variable-length parameters, as defined by the message type. The variable-length parameters contained in a message are defined in a Type-Length-Value (TLV) format as shown below.

0 1	2	3
0 1 2 3 4 5 6 7 8 9 0 1 2 3 4	5 6 7 8 9 0 1 2 3 4 5 6 7	8 9 0 1
+-	-+	-+-+-+
Parameter Tag	Parameter Length	
+-	-+	-+-+-+
\		\
/ Paramet	er Value	/
\		\
+-	-+	-+-+-+

Mandatory parameters MUST be placed before optional parameters in a message.

Parameter Tag: 16 bits (unsigned integer)

The Tag field is a 16-bit identifier of the type of parameter. It takes a value of 0 to 65534. Common parameters used by adaptation layers are in the range of 0x00 to 0x3f. The parameter Tags defined are as follows:

Common Parameters. These TLV parameters are common across the different adaptation layers:

Parameter Name	Parameter ID					
=========	========					
Reserved	$0 \times 0 0 0 0$					
Interface Identifier (integer)	0×0001					
Not Used in IUA	0×0002					
Interface Identifier (text)	0×0003					
INFO String	$0 \times 0 0 0 4$					
DLCI	0×0005					
Not Used in IUA	0×0006					
Diagnostic Information	0×0007					
Interface Identifier Range	0x0008					
Heartbeat Data	0×0009					
Not Used in IUA	0x000a					
Traffic Mode Type	0x000b					
Error Code	0x000c					
Status	0x000d					
Protocol Data	0x000e					
Release Reason	0x000f					
TEI Status	0×0010					
ASP Identifier	0×0011					
Not Used in IUA	$0 \times 0012 - 0 \times 003f$					

The value of 65535 is reserved for IETF-defined extensions. Values other than those defined in specific parameter description are reserved for use by the IETF.

Parameter Length: 16 bits (unsigned integer)

The Parameter Length field contains the size of the parameter in bytes, including the Parameter Tag, Parameter Length, and Parameter Value fields. The Parameter Length does not include any padding bytes.

Parameter Value: variable-length

The Parameter Value field contains the actual information to be transferred in the parameter.

The total length of a parameter (including Tag, Parameter Length, and Value fields) MUST be a multiple of 4 bytes. If the length of the parameter is not a multiple of $4\ \text{bytes}$, the sender pads the Parameter at the end (i.e., after the Parameter Value field) with all zero bytes. The length of the padding is NOT included in the Parameter Length field. A sender SHOULD NEVER pad with more than 3 bytes. The receiver MUST ignore the padding bytes.

3.2. IUA Message Header

In addition to the common message header, there will be a specific message header for QPTM and the TEI Status MGMT messages. The IUA message header will immediately follow the Common header in these messages.

This message header will contain the Interface Identifier and Data Link Connection Identifier (DLCI). The Interface Identifier identifies the physical interface terminating the signaling channel at the SG for which the signaling messages are sent/received. The format of the Interface Identifier parameter can be text or integer. The Interface Identifiers are assigned according to network operator policy. The integer values used are of local significance only, coordinated between the SG and ASP.

The integer-formatted Interface Identifier MUST be supported. The text-formatted Interface Identifier MAY optionally be supported.

0	1	2	3
0 1 2 3 4 5 6 7 8	9 0 1 2 3 4 5	6 7 8 9 0 1 2	3 4 5 6 7 8 9 0 1
+-+-+-+-+-+-+-+	-+-+-+-+-		-+-+-+-+-+-+-+
Tag (0x	1)	L	ength
+-+-+-+-+-+-+-+-+	-+-+-+-		-+-+-+-+-+-+-+
I	nterface Ident	tifier (integer)
+-+-+-+-+-+-+-+-+	-+-+-+-		-+-+-+-+-+-+-+
Tag (0x	5)	L	ength=8
+-+-+-+-+-+-+-+	-+-+-+-		-+-+-+-+-+-+-+
DLCI			Spare
+-+-+-+-+-+-+-+	-+-+-+-+-+-		-+-+-+-+-+-+-+

Figure 3. IUA Message Header (Integer-based Interface Identifier)

The Tag value for the Integer-based Interface Identifier is 0x1. The length is always set to a value of 8.




Figure 4. IUA Message Header (Text-based Interface Identifier)

The Tag value for the Text-based [2] Interface Identifier is 0x3. The length is variable.

The DLCI format is shown below in Figure 5.




Figure 5. DLCI Format

SPR: Spare 2nd bit in octet 1 (1 bit)

SAPI: Service Access Point Identifier (6 bits)

TEI: Terminal Endpoint Identifier (7 bits)

As an example, SAPI = 0, TEI = 64, SPR = 0 would be encoded as follows:

+-+-+		-+-+-+-	+-+-+-	-+-+-+-	+-
	Τá	ag (0x5)			Length=8
+-+-+	-+-+-+-	-+-+-+-	+-+-+-	-+-+-	+-
	0x0		0x81		0x0
+-+-+	-+-+-+-	-+-+-+-	+-+-+-	-+-+-	+-

The DLCI field (including the SAPI and TEI) is coded in accordance with Q.921.

3.3. IUA Messages

The following section defines the messages and parameter contents. The IUA messages will use the common message header (Figure 2) and the IUA message header (Figure 3 and Figure 4).

3.3.1. Q.921/Q.931 Boundary Primitives Transport (QPTM) Messages

3.3.1.1. Establish Messages (Request, Confirm, Indication)

The Establish Messages are used to establish a data link on the signaling channel or to confirm that a data link on the signaling channel has been established. The MGC controls the state of the D channel. When the MGC desires the D channel to be in-service, it will send the Establish Request message.

When the MGC sends an IUA Establish Request message, the MGC MAY start a timer. This timer would be stopped upon receipt of an IUA Establish Confirm or Establish Indication. If the timer expires, the MGC would resend the IUA Establish Request message and restart the timer. In other words, the MGC MAY continue to request the establishment of the data link on a periodic basis until the desired state is achieved or take some other action (notify the Management Layer).

When the SG receives an IUA Establish Request from the MGC, the SG shall send the Q.921 Establish Request primitive to the Q.921 entity. In addition, the SG shall map any response received from the Q.921 entity to the appropriate message to the MGC. For example, if the Q.921 entity responds with a Q.921 Establish Confirm primitive, the

IUA layer shall map this to an IUA Establish Confirm message. As another example, if the IUA Layer receives a Q.921 Release Confirm or Release Indication as an apparent response to the Q.921 Establish Request primitive, the IUA Layer shall map these to the corresponding IUA Release Confirm or Release Indication messages.

The Establish messages contain the common message header followed by IUA message header. It does not contain any additional parameters.

3.3.1.2. Release Messages (Request, Indication, Confirmation)

The Release Request message is used to release the data link on the signaling channel. The Release Confirm and Indication messages are used to indicate that the data link on the signaling channel has been released.

If a response to the Release Request message is not received, the MGC MAY resend the Release Request message. If no response is received, the MGC can consider the data link as being released. In this case, signaling traffic on that D channel is not expected from the SG and signaling traffic will not be sent to the SG for that D channel.

The Release messages contain the common message header followed by IUA message header. The Release Confirm message is in response to a Release Request message and it does not contain any additional parameters. The Release Request and Indication messages contain the following parameter:

Reason

The format for Release Message parameters is as follows:

0										1										2										3	
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0	1
+	+-+	-	+	+	+	+	+	+	+	+	+ - -	- - +	 -	+	+	+	+	+	+	+	+	 -	+	+	+	+	+	+	+	-	+-+
					5	Га	3	(02	кf)												Ι	Ler	ngt	:h						
+	+-+	- - +	+	+	+	+	+	+	+	+	-	- - +	⊢ – -	+	+	+	-	+	+	+	+	- -	+	+	+	+	+	+	+	- - +	+-+
															Re	eas	soi	ı													
+	+-+	- - +	+	+	+	+	+	+	+	+	-	H — H	 -	+	+	+	 	+	+	+	+	 -	+	+	+	+	+	+	 	- - +	+-+

The valid values for Reason are shown in the following table.

Define	Value	Description
RELEASE_MGMT	0x0	Management layer generated release.
RELEASE_PHYS	0x1	Physical layer alarm generated release.
RELEASE_DM	0x2	Specific to a request. Indicates Layer 2
		SHOULD release and deny all requests from
		far end to establish a data link on the
		signaling channel (i.e., if SABME is
		received, send a DM)
RELEASE OTHER	0x3	Other reasons

Note: Only RELEASE_MGMT, RELEASE_DM, and RELEASE_OTHER are valid reason codes for a Release Request message.


3.3.1.3. Data Messages (Request, Indication)

The Data message contains an ISDN Q.921-User Protocol Data Unit (PDU) corresponding to acknowledged information transfer service.

The Data messages contain the common message header followed by IUA message header. The Data message contains the following parameter:

Protocol Data

The format for Data Message parameters is as follows:



The protocol data contains upper layer signaling message, e.g., Q.931, QSIG.

3.3.1.4. Unit Data Messages (Request, Indication)

The Unit Data message contains an ISDN Q.921-User Protocol Data Unit (PDU) corresponding to unacknowledged information transfer service.

The Unit Data messages contain the common message header followed by IUA message header. The Unit Data message contains the following parameter:

Morneault, et al. Standards Track

[Page 23]

Protocol Data

The format for Unit Data Message parameters is as follows:

0	1	2		3
0 1 2 3 4 5 6 7 8 9	0 1 2 3 4 5	6 7 8 9 0 1	2 3 4 5 6 7	8 9 0 1
+-+-+-+-+-+-+-+-+-+	+-+-+-	+-+-+-+-+-+	-+-+-+-	+-+-+-+
Tag (0xe)			Length	-
+-	+-+-+-	+-+-+-+-+	-+-+-+-+-	+-+-+-+
\				\
/	Protoco	l Data		/
\				\
+-	+-+-+-	+-+-+-+-+	-+-+-+-+-	+-+-+-+

3.3.2. Application Server Process Maintenance (ASPM) Messages

The ASPM messages will use only the common message header.


3.3.2.1. ASP Up (ASPUP)

The ASP Up (ASPUP) message is sent by an ASP to indicate to an SG that it is ready to receive traffic or maintenance messages.

The ASPUP message contains the following parameters:

```
ASP Identifier
                      (Optional)
INFO String
                      (Optional)
```

The format for ASPUP Message parameters is as follows:



ASP Identifier: 32-bit unsigned integer

The optional ASP Identifier parameter contains a unique value that is locally significant among the ASPs that support an AS. The SG should save the ASP Identifier to be used, if necessary, with the Notify message (see Section 3.3.3.2).

The optional INFO String parameter can carry any meaningful 8-bit ASCII [2] character string along with the message. Length of the INFO String parameter is from 0 to 255 characters. No procedures are presently identified for its use, but the INFO String MAY be used for debugging purposes.


3.3.2.2. ASP Up Ack

The ASP Up Ack message is used to acknowledge an ASP Up message received from a remote IUA peer.

The ASPUP Ack message contains the following parameters:

```
INFO String (optional)
```

The format for ASPUP Ack Message parameters is as follows:



The format and description of the optional INFO String parameter are the same as for the ASP Up message (see Section 3.3.2.1).


3.3.2.3. ASP Down (ASPDN)

The ASP Down (ASPDN) message is sent by an ASP to indicate to an SG that it is NOT ready to receive traffic or maintenance messages.

The ASPDN message contains the following parameters:

INFO String (Optional)

The format for the ASPDN message parameters is as follows:



The format and description of the optional INFO String parameter are the same as for the ASP Up message (see Section 3.3.2.1).


3.3.2.4. ASP Down Ack

The ASP Down Ack message is used to acknowledge an ASP Down message received from a remote IUA peer.

The ASP Down Ack message contains the following parameters:

```
INFO String (Optional)
```

The format for the ASP Down Ack message parameters is as follows:



The format and description of the optional INFO String parameter are the same as for the ASP Up message (see Section 3.3.2.1).

3.3.2.5. ASP Active (ASPAC)

The ASPAC message is sent by an ASP to indicate to an SG that it is Active and ready to be used.

The ASPAC message contains the following parameters:

Traffic Mode Type (Mandatory) Interface Identifiers (Optional) - Combination of integer and integer ranges, OR - string (text-formatted) INFO String (Optional)

The format for the ASPAC message using integer-formatted Interface Identifiers is as follows:

0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5	6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1					
Tag = $0x000b$	Length = 8					
Traffic Mod						
Tag (0x1=integer)	Length					
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-						
Tag (0x8=integer range)	Length					
Interface Ident	cifier Start1*					
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-						
Interface Ident						
Interface Iden						
\ / Additional Interface \ of Tag Type 02	e Identifier Parameters / x1 or 0x8 \					
Tag (0x4)						
/ INFO St	\					

The format for the ASPAC message using text-formatted (string) Interface Identifiers is as follows:

0	1 2 3	
. 0	1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0	1.
	Tag = 0x000b Length = 8	
+	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	
	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	
/	Interface Identifiers	/ / /
\ / \ /	Additional Interface Identifier Parameters of Tag Type 0x3	\ / \ /
	Tag (0x4) Length	
\ / \	INFO String	r-+ \ / \

The Traffic Mode Type parameter identifies the traffic mode of operation of the ASP within an AS. The valid values for Type are shown in the following table:

Value	Description
0x1	Over-ride
0x2	Load-share

Within a particular AS, only one Traffic Mode Type can be used. Over-ride value indicates that the ASP is operating in Over-ride mode, where the ASP takes over all traffic in an Application Server (i.e., primary/backup operation), over-riding any currently active ASPs in the AS. In Load-share mode, the ASP will share in the traffic distribution with any other currently active ASPs.

The optional Interface Identifiers parameter contains a list of Interface Identifier integers (Type 0x1 or Type 0x8) or text strings (Type 0x3) indexing the Application Server traffic that the sending ASP is configured/registered to receive. If integer-formatted

Interface Identifiers are being used, the ASP can also send ranges of Interface Identifiers (Type 0x8). Interface Identifier types Integer (0x1) and Integer Range (0x8) are allowed in the same message. Text-formatted Interface Identifiers (0x3) cannot be used with either Integer (0x1) or Integer Range (0x8) types.

If no Interface Identifiers are included, the message is for all provisioned Interface Identifiers within the AS or ASes in which the ASP is provisioned. If only a subset of Interface Identifiers is included, the ASP is noted as Active for all the Interface Identifiers provisioned for that AS.

Note: If the optional Interface Identifier parameter is present, the integer-formatted Interface Identifier MUST be supported, whereas the text-formatted Interface Identifier MAY be supported.

The format and description of the optional INFO String parameter are the same as for the ASP Up message (see Section 3.3.2.1.).

An SG that receives an ASPAC with an incorrect Traffic Mode Type for a particular Interface Identifier will respond with an Error Message (Cause: Unsupported Traffic Handling Mode).

3.3.2.6. ASP Active Ack

The ASPAC Ack message is used to acknowledge an ASP Active message received from a remote IUA peer.

The ASPAC Ack message contains the following parameters:

Traffic Mode Type (Mandatory) Interface Identifier (Optional) - Combination of integer and integer ranges, OR - string (text formatted) INFO String (Optional)

The format for the ASPAC Ack message with integer-formatted Interface Identifiers is as follows:

	2 3 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1					
Tag = 0x000b	Length = 8					
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-						
Tag (0x1=integer)	Length					
\ / Interface I	\ / / Interface Identifiers /					
Tag (0x8=integer range)	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-					
Interface Ident	tifier Start1*					
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-						
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-						
· ·	· · 					
Interface Ident	· ·					
Interface Identifier StopN*						
<pre></pre>						
Tag (0x4)	 Length +					
/ INFO St	\					

The format for the ASP Active Ack message using text-formatted (string) Interface Identifiers is as follows:

0 1 2 3 4 5 6 7 8 9 0) 1 2 3 4 5			
Tag = 0x000k		+-+-+-+ 	Length = 8	-+-+-+-+
	Traffic Mo	de Type	-+-+-+-+	
Tag (0x3=strir	ng)		Length	
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-		Identifiers		\ / \
Additional	of Tag Ty			\ / \
Tag (0x4)	-+-+-+-+-	+-+-+-+	-+-+-+-+ Length	
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	INFO S	J	-+-+-+-+	/

The format of the Traffic Mode Type and Interface Identifier parameters is the same as for the ASP Active message (see Section 3.3.2.5).

The format and description of the optional INFO String parameter are the same as for the ASP Up message (see Section 3.3.2.1).

3.3.2.7. ASP Inactive (ASPIA)

The ASPIA message is sent by an ASP to indicate to an SG that it is no longer an active ASP to be used from within a list of ASPs. The SG will respond with an ASPIA Ack message and either discard incoming messages or buffer for a timed period and then discard.

The ASPIA message contains the following parameters:

Interface Identifiers (Optional)

- Combination of integer and integer ranges, OR
- string (text formatted)

INFO String (Optional)

The format for the ASP Inactive message parameters using integerformatted Interface Identifiers is as follows:

	0		1							2							3	
	0 1	2 3 4 5 6 7	7890	1	2 3	4	5 6	. 7 	8 9	0 :	1 2	3 4	ł 5	6 7	_			1
	++	Tag (0x1=:	-+-+-+- integer -+-+-+-		+	+-+		+-+	_+-	+-+		+-+- engt +-+-		+-+-	.+			_+
. \ / \ +			-+-+-	Int	erfa	ace	Ide	ent	ifi	ers								\ /
		Tag (0x8=ir	_		J ,							engt						
			Inte	rfa	ice :	Ide	nti	fie	r S	tar	t1*							
+	-+-+	+-+-+-+-	-+-+- Int		ace							+-+-	-+-	+-+-	+	+	+	-+
+	-+-+	+-+-+-+-	-+-+- Inte										+-	+-+-	+	+	+-+	-+
+	-+-+	+-+-+-+-	-+-+-	+-+	+	+-+	-+-	+-+	-+-	+-+	-+-	+-+-	+-	+-+-	+	+	+	-+
		+-+-+-+-			ace						-							
+			-+-+-															
İ			Inte															i
+	-+-+	+-+-+-+-	-+-+-+- Int		ace								+-	+-+-	+	+	+-+	-+
+ \ / / \	-+-+		-+-+-+- ditiona of	.1 I		rfa	.ce :	Ide:	nti	fie					+	+	+	-+ \ / \
/	_+_+	+-+-+-+-	-+-+-+-								-+-	+-+-	-+-	+-+-	.+	+	⊦ – +	/ -+
	-+-+	Tag ((0x4)									Leng	jth		. +	· +	· ·	
\ / / +	-+-+	+-+-+-+-	-+-+-+	.+-+			Str		-+-		-+-	+-+-	-+-	+-+-	+	+	. T	\ / \ -+

The format for the ASP Inactive message using text-formatted (string) Interface Identifiers is as follows:

0 1		2	3
0 1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9	0 1 2 3 4 5 6 7	8 9 0 1
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-	+-+-+-+-+-+-+	-+-+-+
Tag (0x3=string	3)	Length	
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+-+	+-+-+-+-+-+-+-+	-+-+-+
\			\
/	Interface Identifie	ers	/
\			\
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+-+	+-+-+-+-+-+-+	-+-+-+
\			\
/ Additional	Interface Identifi	ier Parameters	/
\	of Tag Type 0x3		\
/			/
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-	+-+-+-+-+-+-+	-+-+-+
Tag (0x4)		Length	
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+-+	+-+-+-+-+-+-+	-+-+-+
\			\
/	INFO String		/
\			\
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+	+-+-+-+-+-+	-+-+-+

The optional Interface Identifiers parameter contains a list of Interface Identifier integers or text strings indexing the Application Server traffic that the sending ASP is configured/registered to receive, but does not want to receive at this time.

The format and description of the optional Interface Identifiers and INFO String parameters are the same as for the ASP Active message (see Section 3.3.2.5).

3.3.2.8. ASP Inactive Ack

The ASP Inactive (ASPIA) Ack message is used to acknowledge an ASP Inactive message received from a remote IUA peer.

The ASPIA Ack message contains the following parameters:

```
Interface Identifiers (Optional)
  - Combination of integer and integer ranges, OR
  - string (text formatted)
INFO String (Optional)
```

The format for the ASP Inactive Ack message parameters using integer-formatted Interface Identifiers is as follows:

0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2	3 4 5 6 7 8 9 0 1
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+-+ ength
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+ \ / \
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	ength
Interface Identifier Start1*	1
Interface Identifier Stop1*	1
Interface Identifier Start2*	 +-+-+-+-+-+-+-+-+
Interface Identifier Stop2* +-+-+	+-+-+-+-+-+-+-+-+-+-+-+-+-+++
Interface Identifier StartN*	+-+-+-+-+-+-+-+-+
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	1
\ / Additional Interface Identifier P \ of Tag Type 0x1 or 0x8 /	arameters /
	Length
+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-

The format for the ASP Inactive Ack message using text-formatted (string) Interface Identifiers is as follows:

0 1		2		3
0 1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7	8 9 0 1 2 3	4 5 6 7 8	9 0 1
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+	-+-+-+-+-+	-+-+-+-	+-+-+
Tag (0x3=string	3)	Leng	th	
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+	-+-+-+-+-+	-+-+-+-	+-+-+
\				\
/	Interface Ident	ifiers		/
\				\
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+	-+-+-+-+-+	-+-+-+-	+-+-+
\				\
/ Additional	Interface Iden	tifier Param	eters	/
\	of Tag Type 0x	3		\
/				/
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+	-+-+-+-+-+	-+-+-+-	+-+-+
Tag (0x4)		Len	gth	
+-+-+-+-+-+-+-+-+-	+-+-+-+-+-+	-+-+-+-+-+	-+-+-+-	+-+-+
\				\
/	INFO String			/
\				\
+-+-+-+-+-+-+-+-+-	+-+-+-+-+	-+-+-+-+	-+-+-+-	+-+-+

The format and description of the optional Interface Identifiers and INFO String parameters are the same as for the ASP Active message (see Section 3.3.2.5).

3.3.2.9. Heartbeat (BEAT)

The Heartbeat message is optionally used to ensure that the ${\tt IUA}$ peers are still available to each other. It is recommended for use when the IUA runs over a transport layer other than the SCTP, which has its own heartbeat.

The BEAT message contains the following parameters:

Heartbeat Data (Optional)

The format for the BEAT message is as follows:

0	1	2	2	3
0 1 2 3 4 5	6 7 8 9 0 1 2 3 4	5 6 7 8 9 0	0 1 2 3 4 5 6	7 8 9 0 1
+-+-+-+-	+-+-+-+-+-+-+-+	+-+-+-+-+-	-+-+-+-+-+-	
Ta	g = 0x0009		Length	
+-+-+-+-	+-+-+-+-+-+-+-+	+-+-+-+-	-+-+-+-+-+	+-+-+-+-+
\				\
/	Heartbe	eat Data		/
\				\

The Heartbeat Data parameter contents are defined by the sending node. The Heartbeat Data could include, for example, a Heartbeat Sequence Number and/or Timestamp. The receiver of a Heartbeat message does not process this field as it is only of significance to the sender. The receiver MUST respond with a Heartbeat Ack message.

3.3.2.10. Heartbeat Ack (BEAT-Ack)

The Heartbeat Ack message is sent in response to a received Heartbeat message. It includes all the parameters of the received Heartbeat message, without any change.

3.3.3. Layer Management (MGMT) Messages

3.3.3.1. Error (ERR)

The Error message is used to notify a peer of an error event associated with an incoming message. For example, the message type might be unexpected given the current state, or a parameter value might be invalid.

The Error message will have only the common message header. The Error message contains the following parameters:

Error Code Diagnostic Information (Optional)

0	1	2	3
0 1 2	3 4 5 6 7 8 9 0 1 2 3 4	5 6 7 8 9 0 1 2 3	4 5 6 7 8 9 0 1
+-+-+	+-+-+-+-+-+-+-+-+-+-+-+-+	-+-+-+-+-	+-+-+-+-+-+-+
	Tag = 0x000c	Lengtl	h = 8
+-+-+	+-+-+-+-+-+-+-+-+-+-+-+-+-+	-+-+-+-+-+-+-	+-+-+-+-+-+-+
	Erro	r Code	
+-+-+	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+		
	Tag = 0x0007	Leng	J 1
+-+-+-+	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+	-+-+-+-+-+-+-	+-+-+-+-+-+-+-+
\		- 6	/
/	Diagnosti	c Information	\
\			/
+-+-+-+	t-+-+-+-+-+-+-+-+-+-+-+	-+-+-+-+-+-+-	+-+-+-+-+-+-+

The Error Code parameter indicates the reason for the Error message. The Error parameter value can be one of the following values:

Invalid Version	0x01
Invalid Interface Identifier	0×02
Unsupported Message Class	0x03
Unsupported Message Type	0×04
Unsupported Traffic Handling Mode	0x05
Unexpected Message	0x06
Protocol Error	0x07
Unsupported Interface Identifier Type	0x08
Invalid Stream Identifier	0x09
Unassigned TEI	0x0a
Unrecognized SAPI	0x0b
Invalid TEI, SAPI combination	0x0c
Refused - Management Blocking	0x0d
ASP Identifier Required	0x0e
Invalid ASP Identifier	0x0f

The "Invalid Version" error would be sent if a message was received with an invalid or unsupported version. The Error message would contain the supported version in the Common header. The Error message could optionally provide the supported version in the Diagnostic Information area.

The "Invalid Interface Identifier" error would be sent by an SG if an ASP sends a message with an invalid (unconfigured) Interface Identifier value. For this error, the Diagnostic Information MUST contain enough of the offending message to identify the invalid Interface Identifier. For example, in the case of QPTM and TEI Status management messages, the Common and IUA message headers of the offending message would be placed in the Diagnostic Information at a minimum.

The "Unsupported Traffic Handling Mode" error would be sent by an SG if an ASP sends an ASP Active with an unsupported Traffic Handling Mode. An example would be a case in which the SG did not support load-sharing.

The "Unexpected Message" error would be sent by an ASP if it received a QPTM message from an SG while it was in the Inactive state (the ASP could optionally drop the message and not send an error). It would also be sent by an ASP if it received a defined and recognized message that the SG is not expected to send (e.g., if the MGC receives an IUA Establish Request message).

The "Protocol Error" error would be sent for any protocol anomaly (i.e., a bogus message).

The "Invalid Stream Identifier" error would be sent if a message was received on an unexpected SCTP stream (e.g., a MGMT message was received on a stream other than "0").

The "Unsupported Interface Identifier Type" error would be sent by an SG if an ASP sends a text-formatted Interface Identifier and the SG only supports integer-formatted Interface Identifiers. When the ASP receives this error, it will need to resend its message with an integer-formatted Interface Identifier.

The "Unsupported Message Type" error would be sent if a message with an unexpected or unsupported Message Type is received.

The "Unsupported Message Class" error would be sent if a message with an unexpected or unsupported Message Class is received.

The "Unassigned TEI" error may be used when the SG receives an IUA message that includes a TEI that has not been assigned or recognized for use on the indicated ISDN D-channel.

The "Unrecognized SAPI" error would handle the case of using an SAPI that is not recognized by the SG. The "Invalid TEI, SAPI combination" error identifies errors where the TEI is assigned and the SAPI is recognized, but the combination is not valid for the interface (e.g., on a Basic Rate Interface (BRI), the MGC tries to send Q.921 Management messages via IUA when Layer Management at the SG SHOULD be performing this function).

The "Refused - Management Blocking" error is sent when an ASP Up or ASP Active message is received and the request is refused for management reasons (e.g., management lockout).

The "ASP Identifier Required" is sent by an SG in response to an ASP Up message that does not contain an ASP Identifier parameter when the SG requires one. The ASP SHOULD resend the ASP Up message with an ASP Identifier.

The "Invalid ASP Identifier" is sent by a SG in response to an ASP Up message with an invalid (i.e., non-unique) ASP Identifier.

Diagnostic Information: variable length

When included, the optional Diagnostic information can be any information germane to the error condition, to assist in identification of the error condition. The Diagnostic information SHOULD contain the offending message.

Error messages MUST NOT be generated in response to other Error messages.

3.3.3.2. Notify (NTFY)

The Notify message used to provide an autonomous indication of IUA events to an IUA peer.

The Notify message will use only the common message header. The Notify message contains the following parameters:

Status (Mandatory) ASP Identifier (Optional) Interface Identifiers (Optional) INFO String (Optional)

The format for the Notify message with integer-formatted Interface Identifiers is as follows:

	0	1 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5	2 3 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1	L
		Tag = 0x000d	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+- Length = 8	
		Status Type	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+- Status Identification	
		Tag = 0x0011	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+- Length = 8	
		ASP Ide	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+- ntifier +-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	
		Tag (0x1=integer)	 Length +-+-+-+-+-+-+-+-+-+-+-+-+-+-	
\ / / \		Interface	Identifiers	\ / \
		Tag (0x8=integer range)	+-+-+-+-+-+-+-+-+-+-+-+-+-+- Length +-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	
		Interface Iden		
		Interface Ide	ntifier Stop1* +-+-+-	
		Interface Iden		
	-+	Interface Ide	ntifier Stop2* +-+-+-	
		· ·	· · ·	
		Interface Iden		
		Interface Ide	+-+-+-+-+-+-+-+-+-+-+-+-+-+-+- ntifier StopN* +-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-+-	
1 / / / .		Additional Interfac of Tag Type 0	e Identifier Parameters	\ / \ /
		Tag = 0x0004	 Length +-+-+-+-+-+-+-+-+-+-+-+-+-+-	
. \ / \ +		INFO S		· / /

The format for the Notify message with text-formatted Interface Identifiers is as follows:

	2 3 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1
Tag = 0x000d	
Status Type	Status Identification
Tag = 0x0011	Length = 8
ASP Iden	
Tag (0x3=string)	Length
\	Identifiers /
\ of Tag Typ	Identifier Parameters / pe 0x3 \
Tag = $0x0004$	
/ INFO St	\

Status Type: 16 bits (unsigned integer)

The Status Type parameter identifies the type of the Notify message. The following are the valid Status Type values:

- Application Server State Change (AS-State_Change)
- 2 Other

Status Information: 16 bits (unsigned integer)

The Status Information parameter contains more detailed information for the notification, based on the value of the Status Type. If the Status Type is AS-State_Change, the following Status Information values are used:

- 1 reserved
- Application Server Inactive (AS-INACTIVE) 2.
- Application Server Active (AS-ACTIVE)
- Application Server Pending (AS-PENDING)

These notifications are sent from an SG to an ASP upon a change in status of a particular Application Server. The value reflects the new state of the Application Server.

If the Status Type is Other, then the following Status Information values are defined:

Value Description

- Insufficient ASP resources active in AS
- Alternate ASP Active
- ASP Failure

These notifications are not based on the SG reporting the state change of an ASP or AS. In the Insufficient ASP Resources case, the SG is indicating to an ASP-INACTIVE ASP(s) in the AS that another ASP is required in order to handle the load of the AS (Load-sharing mode). For the Alternate ASP Active case, an ASP is informed when an alternate ASP transitions to the ASP-ACTIVE state in Over-ride mode. The ASP Identifier (if available) of the Alternate ASP MUST be placed in the message. For the ASP Failure case, the SG is indicating to ASP(s) in the AS that one of the ASPs has transitioned to ASP-DOWN. The ASP Identifier (if available) of the failed ASP MUST be placed in the message.

The format and description of the optional ASP Identifier are the same as for the ASP Up message (see Section 3.3.2.1). The format and description of the optional Interface Identifiers and INFO String parameters are the same as for the ASP Active message (see Section 3.3.2.5).

3.3.3. TEI Status Messages (Request, Confirm, and Indication)


The TEI Status messages are exchanged between IUA layer peers to request, confirm, and indicate the status of a particular TEI.

The TEI Status messages contain the common message header followed by IUA message header. The TEI Status Request message does not contain any additional parameters.

In the integrated ISDN Layer 2/3 model (e.g., in traditional ISDN switches), it is assumed that the Layer Management for the Q.921 Layer and the Q.931 layer are co-located. When backhauling ISDN, this assumption is not necessarily valid. The TEI Status messages allow the two Layer Management entities to communicate the status of the TEI. In addition, knowing that a TEI is in service allows the ASP to request the SG to establish the datalink to the terminal (via the IUA Establish message) for signaling if the ASP wants to be in control of data link establishment. Another use of the TEI Status procedure is where the Layer Management at the ASP can prepare for send/receive signaling to/from a given TEI and confirm/verify the establishment of a datalink to that TEI. For example, if a datalink is established for a TEI that the ASP did not know was assigned, the ASP can check to see whether it was assigned or whether there was an error in the signaling message. Also, knowing that a TEI is out of service, the ASP need not request the SG to establish a datalink to that TEI.

The TEI Status Indication and Confirm messages contain the following parameter:

STATUS



The valid values for Status are shown in the following table.

Define	Value	Description
ASSIGNED	0x0	TEI is considered assigned by Q.921
UNASSIGNED	0x1	TEI is considered unassigned by Q.921

3.3.3.4. TEI Query Message (Request)

The TEI Query message is sent by the ASP to query the TEI(s). This message consists of the common header and IUA header. The DLCI in the IUA header MUST be ignored by the SG. The SG will respond to this message with TEI Status Indication(s).

4. Procedures

The IUA layer needs to respond to various primitives it receives from other layers as well as messages it receives from the peer IUA layer. This section describes various procedures involved in response to these events.

4.1. Procedures to Support Service in Section 1.4.1

These procedures achieve the IUA layer's "Transport of Q.921/Q.931 boundary primitives" service.

4.1.1. Q.921 or Q.931 Primitives Procedures

On receiving these primitives from the local layer, the IUA layer will send the corresponding QPTM message (Data, Unit Data, Establish, Release) to its peer. While doing so, the IUA layer needs to fill various fields of the common and specific headers correctly. In addition, the message needs to be sent on the SCTP stream that corresponds to the D channel (Interface Identifier).

4.1.2. QPTM Message Procedures

On receiving QPTM messages from a peer IUA layer, the IUA layer on an SG or MGC needs to invoke the corresponding layer primitives (DL-ESTABLISH, DL-DATA, DL-UNIT DATA, DL-RELEASE) to the local Q.921 or Q.931 layer.

4.2. Procedures to Support Service in Section 1.4.2

These procedures achieve the IUA layer's "Support for Communication between Layer Managements" service.

4.2.1. Layer Management Primitives Procedures

On receiving these primitives from the local Layer Management, the IUA layer will provide the appropriate response primitive across the internal local Layer Management interface.

An M-SCTP ESTABLISH request from Layer Management will initiate the establishment of an SCTP association. An M-SCTP ESTABLISH confirm will be sent to Layer Management when the initiated association setup is complete. An M-SCTP ESTABLISH indication is sent to Layer Management upon successful completion of an incoming SCTP association setup from a peer IUA node.

An M-SCTP RELEASE request from Layer Management will initiate the teardown of an SCTP association. An M-SCTP RELEASE confirm will be sent by Layer Management when the association teardown is complete. An M-SCTP RELEASE indication is sent to Layer Management upon successful teardown of an SCTP association initiated by a peer IUA.

M-SCTP STATUS request and indication support a Layer Management query of the local status of a particular SCTP association.

M-NOTIFY indication and M-ERROR indication indicate to Layer Management the notification or error information contained in a received IUA Notify or Error message, respectively. These indications can also be generated based on local IUA events.

M-ASP STATUS request/indication and M-AS-STATUS request/indication support a Layer Management query of the local status of a particular ASP or AS. No IUA peer protocol is invoked.

M-ASP-UP request, M-ASP-DOWN request, M-ASP-INACTIVE request, and M-ASP-ACTIVE request allow Layer Management at an ASP to initiate state changes. These requests result in outgoing IUA ASP UP, ASP DOWN, ASP INACTIVE, and ASP ACTIVE messages.

M-ASP-UP confirmation, M-ASP-DOWN confirmation, M-ASP-INACTIVE confirmation, and M-ASP-ACTIVE confirmation indicate to Layer Management that the previous request has been confirmed.

Upon receipt of an M-TEI Status primitive from Layer Management, the IUA will send the corresponding MGMT message (TEI Status) to its peer. While doing so, the IUA layer needs to fill various fields of the common and specific headers correctly.

All MGMT messages are sent on a sequenced stream to ensure ordering. SCTP stream '0' SHOULD be used.

4.2.2. Receipt of IUA Peer Management Messages

Upon receipt of IUA Management messages, the IUA layer MUST invoke the corresponding Layer Management primitive indications (e.g., M-AS Status ind., M-ASP Status ind., M-ERROR ind., M-TEI STATUS) to the local layer management.

M-NOTIFY indication and M-ERROR indication indicate to Layer Management the notification or error information contained in a received IUA Notify or Error message. These indications can also be generated based on local IUA events.

All MGMT messages are sent on a sequenced stream to ensure ordering. SCTP stream '0' SHOULD be used.

4.3. Procedures to Support Service in Section 1.4.3

These procedures achieve the IUA layer's "Support for management of active associations between SG and MGC" service.

4.3.1. AS and ASP State Maintenance

The IUA layer on the SG needs to maintain the states of each ASP as well as the state of the AS.

4.3.1.1. ASP States

The state of the each ASP, in each AS that it is configured, is maintained in the IUA layer on the SG. The state of an ASP changes due to the following type of events:

- * Reception of messages from peer IUA layer at that ASP
- * Reception of some messages from the peer IUA layer at other ASPs in the AS
- * Reception of indications from SCTP layer
- * Local Management intervention

The ASP state transition diagram is shown in Figure 6. The possible states of an ASP are the following:

ASP-DOWN: Application Server Process is unavailable and/or the related SCTP association is down. Initially, all ASPs will be in this state. An ASP in this state SHOULD NOT be sent any IUA messages.

ASP-INACTIVE: The remote IUA peer at the ASP is available (and the related SCTP association is up) but application traffic is stopped. In this state, the ASP can be sent any non-QPTM IUA messages (except for TEI Status messages).

ASP-ACTIVE: The remote IUA peer at the ASP is available and application traffic is active.




Figure 6. ASP State Transition Diagram

SCTP CDI: The local SCTP layer's Communication Down Indication to the Upper Layer Protocol (IUA) on an SG. The local SCTP will send this indication when it detects the loss of connectivity to the ASP's peer SCTP layer. SCTP CDI is understood as either a SHUTDOWN COMPLETE notification and COMMUNICATION LOST notification from the SCTP.

SCTP RI: The local SCTP layer's Restart indication to the upper layer protocol (IUA) on an SG. The local SCTP will send this indication when it detects a restart from the ASP's peer SCTP layer.

4.3.1.2. AS States

The state of the AS is maintained in the IUA layer on the SG.

The state of an AS changes due to events. These events include the following:

- * ASP state transitions
- * Recovery timer triggers

The possible states of an AS are the following:


AS-DOWN: The Application Server is unavailable. This state implies that all related ASPs are in the ASP-DOWN state for this AS. Initially, the AS will be in this state.

AS-INACTIVE: The Application Server is available but no application traffic is active (i.e., one or more related ASPs are in the ASP-INACTIVE state, but none in the ASP-ACTIVE state). The recovery timer T(r) is not running or has expired.

AS-ACTIVE: The Application Server is available and application traffic is active. This state implies that at least one ASP is in the ASP-ACTIVE state.

AS-PENDING: An active ASP has transitioned from active to inactive or down and it was the last remaining active ASP in the AS. A recovery timer T(r) will be started and all incoming SCN messages will be queued by the SG. If an ASP becomes active before T(r) expires, the AS will move to AS-ACTIVE state and all the queued messages will be sent to the active ASP.

If T(r) expires before an ASP becomes active, the SG stops queuing messages and discards all previously queued messages. The AS will move to AS-INACTIVE if at least one ASP is in ASP-INACTIVE state, otherwise it will move to AS-DOWN state.



Tr = Recovery Timer

Figure 7: AS State Transition Diagram

4.3.2. ASPM Procedures for Primitives

Before the establishment of an SCTP association, the ASP state at both the SG and ASP is assumed to be in the state ASP-DOWN.

As the ASP is responsible for initiating the setup of an SCTP association to an SG, the IUA layer at an ASP receives an M-SCTP ESTABLISH request primitive from the Layer Management, the IUA layer will try to establish an SCTP association with the remote IUA peer at an SG. Upon reception of an eventual SCTP-Communication Up confirm primitive from the SCTP, the IUA layer will invoke the primitive M-SCTP ESTABLISH confirm to the Layer Management.

At the SG, the IUA layer will receive an SCTP Communication Up indication primitive from the SCTP. The IUA layer will then invoke the primitive M-SCTP ESTABLISH indication to the Layer Management.

Once the SCTP association is established and assuming that the local IUA-User is ready, the local ASP IUA Application Server Process Maintenance (ASPM) function will initiate the ASPM procedures, using the ASP Up/-Down/-Active/-Inactive messages to convey the ASP state to the SG (see Section 4.3.3).

The Layer Management and the IUA layer on SG can communicate the status of the application server using the M-AS_STATUS primitives. The Layer Management and the IUA layer on both the SG and ASP can communicate the status of an SCTP association using the M-SCTP_STATUS primitives.

If the Layer Management on SG or ASP wants to bring down an SCTP association for management reasons, it would send M-SCTP RELEASE request primitive to the local IUA layer. The IUA layer would release the SCTP association and upon receiving the SCTP-COMMUNICATION DOWN indication from the underlying SCTP layer, it would inform the local Layer Management using M-SCTP_RELEASE confirm primitive.

If the IUA layer receives an SCTP-COMMUNICATION DOWN indication from the underlying SCTP layer, it will inform the Layer Management by invoking the M-SCTP RELEASE indication primitive. The state of the ASP will be moved to "Down" at both the SG and ASP.

At an ASP, the Layer Management MAY try to reestablish the SCTP association using M-SCTP_ESTABLISH request primitive.

In the case of an SCTP-RESTART indication at an ASP, the ASP is now considered by its IUA peer to be in the ASP-DOWN state. The ASP, if it is to recover, must begin any recovery with the ASP Up procedure.

4.3.3. ASPM Procedures for Peer-to-Peer Messages

All ASPM messages are sent on a sequenced stream to ensure ordering. SCTP stream '0' SHOULD be used.

4.3.3.1. ASP Up Procedures

After an ASP has successfully established an SCTP association to an SG, the SG waits for the ASP to send an ASP Up message, indicating that the ASP IUA peer is available. The ASP is always the initiator of the ASP Up message. This action MAY be initiated at the ASP by an M-ASP_UP request primitive from Layer Management or MAY be initiated automatically by an IUA management function.

When an ASP Up message is received at an SG and internally the remote ASP is in the ASP-DOWN state and not considered locked out for local management reasons, the SG marks the remote ASP in the state ASP-INACTIVE and informs Layer Management with an M-ASP Up indication primitive. If the SG is aware, via current configuration data, which Application Servers the ASP is configured to operate in, the SG updates the ASP state to ASP-INACTIVE in each AS that it is a member.

Alternatively, the SG may move the ASP into a pool of Inactive ASPs available for future configuration within Application Server(s), determined in a subsequent ASP Active procedure. If the ASP Up message contains an ASP Identifier, the SG should save the ASP Identifier for that ASP. The SG MUST send an ASP Up Ack message in response to a received ASP Up message even if the ASP is already marked as ASP-INACTIVE at the SG.

If for any local reason (e.g., management lockout) the SG cannot respond with an ASP Up Ack message, the SG responds to an ASP Up message with an Error message with reason "Refused - Management Blocking".

At the ASP, the ASP Up Ack message received is not acknowledged. Layer Management is informed with an M-ASP_UP confirm primitive.

When the ASP sends an ASP Up message, it starts timer T(ack). If the ASP does not receive a response to an ASP Up message within T(ack), the ASP MAY restart T(ack) and resend ASP Up messages until it receives an ASP Up Ack message. T(ack) is provisionable, with a default of 2 seconds. Alternatively, retransmission of ASP Up messages MAY be put under control of Layer Management. In this method, expiry of T(ack) results in an M-ASP_UP confirm primitive carrying a negative indication.

The ASP must wait for the ASP Up Ack message before sending any other IUA messages (e.g., ASP Active). If the SG receives any other IUA messages before an ASP Up message is received (other than ASP Down; see Section 4.3.3.2), the SG MAY discard them.

If an ASP Up message is received and internally the remote ASP is in the ASP-ACTIVE state, an ASP Up Ack message is returned, as well as an Error message ("Unexpected Message"), and the remote ASP state is changed to ASP-INACTIVE in all relevant Application Servers.

If an ASP Up message is received and internally the remote ASP is already in the ASP-INACTIVE state, an ASP Up Ack message is returned and no further action is taken.

4.3.3.2. ASP Down Procedures

The ASP will send an ASP Down message to an SG when the ASP wishes to be removed from the list of ASPs in all Application Servers that it is a member and no longer receive any IUA QPTM or ASPTM messages. This action MAY be initiated at the ASP by an M-ASP_DOWN request primitive from Layer Management or MAY be initiated automatically by an IUA management function.

Whether the ASP is permanently removed from an AS is a function of configuration management.

The SG marks the ASP as ASP-DOWN, informs Layer Management with an M-ASP_Down indication primitive, and returns an ASP Down Ack message to the ASP.

The SG MUST send an ASP Down Ack message in response to a received ASP Down message from the ASP even if the ASP is already marked as ASP-DOWN at the SG.

At the ASP, the ASP Down Ack message received is not acknowledged. Layer Management is informed with an M-ASP_DOWN confirm primitive. If the ASP receives an ASP Down Ack without having sent an ASP Down message, the ASP should now consider itself as in the ASP-DOWN state. If the ASP was previously in the ASP-ACTIVE or ASP-INACTIVE state, the ASP should then initiate procedures to return itself to its previous state.

When the ASP sends an ASP Down message, it starts timer T(ack). the ASP does not receive a response to an ASP Down message within T(ack), the ASP MAY restart T(ack) and resend ASP Down messages until it receives an ASP Down Ack message. T(ack) is provisionable, with a default of 2 seconds. Alternatively, retransmission of ASP Down messages MAY be put under control of Layer Management. In this method, expiry of T(ack) results in an M-ASP_DOWN confirm primitive carrying a negative indication.

4.3.3.3. IUA Version Control

If a ASP Up message with an unsupported version is received, the receiving end responds with an Error message, indicating the version the receiving node supports and notifies Layer Management.

This is useful when protocol version upgrades are being performed in a network. A node upgraded to a newer version SHOULD support the older versions used on other nodes it is communicating with. Because ASPs initiate the ASP Up procedure it is assumed that the Error message would normally come from the SG.

4.3.3.4. ASP Active Procedures

Any time after the ASP has received an ASP Up Ack from the SG, the ASP sends an ASP Active message to the SG indicating that the ASP is ready to start processing traffic. This action MAY be initiated at the ASP by an M-ASP_ACTIVE request primitive from Layer Management or MAY be initiated automatically by an IUA management function. In the case where an ASP is configured/registered to process the traffic for more than one Application Server across an SCTP association, the ASPAC contains one or more Interface Identifiers to indicate for which Application Servers the ASPAC applies.

If the Application Server can be successfully activated, the SG responds to the ASP with an ASPAC Ack message acknowledging that the ASPAC message was received and starts sending traffic for the Application Server to that ASP.

In the case where an "out-of-the-blue" ASP Active message is received (i.e., the ASP has not registered with the SG or the SG has no static configuration data for the ASP), the message MAY be silently discarded.

The SG MUST send an ASP Active Ack message in response to a received ASP Active message from the ASP, if the ASP is already marked in the ASP-ACTIVE state at the SG.

At the ASP, the ASP Active Ack message received is not acknowledged. Layer Management is informed with an M-ASP_ACTIVE confirm primitive. It is possible for the ASP to receive Data message(s) before the ASP Active Ack message as the ASP Active Ack and Data messages from an SG may be sent on different SCTP streams. Message loss is possible as the ASP does not consider itself in the ASP-ACTIVE state until reception of the ASP Active Ack message.

When the ASP sends an ASP Active message, it starts timer T(ack). the ASP does not receive a response to an ASP Active message within T(ack), the ASP MAY restart T(ack) and resend ASP Active messages until it receives an ASP Active Ack message. T(ack) is provisionable, with a default of 2 seconds. Alternatively, retransmission of ASP Active messages MAY be put under control of Layer Management. In this method, expiry of T(ack) results in an M-ASP_ACTIVE confirm primitive carrying a negative indication.

The ASP MUST wait for the ASP Active Ack message from the SG before sending any Data messages or it will risk message loss. If the SG receives QPTM messages before an ASP Active is received, the SG SHOULD discard these messages.

There are two modes of Application Server traffic handling in the SG IUA: Over-ride and Load-sharing. The Type parameter in the ASPAC message indicates the mode used in a particular Application Server. If the SG determines that the mode indicates in an ASPAC is incompatible with the traffic handling mode currently used in the AS, the SG responds with an Error message indicating Unsupported Traffic Handling Mode.

In the case of an Over-ride mode AS, reception of an ASPAC message at an SG causes the redirection of all traffic for the AS to the ASP that sent the ASPAC. The SG responds to the ASPAC with an ASP Active Ack message to the ASP. Any previously active ASP in the AS is now considered Inactive and will no longer receive traffic from the SG within the AS. The SG sends a Notify (Alternate ASP Active) to the previously active ASP in the AS, after stopping all traffic to that ASP.

In the case of a load-share mode AS, reception of an ASPAC message at an SG causes the direction of traffic to the ASP sending the ASPAC, in addition to all the other ASPs that are currently active in the AS. The algorithm at the SG for load-sharing traffic within an AS to all the active ASPs is implementation dependent. The algorithm could, for example, be round-robin or based on information in the Data message, such as Interface Identifier, depending on the requirements of the application and the call state handling assumptions of the collection of ASPs in the AS. The SG responds to the ASPAC with an ASP Active Ack message to the ASP.

4.3.3.5. ASP Inactive Procedures

When an ASP wishes to withdraw from receiving traffic within an AS, the ASP sends an ASP Inactive message to the SG. This action MAY be initiated at the ASP by an M-ASP_INACTIVE request primitive from Layer Management or MAY be initiated automatically by an IUA management function. In the case where an ASP is configured/ registered to process the traffic for more than one Application Server across an SCTP association, the ASPIA contains one or more Interface Identifiers to indicate for which Application Servers the ASP Inactive message applies.

There are two modes of Application Server traffic handling in the SG IUA when withdrawing an ASP from service: Over-ride and Load-sharing. In the case of an Over-ride mode AS, where normally another ASP has already taken over the traffic within the AS with an Over-ride ASPAC message, the ASP that sends the ASPIA message is already considered by the SG to be ASP-INACTIVE. An ASPIA Ack message is sent to the ASP, after ensuring that all traffic is stopped to the ASP.

In the case of a Load-share mode AS, the SG moves the ASP to the ASP-INACTIVE state and the AS traffic is re-allocated across the remaining ASP-ACTIVE ASPs per the load-sharing algorithm currently used within the AS. An ASPIA Ack message is sent to the ASP after all traffic is halted to the ASP. A Notify (Insufficient ASPs) message MAY be sent to all inactive ASPs, if required.

When the ASP sends an ASP Inactive message it starts timer T(ack). If the ASP does not receive a response to an ASP Inactive message within T(ack), the ASP MAY restart T(ack) and resend ASP Inactive messages until it receives an ASP Inactive Ack message. T(ack) is provisionable, with a default of 2 seconds. Alternatively, retransmission of ASP Inactive messages MAY be put under control of Layer Management. In this method, expiry of T(ack) results in a M-ASP_Inactive confirm primitive carrying a negative indication.

If no other ASPs in the Application Server are in the state ASP-ACTIVE, the SG MUST send a Notify ("AS-Pending") message to all of the ASPs in the AS that are in the state ASP-INACTIVE. The SG SHOULD start buffering the incoming messages for T(r) seconds, after which messages MAY be discarded. T(r) is configurable by the network operator. If the SG receives an ASP Active message from an ASP in the AS before expiry of T(r), the buffered traffic is directed to that ASP and the timer is cancelled. If T(r) expires, the AS is moved to the AS-INACTIVE state.

At the ASP, the ASP Inactive Ack message received is not acknowledged. Layer Management is informed with an M-ASP INACTIVE confirm primitive. If the ASP receives an ASP Inactive Ack without having sent an ASP Inactive message, the ASP should now consider itself as in the ASP-INACTIVE state. If the ASP was previously in the ASP-ACTIVE state, the ASP should then initiate procedures to return itself to its previous state.

4.3.3.6. Notify Procedures

A Notify message reflecting a change in the AS state MUST be sent to all ASPs in the AS, except those in the ASP-DOWN state, with appropriate Status Information and any ASP Identifier of the failed ASP. At the ASP, Layer Management is informed with an M-NOTIFY indication primitive. The Notify message must be sent whether the AS state change was a result of an ASP failure or reception of an ASP State Management (ASPSM) / ASP Traffic Management (ASPTM) message. In the second case, the Notify message MUST be sent after any related acknowledgement messages (e.g., ASP Up Ack, ASP Down Ack, ASP Active Ack, or ASP Inactive Ack).

In the case where a Notify ("AS-Pending") message is sent by an SG that now has no ASPs active to service the traffic, or a NTFY ("Insufficient ASPs") is sent in the Load-share mode, the Notify does not explicitly compel the ASP(s) receiving the message to become active. The ASPs remain in control of what (and when) action is taken.

4.3.3.7. Heartbeat

The optional Heartbeat procedures MAY be used when operating over transport layers that do not have their own heartbeat mechanism for detecting loss of the transport association (i.e., other than the SCTP).

Either IUA peer may optionally send Heartbeat messages periodically, subject to a provisionable timer T(beat). Upon receiving a Heartbeat message, the IUA peer MUST respond with a Heartbeat Ack message.

If no Heartbeat Ack message (or any other IUA message) is received from the IUA peer within 2*T(beat), the remote IUA peer is considered unavailable. Transmission of Heartbeat messages is stopped and the signaling process SHOULD attempt to re-establish communication if it is configured as the client for the disconnected IUA peer.


The BEAT message MAY optionally contain an opaque Heartbeat Data parameter that MUST be echoed back unchanged in the related Beat Ack message. The ASP upon examining the contents of the returned BEAT Ack message MAY choose to consider the remote ASP as unavailable. The contents/format of the Heartbeat Data parameter is implementation dependent and only of local interest to the original sender. The contents MAY be used, for example, to support a Heartbeat sequence algorithm (to detect missing Heartbeats), and/or a timestamp mechanism (to evaluate delays).

Note: Heartbeat-related events are not shown in Figure 6, "ASP State Transition Diagram".

5. Examples


- 5.1. Establishment of Association and Traffic between SGs and ASPs
- 5.1.1. Single ASP in an Application Server (1+0 sparing)

This scenario shows the example IUA message flows for the establishment of traffic between an SG and an ASP, where only one ASP is configured within an AS (no backup). It is assumed that the SCTP association is already setup.




5.1.2. Two ASPs in Application Server (1+1 sparing)

This scenario shows the example IUA message flows for the establishment of traffic between an SG and two ASPs in the same Application Server, where ASP1 is configured to be Active and ASP2 a standby in the event of communication failure or the withdrawal from service of ASP1. ASP2 MAY act as a hot, warm, or cold standby depending on the extent to which ASP1 and ASP2 share call state or can communicate call state under failure/withdrawal events. The example message flow is the same whether the ASP Active messages are Over-ride or Load-share mode although typically this example would use an Over-ride mode.




5.1.3. Two ASPs in an Application Server (1+1 sparing, load-sharing case)

This scenario shows a similar case to Section 5.1.2 but where the two ASPs are brought to active and load-share the traffic load. In this case, one ASP is sufficient to handle the total traffic load.



5.1.4. Three ASPs in an Application Server (n+k sparing, load-sharing

This scenario shows the example IUA message flows for the establishment of traffic between an SG and three ASPs in the same Application Server, where two of the ASPs are brought to active and share the load. In this case, a minimum of two ASPs are required to handle the total traffic load (2+1 sparing).



5.1.5. Interface Identifier Configuration Mismatch Example


This scenario shows the example IUA message flows for the establishment of traffic between an SG and an ASP in which some of the Interface Identifiers have been misconfigured on the ASP side. The SG in this case has Interface Identifiers 1-5 configured for ASP1.

```
SG
                             ASP1
 <----ASP Active (IIDs 1-10)-----</pre>
 |---ASP Active Ack (IIDs 1-5)--->
 |-----Error (IIDs 6)----->
 |-----Error (IIDs 7)----->
 |-----Error (IIDs 8)----->
 |-----Error (IIDs 9)----->|
 -----Error (IIDs 10)----->
```

5.2. ASP Traffic Fail-over Examples

5.2.1. (1+1 Sparing, withdrawal of ASP, Backup Over-ride)

The following example shows a case in which an ASP withdraws from service:




In this case, the SG notifies ASP2 that the AS has moved to the Down state. The SG could have also (optionally) sent a Notify message when the AS moved to the Pending state.

Note: If the SG detects loss of the IUA peer (IUA heartbeat loss or detection of SCTP failure), the initial SG-ASP1 ASP Inactive message exchange would not occur.

5.2.2. (1+1 Sparing, Backup Over-ride)


The following example shows a case in which ASP2 wishes to override ASP1 and take over the traffic:



In this case, the SG notifies ASP1 that an alternative ASP has overridden it.

5.2.3. (n+k Sparing, Load-sharing case, withdrawal of ASP)

Following on from the example in Section 5.1.4, and ASP1 withdraws from service:



In this case, the SG has knowledge of the minimum ASP resources required (implementation dependent), for example, if the SG knows that n+k = 2+1 for a load-share AS and n currently equals 1.

Note: If the SG detects loss of the ASP1 IUA peer (IUA heartbeat loss or detection of SCTP failure), the first SG-ASP1 ASP Inactive message exchange would not occur.

5.3. Q.921/Q.931 Primitives Backhaul Examples

When the IUA layer on the ASP has a QPTM message to send to the SG, it will do the following:

- Determine the correct SG
- Find the SCTP association to the chosen SG
- Determine the correct stream in the SCTP association based on the D channel
- Fill in the QPTM message, fill in IUA Message Header, fill in
- Send the QPTM message to the remote IUA peer in the SG, over the SCTP association

When the IUA layer on the SG has a QPTM message to send to the ASP, it will do the following:

- Determine the AS for the Interface Identifier
- Determine the Active ASP (SCTP association) within the AS

- Determine the correct stream in the SCTP association based on the D channel
- Fill in the OPTM message, fill in IUA Message Header, fill in Common Header
- Send the QPTM message to the remote IUA peer in the ASP, over the SCTP association

An example of the message flows for establishing a data link on a signaling channel, passing PDUs and releasing a data link on a signaling channel is shown below. An active association between MGC and SG is established (Section 5.1) prior to the following message flows.

SG ASP <---- Establish Request Establish Confirm ----> <---- Data Request Data Indication ----> <---- Data Request Data Indication ----> <---- Data Request <---- Data Request Data Indication ----> <---- Release Request (RELEASE MGMT) Release Confirm ---->

An example of the message flows for a failed attempt to establish a data link on the signaling channel is shown below. In this case, the gateway has a problem with its physical connection (e.g., Red Alarm), so it cannot establish a data link on the signaling channel.

SG ASP <----- Establish Request (ESTABLISH_START) Release Indication ----> (RELEASE_PHYS)

5.4. Layer Management Communication Examples

An example of the message flows for communication between Layer Management modules between SG and ASP is shown below. An active association between ASP and SG is established (Section 5.1) prior to the following message flows.

SG ASP

<----- Data Request
Error Indication ----->
(INVALID_TEI)

<----- TEI Status Request
TEI Status Confirm ----->
 (Unassigned)

6. Security

The security considerations discussed in "Security Considerations for SIGTRAN Protocols", RFC 3788 [3], apply to this document.

7. IANA Considerations

7.1. SCTP Payload Protocol Identifier

The IANA has assigned an IUA value for the Payload Protocol Identifier in SCTP Payload Data chunk. The following SCTP Payload Protocol Identifier has been registered:

IUA "1"

The SCTP Payload Protocol Identifier is included in each SCTP Data chunk, to indicate which protocol the SCTP is carrying. This Payload Protocol Identifier is not directly used by SCTP but MAY be used by certain network entities to identify the type of information being carried in a Data chunk.

The User Adaptation peer MAY use the Payload Protocol Identifier as a way of determining additional information about the data being presented to it by SCTP.

7.2. IUA Protocol Extensions

This protocol may also be extended through IANA in three ways:

- -- through definition of additional message classes,
- -- through definition of additional message types, and
- -- through definition of additional message parameters.

The definition and use of new message classes, types, and parameters are an integral part of SIGTRAN adaptation layers. Thus, these extensions are assigned by IANA through an IETF Consensus action as defined in [7].

The proposed extension must in no way adversely affect the general working of the protocol.

7.2.1. IETF-Defined Message Classes

The documentation for a new message class MUST include the following information:

- (a) A long and short name for the message class.
- (b) A detailed description of the purpose of the message class.

7.2.2. IETF-Defined Message Types

Documentation of the message type MUST contain the following information:

- (a) A long and short name for the new message type.
- (b) A detailed description of the structure of the message.
- (c) A detailed definition and description of intended use of each field within the message.
- (d) A detailed procedural description of the use of the new message type within the operation of the protocol.
- (e) A detailed description of error conditions when receiving this message type.

When an implementation receives a message type that it does not support, it MUST respond with an Error (ERR) message with an Error Code of Unsupported Message Type.

7.2.3. IETF-Defined TLV Parameter Extension

Documentation of the message parameter MUST contain the following information:

- (a) Name of the parameter type.
- (b) Detailed description of the structure of the parameter field. This structure MUST conform to the general type-length-value format described in Section 3.1.5.
- (c) Detailed definition of each component of the parameter value.
- (d) Detailed description of the intended use of this parameter type, and an indication of whether and under what circumstances multiple instances of this parameter type may be found within the same message type.

8. Timer Values

The following are suggestions for default timer values.

T(r)3-5 seconds 2-5 seconds T(ack) T(beat) Heartbeat Timer 30 seconds

9. Acknowledgements

The authors would like to thank Alex Audu, Maria Sonia Vazquez Arevalillo, Ming-te Chao, Keith Drage, Norm Glaude, Nikhil Jain, Bernard Kuc, Ming Lin, Stephen Lorusso, John Loughney, Barry Nagelberg, Neil Olson, Lyndon Ong, Heinz Prantner, Jose Luis Jimenez Ramirez, Ian Rytina, Michael Tuexen, and Hank Wang for their valuable comments and suggestions.

10. References

10.1. Normative References

- [1] ITU-T Recommendation Q.920, 'Digital Subscriber signaling System No. 1 (DSS1) - ISDN User-Network Interface Data Link Layer -General Aspects'
- [2] Coded Character Set--7-Bit American Standard Code for Information Interchange, ANSI X3.4-1986.
- [3] Loughney, J., Tuexen, M., and J. Pastor-Balbas, "Security Considerations for Signaling Transport (SIGTRAN) Protocols", RFC 3788, June 2004.

10.2. Informative References

- [4] Stewart, R., Xie, Q., Morneault, K., Sharp, C., Schwarzbauer, H., Taylor, T., Rytina, I., Kalla, M., Zhang, L., and V. Paxson, "Stream Control Transmission Protocol", RFC 2960, October 2000.
- [5] Ong, L., Rytina, I., Garcia, M., Schwarzbauer, H., Coene, L., Lin, H., Juhasz, I., Holdrege, M., and C. Sharp, "Framework Architecture for Signaling Transport", RFC 2719, October 1999.
- [6] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [7] Narten, T. and H. Alvestrand, "Guidelines for Writing an IANA Considerations Section in RFCs", BCP 26, RFC 2434, October 1998.

- [8] Stone, J., Stewart, R., and D. Otis, "Stream Control Transmission Protocol (SCTP) Checksum Change", RFC 3309, September 2002.
- 11. Change Log

Below is a list of the major changes between this document and RFC 3057.

- 1. The TEI Query message was added.
- 2. An explanation of the DLCI format (shown in Figure 6) is provided.
- 3. Aligned the ASP and AS procedures in Section 4 with RFC3331 and RFC3332.
- 4. Alinged the format of the ASPSM and ASPTM messages with RFC3331 and RFC3332. These changes include removing the Reason field from the ASP Down and ASP Down Ack messages and the Traffic Mode Type field from the ASP Inactive and ASP Inactive Ack messages.
- 5. Sections 1.3.3 and 1.3.4 were moved to Appendix A. A new section was added in place of Section 1.3.3.
- 6. The references have been split between Normative and Informative.
- 7. The new Sigtran security document is referenced and Section 6 has been updated appropriately.

Appendix A

A.1. Signaling Network Architecture

A Signaling Gateway is used to support the transport of Q.921-User signaling traffic to one or more distributed ASPs (e.g., MGCs). Clearly, the IUA protocol is not designed to meet the performance and reliability requirements for such transport by itself. However, the conjunction of distributed architecture and redundant networks does allow for a sufficiently reliable transport of signaling traffic over IP. The IUA protocol is flexible enough to allow its operation and management in a variety of physical configurations, enabling Network Operators to meet their performance and reliability requirements.

To meet the ISDN signaling reliability and performance requirements for carrier grade networks, Network Operators SHOULD ensure that there is no single point of failure provisioned in the end-to-end network architecture between an ISDN node and an IP ASP.

Depending of course on the reliability of the SG and ASP functional elements, this can typically be met by the provision of redundant Quality of Service (QoS)-bounded IP network paths for SCTP Associations between SCTP End Points, and redundant Hosts, and redundant SGs. The distribution of ASPs within the available Hosts is also important. For a particular Application Server, the related ASPs SHOULD be distributed over at least two Hosts.

An example logical network architecture relevant to carrier-grade operation in the IP network domain is shown in Figure 8 below:




Figure 8. Logical Model Example

For carrier-grade networks, the failure or isolation of a particular ASP SHOULD NOT cause stable calls to be dropped. This implies that ASPs need, in some cases, to share the call state or be able to pass the call state between each other. However, this sharing or communication of call state information is outside the scope of this document.

A.2. Application Server Process Redundancy

To avoid a single point of failure, it is recommended that a minimum of two ASPs be in the list, resident in separate hosts and therefore available over different SCTP Associations. For example, in the network shown in Figure 8, all messages from a particular D Channel (Interface Identifier) could be sent to ASP1 in Host1 or ASP1 in Host2. The AS list at SG1 might look like the following:

```
Interface Identifier(s) - Application Server #1
   ASP1/Host1 - State=Up, Active
   ASP1/Host2 - State=Up, Inactive
```

In this 1+1 redundancy case, ASP1 in Host1 would be sent any incoming message for the Interface Identifiers registered. ASP1 in Host2 would normally be brought to the active state upon failure of, or loss of connectivity to, ASP1/Host1. In this example, both ASPs are Up, meaning that the related SCTP association and far-end IUA peer are ready.

The AS List at SG1 might also be set up in load-share mode as shown below:

```
Interface Identifier(s) - Application Server #1
   ASP1/Host1 - State=Up, Active
   ASP1/Host2 - State=Up, Active
```

In this case, both the ASPs would be sent a portion of the traffic.

In the process of fail-over, it is recommended that in the case of ASPs supporting call processing, stable calls do not get released. It is possible that calls in transition MAY fail, although measures of communication between the ASPs involved can be used to mitigate this problem. For example, the two ASPs MAY share call state via shared memory, or MAY use an ASP-to-ASP protocol to pass call state information. The ASP-to-ASP protocol is outside the scope of this document.

Authors' Addresses

Ken Morneault Cisco Systems Inc. 13615 Dulles Technology Drive Herndon, VA. 20171 USA

Phone: +1-703-484-3323 EMail: kmorneau@cisco.com

Malleswar Kalla Telcordia Technologies PYA 2J-341 3 Corporate Place Piscataway, NJ 08854 USA

Phone: +1-732-699-3728 EMail: mkalla@telcordia.com

Selvam Rengasami Tridea Works

Phone: +1-732-512-0969

EMail: selvam@trideaworks.com

Greg Sidebottom Signatus Technologies Kanata, Ontario, Canada

EMail: greg@signatustechnologies.com

Full Copyright Statement

Copyright (C) The Internet Society (2006).

This document is subject to the rights, licenses and restrictions contained in BCP 78, and except as set forth therein, the authors retain all their rights.

This document and the information contained herein are provided on an "AS IS" basis and THE CONTRIBUTOR, THE ORGANIZATION HE/SHE REPRESENTS OR IS SPONSORED BY (IF ANY), THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Intellectual Property

The IETF takes no position regarding the validity or scope of any Intellectual Property Rights or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; nor does it represent that it has made any independent effort to identify any such rights. Information on the procedures with respect to rights in RFC documents can be found in BCP 78 and BCP 79.

Copies of IPR disclosures made to the IETF Secretariat and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this specification can be obtained from the IETF on-line IPR repository at http://www.ietf.org/ipr.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights that may cover technology that may be required to implement this standard. Please address the information to the IETF at ietf-ipr@ietf.org.

Acknowledgement

Funding for the RFC Editor function is provided by the IETF Administrative Support Activity (IASA).