Network Working Group Request for Comments: 3273 Category: Standards Track

Remote Network Monitoring Management Information Base for High Capacity Networks

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2002). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it defines objects for managing remote network monitoring (RMON) devices for use on high speed networks. This document contains a MIB Module that defines these new objects and also contains definitions of some updated objects from the RMON-MIB in RFC 2819 and the RMON2-MIB in RFC 2021.

Table of Contents

1	The SNMP Management Framework	2
2	Overview	3
2.3	Structure of MIB	3
3	Updates to RMON MIB and RMON2 MIB objects	4
	Conventions	
5	Definitions	7
6	Security Considerations	3
7	Acknowledgments	3
8	References7	3
	Notices	
10	Author's Address7	6
11	Full Copyright Statement7	7

Waldbusser Standards Track [Page 1]

1. The SNMP Management Framework

The SNMP Management Framework presently consists of five major components:

- o An overall architecture, described in RFC 2571 [1].
- o Mechanisms for describing and naming objects and events for the purpose of management. The first version of this Structure of Management Information (SMI) is called SMIv1 and described in STD 16, RFC 1155 [2], STD 16, RFC 1212 [3], and RFC 1215 [4]. The second version, called SMIv2, is described in STD 58, RFC 2578 [5], RFC 2579 [6], and RFC 2580 [7].
- o Message protocols for transferring management information. The first version of the SNMP message protocol is called SNMPv1 and is described in STD 15, RFC 1157 [8]. A second version of the SNMP message protocol, which is not an Internet standards track protocol, is called SNMPv2c and is described in RFC 1901 [9], and RFC 1906 [10]. The third version of the message protocol is called SNMPv3 and is described in RFC 1906 [10], RFC 2572 [11], and RFC 2574 [12].
- o Protocol operations for accessing management information. The first set of protocol operations and associated PDU formats is described in STD 15, RFC 1157 [8]. A second set of protocol operations and associated PDU formats is described in RFC 1905 [13].
- o A set of fundamental applications described in RFC 2573 [14] and the view-based access control mechanism described in RFC 2575 [15].

A more detailed introduction to the current SNMP Management Framework can be found in RFC 2570 [22].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the mechanisms defined in the SMI.

This memo specifies a MIB module that is compliant to the SMIv2. A MIB conforming to the SMIv1 can be produced through the appropriate translations. The resulting translated MIB must be semantically equivalent, except where objects or events are omitted because no translation is possible (use of Counter64). Some machine readable information in SMIv2 will be converted into textual descriptions in

SMIv1 during the translation process. However, this loss of machine readable information is not considered to change the semantics of the MIB.

2. Overview

This document continues the architecture created in the RMON MIB [RFC 2819] by supporting high speed networks.

Remote network monitoring devices, often called monitors or probes, are instruments that exist for the purpose of managing a network. Often these remote probes are stand-alone devices and devote significant internal resources for the sole purpose of managing a network. An organization may employ many of these devices, one per network segment, to manage its internet. In addition, these devices may be used for a network management service provider to access a client network, often geographically remote.

The objects defined in this document are intended as an interface between an RMON agent and an RMON management application and are not intended for direct manipulation by humans. While some users may tolerate the direct display of some of these objects, few will tolerate the complexity of manually manipulating objects to accomplish row creation. These functions should be handled by the management application.

2.1 Structure of MIB

Except for the mediaIndependentTable, each of the tables in this MIB adds high capacity capability to an associated table in the RMON-1 MIB or RMON-2 MIB.

The objects are arranged into the following groups:

- mediaIndependentGroup
- etherStatsHighCapacityGroup
- etherHistoryHighCapacityGroup
- hostHighCapacityGroup
- hostTopNHighCapacityGroup
- matrixHighCapacityGroup
- captureBufferHighCapacityGroup

- protocolDistributionHighCapacityGroup
- nlHostHighCapacityGroup
- nlMatrixHighCapacityGroup
- nlMatrixTopNHighCapacityGroup
- alHostHighCapacityGroup
- alMatrixHighCapacityGroup
- alMatrixTopNHighCapacityGroup
- usrHistoryHighCapacityGroup

These groups are the basic units of conformance. If a remote monitoring device implements a group, then it must implement all objects in that group. For example, a managed agent that implements the network layer matrix group must implement the nlMatrixSDHighCapacityTable and the nlMatrixDSHighCapacityTable.

Implementations of this MIB must also implement the system and interfaces group of MIB-II [16,17]. MIB-II may also mandate the implementation of additional groups.

These groups are defined to provide a means of assigning object identifiers, and to provide a method for agent implementors to know which objects they must implement.

3. Updates to RMON MIB and RMON2 MIB objects

This document extends the enumerations in the following objects from the RMON MIB [18] and the RMON2 MIB [20].

From the RMON MIB:

```
hostTopNRateBase OBJECT-TYPE

SYNTAX INTEGER {
    hostTopNInPkts(1),
    hostTopNOutPkts(2),
    hostTopNInOctets(3),
    hostTopNOutOctets(4),
    hostTopNOutErrors(5),
    hostTopNOutBroadcastPkts(6),
    hostTopNOutMulticastPkts(7),
    hostTopNHCInPkts(8),
    hostTopNHCOutPkts(9),
```

```
hostTopNHCInOctets(10),
                 hostTopNHCOutOctets(11)
               }
   MAX-ACCESS read-create
    STATUS
           current
    DESCRIPTION
        "The variable for each host that the hostTopNRate
        variable is based upon, as well as a control
        for the table that the results will be reported in.
        This object may not be modified if the associated
        hostTopNStatus object is equal to valid(1).
        If this value is less than or equal to 7, when the report
        is prepared, entries are created in the hostTopNTable
        associated with this object.
        If this value is greater than or equal to 8, when the report
        is prepared, entries are created in the
        hostTopNHighCapacityTable associated with this object."
    ::= { hostTopNControlEntry 3 }
From the RMON2 MIB:
nlMatrixTopNControlRateBase OBJECT-TYPE
                INTEGER {
                    nlMatrixTopNPkts(1),
                    nlMatrixTopNOctets(2),
                    nlMatrixTopNHighCapacityPkts(3),
                    nlMatrixTopNHighCapacityOctets(4)
                }
   MAX-ACCESS read-create
    STATUS
              current
    DESCRIPTION
        "The variable for each nlMatrix[SD/DS] entry that the
        nlMatrixTopNEntries are sorted by, as well as a control
        for the table that the results will be reported in.
        This object may not be modified if the associated
        nlMatrixTopNControlStatus object is equal to active(1).
        If this value is less than or equal to 2, when the report
        is prepared, entries are created in the nlMatrixTopNTable
        associated with this object.
        If this value is greater than or equal to 3, when the report
        is prepared, entries are created in the
        nlMatrixTopNHighCapacityTable associated with this object."
    ::= { nlMatrixTopNControlEntry 3 }
```

```
From the RMON2 MIB:
alMatrixTopNControlRateBase OBJECT-TYPE
    SYNTAX
               INTEGER {
                  alMatrixTopNTerminalsPkts(1),
                  alMatrixTopNTerminalsOctets(2),
                  alMatrixTopNAllPkts(3),
                  alMatrixTopNAllOctets(4),
                  alMatrixTopNTerminalsHighCapacityPkts(5),
                  alMatrixTopNTerminalsHighCapacityOctets(6),
                  alMatrixTopNAllHighCapacityPkts(7),
                  alMatrixTopNAllHighCapacityOctets(8)
    MAX-ACCESS read-create
    STATUS
           current
    DESCRIPTION
        "The variable for each alMatrix[SD/DS] entry that the
        alMatrixTopNEntries are sorted by, as well as the
        selector of the view of the matrix table that will be
        used, as well as a control for the table that the results
        will be reported in.
        The values alMatrixTopNTerminalsPkts,
        alMatrixTopNTerminalsOctets,
        alMatrixTopNTerminalsHighCapacityPkts, and
        alMatrixTopNTerminalsHighCapacityOctets cause collection
        only from protocols that have no child protocols that are
        counted. The values alMatrixTopNAllPkts,
        alMatrixTopNAllOctets, alMatrixTopNAllHighCapacityPkts, and
        alMatrixTopNAllHighCapacityOctets cause collection from all
        alMatrix entries.
        This object may not be modified if the associated
        alMatrixTopNControlStatus object is equal to active(1)."
    ::= { alMatrixTopNControlEntry 3 }
```

For convenience, updated MIB modules containing these objects may be

```
ftp://ftp.rfc-editor.org/in-notes/mibs/current.mibs/rmon.mib
ftp://ftp.rfc-editor.org/in-notes/mibs/current.mibs/rmon2.mib
```

4. Conventions

The following conventions are used throughout the RMON MIB and its companion documents.

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119.

Good Packets

Good packets are error-free packets that have a valid frame length. For example, on Ethernet, good packets are error-free packets that are between 64 octets long and 1518 octets long. They follow the form defined in IEEE 802.3 section 3.2.all. Implementors are urged to consult the appropriate media-specific specifications.

Bad Packets

Bad packets are packets that have proper framing and are therefore recognized as packets, but contain errors within the packet or have an invalid length. For example, on Ethernet, bad packets have a valid preamble and SFD (Start of Frame Delimiter), but have a bad FCS (Frame Check Sequence), or are either shorter than 64 octets or longer than 1518 octets. Implementors are urged to consult the appropriate media-specific specifications.

MODULE-IDENTITY, OBJECT-TYPE, Counter32, Integer32,

5. Definitions

```
HC-RMON-MIB DEFINITIONS ::= BEGIN
IMPORTS
```

Gauge32, Counter64 FROM SNMPv2-SMI RowStatus, TimeStamp FROM SNMPv2-TC MODULE-COMPLIANCE, OBJECT-GROUP FROM SNMPv2-CONF rmon, OwnerString, statistics, history, hosts, hostTopN, matrix, etherStatsIndex, etherHistoryIndex, etherHistorySampleIndex, hostIndex, hostAddress, hostTimeIndex, hostTimeCreationOrder, hostTopNReport, hostTopNIndex, matrixSDIndex, matrixSDSourceAddress, matrixSDDestAddress, matrixDSIndex, matrixDSDestAddress, matrixDSSourceAddress, capture, captureBufferControlIndex, captureBufferIndex FROM RMON-MIB protocolDirLocalIndex, protocolDistControlIndex, protocolDist, hlHostControlIndex, nlHost, nlHostTimeMark, nlHostAddress, hlMatrixControlIndex, nlMatrix, nlMatrixSDTimeMark, nlMatrixSDSourceAddress, nlMatrixSDDestAddress, nlMatrixDSTimeMark, nlMatrixDSDestAddress, nlMatrixDSSourceAddress, nlMatrixTopNControlIndex, nlMatrixTopNIndex, alHost, alHostTimeMark, alMatrix, alMatrixSDTimeMark, alMatrixDSTimeMark, alMatrixTopNControlIndex, alMatrixTopNIndex,

```
usrHistory, usrHistoryControlIndex,
    usrHistorySampleIndex, usrHistoryObjectIndex,
    rmonConformance, ZeroBasedCounter32, probeConfig
                                    FROM RMON2-MIB
    ZeroBasedCounter64, CounterBasedGauge64
                                    FROM HCNUM-TC;
-- Remote Network Monitoring MIB
hcrmon Module-IDENTITY
    LAST-UPDATED "200205080000Z" -- May 08, 2002
    ORGANIZATION "IETF RMON MIB Working Group"
    CONTACT-INFO
        "Steve Waldbusser
        Phone: +1-650-948-6500
        Fax: +1-650-745-0671
        Email: waldbusser@nextbeacon.com
        Andy Bierman
        WG Chair
        abierman@cisco.com
        RMONMIB WG Mailing List
        rmonmib@ietf.org
        http://www.ietf.org/mailman/listinfo/rmonmib"
    DESCRIPTION
        "The MIB module for managing remote monitoring
        device implementations. This MIB module
        augments the original RMON MIB as specified in
        RFC 2819 and RFC 1513 and RMON-2 MIB as specified in
        RFC 2021."
    REVISION "200205080000Z"
                              -- May 08, 2002
    DESCRIPTION
       "The original version of this MIB, published as RFC3273."
    ::= { rmonConformance 5 }
-- { rmon 1 } through { rmon 20 } are defined in RMON [RFC 2819] and
-- the Token Ring RMON MIB [RFC 1513] and the RMON-2 MIB [RFC 2021].
mediaIndependentStats OBJECT IDENTIFIER ::= { rmon 21 }
mediaIndependentTable OBJECT-TYPE
    SYNTAX
           SEQUENCE OF MediaIndependentEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
```

"Media independent statistics for promiscuous monitoring of any media.

The following table defines media independent statistics that provide information for full and/or half-duplex links as well as high capacity links.

For half-duplex links, or full-duplex-capable links operating in half-duplex mode, the mediaIndependentIn* objects shall be used and the mediaIndependentOut* objects shall not increment.

For full-duplex links, the mediaIndependentOut* objects shall be present and shall increment. Whenever possible, the probe should count packets moving away from the closest terminating equipment as output packets. Failing that, the probe should count packets moving away from the DTE as output packets."

```
::= { mediaIndependentStats 1 }
mediaIndependentEntry OBJECT-TYPE
           MediaIndependentEntry
   MAX-ACCESS not-accessible
   STATUS
           current.
   DESCRIPTION
        "Media independent statistics for promiscuous monitoring of
       any media."
    INDEX { mediaIndependentIndex }
    ::= { mediaIndependentTable 1 }
MediaIndependentEntry ::= SEQUENCE {
    mediaIndependentIndex
                                               Integer32,
    mediaIndependentDataSource
                                               OBJECT IDENTIFIER,
    mediaIndependentDropEvents
                                               Counter32,
    mediaIndependentDroppedFrames
                                               Counter32,
    mediaIndependentInPkts
                                               Counter32,
   mediaIndependentInOverflowPkts
                                               Counter32,
   mediaIndependentInHighCapacityPkts
                                             Counter64,
   mediaIndependentOutPkts
                                               Counter32,
   mediaIndependentOutOverflowPkts
                                               Counter32,
   mediaIndependentOutHighCapacityPkts
                                               Counter64,
   mediaIndependentInOctets
                                               Counter32,
```

mediaIndependentInOverflowOctets

mediaIndependentOutOverflowOctets

mediaIndependentOutOctets

mediaIndependentInNUCastPkts

mediaIndependentInHighCapacityOctets

mediaIndependentOutHighCapacityOctets

mediaIndependentInNUCastOverflowPkts

Counter32,

Counter64,

Counter32,

Counter32,

Counter32,

Counter32,

Counter64,

```
mediaIndependentInNUCastHighCapacityPkts Counter64,
   mediaIndependentOutNUCastPkts
                                             Counter32,
   mediaIndependentOutNUCastOverflowPkts Counter32,
   mediaIndependentOutNUCastHighCapacityPkts Counter64,
   mediaIndependentInErrors
                                               Counter32,
   mediaIndependentOutErrors
                                               Counter32,
   mediaIndependentInputSpeed
                                               Gauge32,
   mediaIndependentOutputSpeed
                                               Gauge32,
   mediaIndependentDuplexMode
                                               INTEGER,
   mediaIndependentDuplexChanges
                                              Counter32,
   mediaIndependentDuplexLastChange
                                              TimeStamp,
   mediaIndependentOwner
                                              OwnerString,
   mediaIndependentStatus
                                              RowStatus
}
mediaIndependentIndex OBJECT-TYPE
    SYNTAX
           Integer32 (1..65535)
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The value of this object uniquely identifies this
       mediaIndependent entry."
    ::= { mediaIndependentEntry 1 }
mediaIndependentDataSource OBJECT-TYPE
   SYNTAX OBJECT IDENTIFIER
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
        "This object identifies the source of the data that
       this mediaIndependent entry is configured to analyze. This
       source can be any interface on this device.
       In order to identify a particular interface, this
       object shall identify the instance of the ifIndex
       object, defined in RFC 1213 and RFC 2233 [16,17], for
       the desired interface. For example, if an entry
       were to receive data from interface #1, this object
       would be set to ifIndex.1.
       The statistics in this group reflect all packets
       on the local network segment attached to the
        identified interface.
       An agent may or may not be able to tell if
       fundamental changes to the media of the interface
       have occurred and necessitate a deletion of
       this entry. For example, a hot-pluggable ethernet
       card could be pulled out and replaced by a
```

```
token-ring card. In such a case, if the agent has
       such knowledge of the change, it is recommended that
       it delete this entry.
       This object may not be modified if the associated
       mediaIndependentStatus object is equal to active(1)."
    ::= { mediaIndependentEntry 2 }
mediaIndependentDropEvents OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Events"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of events in which packets
       were dropped by the probe due to lack of resources.
       Note that this number is not necessarily the number of
       packets dropped; it is just the number of times this
       condition has been detected."
    ::= { mediaIndependentEntry 3 }
mediaIndependentDroppedFrames OBJECT-TYPE
   SYNTAX Counter32
   UNITS "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of frames which were received by the probe
       and therefore not accounted for in the
       mediaIndependentDropEvents, but for which the probe chose not
       to count for this entry for whatever reason. Most often, this
       event occurs when the probe is out of some resources and
       decides to shed load from this collection.
       This count does not include packets that were not counted
       because they had MAC-layer errors.
       Note that, unlike the dropEvents counter, this number is the
       exact number of frames dropped."
    ::= { mediaIndependentEntry 4 }
mediaIndependentInPkts OBJECT-TYPE
   SYNTAX Counter32
               "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of packets (including bad packets,
```

```
broadcast packets, and multicast packets) received
       on a half-duplex link or on the inbound connection of a
       full-duplex link."
    ::= { mediaIndependentEntry 5 }
mediaIndependentInOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated
       mediaIndependentInPkts counter has overflowed."
    ::= { mediaIndependentEntry 6 }
mediaIndependentInHighCapacityPkts OBJECT-TYPE
   SYNTAX Counter64
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of packets (including bad packets,
       broadcast packets, and multicast packets) received
       on a half-duplex link or on the inbound connection of a
       full-duplex link."
    ::= { mediaIndependentEntry 7 }
mediaIndependentOutPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
        "The total number of packets (including bad packets,
       broadcast packets, and multicast packets) received on a
       full-duplex link in the direction of the network."
    ::= { mediaIndependentEntry 8 }
mediaIndependentOutOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated
       mediaIndependentOutPkts counter has overflowed."
    ::= { mediaIndependentEntry 9 }
```

```
mediaIndependentOutHighCapacityPkts OBJECT-TYPE
   SYNTAX Counter64
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of packets (including bad packets,
       broadcast packets, and multicast packets) received on a
       full-duplex link in the direction of the network."
    ::= { mediaIndependentEntry 10 }
mediaIndependentInOctets OBJECT-TYPE
   SYNTAX Counter32
              "Octets"
   UNTTS
   MAX-ACCESS read-only
               current
   STATUS
   DESCRIPTION
       "The total number of octets of data (including those in bad
       packets) received (excluding framing bits but including FCS
       octets) on a half-duplex link or on the inbound connection of
       a full-duplex link."
    ::= { mediaIndependentEntry 11 }
mediaIndependentInOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated
       mediaIndependentInOctets counter has overflowed."
    ::= { mediaIndependentEntry 12 }
mediaIndependentInHighCapacityOctets OBJECT-TYPE
   SYNTAX Counter64
   UNITS
               "Octets"
   MAX-ACCESS read-only
               current
   DESCRIPTION
        "The total number of octets of data (including those in bad
       packets) received (excluding framing bits but
       including FCS octets) on a half-duplex link or on the inbound
       connection of a full-duplex link."
    ::= { mediaIndependentEntry 13 }
mediaIndependentOutOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Octets"
```

```
MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of octets of data (including those in bad
       packets) received on a full-duplex link in the direction of
       the network (excluding framing bits but including FCS
       octets)."
    ::= { mediaIndependentEntry 14 }
mediaIndependentOutOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Octets"
   MAX-ACCESS read-only
              current
   STATUS
   DESCRIPTION
       "The number of times the associated
       mediaIndependentOutOctets counter has overflowed."
    ::= { mediaIndependentEntry 15 }
mediaIndependentOutHighCapacityOctets OBJECT-TYPE
   SYNTAX
              Counter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of octets of data (including those in bad
       packets) received on a full-duplex link in the direction of
       the network (excluding framing bits but including FCS
       octets)."
    ::= { mediaIndependentEntry 16 }
mediaIndependentInNUCastPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
       "The total number of non-unicast packets (including bad
       packets) received on a half-duplex link or on the inbound
       connection of a full-duplex link."
    ::= { mediaIndependentEntry 17 }
mediaIndependentInNUCastOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
```

```
"The number of times the associated
       mediaIndependentInNUCastPkts counter has overflowed."
    ::= { mediaIndependentEntry 18 }
mediaIndependentInNUCastHighCapacityPkts OBJECT-TYPE
   SYNTAX
           Counter64
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of non-unicast packets (including bad
       packets) received on a half-duplex link or on the inbound
       connection of a full-duplex link."
    ::= { mediaIndependentEntry 19 }
mediaIndependentOutNUCastPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of non-unicast packets (including bad
       packets) received on a full-duplex link in the direction of
       the network."
    ::= { mediaIndependentEntry 20 }
mediaIndependentOutNUCastOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
   STATUS
              current
   DESCRIPTION
       "The number of times the associated
       mediaIndependentOutNUCastPkts counter has overflowed."
    ::= { mediaIndependentEntry 21 }
mediaIndependentOutNUCastHighCapacityPkts OBJECT-TYPE
             Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
        "The total number of packets (including bad packets)
       received on a full-duplex link in the direction of the
       network."
    ::= { mediaIndependentEntry 22 }
mediaIndependentInErrors OBJECT-TYPE
```

```
SYNTAX
             Counter32
    UNITS
               "Packets"
   MAX-ACCESS read-only
    STATUS
             current
   DESCRIPTION
        "The total number of bad packets received on a
       half-duplex link or on the inbound connection of a
        full-duplex link."
    ::= { mediaIndependentEntry 23 }
mediaIndependentOutErrors OBJECT-TYPE
    SYNTAX
           Counter32
   UNITS
               "Packets"
   MAX-ACCESS read-only
    STATUS
           current
    DESCRIPTION
        "The total number of bad packets received on a full-duplex
       link in the direction of the network."
    ::= { mediaIndependentEntry 24 }
mediaIndependentInputSpeed OBJECT-TYPE
   SYNTAX
             Gauge32
              "Kilobits per Second"
   UNITS
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The nominal maximum speed in kilobits per second of this
       half-duplex link or on the inbound connection of this
       full-duplex link. If the speed is unknown or there is no fixed
       maximum (e.g. a compressed link), this value shall be zero."
    ::= { mediaIndependentEntry 25 }
mediaIndependentOutputSpeed OBJECT-TYPE
    SYNTAX Gauge32
    UNITS
              "Kilobits per Second"
   MAX-ACCESS read-only
   STATUS current
    DESCRIPTION
        "The nominal maximum speed in kilobits per second of this
        full-duplex link in the direction of the network. If the speed
       is unknown, the link is half-duplex, or there is no fixed
        maximum (e.g. a compressed link), this value shall be zero."
    ::= { mediaIndependentEntry 26 }
mediaIndependentDuplexMode OBJECT-TYPE
    SYNTAX
              INTEGER {
                   halfduplex(1),
                   fullduplex(2)
```

```
}
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The current mode of this link.
       Note that if the link has full-duplex capabilities but
       is operating in half-duplex mode, this value will be
       halfduplex(1)."
    ::= { mediaIndependentEntry 27 }
mediaIndependentDuplexChanges OBJECT-TYPE
   SYNTAX
             Counter32
              "Events"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times this link has changed from full-duplex
       mode to half-duplex mode or from half-duplex mode to
       full-duplex mode."
    ::= { mediaIndependentEntry 28 }
mediaIndependentDuplexLastChange OBJECT-TYPE
   SYNTAX TimeStamp
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The value of sysUpTime at the time the duplex status
       of this link last changed."
    ::= { mediaIndependentEntry 29 }
mediaIndependentOwner OBJECT-TYPE
   SYNTAX OwnerString
   MAX-ACCESS read-create
   STATUS
           current
   DESCRIPTION
       "The entity that configured this entry and is
       therefore using the resources assigned to it."
    ::= { mediaIndependentEntry 30 }
mediaIndependentStatus OBJECT-TYPE
   SYNTAX RowStatus
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
       "The status of this media independent statistics entry."
    ::= { mediaIndependentEntry 31 }
```

```
-- High Capacity extensions for the etherStatsTable
etherStatsHighCapacityTable OBJECT-TYPE
            SEQUENCE OF EtherStatsHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       etherStatsTable."
    ::= { statistics 7 }
etherStatsHighCapacityEntry OBJECT-TYPE
   SYNTAX EtherStatsHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Contains the High Capacity RMON extensions to the RMON-1
       etherStatsEntry. These objects will be created by the agent
       for all etherStatsEntries it deems appropriate."
   INDEX { etherStatsIndex }
    ::= { etherStatsHighCapacityTable 1 }
EtherStatsHighCapacityEntry ::= SEQUENCE {
   etherStatsHighCapacityOverflowPkts
                                                      Counter32,
   etherStatsHighCapacityPkts
                                                      Counter64,
   etherStatsHighCapacityOverflowOctets
                                                      Counter32,
   etherStatsHighCapacityOctets
                                                      Counter64,
   etherStatsHighCapacityOverflowPkts64Octets
                                                      Counter32,
   etherStatsHighCapacityPkts64Octets
                                                      Counter64,
   etherStatsHighCapacityOverflowPkts65to127Octets
                                                     Counter32,
   etherStatsHighCapacityPkts65to1270ctets
                                                     Counter64,
   etherStatsHighCapacityOverflowPkts128to255Octets Counter32,
   etherStatsHighCapacityPkts128to2550ctets
                                                     Counter64,
   etherStatsHighCapacityOverflowPkts256to511Octets Counter32,
   etherStatsHighCapacityPkts256to511Octets
                                                    Counter64,
   etherStatsHighCapacityOverflowPkts512to1023Octets Counter32,
   etherStatsHighCapacityPkts512to1023Octets Counter64,
   etherStatsHighCapacityOverflowPkts1024to1518Octets Counter32,
   etherStatsHighCapacityPkts1024to1518Octets Counter64
}
etherStatsHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
```

```
"The number of times the associated etherStatsPkts
       counter has overflowed."
    ::= { etherStatsHighCapacityEntry 1 }
etherStatsHighCapacityPkts OBJECT-TYPE
    SYNTAX Counter64
            "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of packets (including bad packets,
       broadcast packets, and multicast packets) received."
    ::= { etherStatsHighCapacityEntry 2 }
etherStatsHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated etherStatsOctets
       counter has overflowed."
    ::= { etherStatsHighCapacityEntry 3 }
etherStatsHighCapacityOctets OBJECT-TYPE
   SYNTAX Counter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of octets of data (including
       those in bad packets) received on the
       network (excluding framing bits but including
       FCS octets).
       If the network is half-duplex Fast Ethernet, this
       object can be used as a reasonable estimate of
       utilization. If greater precision is desired, the
       etherStatsHighCapacityPkts and
       etherStatsHighCapacityOctets objects should be sampled
       before and after a common interval. The differences
       in the sampled values are Pkts and Octets,
       respectively, and the number of seconds in the
       interval is Interval. These values
       are used to calculate the Utilization as follows:
```

```
Pkts * (.96 + .64) + (Octets * .08)
Utilization = ------
Interval * 10,000
```

The result of this equation is the value Utilization which is the percent utilization of the ethernet segment on a scale of 0 to 100 percent.

This table is not appropriate for monitoring full-duplex ethernets. If the network is a full-duplex ethernet and the mediaIndependentTable is monitoring that network, the utilization can be calculated as follows:

- 1) Determine the utilization of the inbound path by using the appropriate equation (for ethernet or fast ethernet) to determine the utilization, substituting mediaIndependentInPkts for etherStatsHighCapacityPkts, and mediaIndependentInOctets for etherStatsHighCapacityOctets. Call the resulting utilization inUtilization.
- 2) Determine the utilization of the outbound path by using the same equation to determine the utilization, substituting mediaIndependentOutPkts for etherStatsHighCapacityPkts, and mediaIndependentOutOctets for etherStatsHighCapacityOctets. Call the resulting utilization outUtilization.
- 3) The utilization is the maximum of inUtilization and outUtilization. This metric shows the amount of percentage of bandwidth that is left before congestion will be experienced on the link."

```
::= { etherStatsHighCapacityEntry 4 }
```

```
etherStatsHighCapacityOverflowPkts64Octets OBJECT-TYPE
```

```
SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
```

"The number of times the associated ether StatsPkts64Octets counter has overflowed." $\,$

```
::= { etherStatsHighCapacityEntry 5 }
```

etherStatsHighCapacityPkts64Octets OBJECT-TYPE

SYNTAX Counter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

```
"The total number of packets (including bad
       packets) received that were 64 octets in length
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 6 }
etherStatsHighCapacityOverflowPkts65to127Octets OBJECT-TYPE
   SYNTAX Counter32
             "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated etherStatsPkts65to1270ctets
       counter has overflowed."
    ::= { etherStatsHighCapacityEntry 7 }
etherStatsHighCapacityPkts65to1270ctets OBJECT-TYPE
   SYNTAX Counter64
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of packets (including bad
       packets) received that were between
       65 and 127 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 8 }
etherStatsHighCapacityOverflowPkts128to255Octets OBJECT-TYPE
   SYNTAX Counter32
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The number of times the associated etherStatsPkts128to255Octets
       counter has overflowed."
    ::= { etherStatsHighCapacityEntry 9 }
etherStatsHighCapacityPkts128to2550ctets OBJECT-TYPE
   SYNTAX Counter64
            "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of packets (including bad
       packets) received that were between
       128 and 255 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 10 }
```

```
etherStatsHighCapacityOverflowPkts256to511Octets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated etherStatsPkts256to5110ctets
       counter has overflowed."
    ::= { etherStatsHighCapacityEntry 11 }
etherStatsHighCapacityPkts256to511Octets OBJECT-TYPE
   SYNTAX Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The total number of packets (including bad
       packets) received that were between
       256 and 511 octets in length inclusive
       (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 12 }
etherStatsHighCapacityOverflowPkts512to1023Octets OBJECT-TYPE
   SYNTAX Counter32
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated
        etherStatsPkts512to1023Octets counter has overflowed."
    ::= { etherStatsHighCapacityEntry 13 }
etherStatsHighCapacityPkts512to1023Octets OBJECT-TYPE
    SYNTAX Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of packets (including bad
       packets) received that were between
       512 and 1023 octets in length inclusive
        (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 14 }
etherStatsHighCapacityOverflowPkts1024to1518Octets OBJECT-TYPE
   SYNTAX Counter32
              "Packets"
   UNITS
   MAX-ACCESS read-only
```

```
STATUS
            current
   DESCRIPTION
       "The number of times the associated
       etherStatsPkts1024to1518Octets counter has overflowed."
    ::= { etherStatsHighCapacityEntry 15 }
etherStatsHighCapacityPkts1024to1518Octets OBJECT-TYPE
    SYNTAX Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The total number of packets (including bad
       packets) received that were between
       1024 and 1518 octets in length inclusive
        (excluding framing bits but including FCS octets)."
    ::= { etherStatsHighCapacityEntry 16 }
-- High Capacity extensions for the etherHistoryTable
etherHistoryHighCapacityTable OBJECT-TYPE
   SYNTAX SEQUENCE OF EtherHistoryHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       etherHistoryTable."
    ::= { history 6 }
etherHistoryHighCapacityEntry OBJECT-TYPE
   SYNTAX EtherHistoryHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       etherHistoryEntry. These objects will be created by the agent
       for all etherHistoryEntries associated with whichever
       historyControlEntries it deems appropriate. (i.e., either all
       etherHistoryHighCapacityEntries associated with a particular
       historyControlEntry will be created, or none of them will
       be.)"
    INDEX { etherHistoryIndex, etherHistorySampleIndex }
    ::= { etherHistoryHighCapacityTable 1 }
EtherHistoryHighCapacityEntry ::= SEQUENCE {
   etherHistoryHighCapacityOverflowPkts
                                                  Gauge32,
   etherHistoryHighCapacityPkts
                                                  CounterBasedGauge64,
   etherHistoryHighCapacityOverflowOctets
                                                 Gauge32,
```

```
etherHistoryHighCapacityOctets
                                                CounterBasedGauge64
}
etherHistoryHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX
             Gauge32
             "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated etherHistoryPkts
       Gauge overflowed during this sampling interval."
    ::= { etherHistoryHighCapacityEntry 1 }
etherHistoryHighCapacityPkts OBJECT-TYPE
   SYNTAX CounterBasedGauge64
             "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of packets (including bad packets,
       broadcast packets, and multicast packets) received during
       this sampling interval."
    ::= { etherHistoryHighCapacityEntry 2 }
etherHistoryHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX Gauge32
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated etherHistoryOctets
       counter has overflowed during this sampling interval."
    ::= { etherHistoryHighCapacityEntry 3 }
etherHistoryHighCapacityOctets OBJECT-TYPE
   SYNTAX CounterBasedGauge64
   UNITS
             "Octets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The total number of octets of data (including
       those in bad packets) received on the
       network (excluding framing bits but including
       FCS octets) during this sampling interval."
    ::= { etherHistoryHighCapacityEntry 4 }
-- High Capacity Extensions for the hostTable
```

```
hostHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       hostTable."
    ::= { hosts 5 }
hostHighCapacityEntry OBJECT-TYPE
    SYNTAX HostHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       hostEntry. These objects will be created by the agent
       for all hostEntries associated with whichever
       hostControlEntries it deems appropriate. (i.e., either all
       hostHighCapacityEntries associated with a particular
       hostControlEntry will be created, or none of them will
    INDEX { hostIndex, hostAddress }
    ::= { hostHighCapacityTable 1 }
HostHighCapacityEntry ::= SEQUENCE {
   hostHighCapacityInOverflowPkts Counter32,
   hostHighCapacityInPkts
                                    Counter64,
   hostHighCapacityOutOverflowPkts Counter32,
   hostHighCapacityOutPkts Counter64,
   hostHighCapacityInOverflowOctets Counter32,
   hostHighCapacityInOctets Counter64,
   hostHighCapacityOutOverflowOctets Counter32,
   hostHighCapacityOutOctets
                                    Counter64
}
hostHighCapacityInOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
             "Packets"
   MAX-ACCESS read-only
   STATUS
           current.
   DESCRIPTION
        "The number of times the associated hostInPkts
       counter has overflowed."
    ::= { hostHighCapacityEntry 1 }
hostHighCapacityInPkts OBJECT-TYPE
   SYNTAX Counter64
    UNITS
             "Packets"
```

```
MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of good packets transmitted to
       this address since it was added to the
       hostHighCapacityTable."
    ::= { hostHighCapacityEntry 2 }
hostHighCapacityOutOverflowPkts OBJECT-TYPE
    SYNTAX Counter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
       "The number of times the associated hostOutPkts
       counter has overflowed."
    ::= { hostHighCapacityEntry 3 }
hostHighCapacityOutPkts OBJECT-TYPE
   SYNTAX Counter64
   UNITS
             "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets, including bad packets, transmitted
       by this address since it was added to the
       hostHighCapacityTable."
    ::= { hostHighCapacityEntry 4 }
hostHighCapacityInOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS
           current
   DESCRIPTION
       "The number of times the associated hostInOctets
       counter has overflowed."
    ::= { hostHighCapacityEntry 5 }
hostHighCapacityInOctets OBJECT-TYPE
   SYNTAX Counter64
            "Octets"
    UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets transmitted to this address
        since it was added to the hostHighCapacityTable (excluding
       framing bits but including FCS octets), except for
```

```
those octets in bad packets."
    ::= { hostHighCapacityEntry 6 }
hostHighCapacityOutOverflowOctets OBJECT-TYPE
    SYNTAX
             Counter32
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of times the associated hostOutOctets
        counter has overflowed."
    ::= { hostHighCapacityEntry 7 }
hostHighCapacityOutOctets OBJECT-TYPE
    SYNTAX Counter64
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets transmitted by this address
        since it was added to the hostHighCapacityTable (excluding
       framing bits but including FCS octets), including
        those octets in bad packets."
    ::= { hostHighCapacityEntry 8 }
-- High Capacity extensions for the hostTimeTable
hostTimeHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostTimeHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       hostTimeTable."
    ::= { hosts 6 }
hostTimeHighCapacityEntry OBJECT-TYPE
            HostTimeHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTimeEntry. These objects will be created by the agent
        for all hostTimeEntries associated with whichever
        hostControlEntries it deems appropriate. (i.e., either all
        hostTimeHighCapacityEntries associated with a particular
        hostControlEntry will be created, or none of them will
        be.)"
```

```
INDEX { hostTimeIndex, hostTimeCreationOrder }
    ::= { hostTimeHighCapacityTable 1 }
HostTimeHighCapacityEntry ::= SEQUENCE {
    hostTimeHighCapacityInOverflowPkts Counter32,
                                        Counter64,
    hostTimeHighCapacityInPkts
    hostTimeHighCapacityOutOverflowPkts Counter32, hostTimeHighCapacityOutPkts Counter64,
    host \verb|TimeHighCapacityInOverflowOctets| Counter 32,
    hostTimeHighCapacityInOctets Counter64,
    hostTimeHighCapacityOutOverflowOctets Counter32,
    hostTimeHighCapacityOutOctets
                                         Counter64
}
hostTimeHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX Counter32
    UNITS
               "Packets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of times the associated hostTimeInPkts
        counter has overflowed."
    ::= { hostTimeHighCapacityEntry 1 }
hostTimeHighCapacityInPkts OBJECT-TYPE
    SYNTAX Counter64
    UNITS
               "Packets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of good packets transmitted to this address
        since it was added to the hostTimeHighCapacityTable."
    ::= { hostTimeHighCapacityEntry 2 }
hostTimeHighCapacityOutOverflowPkts OBJECT-TYPE
    SYNTAX Counter32
    UNITS
              "Packets"
    MAX-ACCESS read-only
    STATUS
            current
    DESCRIPTION
        "The number of times the associated hostTimeOutPkts
        counter has overflowed."
    ::= { hostTimeHighCapacityEntry 3 }
hostTimeHighCapacityOutPkts OBJECT-TYPE
    SYNTAX Counter64
    UNITS
              "Packets"
    MAX-ACCESS read-only
```

```
STATUS
            current
    DESCRIPTION
        "The number of packets, including bad packets, transmitted
       by this address since it was added to the
       hostTimeHighCapacityTable."
    ::= { hostTimeHighCapacityEntry 4 }
hostTimeHighCapacityInOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of times the associated hostTimeInOctets
        counter has overflowed."
    ::= { hostTimeHighCapacityEntry 5 }
hostTimeHighCapacityInOctets OBJECT-TYPE
    SYNTAX Counter64
    UNITS "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets transmitted to this address
        since it was added to the hostTimeHighCapacityTable
       (excluding framing bits but including FCS octets),
        except for those octets in bad packets."
    ::= { hostTimeHighCapacityEntry 6 }
hostTimeHighCapacityOutOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
              "Octets"
   UNITS
   MAX-ACCESS read-only
    STATUS
           current
   DESCRIPTION
       "The number of times the associated hostTimeOutOctets
       counter has overflowed."
    ::= { hostTimeHighCapacityEntry 7 }
hostTimeHighCapacityOutOctets OBJECT-TYPE
   SYNTAX Counter64
            "Octets"
    UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets transmitted by this address since
       it was added to the hostTimeTable (excluding framing
       bits but including FCS octets), including those
```

```
octets in bad packets."
    ::= { hostTimeHighCapacityEntry 8 }
-- High Capacity Extensions for the hostTopNTable
hostTopNHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF HostTopNHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTopNTable when hostTopNRateBase specifies a High Capacity
        TopN Report."
    ::= { hostTopN 3 }
hostTopNHighCapacityEntry OBJECT-TYPE
    SYNTAX HostTopNHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTopNEntry when hostTopNRateBase specifies a High Capacity
        TopN Report. These objects will be created by the agent
        for all hostTopNEntries associated with whichever
        hostTopNControlEntries have a hostTopNRateBase that specify
        a high capacity report."
    INDEX { hostTopNReport, hostTopNIndex }
    ::= { hostTopNHighCapacityTable 1 }
HostTopNHighCapacityEntry ::= SEQUENCE {
    TopNHighCapacityEntry
hostTopNHighCapacityAddress
OCTET ST
Gauge32,
                                       OCTET STRING,
     \verb|hostTopNHighCapacityOverflowRate| Gauge 32,\\
     hostTopNHighCapacityRate
                                       CounterBasedGauge64
}
hostTopNHighCapacityAddress OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
          "The physical address of this host."
    ::= { hostTopNHighCapacityEntry 1 }
hostTopNHighCapacityBaseRate OBJECT-TYPE
    SYNTAX Gauge32
    MAX-ACCESS read-only
    STATUS
             current
```

```
DESCRIPTION
          "The amount of change in the selected variable
         during this sampling interval, modulo 2^32. The
          selected variable is this host's instance of the
          object selected by hostTopNRateBase."
    ::= { hostTopNHighCapacityEntry 2 }
hostTopNHighCapacityOverflowRate OBJECT-TYPE
    SYNTAX
           Gauge32
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
          "The amount of change in the selected variable
         during this sampling interval, divided by 2^32, truncating
          fractions (i.e., X DIV 2^32). The selected variable is
          this host's instance of the object selected by
         hostTopNRateBase."
    ::= { hostTopNHighCapacityEntry 3 }
hostTopNHighCapacityRate OBJECT-TYPE
              CounterBasedGauge64
     SYNTAX
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
          "The amount of change in the selected variable
         during this sampling interval. The selected
         variable is this host's instance of the object
          selected by hostTopNRateBase."
     ::= { hostTopNHighCapacityEntry 4 }
-- High Capacity Extensions for the matrixSDTable
matrixSDHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF MatrixSDHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       matrixSDTable."
    ::= { matrix 5 }
matrixSDHighCapacityEntry OBJECT-TYPE
    SYNTAX
           MatrixSDHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       matrixSDEntry. These objects will be created by the agent
```

```
for all matrixSDEntries associated with whichever
       matrixControlEntries it deems appropriate. (i.e., either all
       matrixSDHighCapacityEntries associated with a particular
       matrixControlEntry will be created, or none of them will
       be.)"
    INDEX { matrixSDIndex,
           matrixSDSourceAddress, matrixSDDestAddress }
    ::= { matrixSDHighCapacityTable 1 }
MatrixSDHighCapacityEntry ::= SEQUENCE {
   matrixSDHighCapacityOverflowPkts Counter32,
   matrixSDHighCapacityPkts
                                    Counter64,
   matrixSDHighCapacityOverflowOctets Counter32,
   matrixSDHighCapacityOctets
                                     Counter64
}
matrixSDHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The number of times the associated matrixSDPkts
       counter has overflowed."
    ::= { matrixSDHighCapacityEntry 1 }
matrixSDHighCapacityPkts OBJECT-TYPE
   SYNTAX Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets transmitted from the source
       address to the destination address (this number
       includes bad packets)."
    ::= { matrixSDHighCapacityEntry 2 }
matrixSDHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX
             Counter32
   UNITS "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated matrixSDOctets
       counter has overflowed."
    ::= { matrixSDHighCapacityEntry 3 }
matrixSDHighCapacityOctets OBJECT-TYPE
```

```
Counter64
    SYNTAX
    UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The number of octets (excluding framing bits but
        including FCS octets) contained in all packets
       transmitted from the source address to the
       destination address."
    ::= { matrixSDHighCapacityEntry 4 }
-- High Capacity extensions for the matrixDSTable
\verb|matrixDSHighCapacityTable| OBJECT-TYPE|
    SYNTAX SEQUENCE OF MatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
       "Contains the High Capacity RMON extensions to the RMON-1
       matrixDSTable."
    ::= { matrix 6 }
\verb|matrixDSHighCapacityEntry| OBJECT-TYPE|
    SYNTAX MatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS
           current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       matrixDSEntry. These objects will be created by the agent
       for all matrixDSEntries associated with whichever
       matrixControlEntries it deems appropriate. (i.e., either all
       matrixDSHighCapacityEntries associated with a particular
       matrixControlEntry will be created, or none of them will
       be.)"
    INDEX { matrixDSIndex,
           matrixDSDestAddress, matrixDSSourceAddress }
    ::= { matrixDSHighCapacityTable 1 }
MatrixDSHighCapacityEntry ::= SEQUENCE {
   matrixDSHighCapacityOverflowPkts Counter32,
   matrixDSHighCapacityPkts Counter64,
   matrixDSHighCapacityOverflowOctets Counter32,
   matrixDSHighCapacityOctets
}
matrixDSHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
              "Packets"
```

```
MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated matrixDSPkts
       counter has overflowed."
    ::= { matrixDSHighCapacityEntry 1 }
matrixDSHighCapacityPkts OBJECT-TYPE
   SYNTAX Counter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of packets transmitted from the source
       address to the destination address (this number
       includes bad packets)."
    ::= { matrixDSHighCapacityEntry 2 }
matrixDSHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX Counter32
   UNITS "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated matrixDSOctets
       counter has overflowed."
    ::= { matrixDSHighCapacityEntry 3 }
matrixDSHighCapacityOctets OBJECT-TYPE
   SYNTAX Counter64
             "Octets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of octets (excluding framing bits
       but including FCS octets) contained in all packets
       transmitted from the source address to the
       destination address."
    ::= { matrixDSHighCapacityEntry 4 }
-- High Capacity extensions for the captureBufferTable
captureBufferHighCapacityTable OBJECT-TYPE
   SYNTAX SEQUENCE OF CaptureBufferHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1 \,
```

```
captureBufferTable."
    ::= { capture 3 }
captureBufferHighCapacityEntry OBJECT-TYPE
   SYNTAX CaptureBufferHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
       captureBufferEntry. These objects will be created by the agent
       for all captureBufferEntries associated with whichever
       bufferControlEntries it deems appropriate. (i.e., either all
       captureBufferHighCapacityEntries associated with a particular
       bufferControlEntry will be created, or none of them will
       be.)"
    INDEX { captureBufferControlIndex, captureBufferIndex }
    ::= { captureBufferHighCapacityTable 1 }
CaptureBufferHighCapacityEntry ::= SEQUENCE {
   }
captureBufferPacketHighCapacityTime OBJECT-TYPE
   SYNTAX Integer32 (0..999999)
UNITS "nanoseconds"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of nanoseconds that had passed since this capture
       buffer was first turned on when this packet was captured,
       modulo 10<sup>6</sup>.
       This object is used in conjunction with the
       captureBufferPacketTime object. This object returns the
       number of nano-seconds to be added to to number of
       milli-seconds obtained from the captureBufferPacketTime
       object, to obtain more accurate inter packet arrival time."
  ::= { captureBufferHighCapacityEntry 1 }
-- High Capacity extensions for the protocolDistStatsTable
protocolDistStatsHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF ProtocolDistStatsHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       protocolDistStatsTable."
```

```
::= { protocolDist 3 }
protocolDistStatsHighCapacityEntry OBJECT-TYPE
            ProtocolDistStatsHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       protocolDistStatsTable. These objects will be created by the
       agent for all protocolDistStatsEntries associated with
        whichever protocolDistControlEntries it deems appropriate.
        (i.e., either all protocolDistStatsHighCapacityEntries
        associated with a particular protocolDistControlEntry will be
        created, or none of them will be.)"
    INDEX { protocolDistControlIndex, protocolDirLocalIndex }
    ::= { protocolDistStatsHighCapacityTable 1 }
ProtocolDistStatsHighCapacityEntry ::= SEQUENCE {
   protocolDistStatsHighCapacityOverflowPkts ZeroBasedCounter32,
   protocolDistStatsHighCapacityPkts
                                       ZeroBasedCounter64,
   \verb|protocolDistStatsHighCapacityOverflowOctets ZeroBasedCounter 32|,
   protocolDistStatsHighCapacityOctets
                                              ZeroBasedCounter64
protocolDistStatsHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
    UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of times the associated protocolDistStatsPkts
        counter has overflowed."
    ::= { protocolDistStatsHighCapacityEntry 1 }
protocolDistStatsHighCapacityPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
    UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
           current
    DESCRIPTION
        "The number of packets without errors received of this
       protocol type. Note that this is the number of link-layer
       packets, so if a single network-layer packet is fragmented
       into several link-layer frames, this counter is incremented
        several times."
    ::= { protocolDistStatsHighCapacityEntry 2 }
protocolDistStatsHighCapacityOverflowOctets OBJECT-TYPE
```

```
ZeroBasedCounter32
    SYNTAX
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS
           current
    DESCRIPTION
        "The number of times the associated protocolDistStatsOctets
        counter has overflowed."
    ::= { protocolDistStatsHighCapacityEntry 3 }
protocolDistStatsHighCapacityOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
              "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets in packets received of this protocol
        type since it was added to the protocolDistStatsTable
        (excluding framing bits but including FCS octets), except for
        those octets in packets that contained errors.
        Note this doesn't count just those octets in the particular
        protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { protocolDistStatsHighCapacityEntry 4 }
-- High Capacity extensions for the nlHostTable.
nlHostHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF NlHostHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        nlHostTable."
    ::= { nlHost 3 }
nlHostHighCapacityEntry OBJECT-TYPE
            NlHostHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        nlHostEntry. These objects will be created by the agent
        for all nlHostEntries associated with whichever
        hlHostControlEntries it deems appropriate. (i.e., either all
        nlHostHighCapacityEntries associated with a particular
        hlHostControlEntry will be created, or none of them will
        be.)"
```

```
INDEX { hlHostControlIndex, nlHostTimeMark,
           protocolDirLocalIndex, nlHostAddress }
    ::= { nlHostHighCapacityTable 1 }
NlHostHighCapacityEntry ::= SEQUENCE {
   nlHostHighCapacityInOverflowPkts ZeroBasedCounter32,
   nlHostHighCapacityInPkts
                                       ZeroBasedCounter64,
   nlHostHighCapacityOutOverflowPkts ZeroBasedCounter32,
   nlHostHighCapacityOutPkts
                                       ZeroBasedCounter64,
   nlHostHighCapacityInOverflowOctets ZeroBasedCounter32,
   nlHostHighCapacityInOctets ZeroBasedCounter64,
   nlHostHighCapacityOutOverflowOctets ZeroBasedCounter32,
   nlHostHighCapacityOutOctets
                                       ZeroBasedCounter64
}
nlHostHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated nlHostInPkts
       counter has overflowed."
    ::= { nlHostHighCapacityEntry 1 }
nlHostHighCapacityInPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
             current
   DESCRIPTION
       "The number of packets without errors transmitted to
       this address since it was added to the nlHostHighCapacityTable.
       Note that this is the number of link-layer packets, so if a
       single network-layer packet is fragmented into several
       link-layer frames, this counter is incremented several times."
    ::= { nlHostHighCapacityEntry 2 }
nlHostHighCapacityOutOverflowPkts OBJECT-TYPE
   SYNTAX
             ZeroBasedCounter32
   UNITES
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated nlHostOutPkts
       counter has overflowed."
    ::= { nlHostHighCapacityEntry 3 }
```

```
nlHostHighCapacityOutPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
    UNITS
              "Packets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of packets without errors transmitted by
        this address since it was added to the nlHostHighCapacityTable.
        Note that this is the number of link-layer packets, so if a
        single network-layer packet is fragmented into several
        link-layer frames, this counter is incremented several times."
    ::= { nlHostHighCapacityEntry 4 }
nlHostHighCapacityInOverflowOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of times the associated nlHostInOctets
        counter has overflowed."
    ::= { nlHostHighCapacityEntry 5 }
nlHostHighCapacityInOctets OBJECT-TYPE
    SYNTAX
              ZeroBasedCounter64
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets transmitted to this address
        since it was added to the nlHostHighCapacityTable
        (excluding framing bits but including FCS octets),
        excluding those octets in packets that contained
        errors.
        Note this doesn't count just those octets in the
        particular protocol frames, but includes the entire
       packet that contained the protocol."
    ::= { nlHostHighCapacityEntry 6 }
nlHostHighCapacityOutOverflowOctets OBJECT-TYPE
    SYNTAX
              ZeroBasedCounter32
    UNITS
               "Octets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of times the associated nlHostOutOctets
       counter has overflowed."
```

```
::= { nlHostHighCapacityEntry 7 }
nlHostHighCapacityOutOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets transmitted by this address
        since it was added to the nlHostHighCapacityTable
        (excluding framing bits but including FCS octets),
       excluding those octets in packets that contained
       errors.
       Note this doesn't count just those octets in the
       particular protocol frames, but includes the entire
       packet that contained the protocol."
    ::= { nlHostHighCapacityEntry 8 }
-- High Capacity extensions for the nlMatrixTable
nlMatrixSDHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF NlMatrixSDHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       nlMatrixTable."
    ::= { nlMatrix 6 }
nlMatrixSDHighCapacityEntry OBJECT-TYPE
            NlMatrixSDHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       nlMatrixEntry. These objects will be created by the agent
        for all nlMatrixSDEntries associated with whichever
       hlMatrixControlEntries it deems appropriate. (i.e., either all
       nlMatrixSDHighCapacityEntries associated with a particular
       hlMatrixControlEntry will be created, or none of them will
    INDEX { hlMatrixControlIndex, nlMatrixSDTimeMark,
           protocolDirLocalIndex,
           nlMatrixSDSourceAddress, nlMatrixSDDestAddress }
    ::= { nlMatrixSDHighCapacityTable 1 }
NlMatrixSDHighCapacityEntry ::= SEQUENCE {
```

```
nlMatrixSDHighCapacityOverflowPkts ZeroBasedCounter32,
   nlMatrixSDHighCapacityPkts
                                      ZeroBasedCounter64,
   nlMatrixSDHighCapacityOverflowOctets ZeroBasedCounter32,
   nlMatrixSDHighCapacityOctets
                                        ZeroBasedCounter64
}
nlMatrixSDHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX
              ZeroBasedCounter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated nlMatrixSDPkts
       counter has overflowed."
    ::= { nlMatrixSDHighCapacityEntry 1 }
nlMatrixSDHighCapacityPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
             current
   DESCRIPTION
        "The number of packets without errors transmitted from the
       source address to the destination address since this entry was
       added to the nlMatrixSDHighCapacityTable. Note that this is
       the number of link-layer packets, so if a single network-layer
       packet is fragmented into several link-layer frames, this
       counter is incremented several times."
    ::= { nlMatrixSDHighCapacityEntry 2 }
nlMatrixSDHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated nlMatrixSDOctets
       counter has overflowed."
    ::= { nlMatrixSDHighCapacityEntry 3 }
nlMatrixSDHighCapacityOctets OBJECT-TYPE
    SYNTAX
              ZeroBasedCounter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets transmitted from the source address to
       the destination address since this entry was added to the
```

```
nlMatrixSDHighCapacityTable (excluding framing bits but
        including FCS octets), excluding those octets in packets that
        contained errors.
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { nlMatrixSDHighCapacityEntry 4 }
-- High Capacity extensions for the nlMatrixDSTable
nlMatrixDSHighCapacityTable OBJECT-TYPE
           SEQUENCE OF NlMatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       nlMatrixDSTable."
    ::= { nlMatrix 7 }
nlMatrixDSHighCapacityEntry OBJECT-TYPE
    SYNTAX NlMatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       nlMatrixDSEntry. These objects will be created by the agent
       for all nlMatrixDSEntries associated with whichever
       hlmatrixControlEntries it deems appropriate. (i.e., either all
       nlMatrixDSHighCapacityEntries associated with a particular
       hlMatrixControlEntry will be created, or none of them will
       be.)"
    INDEX { hlMatrixControlIndex, nlMatrixDSTimeMark,
           protocolDirLocalIndex,
           nlMatrixDSDestAddress, nlMatrixDSSourceAddress }
    ::= { nlMatrixDSHighCapacityTable 1 }
NlMatrixDSHighCapacityEntry ::= SEQUENCE {
   nlMatrixDSHighCapacityOverflowPkts ZeroBasedCounter32,
                                       ZeroBasedCounter64,
   nlMatrixDSHighCapacityPkts
   nlMatrixDSHighCapacityOverflowOctets ZeroBasedCounter32,
   nlMatrixDSHighCapacityOctets
                                        ZeroBasedCounter64
}
nlMatrixDSHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
```

```
STATUS
            current
    DESCRIPTION
        "The number of times the associated nlMatrixDSPkts
        counter has overflowed."
    ::= { nlMatrixDSHighCapacityEntry 1 }
nlMatrixDSHighCapacityPkts OBJECT-TYPE
    SYNTAX
              ZeroBasedCounter64
    UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of packets without errors transmitted from the
       source address to the destination address since this entry was
        added to the nlMatrixDSHighCapacityTable. Note that this is
        the number of link-layer packets, so if a single network-layer
       packet is fragmented into several link-layer frames, this
       counter is incremented several times."
    ::= { nlMatrixDSHighCapacityEntry 2 }
nlMatrixDSHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
             "Octets"
   UNITS
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of times the associated nlMatrixDSOctets
        counter has overflowed."
    ::= { nlMatrixDSHighCapacityEntry 3 }
nlMatrixDSHighCapacityOctets OBJECT-TYPE
    SYNTAX
           ZeroBasedCounter64
    UNITS
              "Octets"
    MAX-ACCESS read-only
    STATUS
           current
    DESCRIPTION
        "The number of octets transmitted from the source address
       to the destination address since this entry was added to the
       nlMatrixDSHighCapacityTable (excluding framing bits but
       including FCS octets), excluding those octets in packets that
        contained errors.
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { nlMatrixDSHighCapacityEntry 4 }
-- High Capacity extensions for the nlMatrixTopNTable
```

```
nlMatrixTopNHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF NlMatrixTopNHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        nlMatrixTopNTable when nlMatrixTopNControlRateBase specifies
        a High Capacity TopN Report."
    ::= { nlMatrix 8 }
nlMatrixTopNHighCapacityEntry OBJECT-TYPE
             NlMatrixTopNHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       nlMatrixTopNEntry when nlMatrixTopNControlRateBase specifies
        a High Capacity TopN Report. These objects will be created by
        the agent for all nlMatrixTopNEntries associated with whichever
        nlMatrixTopNControlEntries have a nlMatrixTopNControlRateBase
        that specify a high capacity report."
    INDEX { nlMatrixTopNControlIndex, nlMatrixTopNIndex }
    NlMatrixTopNHighCapacityEntry ::= SEQUENCE {
  nlMatrixTopNHighCapacityProtocolDirLocalIndex Integer32,
 nlMatrixTopNHighCapacitySourceAddress
                                                 OCTET STRING,
 nlMatrixTopNHighCapacityDestAddress
                                                 OCTET STRING,
 nlMatrixTopNHighCapacityBasePktRate
                                                 Gauge32,
 nlMatrixTopNHighCapacityOverflowPktRate
                                                 Gauge32,
 nlMatrixTopNHighCapacityPktRate
                                                  CounterBasedGauge64,
 nlMatrixTopNHighCapacityReverseBasePktRate
                                                  Gauge32,
  nlMatrixTopNHighCapacityReverseOverflowPktRate
                                                 Gauge32,
 nlMatrixTopNHighCapacityReversePktRate
                                                 CounterBasedGauge64,
 nlMatrixTopNHighCapacityBaseOctetRate
                                                 Gauge32,
 nlMatrixTopNHighCapacityOverflowOctetRate
                                                 Gauge32,
 nlMatrixTopNHighCapacityOctetRate
                                                  CounterBasedGauge64,
 nlMatrixTopNHighCapacityReverseBaseOctetRate
                                                Gauge32,
 nlMatrixTopNHighCapacityReverseOverflowOctetRate Gauge32,
 nlMatrixTopNHighCapacityReverseOctetRate
                                                  CounterBasedGauge64
nlMatrixTopNHighCapacityProtocolDirLocalIndex OBJECT-TYPE
           Integer32 (1..2147483647)
    SYNTAX
   MAX-ACCESS read-only
    STATUS
             current
    DESCRIPTION
        "The protocolDirLocalIndex of the network layer protocol of
```

```
this entry's network address."
    ::= { nlMatrixTopNHighCapacityEntry 1 }
nlMatrixTopNHighCapacitySourceAddress OBJECT-TYPE
   SYNTAX
           OCTET STRING
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The network layer address of the source host in this
       conversation.
       This is represented as an octet string with
       specific semantics and length as identified
       by the associated nlMatrixTopNProtocolDirLocalIndex.
       For example, if the protocolDirLocalIndex indicates an
        encapsulation of ip, this object is encoded as a length
       octet of 4, followed by the 4 octets of the ip address,
       in network byte order."
    ::= { nlMatrixTopNHighCapacityEntry 2 }
nlMatrixTopNHighCapacityDestAddress OBJECT-TYPE
    SYNTAX OCTET STRING
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The network layer address of the destination host in this
       conversation.
       This is represented as an octet string with
        specific semantics and length as identified
       by the associated nlMatrixTopNProtocolDirLocalIndex.
       For example, if the nlMatrixTopNProtocolDirLocalIndex
        indicates an encapsulation of ip, this object is encoded as a
        length octet of 4, followed by the 4 octets of the ip address,
       in network byte order."
    ::= { nlMatrixTopNHighCapacityEntry 3 }
nlMatrixTopNHighCapacityBasePktRate OBJECT-TYPE
   SYNTAX Gauge32
              "Packets"
    UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets seen from the source host
       to the destination host during this sampling interval,
       modulo 2^32, counted using the rules for counting the
```

```
nlMatrixSDPkts object."
    ::= { nlMatrixTopNHighCapacityEntry 4 }
nlMatrixTopNHighCapacityOverflowPktRate OBJECT-TYPE
   SYNTAX
             Gauge32
              "Packets"
   UNITS
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of packets seen from the source host
        to the destination host during this sampling interval,
       divided by 2^32, truncating fractions (i.e., X DIV 2^32),
        and counted using the rules for counting the
       nlMatrixSDPkts object."
    ::= { nlMatrixTopNHighCapacityEntry 5 }
nlMatrixTopNHighCapacityPktRate OBJECT-TYPE
   SYNTAX CounterBasedGauge64
   UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS
            current
   DESCRIPTION
        "The number of packets seen from the source host to the
        destination host during this sampling interval, counted
       using the rules for counting the nlMatrixSDPkts object.
       If the value of nlMatrixTopNControlRateBase is
       nlMatrixTopNHighCapacityPkts, this variable will be
       used to sort this report."
    ::= { nlMatrixTopNHighCapacityEntry 6 }
nlMatrixTopNHighCapacityReverseBasePktRate OBJECT-TYPE
    SYNTAX
           Gauge32
    UNITS
              "Packets"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of packets seen from the destination host to the
        source host during this sampling interval, modulo 2^32, counted
       using the rules for counting the nlMatrixSDPkts object (note
       that the corresponding nlMatrixSDPkts object selected is the
        one whose source address is equal to nlMatrixTopNDestAddress
        and whose destination address is equal to
       nlMatrixTopNSourceAddress.)
       Note that if the value of nlMatrixTopNControlRateBase is equal
        to nlMatrixTopNHighCapacityPkts, the sort of topN entries is
       based entirely on nlMatrixTopNHighCapacityPktRate, and not on
        the value of this object."
```

```
::= { nlMatrixTopNHighCapacityEntry 7 }
nlMatrixTopNHighCapacityReverseOverflowPktRate OBJECT-TYPE
    SYNTAX
             Gauge32
    UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of packets seen from the destination host to the
        source host during this sampling interval, divided by 2^32,
       truncating fractions (i.e., X DIV 2^32), and counted
       using the rules for counting the nlMatrixSDPkts object (note
       that the corresponding nlMatrixSDPkts object selected is the
       one whose source address is equal to nlMatrixTopNDestAddress
        and whose destination address is equal to
       nlMatrixTopNSourceAddress.)
       Note that if the value of nlMatrixTopNControlRateBase is equal
        to nlMatrixTopNHighCapacityPkts, the sort of topN entries is
       based entirely on nlMatrixTopNHighCapacityPktRate, and not on
        the value of this object."
    ::= { nlMatrixTopNHighCapacityEntry 8 }
nlMatrixTopNHighCapacityReversePktRate OBJECT-TYPE
    SYNTAX CounterBasedGauge64
    UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS
           current
    DESCRIPTION
        "The number of packets seen from the destination host to the
        source host during this sampling interval, counted
       using the rules for counting the nlMatrixSDPkts object (note
        that the corresponding nlMatrixSDPkts object selected is the
        one whose source address is equal to nlMatrixTopNDestAddress
        and whose destination address is equal to
       nlMatrixTopNSourceAddress.)
       Note that if the value of nlMatrixTopNControlRateBase is equal
        to nlMatrixTopNHighCapacityPkts, the sort of topN entries is
       based entirely on nlMatrixTopNHighCapacityPktRate, and not on
        the value of this object."
    ::= { nlMatrixTopNHighCapacityEntry 9 }
nlMatrixTopNHighCapacityBaseOctetRate OBJECT-TYPE
    SYNTAX
           Gauge32
              "Octets"
   MAX-ACCESS read-only
    STATUS
             current
```

```
DESCRIPTION
        "The number of octets seen from the source host to the
       destination host during this sampling interval, modulo 2^32,
       counted using the rules for counting the nlMatrixSDOctets
       object."
    ::= { nlMatrixTopNHighCapacityEntry 10 }
nlMatrixTopNHighCapacityOverflowOctetRate OBJECT-TYPE
    SYNTAX
             Gauge32
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of octets seen from the source host
        to the destination host during this sampling interval,
       divided by 2^32, truncating fractions (i.e., X DIV 2^32),
       and counted using the rules for counting the
       nlMatrixSDOctets object."
    ::= { nlMatrixTopNHighCapacityEntry 11 }
nlMatrixTopNHighCapacityOctetRate OBJECT-TYPE
   SYNTAX
             CounterBasedGauge64
   UNITS "Octets"
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of octets seen from the source host
       to the destination host during this sampling interval,
       counted using the rules for counting the
       nlMatrixSDOctets object.
        If the value of nlMatrixTopNControlRateBase is
       nlMatrixTopNHighCapacityOctets, this variable will be used
       to sort this report."
    ::= { nlMatrixTopNHighCapacityEntry 12 }
nlMatrixTopNHighCapacityReverseBaseOctetRate OBJECT-TYPE
   SYNTAX Gauge32
             "Octets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The number of octets seen from the destination host to the
        source host during this sampling interval, modulo 2^32, counted
       using the rules for counting the nlMatrixSDOctets object (note
       that the corresponding nlMatrixSDOctets object selected is the
       one whose source address is equal to nlMatrixTopNDestAddress
       and whose destination address is equal to
       nlMatrixTopNSourceAddress.)
```

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

::= { nlMatrixTopNHighCapacityEntry 13 }

nlMatrixTopNHighCapacityReverseOverflowOctetRate OBJECT-TYPE

SYNTAX Gauge32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The number of octets seen from the destination host to the source host during this sampling interval, divided by 2^32, truncating fractions (i.e., X DIV 2^32), and counted using the rules for counting the nlMatrixSDOctets object (note that the corresponding nlMatrixSDOctets object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

::= { nlMatrixTopNHighCapacityEntry 14 }

nlMatrixTopNHighCapacityReverseOctetRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The number of octets seen from the destination host to the source host during this sampling interval, counted using the rules for counting the nlMatrixSDOctets object (note that the corresponding nlMatrixSDOctets object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

::= { nlMatrixTopNHighCapacityEntry 15 }

-- High Capacity extensions for the alHostTable

```
alHostHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AlHostHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alHostTable."
    ::= { alHost 2 }
alHostHighCapacityEntry OBJECT-TYPE
    SYNTAX AlHostHighCapacityEntry
    MAX-ACCESS not-accessible
    STATUS
           current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alHostEntry. These objects will be created by the agent
        for all alHostEntries associated with whichever
       hlHostControlEntries it deems appropriate. (i.e., either all
       alHostHighCapacityEntries associated with a particular
       hlHostControlEntry will be created, or none of them will
    INDEX { hlHostControlIndex, alHostTimeMark,
           protocolDirLocalIndex, nlHostAddress,
           protocolDirLocalIndex }
    ::= { alHostHighCapacityTable 1 }
AlHostHighCapacityEntry ::= SEQUENCE {
    \verb| alHostHighCapacityInOverflowPkts & ZeroBasedCounter32|, \\
    alHostHighCapacityInPkts
                                      ZeroBasedCounter64,
    \verb|alHostHighCapacityOutOverflowPkts| ZeroBasedCounter 32,\\
                                      ZeroBasedCounter64,
    alHostHighCapacityOutPkts
    alHostHighCapacityInOverflowOctets ZeroBasedCounter32,
    alHostHighCapacityInOctets
                                       ZeroBasedCounter64,
    alHostHighCapacityOutOverflowOctets ZeroBasedCounter32,
   alHostHighCapacityOutOctets
                                       ZeroBasedCounter64
}
alHostHighCapacityInOverflowPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
             "Packets"
    UNITS
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The number of times the associated alHostInPkts
        counter has overflowed."
    ::= { alHostHighCapacityEntry 1 }
```

```
alHostHighCapacityInPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets of this protocol type without errors
       transmitted to this address since it was added to the
       alHostHighCapacityTable. Note that this is the number of
       link-layer packets, so if a single network-layer packet
       is fragmented into several link-layer frames, this counter
       is incremented several times."
    ::= { alHostHighCapacityEntry 2 }
alHostHighCapacityOutOverflowPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The number of times the associated alHostOutPkts
       counter has overflowed."
    ::= { alHostHighCapacityEntry 3 }
alHostHighCapacityOutPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets of this protocol type without errors
       transmitted by this address since it was added to the
       alHostHighCapacityTable. Note that this is the number of
       link-layer packets, so if a single network-layer packet
       is fragmented into several link-layer frames, this counter
       is incremented several times."
    ::= { alHostHighCapacityEntry 4 }
alHostHighCapacityInOverflowOctets OBJECT-TYPE
   SYNTAX
             ZeroBasedCounter32
   UNITES
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times the associated alHostInOctets
       counter has overflowed."
    ::= { alHostHighCapacityEntry 5 }
```

```
alHostHighCapacityInOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
    UNITS
             "Octets"
   MAX-ACCESS read-only
   STATUS current
    DESCRIPTION
        "The number of octets transmitted to this address
        of this protocol type since it was added to the
       alHostHighCapacityTable (excluding framing bits but
       including FCS octets), excluding those octets in
       packets that contained errors.
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { alHostHighCapacityEntry 6 }
alHostHighCapacityOutOverflowOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
             "Octets"
    UNITS
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated alHostOutOctets
        counter has overflowed."
    ::= { alHostHighCapacityEntry 7 }
alHostHighCapacityOutOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS
              current
    DESCRIPTION
        "The number of octets transmitted by this address
        of this protocol type since it was added to the
        alHostHighCapacityTable (excluding framing bits but
        including FCS octets), excluding those octets in
       packets that contained errors.
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
       the protocol."
    ::= { alHostHighCapacityEntry 8 }
-- High Capacity extensions for the alMatrixSDTable
alMatrixSDHighCapacityTable OBJECT-TYPE
   SYNTAX SEQUENCE OF AlMatrixSDHighCapacityEntry
```

```
MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       alMatrixSDTable."
    ::= { alMatrix 5 }
alMatrixSDHighCapacityEntry OBJECT-TYPE
    SYNTAX AlMatrixSDHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alMatrixSDEntry. These objects will be created by the agent
        for all alMatrixSDEntries associated with whichever
       hlMatrixControlEntries it deems appropriate. (i.e., either all
        alMatrixSDHighCapacityEntries associated with a particular
       hlMatrixControlEntry will be created, or none of them will
       be.)"
    INDEX { hlMatrixControlIndex, alMatrixSDTimeMark,
           protocolDirLocalIndex,
           nlMatrixSDSourceAddress, nlMatrixSDDestAddress,
           protocolDirLocalIndex }
    ::= { alMatrixSDHighCapacityTable 1 }
AlMatrixSDHighCapacityEntry ::= SEQUENCE {
    \verb|alMatrixSDHighCapacityOverflowPkts| ZeroBasedCounter 32,\\
    alMatrixSDHiqhCapacityPkts ZeroBasedCounter64,
    alMatrixSDHiqhCapacityOverflowOctets ZeroBasedCounter32,
    alMatrixSDHighCapacityOctets
                                       ZeroBasedCounter64
}
alMatrixSDHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
    UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
    DESCRIPTION
        "The number of times the associated alMatrixSDPkts
        counter has overflowed."
    ::= { alMatrixSDHighCapacityEntry 1 }
alMatrixSDHighCapacityPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
   UNITS
              "Packets"
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
```

```
"The number of good packets of this protocol type
        transmitted from the source address to the destination address
        since this entry was added to the alMatrixSDHighCapacityTable.
       Note that this is the number of link-layer packets, so if a
       single network-layer packet is fragmented into several
        link-layer frames, this counter is incremented several times."
    ::= { alMatrixSDHighCapacityEntry 2 }
alMatrixSDHighCapacityOverflowOctets OBJECT-TYPE
    SYNTAX ZeroBasedCounter32
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS
           current
   DESCRIPTION
        "The number of times the associated alMatrixSDOctets
       counter has overflowed."
    ::= { alMatrixSDHighCapacityEntry 3 }
alMatrixSDHighCapacityOctets OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
    UNITS
             "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets in good packets of this protocol type
        transmitted from the source address to the destination address
        since this entry was added to the alMatrixSDHighCapacityTable
        (excluding framing bits but including FCS octets).
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { alMatrixSDHighCapacityEntry 4 }
-- High Capacity extensions for the alMatrixDSTable
alMatrixDSHighCapacityTable OBJECT-TYPE
           SEQUENCE OF AlMatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS
           current.
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alMatrixDSTable."
    ::= { alMatrix 6 }
alMatrixDSHighCapacityEntry OBJECT-TYPE
    SYNTAX AlMatrixDSHighCapacityEntry
   MAX-ACCESS not-accessible
```

```
STATUS
             current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alMatrixSDTable. These objects will be created by the agent
       for all alMatrixDSEntries associated with whichever
       hlMatrixControlEntries it deems appropriate. (i.e., either all
        alMatrixDSHighCapacityEntries associated with a particular
       hlMatrixControlEntry will be created, or none of them will
       be.)"
    INDEX { hlMatrixControlIndex, alMatrixDSTimeMark,
           protocolDirLocalIndex,
           nlMatrixDSDestAddress, nlMatrixDSSourceAddress,
           protocolDirLocalIndex }
    ::= { alMatrixDSHighCapacityTable 1 }
AlMatrixDSHighCapacityEntry ::= SEQUENCE {
    alMatrixDSHighCapacityOverflowPkts ZeroBasedCounter32,
    alMatrixDSHighCapacityPkts
                                       ZeroBasedCounter64,
   alMatrixDSHighCapacityOverflowOctets ZeroBasedCounter32,
    alMatrixDSHighCapacityOctets
                                       ZeroBasedCounter64
alMatrixDSHighCapacityOverflowPkts OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
    UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated alMatrixDSPkts
        counter has overflowed."
    ::= { alMatrixDSHighCapacityEntry 1 }
alMatrixDSHighCapacityPkts OBJECT-TYPE
    SYNTAX ZeroBasedCounter64
    UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
    DESCRIPTION
        "The number of good packets of this protocol type
       transmitted from the source address to the destination address
       since this entry was added to the alMatrixDSHighCapacityTable.
       Note that this is the number of link-layer packets, so if a
        single network-layer packet is fragmented into several
        link-layer frames, this counter is incremented several times."
    ::= { alMatrixDSHighCapacityEntry 2 }
alMatrixDSHighCapacityOverflowOctets OBJECT-TYPE
   SYNTAX ZeroBasedCounter32
```

```
UNITS
             "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times the associated alMatrixDSOctets
       counter has overflowed."
    ::= { alMatrixDSHighCapacityEntry 3 }
alMatrixDSHighCapacityOctets OBJECT-TYPE
   SYNTAX ZeroBasedCounter64
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The number of octets in good packets of this protocol type
       transmitted from the source address to the destination address
       since this entry was added to the alMatrixDSHighCapacityTable
       (excluding framing bits but including FCS octets).
       Note this doesn't count just those octets in the particular
       protocol frames, but includes the entire packet that contained
       the protocol."
    ::= { alMatrixDSHighCapacityEntry 4 }
alMatrixTopNHighCapacityTable OBJECT-TYPE
   SYNTAX SEQUENCE OF AlMatrixTopNHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS
           current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       alMatrixTopNTable when alMatrixTopNControlRateBase specifies
       a High Capacity TopN Report."
    ::= { alMatrix 7 }
alMatrixTopNHighCapacityEntry OBJECT-TYPE
   SYNTAX AlMatrixTopNHighCapacityEntry
   MAX-ACCESS not-accessible
   STATUS
             current
   DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       alMatrixTopNEntry when alMatrixTopNControlRateBase specifies
       a High Capacity TopN Report. These objects will be created by
       the agent for all alMatrixTopNEntries associated with whichever
       alMatrixTopNControlEntries have a alMatrixTopNControlRateBase
       that specify a high capacity report."
    INDEX { alMatrixTopNControlIndex, alMatrixTopNIndex }
    ::= { alMatrixTopNHighCapacityTable 1 }
```

```
AlMatrixTopNHighCapacityEntry ::= SEQUENCE {
 alMatrixTopNHighCapacityProtocolDirLocalIndex Integer32,
  alMatrixTopNHighCapacitySourceAddress
                                                 OCTET STRING,
  alMatrixTopNHighCapacityDestAddress
                                                 OCTET STRING,
  \verb|alMatrixTopNHighCapacityAppProtocolDirLocalIndex Integer 32|,
  alMatrixTopNHighCapacityBasePktRate
                                                   Gauge32,
  alMatrixTopNHighCapacityOverflowPktRate
                                                   Gauge32,
                                                  CounterBasedGauge64,
  alMatrixTopNHighCapacityPktRate
  alMatrixTopNHighCapacityReverseBasePktRate
                                                 Gauge32,
  alMatrixTopNHighCapacityReverseOverflowPktRate Gauge32,
  alMatrixTopNHighCapacityReversePktRate
                                                  CounterBasedGauge64,
 alMatrixTopNHighCapacityBaseOctetRate
                                                  Gauge32,
 alMatrixTopNHighCapacityOverflowOctetRate
                                                  Gauge32,
 alMatrixTopNHighCapacityOctetRate
                                                  CounterBasedGauge64,
  alMatrixTopNHighCapacityReverseBaseOctetRate
                                                  Gauge32,
  alMatrixTopNHighCapacityReverseOverflowOctetRate Gauge32,
  alMatrixTopNHighCapacityReverseOctetRate
                                                  CounterBasedGauge64
}
alMatrixTopNHighCapacityProtocolDirLocalIndex OBJECT-TYPE
            Integer32 (1..2147483647)
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The protocolDirLocalIndex of the network layer protocol of
        this entry's network address."
    ::= { alMatrixTopNHighCapacityEntry 1 }
alMatrixTopNHighCapacitySourceAddress OBJECT-TYPE
    SYNTAX
             OCTET STRING
   MAX-ACCESS read-only
    STATUS
              current
    DESCRIPTION
        "The network layer address of the source host in this
       conversation.
       This is represented as an octet string with
        specific semantics and length as identified
       by the associated alMatrixTopNProtocolDirLocalIndex.
        For example, if the alMatrixTopNProtocolDirLocalIndex
        indicates an encapsulation of ip, this object is encoded as a
        length octet of 4, followed by the 4 octets of the ip address,
        in network byte order."
    ::= { alMatrixTopNHighCapacityEntry 2 }
alMatrixTopNHighCapacityDestAddress OBJECT-TYPE
   SYNTAX
             OCTET STRING
```

```
MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The network layer address of the destination host in this
       conversation.
       This is represented as an octet string with
       specific semantics and length as identified
       by the associated alMatrixTopNProtocolDirLocalIndex.
       For example, if the alMatrixTopNProtocolDirLocalIndex
       indicates an encapsulation of ip, this object is encoded as a
       length octet of 4, followed by the 4 octets of the ip address,
       in network byte order."
    ::= { alMatrixTopNHighCapacityEntry 3 }
alMatrixTopNHighCapacityAppProtocolDirLocalIndex OBJECT-TYPE
   SYNTAX Integer32
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The type of the protocol counted by this entry."
    ::= { alMatrixTopNHighCapacityEntry 4 }
alMatrixTopNHighCapacityBasePktRate OBJECT-TYPE
   SYNTAX Gauge32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets seen of this protocol from the
       source host to the destination host during this sampling
       interval, modulo 2^32, counted using the rules for counting
       the alMatrixSDPkts object."
    ::= { alMatrixTopNHighCapacityEntry 5 }
alMatrixTopNHighCapacityOverflowPktRate OBJECT-TYPE
   SYNTAX
             Gauge32
            "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The number of packets seen of this protocol from the source
       host to the destination host during this sampling interval,
       divided by 2^32, truncating fractions (i.e., X DIV 2^32),
       and counted using the rules for counting the
       alMatrixSDPkts object."
    ::= { alMatrixTopNHighCapacityEntry 6 }
```

```
alMatrixTopNHighCapacityPktRate OBJECT-TYPE
   SYNTAX CounterBasedGauge64
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets seen of this protocol from the source
       host to the destination host during this sampling interval,
       counted using the rules for counting the
       alMatrixSDPkts object.
       If the value of alMatrixTopNControlRateBase is
       alMatrixTopNTerminalsPkts, alMatrixTopNAllPkts,
       alMatrixTopNTerminalsHighCapacityPkts, or
       alMatrixTopNAllHighCapacityPkts, this variable will be used
       to sort this report."
    ::= { alMatrixTopNHighCapacityEntry 7 }
alMatrixTopNHighCapacityReverseBasePktRate OBJECT-TYPE
   SYNTAX Gauge32
              "Packets"
   UNITS
   MAX-ACCESS read-only
   STATUS
            current
   DESCRIPTION
        "The number of packets seen of this protocol from the
       destination host to the source host during this sampling
       interval, modulo 2^32, counted using the rules for counting
       the alMatrixSDPkts object (note that the corresponding
       alMatrixSDPkts object selected is the one whose source address
       is equal to alMatrixTopNDestAddress and whose destination
       address is equal to alMatrixTopNSourceAddress.)"
    ::= { alMatrixTopNHighCapacityEntry 8 }
alMatrixTopNHighCapacityReverseOverflowPktRate OBJECT-TYPE
    SYNTAX Gauge32
   UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of packets seen of this protocol from the
       destination host to the source host during this sampling
       interval, divided by 2^32, truncating fractions
        (i.e., X DIV 2^32), and counted using the rules for
       counting the alMatrixSDPkts object (note that the
       corresponding alMatrixSDPkts object selected is the
       one whose source address is equal to alMatrixTopNDestAddress
       and whose destination address is equal to
       alMatrixTopNSourceAddress.)"
    ::= { alMatrixTopNHighCapacityEntry 9 }
```

```
alMatrixTopNHighCapacityReversePktRate OBJECT-TYPE
    SYNTAX CounterBasedGauge64
    UNITS
              "Packets"
   MAX-ACCESS read-only
   STATUS current
    DESCRIPTION
        "The number of packets seen of this protocol from the
       destination host to the source host during this sampling
       interval, counted using the rules for counting the
       alMatrixSDPkts object (note that the corresponding
       alMatrixSDPkts object selected is the one whose source address
        is equal to alMatrixTopNDestAddress and whose destination
        address is equal to alMatrixTopNSourceAddress.) "
    ::= { alMatrixTopNHighCapacityEntry 10 }
alMatrixTopNHighCapacityBaseOctetRate OBJECT-TYPE
    SYNTAX Gauge32
    UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets seen of this protocol from the source host
        to the destination host during this sampling interval,
       modulo 2^32, counted using the rules for counting the
        alMatrixSDOctets object."
    ::= { alMatrixTopNHighCapacityEntry 11 }
alMatrixTopNHighCapacityOverflowOctetRate OBJECT-TYPE
   SYNTAX Gauge32
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS
             current
    DESCRIPTION
        "The number of octets seen of this protocol from the source host
        to the destination host during this sampling interval,
       divided by 2^32, truncating fractions (i.e., X DIV 2^32),
       and counted using the rules for counting the
       alMatrixSDOctets object."
    ::= { alMatrixTopNHighCapacityEntry 12 }
alMatrixTopNHighCapacityOctetRate OBJECT-TYPE
    SYNTAX CounterBasedGauge64
   UNITS
              "Octets"
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of octets seen of this protocol from the source host
       to the destination host during this sampling interval,
```

```
counted using the rules for counting the
       alMatrixSDOctets object.
        If the value of alMatrixTopNControlRateBase is
       alMatrixTopNTerminalsOctets, alMatrixTopNAllOctets,
       alMatrixTopNTerminalsHighCapacityOctets, or
       alMatrixTopNAllHighCapacityOctets, this variable will be used
        to sort this report."
    ::= { alMatrixTopNHighCapacityEntry 13 }
alMatrixTopNHighCapacityReverseBaseOctetRate OBJECT-TYPE
   SYNTAX
           Gauge32
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets seen of this protocol from the
       destination host to the source host during this sampling
        interval, modulo 2^32, counted using the rules for counting
        the alMatrixSDOctets object (note that the corresponding
        alMatrixSDOctets object selected is the one whose source
       address is equal to alMatrixTopNDestAddress and whose
       destination address is equal to alMatrixTopNSourceAddress.)"
    ::= { alMatrixTopNHighCapacityEntry 14 }
\verb|alMatrixTopNHighCapacityReverseOverflowOctetRate OBJECT-TYPE| \\
   SYNTAX Gauge32
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets seen of this protocol from the
        destination host to the source host during this sampling
        interval, divided by 2^32, truncating fractions (i.e., X DIV
        2^32), and counted using the rules for counting the
        alMatrixSDOctets object (note that the corresponding
       alMatrixSDOctets object selected is the one whose source
       address is equal to alMatrixTopNDestAddress and whose
       destination address is equal to alMatrixTopNSourceAddress.)"
    ::= { alMatrixTopNHighCapacityEntry 15 }
alMatrixTopNHighCapacityReverseOctetRate OBJECT-TYPE
             CounterBasedGauge64
    SYNTAX
   UNITS
              "Octets"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of octets seen of this protocol from the
       destination host to the source host during this sampling
```

```
interval, counted using the rules for counting the
       alMatrixSDOctets object (note that the corresponding
       alMatrixSDOctets object selected is the one whose source
       address is equal to alMatrixTopNDestAddress and whose
       destination address is equal to alMatrixTopNSourceAddress.)"
    ::= { alMatrixTopNHighCapacityEntry 16 }
usrHistoryHighCapacityTable OBJECT-TYPE
    SYNTAX SEQUENCE OF UsrHistoryHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
       usrHistoryTable."
        ::= { usrHistory 4 }
usrHistoryHighCapacityEntry OBJECT-TYPE
    SYNTAX UsrHistoryHighCapacityEntry
   MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        usrHistoryEntry. These objects will be created by the agent
        for all usrHistoryEntries associated with whichever
        usrHistoryControlEntries it deems appropriate. (i.e., either all
        usrHistoryHighCapacityEntries associated with a particular
       usrHistoryControlEntry will be created, or none of them will
       be.)"
    INDEX { usrHistoryControlIndex, usrHistorySampleIndex,
           usrHistoryObjectIndex }
    ::= { usrHistoryHighCapacityTable 1 }
UsrHistoryHighCapacityEntry ::= SEQUENCE {
    usrHistoryHighCapacityOverflowAbsValue
                                             Gauge32,
    usrHistoryHighCapacityAbsValue
                                               CounterBasedGauge64
}
usrHistoryHighCapacityOverflowAbsValue OBJECT-TYPE
    SYNTAX Gauge32
   MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The absolute value (i.e. unsigned value) of the
       user-specified statistic during the last sampling period,
       divided by 2^32, truncating fractions (i.e., X DIV 2^32).
       The value during the current sampling period is not made
       available until the period is completed.
```

```
To obtain the true value for this sampling interval, the
        associated instance of usrHistoryValStatus should be checked,
        and usrHistoryAbsValue adjusted as necessary.
        If the MIB instance could not be accessed during the sampling
        interval, then this object will have a value of zero and the
        associated instance of usrHistoryValStatus will be set to
        'valueNotAvailable(1)'."
    ::= { usrHistoryHighCapacityEntry 1 }
usrHistoryHighCapacityAbsValue OBJECT-TYPE
    SYNTAX CounterBasedGauge64
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The absolute value (i.e. unsigned value) of the
        user-specified statistic during the last sampling period. The
        value during the current sampling period is not made available
        until the period is completed.
        To obtain the true value for this sampling interval, the
        associated instance of usrHistoryValStatus should be checked,
        and usrHistoryHighCapacityAbsValue adjusted as necessary.
        If the MIB instance could not be accessed during the sampling
        interval, then this object will have a value of zero and the
        associated instance of usrHistoryValStatus will be set to
        'valueNotAvailable(1)'."
    ::= { usrHistoryHighCapacityEntry 2 }
-- High Capacity RMON Probe Capabilities
hcRMONCapabilities OBJECT-TYPE
   SYNTAX BITS {
       mediaIndependentGroup(0),
        etherStatsHighCapacityGroup(1),
        etherHistoryHighCapacityGroup(2),
        hostHighCapacityGroup(3),
        hostTopNHighCapacityGroup(4),
        matrixHighCapacityGroup(5),
        captureBufferHighCapacityGroup(6),
        protocolDistributionHighCapacityGroup(7),
        nlHostHighCapacityGroup(8),
        nlMatrixHighCapacityGroup(9),
        nlMatrixTopNHighCapacityGroup(10),
        alHostHighCapacityGroup(11),
        alMatrixHighCapacityGroup(12),
```

```
alMatrixTopNHighCapacityGroup(13),
        usrHistoryHighCapacityGroup(14)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "An indication of the High Capacity RMON MIB groups supported
        on at least one interface by this probe."
    ::= { probeConfig 16 }
-- Conformance Macros
hcRmonMIBCompliances OBJECT IDENTIFIER ::= { rmonConformance 6 }
hcRmonMIBGroups OBJECT IDENTIFIER ::= { rmonConformance 7 }
hcMediaIndependentCompliance MODULE-COMPLIANCE
    STATUS
           current
    DESCRIPTION
        "Describes the requirements for conformance to the
        High Capacity Media Independent Group."
    MODULE -- this module
    MANDATORY-GROUPS { mediaIndependentGroup, hcRMONInformationGroup }
    ::= { hcRmonMIBCompliances 1 }
hcRmon1MIBCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to the High
        Capacity RMON-1 MIB"
    MODULE -- this module
        {\tt GROUP}\ {\tt etherStatsHighCapacityGroup}
        DESCRIPTION
            "The etherStatsHighCapacityGroup is optional but requires
            implementation of the rmonEtherStatsGroup."
        GROUP etherHistoryHighCapacityGroup
        DESCRIPTION
            "The etherHistoryHighCapacityGroup is optional but
            requires implementation of the rmonHistoryControlGroup and
            rmonEthernetHistoryGroup."
        GROUP hostHighCapacityGroup
        DESCRIPTION
            "The hostHighCapacityGroup is mandatory when the
            hostTopNHighCapacityGroup is implemented. This group also
            requires implementation of the rmonHostGroup."
        GROUP hostTopNHighCapacityGroup
```

DESCRIPTION

"The hostTopNHighCapacityGroup is optional but requires implementation of the rmonHostTopNGroup."

GROUP matrixHighCapacityGroup DESCRIPTION

"The matrixHighCapacityGroup is optional but requires implementation of the rmonMatrixGroup."

GROUP captureBufferHighCapacityGroup DESCRIPTION

"The captureBufferHighCapacityGroup is optional but requires implementation of the rmonFilterGroup and rmonPacketCaptureGroup."

MODULE RMON-MIB

 ${\tt GROUP \ rmonEtherStatsGroup}$

DESCRIPTION

"The RMON Ethernet Statistics Group is mandatory if the etherStatsHighCapacityGroup is implemented."

GROUP rmonHistoryControlGroup

DESCRIPTION

"The RMON History Control Group is mandatory if the etherHistoryHighCapacityGroup is implemented."

${\tt GROUP} \ {\tt rmonEthernetHistoryGroup}$

DESCRIPTION

"The RMON Ethernet History Group is mandatory if the etherHistoryHighCapacityGroup is implemented."

GROUP rmonHostGroup

DESCRIPTION

"The RMON Host Group is mandatory if the hostHighCapacityGroup is implemented."

GROUP rmonHostTopNGroup

DESCRIPTION

"The RMON Host Top N Group is mandatory if the hostTopNHighCapacityGroup is implemented."

GROUP rmonMatrixGroup

DESCRIPTION

"The RMON Matrix Group is mandatory if the matrixHighCapacityGroup is implemented."

GROUP rmonFilterGroup DESCRIPTION

```
"The RMON Filter Group is mandatory when the
            captureBufferHighCapacityGroup is implemented."
       GROUP rmonPacketCaptureGroup
       DESCRIPTION
            "The RMON Packet Capture Group is mandatory when the
           captureBufferHighCapacityGroup is implemented."
    ::= { hcRmonMIBCompliances 2 }
hcRmon2MIBCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to
        the High Capacity RMON-2 MIB"
    MODULE -- this module
        MANDATORY-GROUPS { protocolDistributionHighCapacityGroup,
                           nlHostHighCapacityGroup,
                           nlMatrixHighCapacityGroup,
                           nlMatrixTopNHighCapacityGroup,
                           usrHistoryHighCapacityGroup,
                           hcRMONInformationGroup }
    MODULE RMON2-MIB
        MANDATORY-GROUPS { protocolDirectoryGroup,
                           protocolDistributionGroup,
                           addressMapGroup,
                           nlHostGroup,
                           nlMatrixGroup,
                           usrHistoryGroup,
                           probeInformationGroup }
        GROUP rmon1EnhancementGroup
        DESCRIPTION
            "The rmonlEnhancementGroup is mandatory for systems which
            implement RMON [RFC2819]"
    ::= { hcRmonMIBCompliances 3 }
hcRmon2MIBApplicationLayerCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to
        the High Capacity RMON-2 MIB with Application Layer
        Enhancements."
    MODULE -- this module
        MANDATORY-GROUPS { protocolDistributionHighCapacityGroup,
                           nlHostHighCapacityGroup,
                           nlMatrixHighCapacityGroup,
```

```
nlMatrixTopNHighCapacityGroup,
                           alHostHighCapacityGroup,
                           alMatrixHighCapacityGroup,
                           alMatrixTopNHighCapacityGroup,
                           usrHistoryHighCapacityGroup,
                           hcRMONInformationGroup }
    MODULE RMON2-MIB
        MANDATORY-GROUPS { protocolDirectoryGroup,
                           protocolDistributionGroup,
                           addressMapGroup,
                           nlHostGroup,
                           nlMatrixGroup,
                           alHostGroup,
                           alMatrixGroup,
                           usrHistoryGroup,
                           probeInformationGroup }
        GROUP
                rmon1EnhancementGroup
        DESCRIPTION
            "The rmonlEnhancementGroup is mandatory for systems which
            implement RMON [RFC2819]"
    ::= { hcRmonMIBCompliances 4 }
mediaIndependentGroup OBJECT-GROUP
    OBJECTS {mediaIndependentDataSource,
        mediaIndependentDropEvents,
        mediaIndependentDroppedFrames,
        mediaIndependentInPkts,
        mediaIndependentInOverflowPkts,
        mediaIndependentInHighCapacityPkts,
        mediaIndependentOutPkts,
        mediaIndependentOutOverflowPkts,
        mediaIndependentOutHighCapacityPkts,
        mediaIndependentInOctets,
        mediaIndependentInOverflowOctets,
        mediaIndependentInHighCapacityOctets,
        mediaIndependentOutOctets,
        mediaIndependentOutOverflowOctets,
        mediaIndependentOutHighCapacityOctets,
        mediaIndependentInNUCastPkts,
        mediaIndependentInNUCastOverflowPkts,
        mediaIndependentInNUCastHighCapacityPkts,
        mediaIndependentOutNUCastPkts,
        mediaIndependentOutNUCastOverflowPkts,
        mediaIndependentOutNUCastHighCapacityPkts,
        mediaIndependentInErrors,
        mediaIndependentOutErrors,
        mediaIndependentInputSpeed,
```

```
mediaIndependentOutputSpeed,
        mediaIndependentDuplexMode,
        mediaIndependentDuplexChanges,
        mediaIndependentDuplexLastChange,
        mediaIndependentOwner,
        mediaIndependentStatus }
    STATUS current
    DESCRIPTION
        "Collects utilization statistics for any type of network."
    ::= { hcRmonMIBGroups 1 }
etherStatsHighCapacityGroup OBJECT-GROUP
    OBJECTS { etherStatsHighCapacityOverflowPkts,
              etherStatsHighCapacityPkts,
              etherStatsHighCapacityOverflowOctets,
              etherStatsHighCapacityOctets,
              etherStatsHighCapacityOverflowPkts64Octets,
              etherStatsHighCapacityPkts64Octets,
              {\tt etherStatsHighCapacityOverflowPkts65to1270ctets},
              etherStatsHighCapacityPkts65to1270ctets,
              etherStatsHighCapacityOverflowPkts128to255Octets,
              etherStatsHighCapacityPkts128to255Octets,
              etherStatsHighCapacityOverflowPkts256to511Octets,
              etherStatsHighCapacityPkts256to511Octets,
              etherStatsHighCapacityOverflowPkts512to1023Octets,
              etherStatsHighCapacityPkts512to1023Octets,
              etherStatsHighCapacityOverflowPkts1024to1518Octets,
              etherStatsHighCapacityPkts1024to15180ctets }
    STATUS current
    DESCRIPTION
        "Collects utilization statistics for ethernet networks."
    ::= { hcRmonMIBGroups 2 }
etherHistoryHighCapacityGroup OBJECT-GROUP
    OBJECTS { etherHistoryHighCapacityOverflowPkts,
              etherHistoryHighCapacityPkts,
              etherHistoryHighCapacityOverflowOctets,
              etherHistoryHighCapacityOctets }
    STATUS current
    DESCRIPTION
        "Collects utilization statistics for ethernet networks."
    ::= { hcRmonMIBGroups 3 }
hostHighCapacityGroup OBJECT-GROUP
    OBJECTS { hostHighCapacityInOverflowPkts,
              hostHighCapacityInPkts,
              hostHighCapacityOutOverflowPkts,
              hostHighCapacityOutPkts,
```

```
hostHighCapacityInOverflowOctets,
              hostHighCapacityInOctets,
              hostHighCapacityOutOverflowOctets,
              hostHighCapacityOutOctets,
              \verb|hostTimeHighCapacityInOverflowPkts|,\\
              hostTimeHighCapacityInPkts,
              hostTimeHighCapacityOutOverflowPkts,
              hostTimeHighCapacityOutPkts,
              \verb|hostTimeHighCapacityInOverflowOctets|,\\
              hostTimeHighCapacityInOctets,
              hostTimeHighCapacityOutOverflowOctets,
              hostTimeHighCapacityOutOctets }
    STATUS current
    DESCRIPTION
        "Collects utilization and error statistics per host."
    ::= { hcRmonMIBGroups 4 }
hostTopNHighCapacityGroup OBJECT-GROUP
    OBJECTS { hostTopNHighCapacityAddress,
        hostTopNHighCapacityBaseRate,
        hostTopNHighCapacityOverflowRate,
        hostTopNHighCapacityRate }
    STATUS current
    DESCRIPTION
        "Prepares sorted reports of utilization and error statistics
        per host."
    ::= { hcRmonMIBGroups 5 }
matrixHighCapacityGroup OBJECT-GROUP
    OBJECTS { matrixSDHighCapacityOverflowPkts,
              matrixSDHighCapacityPkts,
              matrixSDHighCapacityOverflowOctets,
              matrixSDHighCapacityOctets,
              matrixDSHighCapacityOverflowPkts,
              matrixDSHighCapacityPkts,
              matrixDSHighCapacityOverflowOctets,
              matrixDSHighCapacityOctets }
    STATUS current
    DESCRIPTION
        "Collects utilization statistics per conversation."
    ::= { hcRmonMIBGroups 6 }
captureBufferHighCapacityGroup OBJECT-GROUP
    OBJECTS { captureBufferPacketHighCapacityTime }
    STATUS current
    DESCRIPTION
        "Provides finer granularity time stamps."
```

```
::= { hcRmonMIBGroups 7 }
protocolDistributionHighCapacityGroup OBJECT-GROUP
    OBJECTS { protocolDistStatsHighCapacityOverflowPkts,
              protocolDistStatsHighCapacityPkts,
              protocolDistStatsHighCapacityOverflowOctets,
              protocolDistStatsHighCapacityOctets }
    STATUS current
    DESCRIPTION
        "Collects the relative amounts of octets and packets for the
        different protocols detected on a network segment."
    ::= { hcRmonMIBGroups 8 }
nlHostHighCapacityGroup OBJECT-GROUP
    OBJECTS { nlHostHighCapacityInOverflowPkts,
              nlHostHighCapacityInPkts,
              nlHostHighCapacityOutOverflowPkts,
              nlHostHighCapacityOutPkts,
              nlHostHighCapacityInOverflowOctets,
              nlHostHighCapacityInOctets,
              nlHostHighCapacityOutOverflowOctets,
              nlHostHighCapacityOutOctets }
    STATUS current
    DESCRIPTION
        "Counts the amount of traffic sent from and to each network
        address discovered by the probe."
    ::= { hcRmonMIBGroups 9 }
nlMatrixHighCapacityGroup OBJECT-GROUP
    OBJECTS { nlMatrixSDHighCapacityOverflowPkts,
              nlMatrixSDHighCapacityPkts,
              nlMatrixSDHighCapacityOverflowOctets,
              nlMatrixSDHighCapacityOctets,
              nlMatrixDSHighCapacityOverflowPkts,
              nlMatrixDSHighCapacityPkts,
              nlMatrixDSHighCapacityOverflowOctets,
              nlMatrixDSHighCapacityOctets }
    STATUS current
    DESCRIPTION
        "Counts the amount of traffic sent between each pair of
        network addresses discovered by the probe."
    ::= { hcRmonMIBGroups 10 }
nlMatrixTopNHighCapacityGroup OBJECT-GROUP
    OBJECTS { nlMatrixTopNHighCapacityProtocolDirLocalIndex,
        nlMatrixTopNHighCapacitySourceAddress,
        nlMatrixTopNHighCapacityDestAddress,
        nlMatrixTopNHighCapacityBasePktRate,
```

```
nlMatrixTopNHighCapacityOverflowPktRate,
        nlMatrixTopNHighCapacityPktRate,
        nlMatrixTopNHighCapacityReverseBasePktRate,
        nlMatrixTopNHighCapacityReverseOverflowPktRate,
        {\tt nlMatrixTopNHighCapacityReversePktRate},
        nlMatrixTopNHighCapacityBaseOctetRate,
        nlMatrixTopNHighCapacityOverflowOctetRate,
        nlMatrixTopNHighCapacityOctetRate,
        nlMatrixTopNHighCapacityReverseBaseOctetRate,
        nlMatrixTopNHighCapacityReverseOverflowOctetRate,
        nlMatrixTopNHighCapacityReverseOctetRate }
    STATUS current
    DESCRIPTION
        "Prepares sorted reports of the amount of traffic sent between
        each pair of network addresses discovered by the probe."
    ::= { hcRmonMIBGroups 11 }
alHostHighCapacityGroup OBJECT-GROUP
    OBJECTS { alHostHighCapacityInOverflowPkts,
              alHostHighCapacityInPkts,
              alHostHighCapacityOutOverflowPkts,
              alHostHighCapacityOutPkts,
              alHostHighCapacityInOverflowOctets,
              alHostHighCapacityInOctets,
              alHostHighCapacityOutOverflowOctets,
              alHostHighCapacityOutOctets }
    STATUS current
    DESCRIPTION
        "Counts the amount of traffic, by protocol, sent from and to
        each network address discovered by the probe."
    ::= { hcRmonMIBGroups 12 }
alMatrixHighCapacityGroup OBJECT-GROUP
    OBJECTS { alMatrixSDHighCapacityOverflowPkts,
              alMatrixSDHighCapacityPkts,
              alMatrixSDHighCapacityOverflowOctets,
              alMatrixSDHighCapacityOctets,
              alMatrixDSHighCapacityOverflowPkts,
              alMatrixDSHighCapacityPkts,
              alMatrixDSHighCapacityOverflowOctets,
              alMatrixDSHighCapacityOctets }
    STATUS current
    DESCRIPTION
        "Counts the amount of traffic, by protocol, sent between each
        pair of network addresses discovered by the
       probe."
    ::= { hcRmonMIBGroups 13 }
```

```
alMatrixTopNHighCapacityGroup OBJECT-GROUP
    OBJECTS { alMatrixTopNHighCapacityProtocolDirLocalIndex,
        alMatrixTopNHighCapacitySourceAddress,
        alMatrixTopNHighCapacityDestAddress,
        alMatrixTopNHighCapacityAppProtocolDirLocalIndex,
        {\tt alMatrixTopNHighCapacityBasePktRate,}
        alMatrixTopNHighCapacityOverflowPktRate,
        alMatrixTopNHighCapacityPktRate,
        \verb|alMatrixTopNHighCapacityReverseBasePktRate|,
        alMatrixTopNHighCapacityReverseOverflowPktRate,
        alMatrixTopNHighCapacityReversePktRate,
        alMatrixTopNHighCapacityBaseOctetRate,
        alMatrixTopNHighCapacityOverflowOctetRate,
        alMatrixTopNHighCapacityOctetRate,
        alMatrixTopNHighCapacityReverseBaseOctetRate,
        alMatrixTopNHighCapacityReverseOverflowOctetRate,
        alMatrixTopNHighCapacityReverseOctetRate }
    STATUS current
    DESCRIPTION
        "Prepares sorted reports of the amount of traffic per protocol
        sent between each pair of network addresses discovered by the
        probe."
    ::= { hcRmonMIBGroups 14 }
usrHistoryHighCapacityGroup OBJECT-GROUP
    OBJECTS { usrHistoryHighCapacityOverflowAbsValue,
        usrHistoryHighCapacityAbsValue }
    STATUS current
    DESCRIPTION
        "Provides user-defined collection of historical information
        from MIB objects on the probe with scalability to statistics
        from high-capacity networks."
    ::= { hcRmonMIBGroups 15 }
hcRMONInformationGroup OBJECT-GROUP
    OBJECTS { hcRMONCapabilities }
    STATUS current
    DESCRIPTION
        "An indication of the high capacity RMON groups supported on
        at least one interface by this probe."
    ::= { hcRmonMIBGroups 16 }
END
```

6. Security Considerations

In order to implement this MIB, a probe must capture all packets on the locally-attached network, including packets between third parties. These packets are analyzed to collect network addresses, protocol usage information, and conversation statistics. Data of this nature may be considered sensitive in some environments. In such environments the administrator may wish to restrict SNMP access to the probe.

A probe implementing this MIB is likely to also implement RMON [RFC 2819], which includes functions for returning the contents of captured packets, potentially including sensitive user data or passwords. It is recommended that SNMP access to these functions be restricted.

There are a number of management objects defined in this MIB that have a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is recommended that the implementers consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model RFC 2574 [RFC2574] and the View-based Access Control Model RFC 2575 [RFC2575] is recommended.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

7. Acknowledgments

This document was produced by the IETF Remote Network Monitoring Working Group.

8. References

[1] Harrington, D., Presuhn, R. and B. Wijnen, "An Architecture for Describing SNMP Management Frameworks", RFC 2571, April 1999.

- [2] Rose, M. and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based Internets", STD 16, RFC 1155, May 1990.
- [3] Rose, M. and K. McCloghrie, "Concise MIB Definitions", STD 16, RFC 1212, March 1991.
- [4] Rose, M., "A Convention for Defining Traps for use with the SNMP", RFC 1215, March 1991.
- [5] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [6] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [7] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose,
 M. and S. Waldbusser, "Conformance Statements for SMIv2", STD
 58, RFC 2580, April 1999.
- [8] Case, J., Fedor, M., Schoffstall, M. and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, May 1990.
- [9] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Introduction to Community-based SNMPv2", RFC 1901, January 1996.
- [10] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1906, January 1996.
- [11] Case, J., Harrington D., Presuhn R. and B. Wijnen, "Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)", RFC 2572, April 1999.
- [12] Blumenthal, U. and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", RFC 2574, April 1999.
- [13] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1905, January 1996.
- [14] Levi, D., Meyer, P. and B. Stewart, "SNMPv3 Applications", RFC
 2573, April 1999.

- [15] Wijnen, B., Presuhn, R. and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", RFC 2575, April 1999.
- [16] McCloghrie, K. and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets: MIB-II", STD 17, RFC 1213, March 1991.
- [17] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.
- [18] Waldbusser, S., "Remote Network Monitoring MIB", STD 59, RFC 2819, May 2000.
- [19] Waldbusser, S., "Token Ring Extensions to the Remote Network Monitoring MIB", RFC 1513, September 1993.
- [20] Waldbusser, S., "Remote Network Monitoring Management Information Base Version 2 using SMIv2", RFC 2021, January 1997.
- [21] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction to Version 3 of the Internet-standard Network Management Framework, RFC 2570, April 1999.

9. Notices

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in BCP-11. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

10. Author's Address

Steve Waldbusser

Phone: +1-650-948-6500 Fax: +1-650-745-0671
EMail: waldbusser@nextbeacon.com

11. Full Copyright Statement

Copyright (C) The Internet Society (2002). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

${\tt Acknowledgement}$

Funding for the RFC Editor function is currently provided by the Internet Society.