Network Working Group Request for Comments: 4547 Category: Standards Track A. Ahmad Cisco Systems Inc. G. Nakanishi Motorola June 2006

Event Notification Management Information Base for
Data over Cable Service Interface Specifications (DOCSIS)-Compliant
Cable Modems and Cable Modem Termination Systems

Status of This Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2006).

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines a basic set of managed objects for Simple Network Management Protocol (SNMP) based event notification management of Data Over Cable Service Interface Specification (DOCSIS) compliant Cable Modems and Cable Modem Termination Systems. This MIB is defined as an extension to the DOCSIS Cable Device MIB.

This memo specifies a MIB module in a manner that is compliant to the Structure of Management Information Version 2 (SMIv2). The set of objects is consistent with the SNMP framework and existing SNMP standards.

Table of Contents

The Internet-Standard Management Framework	2
2.2. BPI - Baseline Privacy Plus Interface	3
2.4. CM - Cable Modem	3
2.5. CMTS - Cable Modem Termination System	3
2.7. Downstream	4
2.8. Head-end	4
2.9. MAC Packet	4
2.10. RF	4
2.11. SID	4
2.12. TLV	4
2.13. Upstream	4
Definitions	
Contributors	. 35
Acknowledgements	. 36
IANA Considerations	
References	.37
9.1. Normative References	.37
9.2. Informative References	.38
	Contributors Acknowledgements Security Considerations IANA Considerations References 9.1. Normative References

1. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [16].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIv2, which is described in STD 58, RFC 2578 [2], STD 58, RFC 2579 [3] and STD 58, RFC 2580 [4].

2. Glossary

The terms in this document are derived either from normal cable system usage, or from the documents associated with the Data Over Cable Service Interface Specification (DOCSIS) process.

2.1. BPI - Baseline Privacy Interface

A mechanism for providing data privacy over the HFC network in DOCSIS 1.0 systems [8].

2.2. BPI - Baseline Privacy Plus Interface

A mechanism that extends the Baseline Privacy Interface with the addition of CM authentication over the HFC network in DOCSIS 1.1/2.0 systems and beyond [9].

2.3. CATV

Originally "Community Antenna Television", now used to refer to any cable or hybrid fiber and cable system used to deliver video signals to a community.

2.4. CM - Cable Modem

A CM acts as a "slave" station in a DOCSIS-compliant cable data system.

2.5. CMTS - Cable Modem Termination System

A generic term covering a cable bridge or cable router in a head-end. A CMTS acts as the master station in a DOCSIS-compliant cable data system. It is the only station that transmits downstream, and it controls the scheduling of upstream transmissions by its associated CMS.

2.6. DOCSIS

DOCSIS stands for "Data-over-Cable Service Interface Specifications" and refers to the ITU-T J.112 Annex B standard for cable modem systems [10], [13] commonly known as DOCSIS 1.0. The DOCSIS 1.1 specification is an extension of DOCSIS 1.0, with new features to support quality of service, fragmentation, and requirements for European cable plants [14].

DOCSIS 2.0 [15] builds upon DOCSIS 1.1 and provides all of the features and functionality that DOCSIS 1.1 provides. In addition, it provides some significant enhancements in upstream capacity over DOCSIS 1.1, such as 30.72 Mbps maximum upstream channel capacity, Synchronous-Code Division Multiple Access (CDMA) operation, increased robustness to upstream noise and channel impairments, Enhanced Reed-Solomon error correction, and Trellis Coded Modulation.

2.7. Downstream

The direction from the CMTS to the CM.

2.8. Head-end

The origination point in most cable systems of the subscriber video signals. Generally also the location of the CMTS equipment.

2.9. MAC Packet

A term referring to DOCSIS Protocol Data Unit (PDU).

2.10. RF

A term referring to Radio Frequency.

2.11. SID

A term referring to DOCSIS Service ID. The SID identifies a particular upstream bandwidth allocation and class-of-service management for DOCSIS, and identifies a particular bidirectional security association for BPI.

2.12. TLV

TLV stands for Type/Length/Value. TLV is an encoding method consisting of three fields. The first field indicates the type of element, the second field indicates the length of the element, and the third field contains the element's value.

2.13. Upstream

The direction from the CM to the CMTS.

3. Overview

Offering High Speed Internet Service in the cable industry has become extremely successful. DOCSIS devices are being deployed at a rate of multiple thousands per day. Although operators are enjoying successful deployment, they are also facing the challenge of properly managing deployed devices. Operators are using Simple Network Management Protocol, a set of Management Information Base (MIB) required by DOCSIS, and SNMP Notifications to manage deployed DOCSIS devices. The usage of SNMP Notification for event reporting is becoming more popular as an effective and efficient method for network monitoring.

Unfortunately, only a minimal set of SNMP Notifications is currently available. This notification MIB, in conjunction with [11] and [12], provides a minimum set of standard DOCSIS Notifications that DOCSIS devices SHOULD support to enable successful management of DOCSIS devices and networks.

This document defines a set of objects required for the event notification management of DOCSIS-compliant Cable Modems (CMs) and Cable Modem Termination Systems (CMTSs). The MIB module is derived from the DOCSIS [11] and [12].

Appendix H of [11] defines all DOCSIS 1.1 required events, and Appendix D of [12] does that for DOCSIS 2.0. The notifications specified in this document are used to notify these events via SNMP.

In this document, the key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" are to be interpreted as described in RFC 2119 [1].

3.1. Structure of the MIB

This DOCS-IETF-CABLE-DEVICE-NOTIFICATION-MIB was designed to extend the RFC2669 [5] notification module.

Two groups of SNMP notification objects are defined in this document. One group defines notifications for cable modem events, and the other group defines notifications for cable modem termination system events.

DOCSIS defines numerous events, and each event is assigned to a functional category. This MIB defines a notification object for each functional category. The varbinding list of each notification includes information about the event that occurred on the device.

4. Definitions

The MIB module defined here IMPORTs from SNMPv2-SMI [2], SNMPv2-CONF [3], DOCS-CABLE-DEVICE-MIB [5], DOCS-IF-MIB [6], and IF-MIB [7].

DOCS-IETF-CABLE-DEVICE-NOTIFICATION-MIB DEFINITIONS ::= BEGIN

IMPORTS

```
MODULE-IDENTITY,
OBJECT-TYPE,
NOTIFICATION-TYPE,
mib-2
FROM SNMPv2-SMI -- RFC 2578
MODULE-COMPLIANCE,
```

Ahmad & Makanishi

Standards Track

[Page 5]

```
OBJECT-GROUP,
     NOTIFICATION-GROUP
           FROM SNMPv2-CONF -- RFC 2580
     docsDevEvLevel,
     docsDevEvId,
     docsDevEvText,
     docsDevSwFilename,
     docsDevSwServer,
     docsDevServerDhcp,
     docsDevServerTime
           FROM DOCS-CABLE-DEVICE-MIB -- RFC 2669
     docsIfCmCmtsAddress,
     docsIfCmtsCmStatusMacAddress,
     docsIfDocsisBaseCapability,
     docsIfCmStatusDocsisOperMode,
     docsIfCmStatusModulationType,
     docsIfCmtsCmStatusDocsisRegMode,
     docsIfCmtsCmStatusModulationType
           FROM DOCS-IF-MIB -- RFC 4546
      ifPhysAddress
           FROM IF-MIB; -- RFC 2863
docsDevNotifMIB MODULE-IDENTITY
     LAST-UPDATED "200605240000Z" -- May 24, 2006
     ORGANIZATION "IETF IP over Cable Data Network
                     Working Group"
     CONTACT-INFO
                  Azlina Ahmad
          Postal: Cisco Systems, Inc.
                  170 West Tasman Drive
                  San Jose, CA 95134, U.S.A.
           Phone: 408 853 7927
           E-mail: azlina@cisco.com
                  Greg Nakanishi
           Postal: Motorola
                   6450 Sequence Drive
                   San Diego, CA 92121, U.S.A.
                  858 404 2366
           Phone:
           E-mail: gnakanishi@motorola.com
           IETF IPCDN Working Group
           General Discussion: ipcdn@ietf.org
```

```
Archive: ftp://ftp.ietf.org/ietf-mail-archive/ipcdn
             Co-chairs: Richard Woundy,
                          richard woundy@cable.comcast.com
                        Jean-Francois Mule, jf.mule@cablelabs.com"
        DESCRIPTION
            "The Event Notification MIB is an extension of the
            CABLE DEVICE MIB. It defines various notification
            objects for both cable modem and cable modem termination
            systems. Two groups of SNMP notification objects are
            defined. One group is for notifying cable modem events,
            and one group is for notifying cable modem termination
            system events.
            DOCSIS defines numerous events, and each event is
            assigned to a functional category. This MIB defines
            a notification object for each functional category.
            The varbinding list of each notification includes
            information about the event that occurred on the
            device.
            Copyright (C) The Internet Society (2006). This version
            of this MIB module is part of RFC 4547; see the RFC
            itself for full legal notices."
        REVISION "200605240000Z" -- May 24, 2006
        DESCRIPTION
            "Initial version, published as RFC 4547."
        ::= { mib-2 132 }
docsDevNotifControl OBJECT IDENTIFIER ::= { docsDevNotifMIB 1}
docsDevCmNotifs OBJECT IDENTIFIER ::= { docsDevNotifMIB 2 0 }
docsDevCmtsNotifs OBJECT IDENTIFIER ::= { docsDevNotifMIB 3 0 }
docsDevCmNotifControl OBJECT-TYPE
   SYNTAX BITS {
        cmInitTLVUnknownNotif( 0),
        cmDynServRegFailNotif(1),
        cmDynServRspFailNotif( 2),
        cmDynServAckFailNotif( 3),
        cmBpiInitNotif(4),
        cmBPKMNotif(5),
        cmDynamicSANotif(6),
        cmDHCPFailNotif( 7),
        cmSwUpgradeInitNotif( 8),
```

Subscribe: http://www.ietf.org/mailman/listinfo/ipcdn

cmSwUpgradeFailNotif(9),
cmSwUpgradeSuccessNotif(10),

```
cmSwUpgradeCVCNotif(11),
        cmTODFailNotif( 12),
        cmDCCReqFailNotif( 13),
        cmDCCRspFailNotif( 14),
        cmDCCAckFailNotif( 15)
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The object is used to enable specific CM notifications.
       For example, if the first bit is set, then
        docsDevCmInitTLVUnknownNotif is enabled. If it is not set,
        the notification is disabled. Note that notifications are
        also under the control of the MIB modules defined in
       RFC3413.
       If the device is rebooted, the value of this object SHOULD
       revert to the default value.
   DEFVAL { { } }
   ::= { docsDevNotifControl 1 }
docsDevCmtsNotifControl OBJECT-TYPE
    SYNTAX BITS {
        cmtsInitRegReqFailNotif( 0),
        cmtsInitRegRspFailNotif( 1),
        cmtsInitRegAckFailNotif( 2),
        cmtsDynServReqFailNotif( 3),
        cmtsDynServRspFailNotif( 4),
        cmtsDynServAckFailNotif( 5),
        cmtsBpiInitNotif( 6),
        cmtsBPKMNotif( 7),
        cmtsDynamicSANotif( 8),
        cmtsDCCReqFailNotif( 9),
       cmtsDCCRspFailNotif( 10),
        cmtsDCCAckFailNotif( 11)
   MAX-ACCESS read-write
    STATUS current
   DESCRIPTION
       "The object is used to enable specific CMTS notifications.
        For example, if the first bit is set, then
        docsDevCmtsInitRegRspFailNotif is enabled. If it is not set,
        the notification is disabled. Note that notifications are
        also under the control of the MIB modules defined in
        RFC3413.
```

```
If the device is rebooted, the value of this object SHOULD
       revert to the default value.
   DEFVAL { { } }
    ::= { docsDevNotifControl 2 }
docsDevCmInitTLVUnknownNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       ifPhysAddress,
       docsIfCmCmtsAddress,
       docsIfDocsisBaseCapability,
       docsIfCmStatusDocsisOperMode,
       docsIfCmStatusModulationType
   STATUS current
   DESCRIPTION
        "Notification to indicate that an unknown TLV was
          encountered during the TLV parsing process.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
           event.
         - docsDevEvId: the unique identifier of the event that
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
          MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 1 }
```

```
docsDevCmDynServReqFailNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic service
         request during the dynamic services process.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
          to which the CM is connected to (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 2 }
docsDevCmDynServRspFailNotif NOTIFICATION-TYPE
    OBJECTS {
       docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
```

docsIfCmCmtsAddress,

```
docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        " A notification to report the failure of a dynamic service
         response during the dynamic services process.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 3}
docsDevCmDynServAckFailNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
   DESCRIPTION
```

"A notification to report the failure of a dynamic service acknowledgement during the dynamic services process.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is connected).
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1) that the CM is operating in.
- docsIfCmStatusModulationType: the upstream modulation methodology used by the CM.

```
::= { docsDevCmNotifs 4}
```

```
docsDevCmBpiInitNotif NOTIFICATION-TYPE
   OBJECTS {
      docsDevEvLevel,
      docsDevEvId,
      docsDevEvText,
      ifPhysAddress,
      docsIfCmCmtsAddress,
      docsIfDocsisBaseCapability,
      docsIfCmStatusDocsisOperMode,
      docsIfCmStatusModulationType
   }
   STATUS current
   DESCRIPTION
      "A notification to report the failure of a BPI
      initialization attempt during the registration process.
```

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the

```
event.
```

- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is connected).
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1) that the CM is operating in.
- docsIfCmStatusModulationType: the upstream modulation methodology used by the CM.

```
::= { docsDevCmNotifs 5 }
```

```
docsDevCmBPKMNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
   }
   STATUS current
   DESCRIPTION
```

"A notification to report the failure of a Baseline Privacy Key Management (BPKM) operation.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS

```
to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 6 }
docsDevCmDynamicSANotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
```

"A notification to report the failure of a dynamic security association operation.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is connected).
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.

```
- docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
          that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 7 }
docsDevCmDHCPFailNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
       docsIfCmCmtsAddress,
       docsDevServerDhcp,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a DHCP operation.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
          event.
         - docsDevEvId: the unique identifier of the event that
          occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsDevServerDhcp: the IP address of the DHCP server.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 8 }
```

```
docsDevCmSwUpgradeInitNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsDevSwFilename,
        docsDevSwServer,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to indicate that a software upgrade
         has been initiated on the device.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
          interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
          to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 9 }
docsDevCmSwUpgradeFailNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
```

ifPhysAddress,

```
docsIfCmCmtsAddress,
       docsDevSwFilename,
       docsDevSwServer,
       docsIfDocsisBaseCapability,
       docsIfCmStatusDocsisOperMode,
       docsIfCmStatusModulationType
   STATUS current
   DESCRIPTION
        "A notification to report the failure of a software upgrade
        attempt.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
           event.
         - docsDevEvId: the unique identifier of the event that
          occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
          MAC address of the cable interface to which it is
          connected).
         - docsDevSwFilename: the software image file name
         - docsDevSwServer: the IP address of the server that
           the image is retrieved from.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 10 }
docsDevCmSwUpgradeSuccessNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       ifPhysAddress,
       docsIfCmCmtsAddress,
```

docsDevSwFilename,

```
docsDevSwServer,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the software upgrade success
         status.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsDevSwFilename: the software image file name
         - docsDevSwServer: the IP address of the server that
           the image is retrieved from.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 11 }
docsDevCmSwUpgradeCVCFailNotif NOTIFICATION-TYPE
    OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
```

docsIfCmStatusModulationType

```
STATUS current
    DESCRIPTION
        "A notification to report that the verification of the
         code file has failed during a secure software upgrade
         attempt.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
           event.
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - ifPhysAddress: the MAC address of the cable
           interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
           to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
          that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 12 }
docsDevCmTODFailNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsDevServerTime,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a time of day
```

operation.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is connected).
- docsDevServerTime: the IP address of the time server.
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1) that the CM is operating in.
- docsIfCmStatusModulationType: the upstream modulation methodology used by the CM.

```
::= { docsDevCmNotifs 13 }
```

```
docsDevCmDCCReqFailNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
   }
   STATUS current
   DESCRIPTION
```

" A notification to report the failure of a dynamic channel change request during the dynamic channel change process on the CM.

This notification sends additional information about the event by including the following objects in its varbinding list.

```
    docsDevEvLevel: the priority level associated with the
event.
```

- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is connected).
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1) that the CM is operating in.
- docsIfCmStatusModulationType: the upstream modulation methodology used by the CM.

::= { docsDevCmNotifs 14 }

```
docsDevCmDCCRspFailNotif NOTIFICATION-TYPE
   OBJECTS {
      docsDevEvLevel,
      docsDevEvId,
      docsDevEvText,
      ifPhysAddress,
      docsIfCmCmtsAddress,
      docsIfDocsisBaseCapability,
      docsIfCmStatusDocsisOperMode,
      docsIfCmStatusModulationType
   }
  STATUS current
  DESCRIPTION
```

"A notification to report the failure of a dynamic channel change response during the dynamic channel change process on the CM.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable

```
interface of this cable modem.
         - docsIfCmCmtsAddress: the MAC address of the CMTS
          to which the CM is connected (if there is a cable
           card/interface in the CMTS, then it is actually the
           MAC address of the cable interface to which it is
           connected).
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
          that the CM is operating in.
         - docsIfCmStatusModulationType: the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 15 }
docsDevCmDCCAckFailNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        ifPhysAddress,
        docsIfCmCmtsAddress,
        docsIfDocsisBaseCapability,
        docsIfCmStatusDocsisOperMode,
        docsIfCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic channel
         change acknowledgement during the dynamic channel
         change process on the CM.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
```

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- ifPhysAddress: the MAC address of the cable interface of this cable modem.
- docsIfCmCmtsAddress: the MAC address of the CMTS to which the CM is connected (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface to which it is

```
connected).
         - docsIfDocsisBaseCapability: the highest
          version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmStatusDocsisOperMode: the QOS level (1.0, 1.1)
           that the CM is operating in.
         - docsIfCmtsCmStatusModulationType the upstream modulation
           methodology used by the CM.
    ::= { docsDevCmNotifs 16}
docsDevCmtsInitRegReqFailNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       docsIfCmtsCmStatusMacAddress,
       ifPhysAddress,
       docsIfCmtsCmStatusDocsisRegMode,
       docsIfDocsisBaseCapability,
       docsIfCmtsCmStatusModulationType
   STATUS current
   DESCRIPTION
        "A notification to report the failure of a registration
        request from a CM during the CM initialization
        process that was detected on the CMTS.
        This notification sends additional information about
        the event by including the following objects in its
        varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
```

```
- docsIfCmtsCmStatusModulationType: the upstream
          modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 1 }
docsDevCmtsInitRegRspFailNotif NOTIFICATION-TYPE
    OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a registration
        response during the CM initialization
         process that was detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
           event.
         - docsDevEvId: the unique identifier of the event that
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 2 }
```

docsDevCmtsInitRegAckFailNotif NOTIFICATION-TYPE

```
OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       docsIfCmtsCmStatusMacAddress,
       ifPhysAddress,
       docsIfCmtsCmStatusDocsisRegMode,
       docsIfDocsisBaseCapability,
       docsIfCmtsCmStatusModulationType
   STATUS current
   DESCRIPTION
        "A notification to report the failure of a registration
         acknowledgement from the CM during the CM \,
         initialization process that was detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
          occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
          (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
          interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 3 }
docsDevCmtsDynServReqFailNotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       docsIfCmtsCmStatusMacAddress,
       ifPhysAddress,
```

docsIfCmtsCmStatusDocsisRegMode,

```
docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
     }
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic service
         request during the dynamic services process
         that was detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 4 }
docsDevCmtsDynServRspFailNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId.
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
   DESCRIPTION
```

"A notification to report the failure of a dynamic service response during the dynamic services process that was detected by the CMTS.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- docsIfCmtsCmStatusMacAddress: the MAC address of the CM with which this notification is associated.
- ifPhysAddress: the MAC address of the CMTS (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface that connected to the CM) cable interface connected to the CM.
- docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1) that the reporting CM is operating in.
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmtsCmStatusModulationType: the upstream modulation methodology used by the CM.

```
::= { docsDevCmtsNotifs 5 }
```

```
docsDevCmtsDynServAckFailNotif NOTIFICATION-TYPE
    OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic service
         acknowledgement during the dynamic services
```

process that was detected by the CMTS.

This notification sends additional information about the event by including the following objects in its

```
varbinding list.
```

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- docsIfCmtsCmStatusMacAddress: the MAC address of the CM with which this notification is associated.
- ifPhysAddress: the MAC address of the CMTS (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface that connected to the CM) cable interface connected to the CM.
- docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1) that the reporting CM is operating in.
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmtsCmStatusModulationType: the upstream modulation methodology used by the CM.

::= { docsDevCmtsNotifs 6 }

```
docsDevCmtsBpiInitNotif NOTIFICATION-TYPE
   OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
   }
   STATUS current
   DESCRIPTION
```

"A notification to report the failure of a BPI initialization attempt during the CM registration process that was detected by the CMTS.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the event.
- docsDevEvId: the unique identifier of the event that occurred.

```
- docsDevEvText: a textual description of the event.
```

- docsIfCmtsCmStatusMacAddress: the MAC address of the CM with which this notification is associated.
- ifPhysAddress: the MAC address of the CMTS (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface that connected to the CM) cable interface connected to the CM.
- docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1) that the reporting CM is operating in.
- docsIfDocsisBaseCapability: the highest version of the DOCSIS specification (1.0, 1.1, 2.0) that the device is capable of supporting.
- docsIfCmtsCmStatusModulationType: the upstream modulation methodology used by the CM.

::= { docsDevCmtsNotifs 7 }

```
docsDevCmtsBPKMNotif NOTIFICATION-TYPE
   OBJECTS {
      docsDevEvLevel,
      docsDevEvId,
      docsDevEvText,
      docsIfCmtsCmStatusMacAddress,
      ifPhysAddress,
      docsIfCmtsCmStatusDocsisRegMode,
      docsIfDocsisBaseCapability,
      docsIfCmtsCmStatusModulationType
   }
   STATUS current
   DESCRIPTION
```

"A notification to report the failure of a BPKM operation that is detected by the CMTS.

This notification sends additional information about the event by including the following objects in its varbinding list.

- docsDevEvLevel: the priority level associated with the
- docsDevEvId: the unique identifier of the event that occurred.
- docsDevEvText: a textual description of the event.
- docsIfCmtsCmStatusMacAddress: the MAC address of the CM with which this notification is associated.
- ifPhysAddress: the MAC address of the CMTS (if there is a cable card/interface in the CMTS, then it is actually the MAC address of the cable interface that connected to the CM) cable interface

```
connected to the CM.
        - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
          that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
          version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 8 }
docsDevCmtsDynamicSANotif NOTIFICATION-TYPE
   OBJECTS {
       docsDevEvLevel,
       docsDevEvId,
       docsDevEvText,
       docsIfCmtsCmStatusMacAddress,
       ifPhysAddress,
       docsIfCmtsCmStatusDocsisRegMode,
       docsIfDocsisBaseCapability,
       docsIfCmtsCmStatusModulationType
   STATUS current
   DESCRIPTION
        "A notification to report the failure of a dynamic security
        association operation that is detected by the CMTS.
        This notification sends additional information about
        the event by including the following objects in its
        varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
          occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
          that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
```

```
- docsIfCmtsCmStatusModulationType: the upstream
          modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 9 }
docsDevCmtsDCCReqFailNotif NOTIFICATION-TYPE
    OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic channel
         change request during the dynamic channel
         change process and is detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
           event.
         - docsDevEvId: the unique identifier of the event that
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 10 }
docsDevCmtsDCCRspFailNotif NOTIFICATION-TYPE
```

OBJECTS {

```
docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        {\tt docsIfCmtsCmStatusMacAddress,}
        ifPhysAddress,
        docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic channel
         change response during the dynamic channel
         change process and is detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
           that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 11 }
docsDevCmtsDCCAckFailNotif NOTIFICATION-TYPE
    OBJECTS {
        docsDevEvLevel,
        docsDevEvId,
        docsDevEvText,
        docsIfCmtsCmStatusMacAddress,
```

ifPhysAddress,

```
docsIfCmtsCmStatusDocsisRegMode,
        docsIfDocsisBaseCapability,
        docsIfCmtsCmStatusModulationType
    STATUS current
    DESCRIPTION
        "A notification to report the failure of a dynamic channel
         change acknowledgement during the dynamic channel
         change process and is detected by the CMTS.
         This notification sends additional information about
         the event by including the following objects in its
         varbinding list.
         - docsDevEvLevel: the priority level associated with the
         - docsDevEvId: the unique identifier of the event that
           occurred.
         - docsDevEvText: a textual description of the event.
         - docsIfCmtsCmStatusMacAddress: the MAC address of the CM
           with which this notification is associated.
         - ifPhysAddress: the MAC address of the CMTS
           (if there is a cable card/interface in the CMTS,
           then it is actually the MAC address of the cable
           interface that connected to the CM) cable interface
           connected to the CM.
         - docsIfCmtsCmStatusDocsisRegMode: the QOS level (1.0, 1.1)
          that the reporting CM is operating in.
         - docsIfDocsisBaseCapability: the highest
           version of the DOCSIS specification (1.0, 1.1, 2.0)
           that the device is capable of supporting.
         - docsIfCmtsCmStatusModulationType: the upstream
           modulation methodology used by the CM.
    ::= { docsDevCmtsNotifs 12}
--Conformance definitions
docsDevNotifConformance OBJECT IDENTIFIER
   ::= { docsDevNotifMIB 4 }
docsDevNotifGroups OBJECT IDENTIFIER
   ::= { docsDevNotifConformance 1 }
docsDevNotifCompliances OBJECT IDENTIFIER
   ::= { docsDevNotifConformance 2 }
docsDevCmNotifCompliance MODULE-COMPLIANCE
   STATUS current
```

```
DESCRIPTION
    "The compliance statement for CM Notifications and Control."
    MODULE --docsDevNotif
     MANDATORY-GROUPS {
               docsDevCmNotifControlGroup,
               docsDevCmNotificationGroup
    ::= { docsDevNotifCompliances 1 }
docsDevCmNotifControlGroup OBJECT-GROUP
    OBJECTS {
        docsDevCmNotifControl
    STATUS current
    DESCRIPTION
        "This group represents objects that allow control
        over CM Notifications."
    ::= { docsDevNotifGroups 1 }
docsDevCmNotificationGroup NOTIFICATION-GROUP
    NOTIFICATIONS {
        docsDevCmInitTLVUnknownNotif,
        docsDevCmDynServReqFailNotif,
        docsDevCmDynServRspFailNotif,
        docsDevCmDynServAckFailNotif,
        docsDevCmBpiInitNotif,
        docsDevCmBPKMNotif,
        docsDevCmDynamicSANotif,
        docsDevCmDHCPFailNotif,
        docsDevCmSwUpgradeInitNotif,
        docsDevCmSwUpgradeFailNotif,
        docsDevCmSwUpgradeSuccessNotif,
        docsDevCmSwUpgradeCVCFailNotif,
        docsDevCmTODFailNotif,
        docsDevCmDCCReqFailNotif,
        docsDevCmDCCRspFailNotif,
        docsDevCmDCCAckFailNotif
    STATUS current
    DESCRIPTION
        "A collection of CM notifications providing device status
   and control."
    ::= { docsDevNotifGroups 2 }
docsDevCmtsNotifCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
```

```
"The compliance statement for DOCSIS CMTS Notification
         and Control."
    MODULE --docsDevNotif
       MANDATORY-GROUPS {
          docsDevCmtsNotifControlGroup,
          docsDevCmtsNotificationGroup
    ::= { docsDevNotifCompliances 2 }
docsDevCmtsNotifControlGroup OBJECT-GROUP
    OBJECTS {
        docsDevCmtsNotifControl
    STATUS current
    DESCRIPTION
        "This group represents objects that allow control
         over CMTS Notifications."
    ::= { docsDevNotifGroups 3 }
docsDevCmtsNotificationGroup NOTIFICATION-GROUP
    NOTIFICATIONS {
        {\tt docsDevCmtsInitRegReqFailNotif},
        docsDevCmtsInitRegRspFailNotif,
        docsDevCmtsInitRegAckFailNotif ,
        docsDevCmtsDynServReqFailNotif,
        docsDevCmtsDynServRspFailNotif,
        docsDevCmtsDynServAckFailNotif,
        docsDevCmtsBpiInitNotif,
        docsDevCmtsBPKMNotif,
        docsDevCmtsDynamicSANotif,
        docsDevCmtsDCCReqFailNotif,
        docsDevCmtsDCCRspFailNotif,
        docsDevCmtsDCCAckFailNotif
    STATUS current
    DESCRIPTION
        "A collection of CMTS notifications providing device
         status and control."
    ::= { docsDevNotifGroups 4 }
END
```

5. Contributors

Thanks go to the following people, who have made significant contributions to this document: Junming Gao, Jean-Francois Mule, Dave Raftus, Pak Siripunkaw, and Rich Woundy.

6. Acknowledgements

This document was produced by the IPCDN Working Group. Thanks to Harrie Hazewinkel and Bert Wijnen for their thorough review and insightful comments on this document. Special thanks to Rich Woundy, who made several valuable suggestions to improve the notifications.

7. Security Considerations

There are two management objects defined in this MIB module with a MAX-ACCESS clause of read-write and/or read-create (docsDevCmNotifControl and docsDevCmtsNotifControl). Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

Setting docsDevCmNotifControl or docsDevCmtsNotifControl may cause flooding of notifications, which can disrupt network service. Besides causing "flooding", changing the objects can also mean that notifications will not be emitted when one intends that to happen.

This MIB defines a number of notification objects that send detailed information about the event that caused the generation of the notification. Information in the notification message includes: event priority, the event Id, the event message body, the CM DOCSIS capability, the CM DOCSIS QOS level, the CM DOCSIS upstream modulation type, the cable interface MAC address of the cable modem, and the cable card MAC address of the CMTS to which the modem is connected. The monitoring of these notification messages could be used to gather information about the state of the network and devices (CM and CMTS) attached to the network.

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPSec), even then there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [16], section 8), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an

instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

8. IANA Considerations

The MIB module defined in this document uses the following IANA-assigned OBJECT IDENTIFIER values recorded in the SMI Numbers registry:

```
Descriptor OBJECT IDENTIFIER value
-----
docsDevNotifMIB { mib-2 132 }
```

9. References

9.1. Normative References

- [1] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [2] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [3] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [4] McCloghrie, K., Perkins, D., and J. Schoenwaelder, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [5] St. Johns, M., "DOCSIS Cable Device MIB Cable Device Management Information Base for DOCSIS compliant Cable Modems and Cable Modem Termination Systems", RFC 2669, August 1999.
- [6] Raftus, D. and E. Cardona, "Radio Frequency (RF) Interface Management Information Base for Data over Cable Service Interface Specifications (DOCSIS) 2.0 Compliant RF Interfaces", RFC 4546, June 2006.
- [7] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.
- [8] SCTE Data Standards Subcommittee, "Data-Over-Cable Service Interface Specifications: DOCSIS 1.0 Baseline Privacy Interface Specification SCTE 22-2", 2002, http://www.scte.org/standards/.

- [10] SCTE Data Standards Subcommittee, "Data-Over-Cable Service Interface Specifications: DOCSIS 1.0 Operations Support System Interface Specification Radio Frequency Interface SCTE 22-3", 2002, http://www.scte.org/standards/>.
- [11] CableLabs, "Data-Over-Cable Service Interface Specifications:
 Operations Support System Interface Specification CM-SP OSSIv1.1-C01-050907", September 2005,
 http://www.cablemodem.com/specifications/>.
- [12] CableLabs, "Data-Over-Cable Service Interface Specifications:
 Operations Support System Interface Specification CM-SP OSSIv2.0-I09-050812", August 2005,
 http://www.cablemodem.com/specifications/>.
- [13] SCTE Data Standards Subcommittee, "Data-Over-Cable Service
 Interface Specifications: DOCSIS 1.0 Radio Frequency Interface
 Specification SCTE 22-1", 2002,
 http://www.scte.org/standards/>.
- [14] CableLabs, "Data-Over-Cable Service Interface Specifications:
 Radio Frequency Interface Specification CM-SP-RFIv1.1-C01 050907", September 2005,
 http://www.cablemodem.com/specifications/>.
- [15] CableLabs, "Data-Over-Cable Service Interface Specifications:
 Radio Frequency Interface Specification CM-SP-RFIv2.0-I10 051209", December 2005,
 http://www.cablemodem.com/specifications/>.

9.2. Informative References

[16] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", RFC 3410, December 2002.

June 2006

Authors' Addresses

Azlina Ahmad Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134 US

Phone: 408 853 7927 EMail: azlina@cisco.com

Greg Nakanishi Motorola 6450 Sequence Dr. San Diego, CA 92126

Phone: 858 404-2366

EMail: gnakanishi@motorola.com

Full Copyright Statement

Copyright (C) The Internet Society (2006).

This document is subject to the rights, licenses and restrictions contained in BCP 78, and except as set forth therein, the authors retain all their rights.

This document and the information contained herein are provided on an "AS IS" basis and THE CONTRIBUTOR, THE ORGANIZATION HE/SHE REPRESENTS OR IS SPONSORED BY (IF ANY), THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Intellectual Property

The IETF takes no position regarding the validity or scope of any Intellectual Property Rights or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; nor does it represent that it has made any independent effort to identify any such rights. Information on the procedures with respect to rights in RFC documents can be found in BCP 78 and BCP 79.

Copies of IPR disclosures made to the IETF Secretariat and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementers or users of this specification can be obtained from the IETF on-line IPR repository at http://www.ietf.org/ipr.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights that may cover technology that may be required to implement this standard. Please address the information to the IETF at ietf-ipr@ietf.org.

Acknowledgement

Funding for the RFC Editor function is provided by the IETF Administrative Support Activity (IASA).