Internet Engineering Task Force (IETF)

Request for Comments: 6850 Category: Standards Track

ISSN: 2070-1721

A. Rijhsinghani Hewlett-Packard K. Zebrose HW Embedded January 2013

Definitions of Managed Objects for Routing Bridges (RBridges)

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols. In particular, it defines objects for managing a Routing Bridge (RBridge), also known as a TRILL Switch, based on the IETF TRILL (Transparent Interconnection of Lots of Links) protocol.

Status of This Memo

This is an Internet Standards Track document.

This document is a product of the Internet Engineering Task Force (IETF). It represents the consensus of the IETF community. It has received public review and has been approved for publication by the Internet Engineering Steering Group (IESG). Further information on Internet Standards is available in Section 2 of RFC 5741.

Information about the current status of this document, any errata, and how to provide feedback on it may be obtained at http://www.rfc-editor.org/info/rfc6850.

Copyright Notice

Copyright (c) 2013 IETF Trust and the persons identified as the document authors. All rights reserved.

This document is subject to BCP 78 and the IETF Trust's Legal Provisions Relating to IETF Documents (http://trustee.ietf.org/license-info) in effect on the date of publication of this document. Please review these documents carefully, as they describe your rights and restrictions with respect to this document. Code Components extracted from this document must include Simplified BSD License text as described in Section 4.e of the Trust Legal Provisions and are provided without warranty as described in the Simplified BSD License.

Table of Contents

1.	Introduction	2
2.	The Internet-Standard Management Framework	3
3.	Overview	3
4.	Conventions	4
5.	Structure of the MIB Module	4
	5.1. Textual Conventions	4
	5.2. The rbridgeBase Subtree	4
	5.3. The rbridgeFdb Subtree	4
	5.4. The rbridgeVlan Subtree	4
	5.5. The rbridgeEsadi Subtree	4
	5.6. The rbridgeCounters Subtree	
	5.7. The rbridgeSnooping Subtree	
	5.8. The rbridgeDtree Subtree	
	5.9. The rbridgeTrill Subtree	
	5.10. The Notifications Subtree	
6.	Relationship to Other MIB Modules	
	6.1. Relationship to IF-MIB	
	6.2. Relationship to BRIDGE-MIB	
	6.3. Relationship to P-BRIDGE-MIB	
	6.4. Relationship to Q-BRIDGE-MIB	
	6.5. Relationship to IEEE8021-BRIDGE-MIB	
	6.6. Relationship to IEEE8021-Q-BRIDGE-MIB	
	6.7. Relationship to ISIS-MIB	
	6.8. MIB Modules Required for IMPORTS	
7.	Definition of the RBridge MIB Module	
	Security Considerations	
	IANA Considerations	
	Contributors	
	References	
	11.1. Normative References	
	11.2. Informative References	
	TILD. THEOTIMACTIC INCIDENCES	, 0

1. Introduction

This document describes a model for managing Routing Bridges (RBridges), also known as TRILL Switches, as defined in [RFC6325]. RBridges provide optimal pair-wise forwarding without configuration using IS-IS routing and encapsulation of traffic. RBridges are compatible with previous IEEE 802.1 customer bridges as well as IPv4 and IPv6 routers and end nodes. They are as invisible to current IP routers as bridges are and, like routers, they terminate the bridge spanning tree protocol. In creating an RBridge management model, the device is viewed primarily as a customer bridge. For a discussion of the problem addressed by TRILL (Transparent Interconnection of Lots of Links), see [RFC5556].

RBridges support features specified for transparent bridges in IEEE 802.1, and the corresponding MIB modules are used to manage those features. For IS-IS purposes, the corresponding MIB module is used to manage the protocol. This MIB module specifies those objects that are TRILL-specific and hence not available in other MIB modules.

2. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIv2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

3. Overview

The RBridge MIB module is intended as an overall framework for managing RBridges, also known as TRILL Switches. Where possible, the MIB references existing MIB definitions in order to maximize reuse. This results in a considerable emphasis on the relationship with other MIB modules.

Starting with the physical interfaces, there are requirements for certain elements of the IF-MIB to be implemented. These elements are required in order to connect the per-port parameters to higher-level functions of the physical device.

Transparent bridging, VLANs, traffic classes, and multicast filtering are supported by the TRILL protocol, and the corresponding management is expected to conform to the BRIDGE-MIB module [RFC4188] and to the P-BRIDGE-MIB and Q-BRIDGE-MIB modules [RFC4363].

The IS-IS routing protocol is used in order to determine the optimum pair-wise forwarding path. This protocol is managed using the IS-IS MIB module defined in [RFC4444]. Since the TRILL protocol specifies the use of a single level and a fixed area address of zero, some IS-IS MIB objects are not applicable. Some IS-IS MIB objects are used in the TRILL protocol.

4. Conventions

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "NOT RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119 [RFC2119].

5. Structure of the MIB Module

Objects in this MIB module are arranged into subtrees. Each subtree is organized as a set of related objects. The various subtrees are shown below. These are supplemented with required elements of the IF-MIB, ISIS-MIB, BRIDGE-MIB, P-BRIDGE-MIB, Q-BRIDGE-MIB, and IEEE Bridge MIB modules.

5.1. Textual Conventions

Textual conventions are defined to represent object types relevant to TRILL.

5.2. The rbridgeBase Subtree

This subtree contains system- and port-specific objects applicable to all RBridges.

5.3. The rbridgeFdb Subtree

This subtree contains objects applicable to the forwarding database used by the RBridge in making packet-forwarding decisions. Because it contains additional information used by the TRILL protocol not applicable to 802.1D/Q bridges, it is a superset of the corresponding subtrees defined in the BRIDGE-MIB and Q-BRIDGE-MIB.

5.4. The rbridgeVlan Subtree

This subtree describes objects applicable to VLANs configured on the RBridge.

5.5. The rbridgeEsadi Subtree

This subtree describes objects relevant to RBridges that support the optional End-Station Address Distribution Information (ESADI) protocol.

5.6. The rbridgeCounters Subtree

This subtree contains statistics maintained by RBridges that can aid in monitoring and troubleshooting networks connected by them.

5.7. The rbridgeSnooping Subtree

This subtree describes objects applicable to RBridges capable of snooping IPv4 and/or IPv6 multicast control frames and pruning IP multicast traffic based on detection of IP multicast routers and listeners.

5.8. The rbridgeDtree Subtree

This subtree contains objects relevant to distribution trees computed by RBridges for the forwarding of multi-destination frames.

5.9. The rbridgeTrill Subtree

This subtree contains objects applicable to the TRILL IS-IS protocol, beyond what is available in the ISIS-MIB.

5.10. The Notifications Subtree

The defined notifications are focused on the TRILL protocol functionality. Notifications are defined for changes in the Designated RBridge status and the topology.

6. Relationship to Other MIB Modules

The IF-MIB, BRIDGE-MIB, P-BRIDGE-MIB, Q-BRIDGE-MIB, IEEE8021-BRIDGE-MIB, IEEE8021-Q-BRIDGE-MIB, and ISIS-MIB modules all contain objects relevant to the RBridge MIB. Management objects contained in these modules are not duplicated here, to reduce overlap to the extent possible.

The Bridge MIB modules were originally written in the IETF and implemented by many vendors. Per [RFC4663], this has recently been transferred to the IEEE 802.1 working group. As vendors may have implemented either the IETF or IEEE Bridge MIB modules, this RBridge MIB module is designed to work with either one.

6.1. Relationship to IF-MIB

The port identification elements MUST be implemented in order to allow them to be cross-referenced. The Interfaces MIB [RFC2863] requires that any MIB module that is an adjunct of the Interfaces MIB clarify specific areas within the Interfaces MIB module. These areas were intentionally left vague in the Interfaces MIB module to avoid over-constraining the MIB, thereby precluding management of certain media types. Section 4 of [RFC2863] enumerates several areas that a

media-specific MIB module must clarify. The implementor is referred to [RFC2863] in order to understand the general intent of these areas.

6.2. Relationship to BRIDGE-MIB

The following subtrees in the BRIDGE-MIB [RFC4188] contain information relevant to RBridges when the corresponding functionality is implemented.

- o dot1dBase
- o dot1dTp
- o dot1dStatic

6.3. Relationship to P-BRIDGE-MIB

The following subtrees in the P-BRIDGE-MIB [RFC4363] contain information relevant to RBridges when the corresponding functionality is implemented.

- o dot1dExtBase
- o dot1dPriority
- o dot1dGarp
- o dot1dGmrp
- o dot1dTpHCPortTable
- o dot1dTpPortOverflowTable

6.4. Relationship to Q-BRIDGE-MIB

The following groups in the Q-BRIDGE-MIB [RFC4363] contain information relevant to RBridges when the corresponding functionality is implemented. This functionality is also contained in the IEEE8021-Q-BRIDGE-MIB.

- o dot1qBase
- o dot1qTp
- o dot1qStatic

- o dot1qVlan
- o dot1vProtocol

6.5. Relationship to IEEE8021-BRIDGE-MIB

The following subtrees in the IEEE8021-BRIDGE-MIB contain information relevant to RBridges when the corresponding functionality is implemented.

- o ieee8021BridgeBase
- o ieee8021BridgeTp
- o ieee8021BridgePriority
- o ieee8021BridgeMrp
- o ieee8021BridgeMmrp
- o ieee8021BridgeInternalLan
- o ieee8021BridgeDot1d

6.6. Relationship to IEEE8021-Q-BRIDGE-MIB

The following subtrees in the IEEE8021-Q-BRIDGE-MIB contain information relevant to RBridges when the corresponding functionality is implemented.

- o ieee8021QBridgeBase
- o ieee8021QBridgeTp
- o ieee8021QBridgeStatic
- o ieee8021QBridgeVlan
- o ieee8021QBridgeProtocol

6.7. Relationship to ISIS-MIB

"Management Information Base for Intermediate System to Intermediate System (IS-IS)" [RFC4444] defines a MIB module for the IS-IS routing protocol when it is used to construct routing tables for IP networks. While most of these objects are applicable to the TRILL layer 2implementation, note the IS-IS constraints for the current version of TRILL [RFC6325]:

- o The TRILL IS-IS instance uses a single Level 1 IS-IS area.
- o The TRILL Level 1 IS-IS area uses the fixed area address zero.
- o The TRILL IS-IS instance is not used for IP address advertisement.
- o The TRILL IS-IS instance is used for only a single protocol: TRILL.

Accordingly, tables that report IP address reachability and tables that allow configuration or reporting of multiple IS-IS areas, multiple IS-IS levels, or multiple protocols will be empty in the ISIS-MIB module for the current version of TRILL.

Note also that when more than one instance of the IS-IS protocol is running on a device, as in the case of a device performing both RBridge and IS-IS IP router functions, multiple instances of the ISIS-MIB module can be distinguished by the use of SNMPv3 contexts or SNMPv1 communities.

6.8. MIB Modules Required for IMPORTS

The following MIB module imports objects from the SNMPv2-SMI [RFC2578], SNMPv2-TC [RFC2579], SNMPv2-CONF [RFC2580], IF-MIB [RFC2863], INET-ADDRESS-MIB [RFC4001], BRIDGE-MIB [RFC4188], and Q-BRIDGE-MIB [RFC4363]. (The IEEE Bridge MIB modules import similar TCs.)

```
7. Definition of the RBridge MIB Module
  RBRIDGE-MIB DEFINITIONS ::= BEGIN
  -- MIB for RBRIDGE devices, also known as TRILL Switches
  MODULE-IDENTITY, OBJECT-TYPE, NOTIFICATION-TYPE,
      Counter32, Counter64, Unsigned32, mib-2
         FROM SNMPv2-SMI -- RFC2578
      TEXTUAL-CONVENTION, TruthValue, MacAddress, RowStatus
         FROM SNMPv2-TC
                                  -- RFC2579
      MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
         FROM SNMPv2-CONF
                                  -- RFC2580
      VlanId, PortList
         FROM Q-BRIDGE-MIB
                                  -- RFC4363
      InetAddress, InetAddressType
                                 -- RFC4001
         FROM INET-ADDRESS-MIB
      BridgeId
         FROM BRIDGE-MIB
                                  -- RFC4188
      InterfaceIndex
         FROM IF-MIB
                                  -- RFC2863
  rbridgeMIB MODULE-IDENTITY
  LAST-UPDATED "201301070000Z"
  ORGANIZATION "IETF TRILL Working Group"
  CONTACT-INFO
       "http://datatracker.ietf.org/wg/trill/charter/
       Email: trill@ietf.org
             Anil Rijhsinghani
             Hewlett-Packard
         Tel: +1 508 323 1251
       Email: anil@charter.net
             Kate Zebrose
             HW Embedded
         Tel: +1 617 840 9673
       Email: zebrose@alum.mit.edu"
      DESCRIPTION
          "The RBridge MIB module for managing switches that support
          the TRILL protocol."
```

"201301070000Z"

REVISION

DESCRIPTION "Initial version, published as RFC 6850. Copyright (c) 2013 IETF Trust and the persons identified as authors of the code. All rights reserved. Redistribution and use in source and binary forms, with or without modification, is permitted pursuant to, and subject to the license terms contained in, the Simplified BSD License set forth in Section 4.c of the IETF Trust's Legal Provisions Relating to IETF Documents (http://trustee.ietf.org/license-info)." ::= { mib-2 214 } -- Subtrees in the RBridge MIB rbridgeNotifications OBJECT IDENTIFIER ::= { rbridgeMIB 0 } rbridgeBase OBJECT IDENTIFIER ::= { rbridgeObjects 1 } rbridgeFdb OBJECT IDENTIFIER ::= { rbridgeObjects 2 } rbridgeVlan OBJECT IDENTIFIER ::= { rbridgeObjects 3 } rbridgeEsadi OBJECT IDENTIFIER ::= { rbridgeObjects 4 } rbridgeCounter OBJECT IDENTIFIER ::= { rbridgeObjects 5 } rbridgeSnooping OBJECT IDENTIFIER ::= { rbridgeObjects 6 } rbridgeDtree OBJECT IDENTIFIER ::= { rbridgeObjects 7 } rbridgeTrill OBJECT IDENTIFIER ::= { rbridgeObjects 8 } -- Type Definitions RbridgeAddress ::= TEXTUAL-CONVENTION DISPLAY-HINT "1x:" STATUS current

DESCRIPTION

SYNTAX OCTET STRING (SIZE (6))

port. This may match the RBridge IS-IS SystemID."

"The Media Access Control (MAC) address used by an RBridge

January 2013

```
DESCRIPTION
       "Modified aging time for address entries after an appointed
       forwarder change.
       The value of this object MUST be retained across
       re-initializations of the management system."
    REFERENCE
        "RFC 6325, Section 4.8.3"
    ::= { rbridgeBase 3 }
rbridgeBaseUniMultipathEnable OBJECT-TYPE
              TruthValue
   MAX-ACCESS read-write
   STATUS
              current
   DESCRIPTION
        "The enabled status of unicast TRILL multipathing.
       It is enabled when true.
       The value of this object MUST be retained across
       re-initializations of the management system."
        "RFC 6325, Appendix C"
    ::= { rbridgeBase 4 }
rbridgeBaseMultiMultipathEnable OBJECT-TYPE
    SYNTAX TruthValue
   MAX-ACCESS read-write
    STATUS current
   DESCRIPTION
        "The enabled status of multi-destination TRILL multipathing.
       It is enabled when true.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Appendix C"
    ::= { rbridgeBase 5 }
rbridgeBaseAcceptEncapNonadj OBJECT-TYPE
    SYNTAX
              TruthValue
   MAX-ACCESS read-write
    STATUS
           current
   DESCRIPTION
        "Accept TRILL-encapsulated frames from a neighbor with which
```

of this object is 'true'.

this RBridge does not have an IS-IS adjacency, when the value

```
The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.6.2"
   ::= { rbridgeBase 6 }
rbridgeBaseNicknameNumber OBJECT-TYPE
          Unsigned32 (1..256)
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The number of nicknames this RBridge should acquire.
       These can be acquired dynamically or configured
       statically. This value represents the maximum
       number of entries in rbridgeBaseNicknameTable.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 3.7.3"
   ::= { rbridgeBase 7 }
-- The RBridge Base Nickname Table
__ ______ __ __
rbridgeBaseNicknameTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeBaseNicknameEntry
   MAX-ACCESS not-accessible
   STATUS
          current
   DESCRIPTION
       "A table that contains information about nicknames
       configured by an operator or learned dynamically
       by this RBridge."
   REFERENCE
       "RFC 6325, Section 3.7"
   ::= { rbridgeBase 8 }
rbridgeBaseNicknameEntry OBJECT-TYPE
   SYNTAX RbridgeBaseNicknameEntry
   MAX-ACCESS not-accessible
   STATUS
          current
   DESCRIPTION
       "A list of information for each nickname of the RBridge."
   REFERENCE
       "RFC 6325, Section 3.7"
   INDEX { rbridgeBaseNicknameName }
   ::= { rbridgeBaseNicknameTable 1 }
```

```
RbridgeBaseNicknameEntry ::=
    SEQUENCE {
        rbridgeBaseNicknameName
            RbridgeNickname,
        rbridgeBaseNicknamePriority
            Unsigned32,
        rbridgeBaseNicknameDtrPriority
            Unsigned32,
        rbridgeBaseNicknameType
            INTEGER,
        rbridgeBaseNicknameRowStatus
           RowStatus
    }
rbridgeBaseNicknameName OBJECT-TYPE
    SYNTAX RbridgeNickname
    MAX-ACCESS not-accessible
    STATUS
               current
    DESCRIPTION
        "Nicknames are 16-bit quantities that act as
        abbreviations for RBridge's 48-bit IS-IS System ID to
       achieve a more compact encoding."
    REFERENCE
        "RFC 6325, Section 3.7"
    ::= { rbridgeBaseNicknameEntry 1 }
rbridgeBaseNicknamePriority OBJECT-TYPE
    SYNTAX Unsigned32 (0..255)
    MAX-ACCESS read-create
    STATUS
              current
    DESCRIPTION
        "This RBridge's priority to hold this nickname. When
        the nickname is configured, the default value of this
        object is 192. When the nickname is configured, the most
        significant bit (0x80) must be set and the bottom 7 bits
        have the default value of 0x40, so 0x80 + 0x40 == 0xC0,
        which is 192 decimal. Additionally, the bottom 7 bits
        could be configured to a value other than 0x40.
        The value of this object MUST be retained across
        re-initializations of the management system."
    REFERENCE
        "RFC 6325, Section 3.7"
             { 192 }
    DEFVAL
    ::= { rbridgeBaseNicknameEntry 2 }
```

```
rbridgeBaseNicknameDtrPriority OBJECT-TYPE
   SYNTAX Unsigned32 (1..65535)
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
       "The distribution tree root priority for this nickname.
       The default value of this object is 32768.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.5"
   DEFVAL { 32768 }
    ::= { rbridgeBaseNicknameEntry 3 }
rbridgeBaseNicknameType OBJECT-TYPE
   SYNTAX INTEGER {
                   static(1),
                   dynamic(2)
               }
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "This object indicates the status of the entry. The
       default value is static(1).
           static(1) - this entry has been configured and
               will remain after the next reset of the RBridge.
           dynamic(2) - this entry has been acquired by the
               RBridge nickname acquisition protocol."
   REFERENCE
       "RFC 6325, Section 3.7"
   DEFVAL { static }
    ::= { rbridgeBaseNicknameEntry 4 }
rbridgeBaseNicknameRowStatus OBJECT-TYPE
   SYNTAX RowStatus
   MAX-ACCESS read-create
              current
   DESCRIPTION
       "This object indicates the status of the entry."
    ::= { rbridgeBaseNicknameEntry 5 }
```

```
-- The RBridge Port Table
rbridgeBasePortTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeBasePortEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains generic information about every
      port that is associated with this RBridge."
   REFERENCE
       "RFC 6325, Section 5.3"
   ::= { rbridgeBase 9 }
rbridgeBasePortEntry OBJECT-TYPE
   SYNTAX RbridgeBasePortEntry
   MAX-ACCESS not-accessible
   STATUS
            current
   DESCRIPTION
       "A list of information for each port of the bridge."
   REFERENCE
       "RFC 6325, Section 5.3"
   INDEX { rbridgeBasePort }
   ::= { rbridgeBasePortTable 1 }
RbridgeBasePortEntry ::=
   SEQUENCE {
       rbridgeBasePort
          Unsigned32,
       {\tt rbridgeBasePortIfIndex}
          InterfaceIndex,
       rbridgeBasePortDisable
          TruthValue,
       rbridgeBasePortTrunkPort
          TruthValue,
       rbridgeBasePortAccessPort
          TruthValue,
       rbridgeBasePortP2pHellos
          TruthValue,
       rbridgeBasePortState
          INTEGER,
       rbridgeBasePortInhibitionTime
          Unsigned32,
       rbridgeBasePortDisableLearning
          TruthValue,
       rbridgeBasePortDesiredDesigVlan
          VlanId,
```

```
rbridgeBasePortDesigVlan
           VlanId,
       rbridgeBasePortStpRoot
           BridgeId,
       rbridgeBasePortStpRootChanges
           Counter32,
       rbridgeBasePortStpWiringCloset
           BridgeId
}
rbridgeBasePort OBJECT-TYPE
    SYNTAX
            Unsigned32 (1..65535)
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
       "The port number of the port for which this entry
       contains RBridge management information."
   REFERENCE
       "RFC 6325, Section 5.3"
    ::= { rbridgeBasePortEntry 1 }
rbridgeBasePortIfIndex OBJECT-TYPE
    SYNTAX InterfaceIndex
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The value of the instance of the ifIndex object,
       defined in the IF-MIB, for the interface corresponding
       to this port. The RBridge port sits on top of
       this interface."
    ::= { rbridgeBasePortEntry 2 }
rbridgeBasePortDisable OBJECT-TYPE
    SYNTAX
            TruthValue
   MAX-ACCESS read-write
              current
   STATUS
   DESCRIPTION
        "Disable port bit. When this bit is set (true), all frames
       received or to be transmitted are discarded, with the
       possible exception of some layer 2 control frames that may
       be generated and transmitted or received and processed
       locally. Default value is 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
```

```
REFERENCE
     "RFC 6325, Section 4.9.1"
   DEFVAL { false }
   ::= { rbridgeBasePortEntry 3 }
rbridgeBasePortTrunkPort OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "End-station service disable (trunk port) bit. When this bit
       is set (true), all native frames received on the port and all
       native frames that would have been sent on the port are
       discarded. Default value is 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.9.1"
   DEFVAL { false }
    ::= { rbridgeBasePortEntry 4 }
rbridgeBasePortAccessPort OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "TRILL traffic disable (access port) bit. If this bit is
       set, the goal is to avoid sending any TRILL frames, except
       TRILL-Hello frames, on the port, since it is intended only
       for native end-station traffic. This ensures that the link
       is not on the shortest path for any destination. Default
       value is 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.9.1"
   DEFVAL { false }
    ::= { rbridgeBasePortEntry 5 }
rbridgeBasePortP2pHellos OBJECT-TYPE
   SYNTAX
           TruthValue
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "Use point-to-point (P2P) Hellos bit. If this bit is set,
       Hellos sent on this port are IS-IS P2P Hellos, not the
```

```
default TRILL-Hellos. In addition, the IS-IS P2P three-way
       handshake is used on P2P RBridge links. Default value is
       'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
        "RFC 6325, Section 4.9.1"
    DEFVAL
           { false }
    ::= { rbridgeBasePortEntry 6 }
rbridgeBasePortState OBJECT-TYPE
    SYNTAX
           INTEGER {
                      uninhibited(1),
                      portInhibited(2),
                      vlanInhibited(3),
                      disabled(4),
                      broken(5)
                   }
   MAX-ACCESS read-only
              current
   DESCRIPTION
        "The port's current state. If the entire port is
        inhibited, its state is portInhibited(2). If specific VLANs
       are inhibited, the state is vlanInhibited(3), and
       rbridgeVlanPortTable will tell which VLANs are inhibited.
       For ports that are disabled (see rbridgeBasePortDisable),
       this object will have a value of disabled(4). If the
       RBridge has detected a port that is malfunctioning, it will
       place that port into the broken(5) state."
   REFERENCE
       "RFC 6325, Section 4.2.4.3"
    ::= { rbridgeBasePortEntry 7 }
rbridgeBasePortInhibitionTime OBJECT-TYPE
    SYNTAX Unsigned32
   UNITS
               "seconds"
   MAX-ACCESS read-write
    STATUS
              current
   DESCRIPTION
        "Time in seconds that this RBridge will inhibit forwarding
       on this port after it observes a spanning tree root bridge
       change on a link or receives conflicting VLAN forwarder
       information. The default value is 30.
```

The value of this object MUST be retained across re-initializations of the management system."

```
REFERENCE
      "RFC 6325, Section 4.2.4.3"
   DEFVAL { 30 }
   ::= { rbridgeBasePortEntry 8 }
rbridgeBasePortDisableLearning OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "Disable learning of MAC addresses seen on this port.
       To disable learning, the value of this object must be
       set to 'true'. The default is 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.8"
   DEFVAL { false }
    ::= { rbridgeBasePortEntry 9 }
rbridgeBasePortDesiredDesigVlan OBJECT-TYPE
   SYNTAX VlanId
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "The VLAN that a Designated RBridge (DRB) will specify in
       its TRILL-Hellos as the VLAN to be used by all RBridges on
       the link for TRILL frames. This VLAN must be enabled on
       this port.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.4.3"
    ::= { rbridgeBasePortEntry 10 }
rbridgeBasePortDesigVlan OBJECT-TYPE
   SYNTAX VlanId
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The VLAN being used on this link for TRILL frames."
   REFERENCE
       "RFC 6325, Section 4.4.3"
    ::= { rbridgeBasePortEntry 11 }
```

```
rbridgeBasePortStpRoot OBJECT-TYPE
    SYNTAX BridgeId
   MAX-ACCESS read-only
    STATUS current
   DESCRIPTION
        "The bridge identifier of the root of the spanning tree,
       as learned from a Bridge PDU (BPDU) received on this port.
       For the Multiple Spanning Tree Protocol (MSTP), this is
       the root bridge of the Common and Internal Spanning Tree
       (CIST). If no BPDU has been heard, the value returned
       is a string of zeros."
    REFERENCE
        "RFC 6325, Section 4.2.4.3"
    ::= { rbridgeBasePortEntry 12 }
rbridgeBasePortStpRootChanges OBJECT-TYPE
    SYNTAX Counter32
    UNITS
               "changes"
   MAX-ACCESS read-only
    STATUS
              current
    DESCRIPTION
        "The number of times a change in the root bridge is seen from
       spanning tree BPDUs received on this port, indicating a
       change in bridged LAN topology. Each such change may cause
       the port to be inhibited for a period of time. This counter
       should be synchronized with ifCounterDiscontinuityTime.
       Discontinuities in the value of this counter can occur
       at re-initialization of the management system."
    REFERENCE
        "RFC 6325, Section 4.9.3.2"
    ::= { rbridgeBasePortEntry 13 }
rbridgeBasePortStpWiringCloset OBJECT-TYPE
    SYNTAX BridgeId
   MAX-ACCESS read-write
    STATUS
              current
    DESCRIPTION
        "The Bridge ID to be used as the spanning tree root in BPDUs
       sent for the Wiring Closet topology solution described in
       [RFC6325]. Note that the same value of this object must be
       set on all RBridge ports participating in this solution.
       The default value is all Os. A non-zero value configured
       into this object indicates that this solution is in use.
```

The value of this object MUST be retained across re-initializations of the management system."

```
REFERENCE
     "RFC 6325, Appendix A.3.3"
   ::= { rbridgeBasePortEntry 14 }
__ _____
-- RBridge Forwarding Database
__ _____
rbridgeConfidenceNative OBJECT-TYPE
   SYNTAX Unsigned32 (0..255)
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The confidence level associated with MAC addresses
       learned from native frames. This is applicable to
       all RBridge ports.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.8.1"
   ::= { rbridgeFdb 1 }
rbridgeConfidenceDecap OBJECT-TYPE
          Unsigned32 (0..255)
   SYNTAX
   MAX-ACCESS read-write
   STATUS
          current
   DESCRIPTION
       "The confidence level associated with inner MAC addresses
       learned after decapsulation of a TRILL data frame.
       This is applicable to all RBridge ports.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.8.1"
   ::= { rbridgeFdb 2 }
rbridgeConfidenceStatic OBJECT-TYPE
   SYNTAX Unsigned32 (0..255)
   MAX-ACCESS read-write
   STATUS
          current
   DESCRIPTION
       "The confidence level associated with MAC addresses that
       are statically configured. The default value is 255.
       The value of this object MUST be retained across
       re-initializations of the management system."
```

```
REFERENCE
    "RFC 6325, Section 4.8.2"
   DEFVAL { 255 }
   ::= { rbridgeFdb 3 }
__ _____
-- Multiple Forwarding Databases for RBridges
-- This allows for an instance per FdbId, as defined in the
-- Bridge MIB.
-- Each VLAN may have an independent FDB, or multiple VLANs may
-- share one.
__ ______
rbridgeUniFdbTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeUniFdbEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains information about unicast entries
       for which the device has forwarding and/or filtering
       information. This information is used by the
       transparent bridging function in determining how to
      propagate a received frame."
   REFERENCE
      "RFC 6325, Section 4.8"
   ::= { rbridgeFdb 4 }
rbridgeUniFdbEntry OBJECT-TYPE
          RbridgeUniFdbEntry
   SYNTAX
   MAX-ACCESS not-accessible
   STATUS
          current
   DESCRIPTION
       "Information about a specific unicast MAC address for
       which the RBridge has some forwarding and/or filtering
       information."
   INDEX { rbridgeFdbId, rbridgeUniFdbAddr }
   ::= { rbridgeUniFdbTable 1 }
RbridgeUniFdbEntry ::=
   SEQUENCE {
       rbridgeFdbId
          Unsigned32,
       rbridgeUniFdbAddr
          MacAddress,
```

```
rbridgeUniFdbPort
           Unsigned32,
        rbridgeUniFdbNickname
            RbridgeNickname,
        rbridgeUniFdbConfidence
            Unsigned32,
        rbridgeUniFdbStatus
            INTEGER
    }
rbridgeFdbId OBJECT-TYPE
    SYNTAX
           Unsigned32 (0..4294967295)
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The identity of this Filtering Database."
    ::= { rbridgeUniFdbEntry 1 }
rbridgeUniFdbAddr OBJECT-TYPE
    SYNTAX MacAddress
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "A unicast MAC address for which the device has
        forwarding information."
    ::= { rbridgeUniFdbEntry 2 }
rbridgeUniFdbPort OBJECT-TYPE
    SYNTAX Unsigned32 (0..65535)
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "Either the value {}^{\prime}\text{O}{}^{\prime}\text{,} or the RBridge port number of the
        port on which a frame having a source address equal to the
        value of the corresponding instance of rbridgeUniFdbAddr
       has been seen. A value of '0' indicates that the port
        number has not been learned but that the device does have
        some information about this MAC address.
        Implementors are encouraged to assign the port value to
        this object whenever it is available, even for addresses
        for which the corresponding value of rbridgeUniFdbStatus is
        not learned(3)."
    ::= { rbridgeUniFdbEntry 3 }
rbridgeUniFdbNickname OBJECT-TYPE
    SYNTAX RbridgeNickname
   MAX-ACCESS read-only
```

```
STATUS
           current
   DESCRIPTION
       "The RBridge nickname that is placed in the egress
       nickname field of a TRILL frame sent to this
       rbridgeFdbAddress in this rbridgeFdbId."
   REFERENCE
       "RFC 6325, Section 4.8.1"
    ::= { rbridgeUniFdbEntry 4 }
rbridgeUniFdbConfidence OBJECT-TYPE
   SYNTAX Unsigned32 (0..255)
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The confidence level associated with this entry."
   REFERENCE
       "RFC 6325, Section 4.8.1"
    ::= { rbridgeUniFdbEntry 5 }
rbridgeUniFdbStatus OBJECT-TYPE
   SYNTAX
               INTEGER {
                   other(1),
                   invalid(2),
                   learned(3),
                   self(4),
                   mgmt(5),
                   esadi(6)
               }
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
       "The status of this entry. The meanings of the values
       are:
           other(1) - none of the following.
           invalid(2) - this entry is no longer valid (e.g., it
               was learned but has since aged out) but has not
               yet been flushed from the table.
           learned(3) - the information in this entry was learned
               and is being used.
           self(4) - the value of the corresponding instance of
               rbridgeFdbAddress represents one of the device's
               addresses. The corresponding instance of
               rbridgeFdbPort indicates which of the device's
               ports has this address.
```

 ${\tt mgmt}(5)$ - the value of the corresponding instance of rbridgeFdbAddress was configured by management. esadi(6) - the value of the corresponding instance of rbridgeFdbAddress was learned from ESADI." ::= { rbridgeUniFdbEntry 6 } __ _____ -- RBridge Forwarding Information Base (FIB) rbridgeUniFibTable OBJECT-TYPE SYNTAX SEQUENCE OF RbridgeUniFibEntry MAX-ACCESS not-accessible STATUS current DESCRIPTION "A table that contains information about nicknames known by the RBridge. If Equal-Cost Multipath (ECMP) is implemented, there are as many entries for a nickname as there are ECMP paths available for it." ::= { rbridgeFdb 5 } rbridgeUniFibEntry OBJECT-TYPE SYNTAX RbridgeUniFibEntry MAX-ACCESS not-accessible STATUS current DESCRIPTION "A list of information about nicknames known by the RBridge. If ECMP is implemented, there are as many entries as there are ECMP paths available for a given nickname." INDEX { rbridgeUniFibNickname, rbridgeUniFibPort, rbridgeUniFibNextHop } ::= { rbridgeUniFibTable 1 } RbridgeUniFibEntry ::= SEQUENCE { rbridgeUniFibNickname RbridgeNickname, rbridgeUniFibPort Unsigned32, rbridgeUniFibNextHop RbridgeNickname, rbridgeUniFibHopCount Unsigned32 } rbridgeUniFibNickname OBJECT-TYPE SYNTAX RbridgeNickname MAX-ACCESS not-accessible

```
STATUS
           current
   DESCRIPTION
       "An RBridge nickname for which this RBridge has
       forwarding information."
    ::= { rbridgeUniFibEntry 1 }
rbridgeUniFibPort OBJECT-TYPE
    SYNTAX
           Unsigned32 (0..65535)
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "The RBridge port number of the port attached to the
       next-hop RBridge for the path towards the RBridge whose
       nickname is specified in this entry."
    ::= { rbridgeUniFibEntry 2 }
rbridgeUniFibNextHop OBJECT-TYPE
   SYNTAX RbridgeNickname
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
        "The nickname of the next-hop RBridge for the path
       towards the RBridge whose nickname is specified in this
       entry."
    ::= { rbridgeUniFibEntry 3 }
rbridgeUniFibHopCount OBJECT-TYPE
   SYNTAX Unsigned32
   MAX-ACCESS read-only
   STATUS
           current
   DESCRIPTION
        "The hop count from this ingress RBridge to the egress
       RBridge whose nickname is specified in
       rbridgeUniFibNickname."
    ::= { rbridgeUniFibEntry 4 }
rbridgeMultiFibTable OBJECT-TYPE
           SEQUENCE OF RbridgeMultiFibEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "A table that contains information about egress nicknames
       used for multi-destination frame forwarding by this
       RBridge."
    ::= { rbridgeFdb 6 }
```

```
rbridgeMultiFibEntry OBJECT-TYPE
   SYNTAX RbridgeMultiFibEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A list of information about egress nicknames used for
       multi-destination frame forwarding by this RBridge."
    INDEX { rbridgeMultiFibNickname }
    ::= { rbridgeMultiFibTable 1 }
RbridgeMultiFibEntry ::=
    SEQUENCE {
       rbridgeMultiFibNickname
          RbridgeNickname,
       rbridgeMultiFibPorts
          PortList
    }
rbridgeMultiFibNickname OBJECT-TYPE
   SYNTAX RbridgeNickname
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "The nickname of the multicast distribution tree."
    ::= { rbridgeMultiFibEntry 1 }
rbridgeMultiFibPorts OBJECT-TYPE
   SYNTAX PortList
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The list of ports to which a frame destined to this
       multicast distribution tree is flooded. This may be pruned
       further based on other forwarding information."
    ::= { rbridgeMultiFibEntry 2 }
```

```
-- The RBridge VLAN Table
rbridgeVlanTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeVlanEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
      "A table that contains information about VLANs on the
      RBridge."
   ::= { rbridgeVlan 1 }
rbridgeVlanEntry OBJECT-TYPE
   SYNTAX RbridgeVlanEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
      "A list of information about VLANs on the RBridge."
   INDEX { rbridgeVlanIndex }
   ::= { rbridgeVlanTable 1 }
RbridgeVlanEntry ::=
   SEQUENCE {
      rbridgeVlanIndex
          Unsigned32,
      rbridgeVlanForwarderLosts
          Counter32,
      rbridgeVlanDisableLearning
          TruthValue,
      rbridgeVlanSnooping
          INTEGER
   }
rbridgeVlanIndex OBJECT-TYPE
   SYNTAX Unsigned32 (1..4094|4096..4294967295)
   MAX-ACCESS not-accessible
            current
   DESCRIPTION
      "The VLAN-ID referring to this VLAN."
   ::= { rbridgeVlanEntry 1 }
rbridgeVlanForwarderLosts OBJECT-TYPE
   SYNTAX Counter32
   UNITS
            "times"
   MAX-ACCESS read-only
   STATUS current
```

```
DESCRIPTION
       "The number of times this RBridge has lost appointed
       forwarder status for this VLAN on any of its ports.
       Discontinuities in the value of this counter can occur
       at re-initialization of the management system."
    REFERENCE
        "RFC 6325, Section 4.8.3"
    ::= { rbridgeVlanEntry 2 }
rbridgeVlanDisableLearning OBJECT-TYPE
            TruthValue
   MAX-ACCESS read-write
   STATUS
              current
   DESCRIPTION
        "Disable learning of MAC addresses seen in this VLAN.
       One application of this may be to restrict learning to
       ESADI. To disable learning, the value of this object
       should be set to 'true'. The default is 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.8"
            { false }
    DEFVAL
    ::= { rbridgeVlanEntry 3 }
rbridgeVlanSnooping OBJECT-TYPE
    SYNTAX
               INTEGER {
                   notSupported(1),
                   ipv4(2),
                   ipv6(3),
                   ipv4v6(4)
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "IP Multicast Snooping on this VLAN. For RBridges
       performing both IPv4 and IPv6 IP Multicast Snooping, the
       value returned is ipv4v6(4)."
   REFERENCE
```

"RFC 6325, Section 4.7" ::= { rbridgeVlanEntry 4 }

```
-- The RBridge VLAN Port Table
rbridgeVlanPortTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeVlanPortEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "A table that contains information about VLANs on an RBridge
   ::= { rbridgeVlan 2 }
rbridgeVlanPortEntry OBJECT-TYPE
   SYNTAX RbridgeVlanPortEntry
   MAX-ACCESS not-accessible
   STATUS
             current
   DESCRIPTION
       "A list of information about VLANs on the RBridge port."
   INDEX { rbridgeBasePort, rbridgeVlanIndex }
   ::= { rbridgeVlanPortTable 1 }
RbridgeVlanPortEntry ::=
   SEQUENCE {
       rbridgeVlanPortInhibited
          TruthValue,
       rbridgeVlanPortForwarder
          TruthValue,
       rbridgeVlanPortAnnouncing
          TruthValue,
       rbridgeVlanPortDetectedVlanMapping
          TruthValue
   }
rbridgeVlanPortInhibited OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
             current
   DESCRIPTION
       "This VLAN has been inhibited by the RBridge due to
       conflicting forwarder information received from another
       RBridge, when the value of this object is 'true'."
   REFERENCE
       "RFC 6325, Section 4.2.4.3"
   ::= { rbridgeVlanPortEntry 1 }
rbridgeVlanPortForwarder OBJECT-TYPE
   SYNTAX TruthValue
```

```
MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "This RBridge is an appointed forwarder for this VLAN
       on this port, when the value of this object is 'true'."
   REFERENCE
       "RFC 6325, Section 4.2.4.3"
    ::= { rbridgeVlanPortEntry 2 }
rbridgeVlanPortAnnouncing OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-write
   STATUS
           current
   DESCRIPTION
       "TRILL-Hellos tagged with this VLAN can be sent by this
       RBridge on this port, when the value of this object
       The value of this object MUST be retained across
       re-initializations of the management system."
       "RFC 6325, Section 4.4.3"
   DEFVAL { true }
   ::= { rbridgeVlanPortEntry 3 }
rbridgeVlanPortDetectedVlanMapping OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "VLAN mapping has been detected on the link attached
       to this port, when the value of this object is 'true'."
   REFERENCE
       "RFC 6325, Section 4.4.5"
    ::= { rbridgeVlanPortEntry 4 }
-- The RBridge Port Counter Table
-- These counters supplement counters in the Bridge MIB.
-- For example, total frames received by a bridge port and total
-- frames transmitted by a bridge port are reported in the
-- Port In Frames and Port Out Frames counters of the Bridge MIB.
-- These total bridge frame counters include native as well as
-- encapsulated frames.
--
```

```
-- As another example, frames discarded due to excessive frame
-- size are reported in the port counter MTU Exceeded Discards
-- in the Bridge MIB.
rbridgePortCounterTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgePortCounterEntry
   MAX-ACCESS not-accessible
          current
   STATUS
   DESCRIPTION
       "A table that contains per-port counters for this RBridge."
    ::= { rbridgeCounter 1 }
rbridgePortCounterEntry OBJECT-TYPE
   SYNTAX RbridgePortCounterEntry
   MAX-ACCESS not-accessible
   STATUS
              current
   DESCRIPTION
       "Counters for a port on this RBridge."
   INDEX { rbridgeBasePort }
    ::= { rbridgePortCounterTable 1 }
RbridgePortCounterEntry ::=
   SEQUENCE {
       rbridgePortRpfCheckFails
           Counter32,
       rbridgePortHopCountExceeds
           Counter32,
       rbridgePortOptionDrops
           Counter32,
       rbridgePortTrillInFrames
           Counter64,
       rbridgePortTrillOutFrames
           Counter64
    }
rbridgePortRpfCheckFails OBJECT-TYPE
   SYNTAX
             Counter32
   UNITS "frames"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The number of times a multi-destination frame was
       dropped on this port because the Reverse Path Forwarding
       (RPF) check failed.
       Discontinuities in the value of this counter can occur
       at re-initialization of the management system, and at
```

```
other times as indicated by the value of the
       ifCounterDiscontinuityTime object of the associated
       interface."
   REFERENCE
        "RFC 6325, Section 4.5.2"
    ::= { rbridgePortCounterEntry 1 }
rbridgePortHopCountExceeds OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "frames"
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The number of times a frame was dropped on this port
       because its hop count was zero.
       Discontinuities in the value of this counter can occur
       at re-initialization of the management system, and at
       other times as indicated by the value of the
       ifCounterDiscontinuityTime object of the associated
       interface."
   REFERENCE
        "RFC 6325, Section 3.6"
    ::= { rbridgePortCounterEntry 2 }
rbridgePortOptionDrops OBJECT-TYPE
   SYNTAX Counter32
   UNITS
               "frames"
   MAX-ACCESS read-only
   STATUS
             current
   DESCRIPTION
       "The number of times a frame was dropped on this port
       because it contained unsupported options.
       Discontinuities in the value of this counter can occur
       at re-initialization of the management system, and at
       other times as indicated by the value of the
       ifCounterDiscontinuityTime object of the associated
       interface."
   REFERENCE
        "RFC 6325, Section 3.5"
    ::= { rbridgePortCounterEntry 3 }
rbridgePortTrillInFrames OBJECT-TYPE
   SYNTAX Counter64
               "frames"
   MAX-ACCESS read-only
   STATUS
              current
```

DESCRIPTION

"The number of TRILL-encapsulated frames that have been received by this port from its attached link, including management frames.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of the ifCounterDiscontinuityTime object of the associated interface."

```
REFERENCE
```

```
"RFC 6325, Section 2.3"
::= { rbridgePortCounterEntry 4 }
```

rbridgePortTrillOutFrames OBJECT-TYPE

SYNTAX Counter64 UNITS "frames" MAX-ACCESS read-only STATUS current

DESCRIPTION

"The number of TRILL-encapsulated frames that have been transmitted by this port to its attached link, including management frames.

Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of the ifCounterDiscontinuityTime object of the associated interface."

REFERENCE

```
"RFC 6325, Section 2.3"
::= { rbridgePortCounterEntry 5 }
```

```
-- The RBridge VLAN ESADI Table
```

```
rbridgeEsadiTable OBJECT-TYPE
```

SYNTAX SEQUENCE OF RbridgeEsadiEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table that contains information about ESADI instances on VLANs, if available."

REFERENCE

```
"RFC 6325, Section 4.2.5"
::= { rbridgeEsadi 1 }
```

```
rbridgeEsadiEntry OBJECT-TYPE
   SYNTAX RbridgeEsadiEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Information about an ESADI instance on a VLAN."
    INDEX { rbridgeVlanIndex }
    ::= { rbridgeEsadiTable 1 }
RbridgeEsadiEntry ::=
   SEQUENCE {
       rbridgeEsadiEnable
           TruthValue,
       rbridgeEsadiConfidence
           Unsigned32,
       rbridgeEsadiDrbPriority
           Unsigned32,
       rbridgeEsadiDrb
           RbridgeAddress,
       rbridgeEsadiDrbHoldingTime
           Unsigned32,
       rbridgeEsadiRowStatus
           RowStatus
    }
rbridgeEsadiEnable OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
        "If the RBridge is participating in an ESADI instance for
       this VLAN, the value of this object is 'true'. To disable
       participation, set it to 'false'.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.2.5"
   DEFVAL { true }
    ::= { rbridgeEsadiEntry 1 }
rbridgeEsadiConfidence OBJECT-TYPE
   SYNTAX Unsigned32 (0..255)
   MAX-ACCESS read-create
   STATUS
           current
   DESCRIPTION
        "Confidence level of address entries sent by this
       ESADI instance. The default is 16.
```

```
The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.2.5"
   DEFVAL { 16 }
   ::= { rbridgeEsadiEntry 2 }
rbridgeEsadiDrbPriority OBJECT-TYPE
   SYNTAX
           Unsigned32 (0..127)
   MAX-ACCESS read-create
   STATUS current
   DESCRIPTION
       "The priority of this RBridge for being selected as the
       DRB for this ESADI instance.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.2.5"
    ::= { rbridgeEsadiEntry 3 }
rbridgeEsadiDrb OBJECT-TYPE
   SYNTAX RbridgeAddress
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The DRB on this ESADI instance's virtual link."
   REFERENCE
       "RFC 6325, Section 4.2.5"
    ::= { rbridgeEsadiEntry 4 }
rbridgeEsadiDrbHoldingTime OBJECT-TYPE
   SYNTAX Unsigned32 (0..127)
   MAX-ACCESS read-create
   STATUS
              current
   DESCRIPTION
       "The holding time for this ESADI instance.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
        "RFC 6325, Section 4.2.5"
    ::= { rbridgeEsadiEntry 5 }
rbridgeEsadiRowStatus OBJECT-TYPE
   SYNTAX RowStatus
   MAX-ACCESS read-create
   STATUS
              current
```

```
DESCRIPTION
      "This object indicates the status of the entry."
    ::= { rbridgeEsadiEntry 6 }
-- The RBridge IP Multicast Snooping Port Table
rbridgeSnoopingPortTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeSnoopingPortEntry
   MAX-ACCESS not-accessible
   STATUS
           current
   DESCRIPTION
       "For RBridges implementing IP Multicast Snooping,
       information about ports on which the presence of IPv4
       or IPv6 multicast routers has been detected."
   REFERENCE
       "RFC 6325, Section 4.7"
    ::= { rbridgeSnooping 1 }
rbridgeSnoopingPortEntry OBJECT-TYPE
   SYNTAX RbridgeSnoopingPortEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Information about ports on which the presence of IPv4
       or IPv6 multicast routers has been detected for a
       VLAN."
   INDEX { rbridgeBasePort, rbridgeVlanIndex }
    ::= { rbridgeSnoopingPortTable 1 }
RbridgeSnoopingPortEntry ::=
   SEQUENCE {
       rbridgeSnoopingPortAddrType
           INTEGER
    }
rbridgeSnoopingPortAddrType OBJECT-TYPE
   SYNTAX
               INTEGER {
                   ipv4(1),
                   ipv6(2),
                   ipv4v6(3)
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
        "The IP address type of an IP multicast router detected
```

```
on this port and VLAN. If only IPv4 router(s)
       are detected, the value returned is 'ipv4'. If only
       IPv6 routers are detected, the value returned is
       'ipv6'. If both IPv4 and IPv6 routers are detected on
       this port and VLAN, the value returned is 'ipv4v6'."
   REFERENCE
       "RFC 6325, Section 4.7"
   ::= { rbridgeSnoopingPortEntry 1 }
-- The RBridge IP Multicast Snooping Address Table
rbridgeSnoopingAddrTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeSnoopingAddrEntry
   MAX-ACCESS not-accessible
   STATUS
             current
   DESCRIPTION
       "For RBridges implementing IP Multicast Snooping,
       information about IP multicast addresses being
       snooped."
   REFERENCE
       "RFC 6325, Section 4.8"
   ::= { rbridgeSnooping 2 }
rbridgeSnoopingAddrEntry OBJECT-TYPE
   SYNTAX RbridgeSnoopingAddrEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Information about IP multicast addresses being
       snooped."
   INDEX { rbridgeVlanIndex, rbridgeSnoopingAddrType,
           rbridgeSnoopingAddr }
   ::= { rbridgeSnoopingAddrTable 1 }
RbridgeSnoopingAddrEntry ::=
   SEQUENCE {
       rbridgeSnoopingAddrType
          InetAddressType,
       rbridgeSnoopingAddr
          InetAddress,
       rbridgeSnoopingAddrPorts
          PortList
   }
rbridgeSnoopingAddrType OBJECT-TYPE
   SYNTAX InetAddressType
```

```
MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The IP multicast address type for which a listener has been
       detected by this RBridge. This MIB requires support for only
       IPv4 and IPv6 address types."
   REFERENCE
       "RFC 6325, Section 4.7"
    ::= { rbridgeSnoopingAddrEntry 1 }
rbridgeSnoopingAddr OBJECT-TYPE
   SYNTAX InetAddress
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The IP multicast address for which a listener has been
       detected by this RBridge. The address type of this object
       is specified in rbridgeSnoopingAddrType. This MIB requires
       support for only global IPv4 and IPv6 addresses, so the
       length of the object can be either 4 or 16 bytes. Hence,
       the index will not exceed the OID size limit."
   REFERENCE
       "RFC 6325, Section 4.7"
    ::= { rbridgeSnoopingAddrEntry 2 }
rbridgeSnoopingAddrPorts OBJECT-TYPE
   SYNTAX PortList
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The set of ports on which a listener has been detected
       for this IP multicast address."
   REFERENCE
       "RFC 6325, Section 4.7"
    ::= { rbridgeSnoopingAddrEntry 3 }
-- Distribution Trees
rbridgeDtreePriority OBJECT-TYPE
   SYNTAX Unsigned32 (1..65535)
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The distribution tree root priority for this RBridge.
```

```
The default value of this object is 32768.
       The value of this object MUST be retained across
       re-initializations of the management system."
   REFERENCE
        "RFC 6325, Section 4.5"
    ::= { rbridgeDtree 1 }
rbridgeDtreeActiveTrees OBJECT-TYPE
   SYNTAX Unsigned32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The total number of trees being computed by all RBridges
       in the campus."
   REFERENCE
       "RFC 6325, Section 4.5"
    ::= { rbridgeDtree 2 }
rbridgeDtreeMaxTrees OBJECT-TYPE
   SYNTAX
           Unsigned32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The maximum number of trees this RBridge can compute."
   REFERENCE
       "RFC 6325, Section 4.5"
    ::= { rbridgeDtree 3 }
rbridgeDtreeDesiredUseTrees OBJECT-TYPE
   SYNTAX Unsigned32
   MAX-ACCESS read-only
   STATUS
               current
   DESCRIPTION
       "The maximum number of trees this RBridge would like to
       use for transmission of ingress multi-destination frames."
   REFERENCE
       "RFC 6325, Section 4.5"
    ::= { rbridgeDtree 4 }
rbridgeDtreeTable OBJECT-TYPE
   SYNTAX SEQUENCE OF RbridgeDtreeEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Information about distribution trees being computed
       by this RBridge."
```

```
REFERENCE
     "RFC 6325, Section 4.5"
    ::= { rbridgeDtree 5 }
rbridgeDtreeEntry OBJECT-TYPE
    SYNTAX RbridgeDtreeEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
       "List of information about distribution trees being computed
       by this RBridge."
    INDEX { rbridgeDtreeNumber }
    ::= { rbridgeDtreeTable 1 }
RbridgeDtreeEntry ::=
    SEQUENCE {
       rbridgeDtreeNumber
           Unsigned32,
       rbridgeDtreeNickname
           RbridgeNickname,
       rbridgeDtreeIngress
           TruthValue
    }
rbridgeDtreeNumber OBJECT-TYPE
    SYNTAX Unsigned32 (0..65535)
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
        "The tree number of a distribution tree being computed by
       this RBridge."
   REFERENCE
       "RFC 6325, Section 4.5"
    ::= { rbridgeDtreeEntry 1 }
rbridgeDtreeNickname OBJECT-TYPE
   SYNTAX RbridgeNickname
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The nickname of the distribution tree."
    REFERENCE
        "RFC 6325, Section 4.5"
    ::= { rbridgeDtreeEntry 2 }
rbridgeDtreeIngress OBJECT-TYPE
    SYNTAX TruthValue
   MAX-ACCESS read-only
```

```
STATUS
          current
   DESCRIPTION
       "Indicates whether this RBridge might choose this
       distribution tree to ingress a multi-destination frame."
   REFERENCE
       "RFC 6325, Section 4.5"
   ::= { rbridgeDtreeEntry 3 }
-- TRILL Neighbor List
rbridgeTrillMinMtuDesired OBJECT-TYPE
   SYNTAX Unsigned32
   MAX-ACCESS read-write
   STATUS
             current
   DESCRIPTION
       "The desired minimum acceptable inter-RBridge link MTU for
       the campus, that is, originatingLSPBufferSize.
       The value of this object MUST be retained across
      re-initializations of the management system."
   REFERENCE
       "RFC 6325, Section 4.3"
   ::= { rbridgeTrill 1 }
rbridgeTrillSz OBJECT-TYPE
   SYNTAX Unsigned32
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "The minimum acceptable inter-RBridge link size for the
      campus for the proper operation of TRILL IS-IS."
   REFERENCE
      "RFC 6325, Section 4.3"
   ::= { rbridgeTrill 2 }
rbridgeTrillMaxMtuProbes OBJECT-TYPE
   SYNTAX Unsigned32 (1..255)
   MAX-ACCESS read-write
   STATUS current
   DESCRIPTION
       "The number of failed MTU-probes before the RBridge
       concludes that a particular MTU is not supported by
       a neighbor.
```

```
The value of this object MUST be retained across
       re-initializations of the management system."
    REFERENCE
       "RFC 6325, Section 4.3"
    ::= { rbridgeTrill 3 }
rbridgeTrillNbrTable OBJECT-TYPE
    SYNTAX SEQUENCE OF RbridgeTrillNbrEntry
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "Information about this RBridge's TRILL neighbors."
   REFERENCE
       "RFC 6325, Section 4.4.2.1"
    ::= { rbridgeTrill 4 }
rbridgeTrillNbrEntry OBJECT-TYPE
   SYNTAX RbridgeTrillNbrEntry
   MAX-ACCESS not-accessible
    STATUS current
   DESCRIPTION
        "List of information about this RBridge's TRILL neighbors."
    INDEX { rbridgeTrillNbrMacAddr }
    ::= { rbridgeTrillNbrTable 1 }
RbridgeTrillNbrEntry ::=
    SEQUENCE {
       rbridgeTrillNbrMacAddr
           MacAddress,
       rbridgeTrillNbrMtu
           Unsigned32,
       rbridgeTrillNbrFailedMtuTest
           TruthValue
    }
rbridgeTrillNbrMacAddr OBJECT-TYPE
   SYNTAX MacAddress
   MAX-ACCESS not-accessible
   STATUS current
   DESCRIPTION
       "The MAC address of a neighbor of this RBridge."
        "RFC 6325, Section 4.4.2.1"
    ::= { rbridgeTrillNbrEntry 1 }
rbridgeTrillNbrMtu OBJECT-TYPE
    SYNTAX Unsigned32
   MAX-ACCESS read-only
```

```
STATUS current
   DESCRIPTION
       "MTU size for this neighbor for IS-IS communication
       purposes."
   REFERENCE
       "RFC 6325, Section 4.3.2"
    ::= { rbridgeTrillNbrEntry 2 }
rbridgeTrillNbrFailedMtuTest OBJECT-TYPE
   SYNTAX TruthValue
   MAX-ACCESS read-only
   STATUS current
   DESCRIPTION
       "If true, indicates that the neighbor's tested MTU is less
       than the minimum acceptable inter-bridge link MTU for the
       campus (1470)."
   REFERENCE
       "RFC 6325, Section 4.3.1"
   ::= { rbridgeTrillNbrEntry 3 }
-- Notifications for use by RBridges
rbridgeBaseNewDrb NOTIFICATION-TYPE
   -- OBJECTS { }
   STATUS current
   DESCRIPTION
       "The rbridgeBaseNewDrb notification indicates that the
       sending agent has become the new Designated RBridge; the
       notification is sent by an RBridge soon after its election
       as the new DRB root, e.g., upon expiration of the Topology
       Change Timer, immediately subsequent to its election."
    ::= { rbridgeNotifications 1 }
rbridgeBaseTopologyChange NOTIFICATION-TYPE
   -- OBJECTS { }
   STATUS current
   DESCRIPTION
       "The rbridgeBaseTopologyChange notification is sent by an
       RBridge when any of its configured ports transition to/from
       the VLAN-x designated forwarder. The notification is not
       sent if an rbridgeBaseNewDrb notification is sent for the
       same transition."
    ::= { rbridgeNotifications 2 }
```

```
-- Compliance and Group sections
rbridgeCompliances OBJECT IDENTIFIER ::= { rbridgeConformance 1 }
rbridgeGroup
                   OBJECT IDENTIFIER ::= { rbridgeConformance 2 }
-- Units of Conformance
rbridgeBaseGroup OBJECT-GROUP
   OBJECTS {
       rbridgeBaseTrillVersion,
       rbridgeBaseNumPorts,
       rbridgeBaseForwardDelay,
       rbridgeBaseUniMultipathEnable,
       rbridgeBaseMultiMultipathEnable,
       rbridgeBaseAcceptEncapNonadj,
       rbridgeBaseNicknameNumber
   STATUS
             current
   DESCRIPTION
       "A collection of objects providing basic control
       and status information for the RBridge."
    ::= { rbridgeGroup 1 }
rbridgeBaseNicknameGroup OBJECT-GROUP
   OBJECTS {
       rbridgeBaseNicknamePriority,
       rbridgeBaseNicknameDtrPriority,
       rbridgeBaseNicknameType,
       rbridgeBaseNicknameRowStatus
   STATUS
             current
   DESCRIPTION
       "A collection of objects providing basic control
       and status information for RBridge nicknames."
    ::= { rbridgeGroup 2 }
rbridgeBasePortGroup OBJECT-GROUP
   OBJECTS {
       rbridgeBasePortIfIndex,
       rbridgeBasePortDisable,
       rbridgeBasePortTrunkPort,
       rbridgeBasePortAccessPort,
       rbridgeBasePortP2pHellos,
       rbridgeBasePortState,
```

```
rbridgeBasePortDesiredDesigVlan,
        rbridgeBasePortDesigVlan,
        rbridgeBasePortInhibitionTime,
        rbridgeBasePortDisableLearning,
        rbridgeBasePortStpRoot,
        rbridgeBasePortStpRootChanges,
        rbridgeBasePortStpWiringCloset
    STATUS
              current
    DESCRIPTION
        "A collection of objects providing basic control
        and status information for RBridge ports."
    ::= { rbridgeGroup 3 }
rbridgeFdbGroup OBJECT-GROUP
    OBJECTS {
        rbridgeConfidenceNative,
        rbridgeConfidenceDecap,
        rbridgeConfidenceStatic,
        rbridgeUniFdbPort,
        rbridgeUniFdbNickname,
        rbridgeUniFdbConfidence,
        rbridgeUniFdbStatus
    STATUS
               current
    DESCRIPTION
        "A collection of objects providing information
        about the Unicast Address Database."
    ::= { rbridgeGroup 4 }
rbridgeFibGroup OBJECT-GROUP
    OBJECTS {
        rbridgeUniFibHopCount,
        rbridgeMultiFibPorts
    STATUS
               current
    DESCRIPTION
        "A collection of objects providing information
        about the Unicast and Multicast FIBs."
    ::= { rbridgeGroup 5 }
rbridgeVlanGroup OBJECT-GROUP
    OBJECTS {
        rbridgeVlanForwarderLosts,
        rbridgeVlanDisableLearning,
        rbridgeVlanSnooping,
        rbridgeVlanPortInhibited,
        rbridgeVlanPortForwarder,
```

```
rbridgeVlanPortAnnouncing,
       rbridgeVlanPortDetectedVlanMapping
    STATUS
                current
   DESCRIPTION
        "A collection of objects providing information
        about VLANs on the RBridge."
    ::= { rbridgeGroup 6 }
rbridgePortCounterGroup OBJECT-GROUP
   OBJECTS {
       rbridgePortRpfCheckFails,
       rbridgePortHopCountExceeds,
       rbridgePortOptionDrops,
        rbridgePortTrillInFrames,
        rbridgePortTrillOutFrames
    STATUS
              current
    DESCRIPTION
        "A collection of objects providing per-port
        counters for the RBridge."
    ::= { rbridgeGroup 7 }
rbridgeEsadiGroup OBJECT-GROUP
    OBJECTS {
       rbridgeEsadiEnable,
       rbridgeEsadiConfidence,
       rbridgeEsadiDrbPriority,
       rbridgeEsadiDrb,
       rbridgeEsadiDrbHoldingTime,
       rbridgeEsadiRowStatus
    STATUS
               current
    DESCRIPTION
        "A collection of objects providing information
        about ESADI instances on the RBridge."
    ::= { rbridgeGroup 8 }
rbridgeSnoopingGroup OBJECT-GROUP
    OBJECTS {
        rbridgeSnoopingPortAddrType,
       rbridgeSnoopingAddrPorts
    STATUS
              current
   DESCRIPTION
        "A collection of objects providing information about
        IP Multicast Snooping. This MIB requires support for
        only global IPv4 and IPv6 address types in
```

```
{\tt rbridgeSnoopingPortAddrType} \ {\tt and} \ {\tt rbridgeSnoopingAddrType},
        so the length of rbridgeSnoopingAddr can be either 4 or
        16 bytes."
    ::= { rbridgeGroup 9 }
rbridgeDtreeGroup OBJECT-GROUP
    OBJECTS {
        rbridgeDtreePriority,
        rbridgeDtreeActiveTrees,
        rbridgeDtreeMaxTrees,
        rbridgeDtreeDesiredUseTrees,
        rbridgeDtreeNickname,
        rbridgeDtreeIngress
    STATUS current
    DESCRIPTION
        "A collection of objects providing information
        about distribution trees."
    ::= { rbridgeGroup 10 }
rbridgeTrillGroup OBJECT-GROUP
    OBJECTS {
        rbridgeTrillMinMtuDesired,
        rbridgeTrillSz,
        rbridgeTrillMaxMtuProbes,
        rbridgeTrillNbrMtu,
        rbridgeTrillNbrFailedMtuTest
    STATUS
               current
    DESCRIPTION
        "A collection of objects providing information
        about TRILL neighbors."
    ::= { rbridgeGroup 11 }
rbridgeNotificationGroup NOTIFICATION-GROUP
    NOTIFICATIONS {
        rbridgeBaseNewDrb,
        rbridgeBaseTopologyChange
    STATUS
                current
    DESCRIPTION
        "A collection of objects describing notifications (traps)."
    ::= { rbridgeGroup 12 }
```

```
-- Compliance Statement
rbridgeCompliance MODULE-COMPLIANCE
      STATUS
               current
      DESCRIPTION
          "The compliance statement for support of RBridge
         services."
      MODULE
         MANDATORY-GROUPS {
            rbridgeBaseGroup,
             rbridgeBaseNicknameGroup,
             rbridgeBasePortGroup,
             rbridgeFdbGroup,
             rbridgeFibGroup,
             rbridgeVlanGroup,
             rbridgeDtreeGroup,
             rbridgeTrillGroup,
             rbridgeNotificationGroup
         }
      GROUP rbridgePortCounterGroup
      DESCRIPTION
          "Implementation of this group is optional."
      GROUP rbridgeEsadiGroup
          "Implementation of this group is optional."
      GROUP rbridgeSnoopingGroup
      DESCRIPTION
          "Implementation of this group is optional."
      ::= { rbridgeCompliances 1 }
rbridgeReadOnlyCompliance MODULE-COMPLIANCE
      STATUS current
      DESCRIPTION
          "When this MIB is implemented in read-only mode, then
         the implementation can claim read-only compliance.
         In that case, RBridge objects can be monitored but
         cannot be configured with this implementation."
```

```
MODULE
   MANDATORY-GROUPS {
       rbridgeBaseGroup,
        rbridgeBaseNicknameGroup,
        rbridgeBasePortGroup,
        rbridgeFdbGroup,
        rbridgeFibGroup,
        rbridgeVlanGroup,
        rbridgeDtreeGroup,
       rbridgeTrillGroup,
       rbridgeNotificationGroup
    }
OBJECT rbridgeBaseForwardDelay
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseUniMultipathEnable
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseMultiMultipathEnable
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseAcceptEncapNonadj
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseNicknameNumber
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseNicknamePriority
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
OBJECT rbridgeBaseNicknameDtrPriority
MIN-ACCESS read-only
DESCRIPTION
    "Write access is not required."
```

OBJECT rbridgeBaseNicknameRowStatus SYNTAX INTEGER { active(1) } MIN-ACCESS read-only DESCRIPTION

"Write access is not required, and 'active' is the only status that needs to be supported."

OBJECT rbridgeBasePortDisable MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortTrunkPort MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortAccessPort MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortP2pHellos MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortInhibitionTime MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortDisableLearning MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortDesiredDesigVlan MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeBasePortStpWiringCloset MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeConfidenceNative MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeConfidenceDecap MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeConfidenceStatic MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeVlanDisableLearning MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeVlanPortAnnouncing MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeEsadiEnable MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeEsadiConfidence MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeEsadiDrbPriority MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeEsadiDrbHoldingTime MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeEsadiRowStatus SYNTAX INTEGER { active(1) } MIN-ACCESS read-only

```
DESCRIPTION
```

"Write access is not required, and 'active' is the only status that needs to be supported."

OBJECT rbridgeDtreePriority MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeTrillMinMtuDesired MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

OBJECT rbridgeTrillMaxMtuProbes MIN-ACCESS read-only DESCRIPTION

"Write access is not required."

GROUP rbridgePortCounterGroup DESCRIPTION

"Implementation of this group is optional."

GROUP rbridgeEsadiGroup DESCRIPTION

"Implementation of this group is optional."

GROUP rbridgeSnoopingGroup

"Implementation of this group is optional."

::= { rbridgeCompliances 2 }

END

RFC 6850 RBridges: TRILL Base MIB January 2013

8. Security Considerations

This MIB relates to a system that will provide network connectivity and packet-forwarding services. As such, improper manipulation of the objects represented by this MIB may result in denial of service to a large number of end-users.

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations. These are the tables and objects and their sensitivity/vulnerability:

The following tables and objects in the RBRIDGE-MIB can be manipulated to interfere with the operation of RBridges:

- o rbridgeBaseUniMultipathEnable affects the ability of the RBridge to route unicast traffic over multiple paths, and rbridgeBaseMultiMultipathEnable affects the ability of the RBridge to route multi-destination traffic over multiple paths.
- o rbridgeBasePortTable contains a number of objects that may affect network connectivity. Actions that may be triggered by manipulating objects in this table include disabling of an RBridge port, discarding of native packets, disabling learning, and others.
- o rbridgeEsadiTable contains objects that affect the operation of the ESADI protocol used for learning, and manipulation of the objects contained therein can be used to confuse the learning ability of RBridges.
- o rbridgeDtreePriority can affect computation of distribution trees within an RBridge campus, thereby affecting the forwarding of multi-destination traffic.
- o rbridgeTrillMinMtuDesired can affect the size of packets being used to exchange information between RBridges.

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt the values of these objects when sending them over

the network via SNMP. For example, access to network topology and RBridge attributes can reveal information that should not be available to all users of the network.

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPsec), there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

Implementations SHOULD provide the security features described by the SNMPv3 framework (see [RFC3410]), and implementations claiming compliance to the SNMPv3 standard MUST include full support for authentication and privacy via the User-based Security Model (USM) [RFC3414] with the AES cipher algorithm [RFC3826]. Implementations MAY also provide support for the Transport Security Model (TSM) [RFC5591] in combination with a secure transport such as SSH [RFC5592] or TLS/DTLS [RFC6353].

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

For other RBridge security considerations, see [RFC6325].

9. IANA Considerations

The MIB module in this document uses the following IANA-assigned OBJECT IDENTIFIER value recorded in the SMI Numbers registry:

```
Descriptor OBJECT IDENTIFIER value
_____
rbridgeMIB { mib-2 214 }
```

10. Contributors

The authors would like to acknowledge the contributions of Donald Eastlake, Radia Perlman, Anoop Ghanwani, Dan Romascanu, Mahesh Akula, Sue Hares, and Joan Cucchiara.

11. References

11.1. Normative References

- Bradner, S., "Key words for use in RFCs to Indicate [RFC2119] Requirement Levels", BCP 14, RFC 2119, March 1997.
- [RFC2578] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [RFC2579] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [RFC2580] McCloghrie, K., Ed., Perkins, D., Ed., and J. Schoenwaelder, Ed., "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [RFC2863] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.
- Blumenthal, U. and B. Wijnen, "User-based Security Model [RFC3414] (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", STD 62, RFC 3414, December 2002.
- [RFC3826] Blumenthal, U., Maino, F., and K. McCloghrie, "The Advanced Encryption Standard (AES) Cipher Algorithm in the SNMP User-based Security Model", RFC 3826, June 2004.
- [RFC4001] Daniele, M., Haberman, B., Routhier, S., and J. Schoenwaelder, "Textual Conventions for Internet Network Addresses", RFC 4001, February 2005.
- Norseth, K., Ed., and E. Bell, Ed., "Definitions of [RFC4188] Managed Objects for Bridges", RFC 4188, September 2005.
- Levi, D. and D. Harrington, "Definitions of Managed [RFC4363] Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions", RFC 4363, January 2006.
- [RFC4444] Parker, J., Ed., "Management Information Base for Intermediate System to Intermediate System (IS-IS)", RFC 4444, April 2006.

- [RFC5591] Harrington, D. and W. Hardaker, "Transport Security Model for the Simple Network Management Protocol (SNMP)", RFC 5591, June 2009.
- [RFC5592] Harrington, D., Salowey, J., and W. Hardaker, "Secure Shell Transport Model for the Simple Network Management Protocol (SNMP)", RFC 5592, June 2009.
- [RFC6325] Perlman, R., Eastlake 3rd, D., Dutt, D., Gai, S., and A. Ghanwani, "Routing Bridges (RBridges): Base Protocol Specification", RFC 6325, July 2011.
- [RFC6353] Hardaker, W., "Transport Layer Security (TLS) Transport Model for the Simple Network Management Protocol (SNMP)", RFC 6353, July 2011.

11.2. Informative References

- [RFC3410] Case, J., Mundy, R., Partain, D., and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", RFC 3410, December 2002.
- Harrington, D., "Transferring MIB Work from IETF Bridge [RFC4663] MIB WG to IEEE 802.1 WG", RFC 4663, September 2006.
- Touch, J. and R. Perlman, "Transparent Interconnection of [RFC5556] Lots of Links (TRILL): Problem and Applicability Statement", RFC 5556, May 2009.

RFC 6850 RBridges: TRILL Base MIB January 2013

Authors' Addresses

Anil Rijhsinghani Hewlett-Packard 153 Taylor St. Littleton, MA USA

Phone: +1 508 323 1251 EMail: anil@charter.net

Kate Zebrose HW Embedded 26 Josephine Ave. Somerville, MA

Phone: +1 617 840 9673 EMail: zebrose@alum.mit.edu