
網管基本實務與能力

mickey@CNA



Mickey



米奇

Outline

- 宿網設備
 - o switch & router
 - o switch & router上的安全機制
- Switch & Router操作
 - 。 指令集
- case處理
 - 。 故障排除

宿網設備

Cisco

• 生產、研發網路設備的廠商

• 網路技術先進


• 全球主要骨幹網路、企業公司均採用

宿網架構



網管負責範圍

Keystone & Patch panel



Switch

• Cisco Catalyst 2960 - L2 交換器





Fast Ethernet port



Gigabit Ethernet port 連接switch or router

Router

- Cisco Catalyst 3750 L3 交換器
 - 。 負責封包路由
 - o 可鎖上ARP(IP-MAC)





連接switch



宿網黃金三角 Port port-security ACL MAC IP ARP

Switch安全機制

- Port-security -> 防止網路孔(port)被盜用
- ACL -> 限制通過的封包
- Dynamic ARP Inspection(DAI) -> 避免惡意攻擊

- DHCP snooping(嗅探) -> 紀錄ip資訊
- IP source guard -> 限制只能使用分配的ip

Switch port-security

- 偵測MAC位址是否符合port上設定的
- 防止網路孔遭到盜用
- MAC不符 -> 產生violation
 - o 申請時填錯 or 差錯孔
- violation 處理方式
 - o shutdown -> 直接把port關閉(預設)
 - o restrict -> 丟棄封包, 紀錄在log
 - o protect -> 丟棄封包,不紀錄在log

宿網黃金三角 Port port-security ACL MAC IP ARP

Switch err-disabled

- port-security(psecure-violation)
 - 卡號錯誤造成violation值不斷上升,達到上限
- link-flap
 - 網路不穩定,造成上下線頻繁(10秒內5次以上)
 - e.g. 爛線、keystone損毀
- bpduguard(偵測到bpdu封包)
 - 。 使用分享器、橋接器

Switch ACL

- Access Control List: 連線存取控制列表
- 限制port可通過的封包
 - opermit(允許通過) or deny(不允許)
- 由上而下檢查,若符合就停止,若檢查到最後一項都不相符,則不允許通過
 - o e.g. permit ip host 140.123.1.2 any
 permit ip host 140.123.1.3 any

宿網黃金三角 Port port-security ACL MAC IP ARP

Switch IP source guard

- 限制 IP 只能是宿網 DHCP server 發的
 - 。防止盜用別人的 IP(手動設定IP)
 - 。 防止超流、中毒斷線仍能使用宿網
- 如果手動設定與DHCP server發的同一個IP?
- 檢查port上來的 IP 與 IP source binding table


MAC	IP	port
aaaa.bbbb.cccc	140.123.10.3	5

IP source binding table 來自DHCP snooping binding table


Switch DHCP snooping

- 紀錄 DHCP server 分配 IP 紀錄:MAC-IP-port
- 存在DHCP snooping binding table裡
- 提供資訊給IP source guard、DAI

DHCP review



DHCP spoofing




20

DHCP spoofing

• 拿到假的DHCP server發出無效的IP,導致無法上網

• 防護機制: DHCP snooping
Switch uplink 介面設定成 trust
其他設定成 untrust

DHCP spoofing





• 22


Switch DHCP snooping

- 紀錄 DHCP server 分配 IP 紀錄:MAC-IP-port
- 存在DHCP snooping binding table裡
- 提供資訊給IP source guard DAI

- 簡稱DAI
- 防止ARP spoofing(Man In The Middle)
 - 。避免封包被撈走,資料外洩或遭修改









ARP table
IP_A - Mac_A
IP B - Mac B



ARP table
IP_B - Mac_C



DoS(Denial of Service)
Passive Sniffing(被動式封包嗅探)
MITM(中間人攻擊)

B


27

Δ

• 保護機制:當swtich收到ARP封包時,會先去找 DHCP snooping binding table裡有沒有符合的,符合才會進行轉送和更新ARP table,若不

符合,則被擋下來





Α

Switch安全機制(review)

- Port-security -> 防止網路孔(port)被盜用
- Err-disable -> 錯誤處理
- ACL -> 限制通過的封包
- DHCP snooping -> 紀錄ip資訊
- IP source guard -> 限制只能使用分配的ip
- Dynamic Arp Inspection(DAI) -> 避免惡意攻擊

• 29

宿網黃金三角 Port port-security ACL Dynamic ARP Inspection MAC IP

Router

- Cisco Catalyst 3750 L3 交換器
 - 負責封包路由
 - o 可鎖上ARP(IP-MAC)





連接switch




宿網黃金三角 Port port-security ACL Dynamic ARP Inspection MAC IP


Switch操作

連上Switch

- 使用pietty連線
- Google "pietty",第一個








連上Switch

• 使用windows telnet 連線




• 使用windows telnet 連線




37

• 使用windows telnet 連線







C:\Windows\system32\cmd.exe C:4. Microsoft Windows [版本 6.3.9600] (c) 2013 Microsoft Corporation. 著作權所有,並保留一切權利。 C:\Users\mickey>telnet 140.123.A.B Cash. User Access Verification Username: [username] Password:

• Privileged EXEC mode(特權模式): 可以做查詢、進入其他mode

```
CNAdemo#
```

Switch & Router操作

Switch 查詢

- port狀況 & 詳細資料
- err-disabled
- access-list 設定(ACL)
- log 紀錄
- IP狀況(DHCP)

帳號:SAcourse

Switch 查詢 port狀態

show interface status

CNAdemo#show interfaces status						
Port	Name	Status	Vlan	Duplex	Speed Type	
Fa0/1	210200	notconnect	1	auto	auto 10/100BaseTX	
Fa0/2		notconnect	1	auto	auto 10/100BaseTX	
Fa0/3		notconnect	1	auto	auto 10/100BaseTX	
Fa0/4		notconnect	1	auto	auto 10/100BaseTX	
Fa0/5		notconnect	1	auto	auto 10/100BaseTX	
Fa0/6		notconnect	1	auto	auto 10/100BaseTX	
Fa0/7		notconnect	1	auto	auto 10/100BaseTX	
Fa0/8		notconnect	1	auto	auto 10/100BaseTX	
Fa0/9		notconnect	1	auto	auto 10/100BaseTX	
Fa0/10		notconnect	1	auto	auto 10/100BaseTX	
Fa0/11		notconnect	1	auto	auto 10/100BaseTX	
Fa0/12		notconnect	1	auto	auto 10/100BaseTX	
Fa0/13		notconnect	1	auto	auto 10/100BaseTX	
Fa0/14		notconnect	1	auto	auto 10/100BaseTX	
Fa0/15		notconnect	1	auto	auto 10/100BaseTX	
Fa0/16		notconnect	1	auto	auto 10/100BaseTX	

帳號:SAcourse

Switch 查詢 port狀態

• # show mac address-table

CNAdemo#show mac address-table				239	14cc.20fb.bfc3	DYNAMIC	Fa0/7
Mac Address Table				239	1803.73dc.6f2e	DYNAMIC	Fa0/24
			239	1c87.2ccb.0fc5	DYNAMIC	Gi0/1	
Vlan	V 144	Type	Ports	239	1c87.2ccb.1342	DYNAMIC	Gi0/1
	Mac Address			239	1cb7.2c8e.e9d1	DYNAMIC	Gi0/1
A11	0100.0cc.ccc	STATIC	CPU	239	206a.8a7f.b726	DYNAMIC	Gi0/1
All	0100.0ccc.ccd	STATIC	CPU	239	20cf.30c8.29c2	STATIC	Fa0/2
A11	0180.c200.0000	STATIC	CPU	239	2c60.0c91.e0d6	DYNAMIC	G10/1

帳號:SAcourse

Switch 查詢 某一 port狀態

show interface fa0/X status

Port	Name	Status	Vlan	Duplex	Speed Type
Fa0/21		connected	239	a-full	a-100 10/100BaseTX

- # show mac address-table interface fa0/X
- # show mac address-table address [MAC]

CNAdemo#show mac address-table address 6431.508b.bbdc

Mac Address Table

Vlan Mac Address Type Ports

239 6431.508b.bbdc DYNAMIC Fa0/21
Total Mac Addresses for this criterion: 1

● 帳號:SAcourse

Switch 查詢 某一port狀態

- # show interface fa0/X
 - o input error:
 - 封包傳送過小
 - 爛線or網卡問題
 - o CRC:
 - 收到data所算 出來了checksum 與封包中紀錄的 不符

```
CNAdemo#show int fa0/20
FastEthernet0/20 is down, line protocol is down (notconnect)
 Hardware is Fast Ethernet, address is ec30.9134.8794 (bia ec30.9134.8794)
 MTU 1500 bytes, BW 10000 Kbit/sec, DLY 1000 usec,
     reliability 255/255, txload 1/255, rxload 1/255
 Encapsulation ARPA, loopback not set
 Keepalive set (10 sec)
 Auto-duplex, Auto-speed, media type is 10/100BaseTX
  input flow-control is off, output flow-control is unsupported
 ARP type: ARPA, ARP Timeout 04:00:00
 Last input never, output never, output hang never
 Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
 Queueing strategy: fifo
 Output queue: 0/40 (size/max)
 5 minute input rate 0 bits/sec, 0 packets/sec
 5 minute output rate 0 bits/sec, 0 packets/sec
    O packets input, O bytes, O no buffer
     Received O broadcasts (O multicasts)
    O runts, O giants, O throttles
    O input errors, O CRC, O frame, O overrun, O ignored
    O watchdog, O multicast, O pause input
     O input packets with dribble condition detected
     O packets output, O bytes, O underruns
     O output errors, O collisions, 1 interface resets
 --More--
```

帳號:SAcourse

Switch 查詢 err-disabled

- # show interface status err-disabled
 - o psecure-violation 卡號跟機器紀錄的不同
 - o link-flap 短時間內上上下下
 - o bpduguard 分享 or 橋接器

```
CNAdemo#show interfaces status err-disabled

Port Name Status Reason Err-disabled Vlans
Fa0/22 err-disabled psecure-violation
Fa0/23 err-disabled link-flap
Fa0/24 err-disabled bpduguard

CNAdemo#
```

• 帳號:SAcourse

Switch 查詢 port-security

show port-security

	port-security MaxSecureAddr (Count)	CurrentAddr (Count)	SecurityViolation (Count)	Security Action			
Fa0/2	1	1	0	Restrict			
Fa0/4	1	1	0	Restrict			
Fa0/5	1	1	0	Restrict			
Fa0/11	1	0	101	Restrict			
Fa0/21	1	1	5350	Restrict			

帳號:SAcourse 密碼:center21x

Switch 查詢 access-list

show access-list [ACL name]

```
CNAdemo#show access-list demoACL

Extended IP access list demoACL

10 permit ip host 140.123. any (17 matches)

20 permit ip host 10.123 any (10 matches)

30 permit udp any any eq bootps (48 matches)

40 permit udp any any eq bootpc

50 deny ip any any (46 matches)
```

○ 10 match:正常,表示有拿到正確IP。

○ 20 match:未申請、超流斷線、中毒斷線=> 導到宿網首頁

○ 30 match: 做DHCP 相關請求 (ex: 電腦剛開機時)

○ 40 match:不正常,作DHCP發送IP的動作

○ 50 match:無法連線,可能手動設定錯IP

帳號:SAcourse

Switch 查詢 log紀錄

• # show log | include 0/X[,.]

```
Sep 15 17:11:22: %LINK-3-UPDOWN: Interface FastEthernet0/3, changed state to up

Sep 15 17:11:23: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to up

Sep 15 17:11:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to down

Sep 15 17:11:26: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to up

Sep 15 17:20:11: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to down

Sep 15 17:20:12: %LINK-3-UPDOWN: Interface FastEthernet0/3, changed state to down

Sep 15 17:20:28: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to up

Sep 15 17:20:28: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to up

Sep 15 17:21:03: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to down
```

```
Sep 28 11:47:35: %PORT_SECURITY-2-PSECURE_VIOLATION: Security violation occurred, caused by MAC address cccc.cccc.cccc on port FastEthernet0/21.

Sep 28 11:49:53: %PORT_SECURITY-2-PSECURE_VIOLATION: Security violation occurred, caused by MAC address cccc.cccc on port FastEthernet0/21.

Sep 28 11:50:02: %PORT_SECURITY-2-PSECURE_VIOLATION: Security violation occurred, caused by MAC address cccc.cccc on port FastEthernet0/21.

Sep 28 11:50:58: %PORT_SECURITY-2-PSECURE_VIOLATION: Security violation occurred, caused by MAC address cccc.cccc.ccc on port FastEthernet0/21.

Sep 28 11:51:03: %PORT_SECURITY-2-PSECURE_VIOLATION: Security violation occurred, caused by MAC address cccc.cccc.ccc on port FastEthernet0/21.
```

帳號: SAcourse

Switch 查詢 IP取得狀況

- # show ip dhcp snooping binding
 - o Lease (sec): 剩下的租約時間,從3600開始倒數,到 1800會重新申請租約,時間到就釋出IP

帳號:SAcourse

DEMO

- # show interface [fa0/X] status
- # show mac address-table
- # show mac address-table interface fa0/X
- # show mac address-table address [MAC]
- # show interface fa0/X
- # show interface status err-disabled
- # show port-security
- # show access-list [ACL name]

Switch 操作

- port-security
 - o鎖上 port-security
 - o 解鎖 port-security
- ACL
 - o設定、套用 ACL
 - o取消 ACL 套用、刪除 ACL

Switch 操作

- 進入全域設定模式
 - o # configure terminal

```
CNAdemo#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
CNAdemo(config)#
```

帳號:SAcourse 密碼:center21x

• 55

Switch 操作 port-security(鎖)

設定 port-security : (port 綁 MAC)

- # configure terminal 進入全域設定模式
- (config) # interface fa0/x 針對哪個port做設定
- o (config-if) # switchport mode access
- o (config-if) # switchport port-security violation restrict
- (config-if) # switchport port-security mac-address aaaa.aaaa
- o (config-if) # switchport port-security
- o (config-if) # end
 - 帳號:SAcourse

Switch 操作 port-security (鎖)

- port-security 鎖上多組卡號 (port 綁 MAC)
 - 預設可以鎖上的卡號是1組
 - (config-if)# switchport port-security maximum [數量]
 - 。若實際上鎖上去的卡號數量比設定可以鎖卡號的最大數量少,等於沒有鎖卡號,因為沒有鎖的空位,會讓連到該port的人變成dynamic mac

帳號:SAcourse

Switch 操作 port-security (鎖)

- 檢查port-security設定
 - o # show running-config interface fa0/X

```
CNAdemo#show run int fa0/20
Building configuration ...
Current configuration: 324 bytes
interface FastEthernet0/20
 switchport mode access
 switchport port-security maximum 3
 switchport port-security
 switchport port-security violation restrict
 switchport port-security mac-address aaaa.aaaab
 switchport port-security mac-address aaaa.aaaa.aaac
 switchport port-security mac-address aaaa.aaaa.aaad
end
```

帳號:SAcourse

Switch 操作 port-security (解)

- 解除 port-security(依鎖上的順序反著解回去)
 - o # configure terminal
 - o (config) # interface fa0/x
 - o (config-if) # no switchport port-security
 - o (config-if) # no switchport port-security mac-address
 - o (config-if) # no switchport port-security violation
 - o (config-if) # no switchport port-security maximum
 - o (config-if) # end

帳號:SAcourse

Switch 操作 port-security (解)

- 檢查port-security設定
 - o #show running-config interface fa0/X

```
CNAdemo#show run int fa0/20
Building configuration...

Current configuration: 324 bytes!
interface FastEthernet0/20
switchport mode accessend
```

• 帳號:SAcourse

Demo

鎖port-security

- # configure terminal 進入全域設定模式
- (config) # interface fa0/x 針對哪個port做設定
- o (config-if) # switchport mode access
- o (config-if) # switchport port-security violation restrict
- (config-if)# switchport port-security maximum [數量]
- o (config-if) # switchport port-security mac-address aaaa.aaa.aa[xx]
- o (config-if) # switchport port-security mac-address aaaa.aaa.aa[xx]
- o (config-if) # switchport port-security
- o (config-if) # end

解port-security

o # show running-config o # configure terminal o (config) # interface fa0/x o (config-if) # no switchport port-security o (config-if) # no switchport port-security mac-address o (config-if) # no switchport port-security violation o (config-if) # no switchport port-security maximum o (config-if) # end

Switch 操作 ACL rule(鎖)

- 設定 ACL: (port 限制可通行的封包 \ IP)
 - o # configure terminal
 - o (config)# ip access-list extended [ACL name]
 - o (config-ext-nacl) # 10 permit ip host 140.123.239.254 any
 - o (config-ext-nacl) # 20 permit ip host 10.123.239.254 any
 - o (config-ext-nacl) # 30 permit udp any any eq bootps
 - o (config-ext-nacl) # 40 permit udp any any eq bootpc
 - o (config-ext-nacl) # 50 deny ip any any
 - o (config-ext-nacl) # end
 - 帳號:SAcourse

Switch 操作 ACL rule (鎖)

• 檢查 ACL 設定

```
o # show access-list [ACL name]
CNAdemo#show access-list demoACL
Extended IP access list demoACL
    10 permit ip host 140.123.
                                      any
    20 permit ip host 10.123.
                                     any
    30 permit udp any any eq bootps
    40 permit udp any any eq bootpc
    50 deny ip any any
```

帳號:SAcourse

Switch 操作 ACL rule (鎖)

- 把ACL套用到port上
 - o # configure terminal
 - o (config) # interface fa0/x
 - o (config-if) # ip access-group [ACL name] in
 - o (config-if) # end

• in: inbond限制進來這個port

Switch 操作 ACL rule (鎖)

• 檢查 ACL 有沒有套用到port

o # show running-config interface fa0/X

```
CNAdemo#show run int fa0/20
Building configuration ...
Current configuration: 352 bytes
interface FastEthernet0/20
 switchport mode access
 switchport port-security maximum 3
 switchport port-security
 switchport port-security violation restrict
 switchport port-security mac-address aaaa.aaaa.aaab
 switchport port-security mac-address aaaa.aaaa.aaac
 switchport port-security mac-address aaaa.aaaa.aaad
 ip access-group demoACL in
```

帳號:SAcourse

Switch 操作 ACL rule (解)

- 解除 ACL 套用
 - o # configure terminal
 - o (config) # interface fa0/x
 - o (config-if) # no ip access-group in
 - o (config-if) # end
- 刪除 ACL 設定
 - o # configure terminal
 - o (config) # no ip access-list extended [ACL name]
 - (config) # end 帳號:SAcourse

Switch 操作 ACL rule (解)

- 檢查 ACL 解除套用
 - o # show running-config interface fa0/x

```
CNAdemo#show run int fa0/20
Building configuration...

Current configuration: 58 bytes!
interface FastEthernet0/20
switchport mode access
end
```

帳號:SAcourse

Switch 操作 ACL rule (解)

- 檢查 ACL 設定已刪除
 - o # show access-list [ACL name]

```
CNAdemo#show access-list demoACL CNAdemo#
```

帳號:SAcourse

Switch 小技巧

- tab鍵:自動補齊(若有多種選項,則不變)
- ?:可以查詢接下來可以接甚麼指令
 - o <cr>: 到此已是可執行的指令
- (config) # do show interface status

- # write memory
 - o 改完設定,寫進memory

帳號:SAcourse

Demo

鎖ACL

- o # configure terminal
- o (config)# ip access-list extended [ACL name]
- o (config-ext-nacl) # 10 permit ip host 140.123.
- o (config-ext-nacl) # 20 permit ip host 10.123any
- o (config-ext-nacl) # 30 permit udp any any eq bootps
- o (config-ext-nacl) # 40 permit udp any any eq bootpc
- o (config-ext-nacl) # 50 deny ip any any
- o (config-ext-nacl) # end

套用到port

- o # configure terminal
- o (config) # interface fa0/x
- o (config-if) # ip access-group [ACL name] in
- o (config-if) # end

Router 操作

Router ARP(鎖)

- # configure terminal
- (config) # arp [IP] [MAC] arpa
- (config) # end

帳號:SAcourse

密碼:center21x

Router ARP(鎖)

- 查詢ARP
- # show ip arp [IP or MAC]

```
CNAdemo#show ip arp 1.1.1.1

Protocol Address Age (min) Hardware Addr Type Interface
Internet 1.1.1.1 - aaaa.aaaa ARPA
```

帳號:SAcourse 密碼:center21x

• 77

Router ARP(解)

- # configure terminal
- (config) # no arp [IP]
- (config) # end

帳號:SAcourse

密碼:center21x

Case 處理

Case 處理 - 基本詢問

- 是否有申請網路(剛開學時)
- 有沒有繳費(過繳費斷線時間)
- 是否中毒 or 超流斷線
- 甚麼時候開始不能用
 - 。 帶回家再帶來、一直不能用
 - 手機 or外接裝置插usb上去,會自動開啟共用
- 期間做過甚麼事(載甚麼軟體、動過甚麼設定)

80

Case 處理 - 小電腦圖示

• 紅色叉叉

- 網路線未連接
- 。 網路介面卡未啟用
- o err-disabled
- 。 線路問題
- 黃色驚嘆號(無法辨識的網路)
 - 。 申請錯床位
 - o 超流 or 中毒斷線
 - 。 開啟共用、手動設定 IP
 - 卡號錯誤





Case 處理 - 小電腦圖示

- 正常(已連線)
 - o DNS 設定錯誤
 - 須設定成自動取得
 - ○防毒軟體(e.g. McAfeX)



Case 處理 - 其他

- 可以幫忙下載、安裝 Office 嗎?
- 電腦中毒無法開機,可以幫我重灌嗎?

→非網管業務範圍

• 可以連到校內網站 (ex: 宿網首頁),但不能玩線上遊戲、FB

→連外問題,可注意相關公告

- 宿網首頁 (https://www.dorm.ccu.edu.tw/)
- 忘記宿網密碼 => 可到宿網申請系統使用「忘記密碼」功能

Q & A

Thank you for listening