Flash firmware on telemetry modules

Frederik Mazur Andersen fm@mmmi.sdu.dk

1 Flash telemetry modules

In order to show the current telemetry and not the average rssi a change has been made in the firmware of the radio modules. To flash your telemetry modules with the new firmware following the steps below.

- 1. Download and extract the zip file from blackboard.
- 2. Go into the downloaded folder in terminal
- 3. Make sure only one telemetry module is connected though usb. (Should be port tty USB0)
- 4. install pexpect with: pip install pexpect If running Ubuntu 16.04 you might have to run pip install -upgrade pexpect to get the latest version.
- 5. Run command: python sik_uploader.py --port /dev/ttyUSB0 --baudrate 57600 radio_hm_trp_2.0_current_rssi.ihx
- 6. Repeat for second module. Both modules needs to be flashed.
- 7. Setup both modules though apm-planner again as instructed in the weekly notes.

¹Ensure it gets installed for Python 2.7. You might have to use pip2 instead.