

Моделирование S параметров

SP1
Type=lin
Start=6 MHz
Stop=8 MHz
Points=1001

Eqn1 SWR=rtoswr(S[1,1]) K=dB(S[2,1])

Уравнение