

Input Password Printer Sharp


1. Go to control panel.




2. View Device and Printers




3. Select the printer. Right click and select printer properties.



4. Select Peferences.., go to Job Handling



5. Check List Use number, and input the password. Next . Ok.



6. Ok, Done