



Create New Project



Select Device & Software Component




■ Select device: Nuvoton -> NuMicro M4 Family -> M480 -> M487JIDAE

Select Device & Software Component


CMSIS -> CORE
 Davide -> Startur

Device -> Startup

▼ Select software components




Set Debugger




▲ Right Click Target1 and Click

Coption for Target 'Target 1' ... 」


▼ Select Debug and Select 「NULink Debugger」



Nu-Link Driver Setup




Check ARM Compiler



Use default compiler version5


Create [main.c]




Right click User and Click 「Add New Item to Group "User" ...」

▲ Right Click Target1 and Click 「Add Group」


Click on 'New Group' and then press 'F2' to change the file name. The file name should be 'user'.




Create 「main.c」 ▶



Include M480 source




Select all M480_include file and Click 「Add」 then close window




▲ Right check 'include' and Click 「Add Existing File to Group "include_file" ...」

Include Included File Path




Create House_ware Group




Select all House_ware file and Click 「Add」 then close window

Write Main Function



Rebuild All Target File



▲ Click 「Rebuild」

▼ Check for no errors; warnings are acceptable.

```
compiling system_M480.c...
compiling LCDConf.c...
linking...
Program Size: Code=28300 RO-data=3596 RW-data=428 ZI-data=68364
".\Objects\uVision_test.axf" - 0 Error(s), 5 Warning(s).
Build Time Elapsed: 00:00:04
```