

FlexRay

Static Seq.	Dynamic Seq.	Symbol Window	Network Idle Time
-------------	--------------	---------------	-------------------

← Comm. Cycle —→
Determined by shortest Periodic Req. in System

Static seq: (always starts at action point)

- Divide into equal size slots, always Tx
- # slots per node depends on node use
- delay at most T₀ to next cycle

Dynamic seq. (Priority on node ID)

M	M+1	M+2	Frameid M+3	M+4	M+5	frameid M+6	M+7
N	N+1	N+2	N+3	N+4	N+5	N+6	N+7

- always same # min. slots, But diff. dynamic slot counter
- always fill 1 min. slot even when not Tx
- each node has latestTx (Latest Possible Tx Time)
else wait next cycle

Symbol window: Special bit pattern e.g. waking up node

NetIDLETime:

- corrects Microtick adjustments to match (Align)
Macro tick Perfectly

Use Case (AN)	rate ↓	Cheap	FR	rate ↑	expensive
Bursty			Periodic + burst		redundancy
Timing not life critical			Exact Timing		2-channel Entis