

CATÁLOGO CABEÇOTE É OVERSHOT

ÍNDICE

CABEÇOTE NO **04**

CABEÇOTE NO2 **05**

CABEÇOTE NOU NG2 06

CABEÇOTE HO **07**

CABEÇOTE HOU NG2 08

CABEÇOTE PO **09**

CABEÇOTE PO NG2 10

OVERSHOT NO 12

OVERSHOT NOU 13

OVERSHOT HO 14

OVERSHOT HOU 15


OVERSHOT PO 16

CABEÇOTE

CABEÇOTE NO HEAD ASSEMBLY NO




2 C 3 D 4 S 5 S 6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	DESCRIPCIÓN pearHead Point compression Spring deteng plunger pearHead Base pirol Pin 7/16"	1 1 1
2 C 3 D 4 S 5 S 6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	ompression Spring leteng plunger pearHead Base	1
3 D 4 S 5 S 6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	leteng plunger pearHead Base	
4 S 5 S 6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	pearHead Base	1
5 S 6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	-	
6 L 7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	pirol Pin 7/16"	1
7 S 8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L		1
8 N 9 W 10 L 11 L 12 L 13 U 14 S 15 L	atch Retracting Case	1
9 W 10 L 11 L 12 L 13 U 14 S 15 L	pring Pin 1/2" x 2"	2
10 L 11 L 12 L 13 U 14 S 15 L 16 S	lyloc Bolt Head	1
11 L 12 L 13 U 14 S 15 L 16 S	Vasher	1
12 L 13 U 14 S 15 L 16 S	atch Compression Spring	1
13 U 14 S 15 L 16 S	ink	2
14 S 15 L 16 S	atch	2
15 L 16 S	Ipper Latch Body	1
16 S	pring Pin 1/2" x 1-1/2"	1
	anding Shoulder	1
17 L	tainless Steel Ball	1
	anding Indicator Bushing	1
18 L	ower Latch Body	1
19 N	lord Lock	1
20 H	lexagonal Nut 1-1/8"	1
21 S	pindle	1
22 S	hut-Off Valve	2
23 V	alve Adjusting Washer	2
24 T	hrust Bearing B9	1
25 S	pindle Bearing	1
26 H	langer Bearing W3/4"	1
27 C	ompression Spring	1
28 S	tover Lock Nut 3/4"	1
29 Ir	nner tube Cap Assembly	1



CABEÇOTE NO2 HEAD ASSEMBLY NO2



ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2"	2
8	Nyloc Bolt Head	1
9	Washer	1
10	Latch Compression Spring	1
11	Link	2
12	Latch	2
13	Upper Latch Body	1
14	Spring Pin 1/2" x 1-1/2"	1
15	Landing Shoulder	1
16	Stainless Steel Ball	1
17	Landing Indicator Bushing	1
18	Lower Latch Body	1
19	Nord Lock	1
20	Hexagonal Nut 1-1/8"	1
21	Spindle	1
22	Shut-Off Valve	2
23	Valve Adjusting Washer	2
24	Thrust Bearing B9	1
25	Spindle Bearing	1
26	Hanger Bearing W3/4"	1
27	Compression Spring	1
28	Stover Lock Nut 3/4"	1
29	Inner tube Cap Assembly	1






CABEÇOTE NOU NG2 HEAD ASSEMBLY NOU NG2




ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5		
	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2"	2
8	Spring Pin 1/4" x 2"	1
9	Nyloc Bolt Head	1
10	Washer	1
11	Latch Compression Spring	1
12	Link	2
13	Latch	2
14	Upper Latch Body	1
15	Spring Pin 1/2" x 1-1/2"	1
16	Valve Piston	1
17	Landing Indicator Bushing	1
18	Adapter	1
19	Pump-In Lip Seal	2
20	Seal Seat	1
21	Landing Shoulder	1
22	Lower Latch Body	1
23	Nord Lock	1
24	Hexagonal Nut 1-1/8"	1
25	Spindle	1
26	Shut-Off Valve	2
27	Valve Adjusting Washer	2
28	Thrust Bearing B9	1
29	Spindle Bearing	1
30	Hanger Bearing W3/4"	1
31	Compression Spring	1
32	Stover Lock Nut 3/4"	1
33	Inner tube Cap Assembly	1



CABEÇOTE HO HEAD ASSEMBLY HO




ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2-3/4"	2
8	Nyloc Bolt Head 3/8"	1
9	Washer	1
10	Latch Compression Spring	1
11	Link	2
12	Latch	2
13	Upper Latch Body	1
14	Spring Pin 1/2" x 2"	1
15	Landing Shoulder	1
16	Stainless Steel Ball 22mm	1
17	Landing Indicator Bushing	1
18	Lower Latch Body	1
19	Nord Lock	1
20	Hexagonal Nut 1-1/4"	1
21	Spindle	1
22	Shut-Off Valve	2
23	Valve Adjusting Washer	2
24	Thrust Bearing B13	2
25	Spindle Bearing	1
26	Hanger Bearing B9	1
27	Compression Spring	1
28	Stover Lock Nut 1"	1
29	Inner tube Cap Assembly	1



CABEÇOTE HOU NG2 HEAD ASSEMBLY HOU NG2




ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2-3/4"	2
8	Spring Pin 1/4" x 2-3/4"	1
9	Nyloc Bolt Head	1
10	Washer	1
11	Latch Compression Spring	1
12	Link	2
13	Latch	2
14	Upper Latch Body	1
15	Spring Pin 1/2" x 1-1/2"	1
16	Valve Piston	1
17	Landing Indicator Bushing	1
18	Adapter	1
19	Pump-In Lip Seal	2
20	Seal Seat	1
21	Landing Shoulder	1
22	Lower Latch Body	1
23	Nord Lock	1
24	Hexagonal Nut 1-1/8"	1
25	Spindle	1
26	Shut-Off Valve	2
27	Valve Adjusting Washer	2
28	Thrust Bearing B9	1
29	Spindle Bearing	1
30	Grease Fitting	1
31	Hanger Bearing W3/4"	1
32	Compression Spring	1
33	Stover Lock Nut 3/4"	1
34	Inner tube Cap Assembly	1



CABEÇOTE PO HEAD ASSEMBLY PO




ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2-3/4"	2
8	Nyloc Insert Machine Screw	2
9	Nyloc Bolt Head 3/8"	1
10	Washer	1
11	Latch Compression Spring	1
12	Link	2
13	Latch	2
14	Upper Latch Body	1
15	Spring Pin 1/2" x 2"	1
16	Shoulder Bolt	1
17	Valve holder	1
18	Landing Shoulder	1
19	Steel Threaded Ball	1
20	Fluid Retention Bushing	1
21	Fluid Retention Spring Light	1
22	Lower Latch Body	1
23	Nord Lock	1
24	Hexagonal Nut 1-1/2"	1
25	Spindle	1
26	Valve Adjusting Washer	2
27	Shut-Off Valve	2
28	Tapered Washer	1
29	Thrust Bearing B13	3
30	Spindle Bearing	1
31	Grease Fitting	1
32	Compression Spring	1
33	Narrow Washer	1
34	Stover Lock Nut 1-1/4"	1
35	Inner tube Cap Assembly	1





ITEM	DESCRIPCIÓN	CANT.
1	SpearHead Point	1
2	Compression Spring	1
3	Deteng plunger	1
4	SpearHead Base	1
5	Spirol Pin 7/16"	1
6	Latch Retracting Case	1
7	Spring Pin 1/2" x 2-3/4"	2
8	Nyloc Bolt Head 3/8" UNC	1
9	Washer	1
10	Latch Compression Spring	1
11	Link	2
12	Latch	2
13	Upper Latch Body	1
14	Spring Pin 1/2" x 2"	1
15	Landing Shoulder	1
16	Stainless Steel Ball 22mm	2
17	Landing Indicator Bushing	1
18	Lower Latch Body	1
19	Nord Lock	1
20	Hexagonal Nut	1
21	Spindle	1
22	Valve Adjusting Washer	2
23	Shut-Off Valve	2
24	Tapered Washer	1
25	Thrust Bearing B13	3
26	Spindle Bearing	1
27	Grease Fitting	2
28	Compression Spring	1
29	Narrow Washer	1
30	Stover Lock Nut	1
31	Inner tube Cap	1
32	Check Valve Body	1




OVERSH0T

OVERSHOT NO EZY LOCK OVERSHOT NO




ITEM	DESCRIPCIÓN	CANT.
1-5	Cable Swivel Assembly	1
6	Grease Fitting 1/4"	1
7	Cable Swivel Body	1
8	Jar Staff	1
9	Jar Tube	1
10	Locking Sleeve	1
11	Hexagonal Nut 3/4"	1
12	Nord Lock	1
13	Сар	1
14	Compression Spring Overshot	1
15	Sleeve Safe Locking	1
16	Compression Spring Ball	1
17	Ball 11/32"	2
18	Set Screw Nyloc	1
19	Compression Spring Lifting Dog	1
20	Lifting Dog	2
21	Locking Pin	1
22	Plain Pin 1/2" x 1-15/16"	1
23	Spring Pin 1/4" x 1-3/4"	1
24	Overshot Head	1



OVERSHOT NOU EZY LOCK OVERSHOT NOU




ITEM	DESCRIPCIÓN	CANT.
1-5	Cable Swivel Assembly	1
6	Cable Swivel Body	1
7	Grease Fitting 1/4"	1
8	Upper Body	1
9	Spring Pin 3/16" x 1-1/8"	1
10	Pump-In Lip Seal	2
11	Seal Seat	1
12	Ball 22mm	1
13	Landing Indicator Bushing	1
14	Overshot Head	1
15	Compression Spring Lifting Dog	1
16	Lifting Dog	1
17	Plain Pin 1/2" x 1-15/16"	1
18	Spring Pin 1/4" x 1-3/4"	1



OVERSHOT HO EZY LOCK OVERSHOT HO

ITEM	DESCRIPCIÓN	CANT.
1-5	Cable Swivel Assembly	1
6	Grease Fitting 1/4"	1
7	Cable Swivel Body	1
8	Jar Staff	1
9	Jar Tube	1
10	Locking Sleeve	1
11	Hexagonal Nut 3/4"	1
12	Nord Lock	1
13	Сар	1
14	Compression Spring Overshot	1
15	Sleeve Safe Locking	1
16	Compression Spring Ball	1
17	Ball 11/32"	2
18	Set Screw Nyloc	1
19	Compression Spring Lifting Dog	1
20	Lifting Dog	2
21	Locking Pin	1
22	Plain Pin 1/2" x 2-1/8"	1
23	Spring Pin 1/4" x 2"	1
24	Overshot Head	1




OVERSHOT HOU EZY LOCK OVERSHOT HOU



ITEM	DESCRIPCIÓN	CANT.
1-5	Cable Swivel Assembly	1
6	Cable Swivel Body	1
7	Grease Fitting 1/4"	1
8	Upper Body	1
9	Spring Pin 3/16" x 1-1/8"	1
10	Pump-In Lip Seal	2
11	Seal Seat	1
12	Ball 22mm	1
13	Landing Indicator Bushing	1
14	Overshot Head	1
15	Compression Spring Lifting Dog	1
16	Lifting Dog	1
17	Plain Pin 1/2" x 2-1/8"	1
18	Spring Pin 1/4" x 2"	1



ITEM	DESCRIPCIÓN	CANT.
1-5	Cable Swivel Assembly	1
6	Grease Fitting 1/4"	1
7	Cable Swivel Body	1
8	Jar Staff	1
9	Jar Tube	1
10	Locking Sleeve	1
11	Hexagonal Nut 3/4"	1
12	Nord Lock	1
13	Сар	1
14	Compression Spring Overshot	1
15	Sleeve Safe Locking	1
16	Compression Spring Ball	1
17	Ball 11/32"	2
18	Set Screw Nyloc	1
19	Compression Spring Lifting Dog	1
20	Lifting Dog	2
21	Locking Pin	1
22	Plain Pin 1/2" x 3-1/4"	1
23	Spring Pin 1/4" x 2"	1
24	Overshot Head	1
25	Head Sleeve PWL	1





EXPLOTOOLS

FERRAMENTAS PARA MINERAÇÃO













X www.explotools.com.br