

AnimeNotify Operating Manual

ESP32-C3 anime and movie notifier with OLED display, Wi-Fi alerts, buttons, LEDs, and buzzer output.

Overview

AnimeNotify shows anime and movie schedule information on a 128x64 SH1106 OLED. It connects to Wi-Fi, loads title data, displays alert timing, and supports a small set of configurable settings.

Controls

- OK: short press to select or open, long press to go back or exit cursor mode.
 - Left / Right: move through titles and list items.
 - Home screen cursor mode can be enabled from the settings or by using left/right on the home screen.
-

Home Screen

- The home screen shows the current titles and a blinking cursor when cursor mode is active.
 - Use left/right to move the cursor across titles.
 - Press OK on a title to open the detail screen.
 - Long press OK to leave cursor mode or return from details to the home screen.
-

Details Screen

- The detail screen shows the selected title, its status, airing time, and description text.
 - Left/right can scroll through longer detail text.
 - The screen returns to the home view automatically when the configured timeout expires, if enabled.
-

Settings

- Brightness.
- LED alerts.
- Buzzer alerts.
- Low power mode.
- Auto low power trigger: 5%, 10%, 15%, or Never.
- Buzzer lead time: 2m before, 5m before, 10m before, or on time.
- Refresh interval: 5m, 15m, 30m, or 60m.
- Home cursor default on boot.
- Detail screen auto-return timeout.
- Screen sleep timeout.

- Clock format: 12-hour or 24-hour.
 - Description source: full or short summary.
-

LED Behaviors

The left LED is a status indicator and uses different blink patterns to show what the device is doing. The right LED is a PWM alert indicator that lights during the lead-up to an airing alert.

- Wi-Fi connecting: the left LED blinks every 500 ms while the device is trying to connect.
- Connected, but title data still loading: the left LED blinks every 700 ms until the first data load finishes.
- Wi-Fi connection failed: the left LED uses a double-pulse pattern to show a connection problem.
- Movie or anime fetch failed: the left LED lights in a short repeating blink to indicate a failed refresh.
- Temporary data-change flash: the left LED gives a quick double-flash when fresh data arrives or a change is detected.
- Upcoming airing alert: when the selected title is within 300 seconds of airing on the same day, the left LED blinks slowly and the right LED is driven with PWM brightness.
- Buzzer timing: when the lead-time threshold is reached, the buzzer can fire before the airing time if buzzer alerts are enabled.

If LED alerts are turned off in settings, these alert patterns are suppressed.

Hardware / Pins

- OLED SDA: GPIO8
 - OLED SCL: GPIO9
 - OK button: GPIO6
 - Left button: GPIO7
 - Right button: GPIO3
 - Battery ADC: GPIO0
 - Buzzer: GPIO21
 - Left LED: GPIO20
 - Right LED: GPIO1
-

Setup Notes

- Flash the firmware with PlatformIO.
 - Enter Wi-Fi credentials and any required API settings in the project configuration.
 - Open the device on power-up and allow the first refresh to complete before judging data load status.
-

Troubleshooting

- If the home screen is empty, check Wi-Fi, refresh status, and API access.
- If the LEDs stay off, confirm LED alerts are enabled.

- If the device sleeps too early, increase the screen sleep or low power thresholds in settings.
-

License

This project is released under the MIT License. See the repository LICENSE file for the full text.