

Fictional Maintenance SOP — Falcon-1

Synthetic training document for the DefenceOps AI portfolio project. This procedure is fictional and intended only for software demonstration.

1. Routine Inspection

Before routine maintenance, switch the Falcon-1 OFF, disconnect external loads, and allow the unit to cool. Inspect the exterior for cracks, loose panels, damaged cables, and blocked ventilation openings.

2. Cleaning Procedure

Use a clean, dry cloth to remove dust from external surfaces. Keep moisture away from electrical connectors and the control panel. Do not insert tools or objects into ventilation openings.

3. Battery Module Check

Inspect the battery casing and visible terminals. If corrosion, leakage, swelling, or a cracked casing is observed, stop the procedure and refer the unit to an authorized technician. Do not attempt to open the battery module.

4. Maintenance Record

Record the inspection date, equipment identifier, observed condition, and the name or identifier of the person performing the inspection. Any unresolved issue should be recorded as pending technician review.

5. Completion

After maintenance, confirm that all external panels are secure, ventilation openings are clear, and no tools or cleaning materials remain near the equipment. The unit should remain OFF if an unresolved fault is present.