

MATLAB

matlab.mathworks.com

Ask Gemini

HOME

PLOTS

APPS

FIGURE

FORMAT

TOOLS

Copy Figure

Print

Show Code

Save As

FILE

Title

Subtitle

X-Label

Y-Label

Z-Label

Legend

Colorbar

Grid

X-Grid

Y-Grid

MATLAB Drive

untitled4

Files

FDMA CASE1.M

Workspace

Name	Value	Size	Class
CBW	200	1x1	double
fc	[100,300,500]	1x3	double
fs	1000	1x1	double
m	1x1001 double	1x1001	double
s1	1x1001 double	1x1001	double
s2	1x1001 double	1x1001	double
s3	1x1001 double	1x1001	double
t	1x1001 double	1x1001	double
TBW	600	1x1	double
Users	3	1x1	double

```
1 clc; clear; close all;
2 fs=1000; t=0:1/fs:1;
3 TBW=600; Users=3;
4
5 CBW=TBW/Users;
6 fc=[100 300 500];
7 m=sin(2*pi*10*t);
8 s1=m.*cos(2*pi*fc(1)*t);
9 s2=m.*cos(2*pi*fc(2)*t);
10 s3=m.*cos(2*pi*fc(3)*t);
11 subplot(2,1,1)
12 plot(t,s1,'r',t,s2,'g',t,s3,'b'),grid on
13 title('FDMA Channel Allocation'),xlabel('Time (s)'),ylabel('Amp]
14 subplot(2,1,2)
15 bar(1:Users,CBW*ones(1,Users)),grid on
16 xlabel('Users'),ylabel('Channel Bandwidth (kHz)'),title('Channe]
```

Command Window

New to MATLAB? See resources for [Getting Started](#).

>>

Figure 1

FDMA Channel Allocation

Channel Bandwidth per User

34°C Sunny

Search

ENG IN

10:25 15-07-2026



