
Bode Plot Code

The transfer function is


$$H_1(s) = rac{1000}{0.01s+1} \cdot rac{1}{0.001s+1} = rac{1000}{(0.01s+1)(0.001s+1)}$$



Root Locus Code

The transfer function is

$$H_2(s)=rac{s}{s^3+5s^2+2s}$$



Nyquist Plot Code

The transfer function is

$$H_3(s) = rac{10}{(s+2)(s+4)}$$

