/demux_18_tb/in1 000		001	010	011	100	101	110	111
/demux_18_tb/in2								
/demux_18_tb/out1 0000	00001	00000010	00000100	00001000	00010000	00100000	01000000	10000000
11111		.1						70000 ps 8000