

Aircraft Structural Repair: Standards for Metallurgy, Composite Architecture, and Airworthiness Compliance

Aviation Standards Division

May 24, 2026

Document ID: MRO-SR-HB-008

Contents

1	Structural Repair Architecture, Regulatory Framework, and ATA Alignment	3
1.1	Theory, Concepts, & Operations	3
1.2	Quantitative Specifications & Limits	5
2	Metallurgical Properties and Heat Treatment of Aerospace Aluminum Alloys	6
2.1	Theory, Concepts, & Operations	6
2.2	Quantitative Specifications & Limits	8
3	Titanium and High-Strength Steel Alloy Fabrication and Repair Constraints	9
3.1	Theory, Concepts, & Operations	9
3.2	Quantitative Specifications & Limits	11
4	Composite Material Architecture, Cure Kinetics, and Damage Tolerance	12
4.1	Theory, Concepts, & Operations	12
4.2	Quantitative Specifications & Limits	13
5	Non-Destructive Testing (NDT) Protocols for Structural Integrity Verification	14
5.1	Theory, Concepts, & Operations	14
5.2	Quantitative Specifications & Limits	16
6	Fastener Selection, Hole Preparation, and Interference Fit Mechanics	17
6.1	Theory, Concepts, & Operations	17
6.2	Quantitative Specifications & Limits	19
7	Riveting Techniques, Flush Countersinking, and Solid/Shank Fastener Installation	20
7.1	Theory, Concepts, & Operations	20
7.2	Quantitative Specifications & Limits	22
8	Structural Bonding: Surface Preparation, Adhesive Chemistry, and Cure Profiles	23
8.1	Theory, Concepts, & Operations	23
8.2	Quantitative Specifications & Limits	25
9	Sheet Metal Forming, Bending Allowances, and Joggling Calculations	26
9.1	Theory, Concepts, & Operations	26

9.2	Quantitative Specifications & Limits	27
10	Corrosion Identification, Chemical Treatment, and Preventative Coatings	28
10.1	Theory, Concepts, & Operations	28
10.2	Quantitative Specifications & Limits	29
11	Damage Assessment, Allowable Damage Limits (ADL), and Repair Design Margins	30
11.1	Theory, Concepts, & Operations	30
11.2	Quantitative Specifications & Limits	32
12	Airworthiness Documentation, Logbook Entries, and Structural Repair Manual (SRM) Compliance	33
12.1	Theory, Concepts, & Operations	33
12.2	Quantitative Specifications & Limits	34
Appendix D:	Daily Airframe Structural Repair Checklist	35
12.3	Operational Checklist Overview and Theory	35
12.4	Quantitative Checklist Items and Tolerances	36

Chapter 1

Structural Repair Architecture, Regulatory Framework, and ATA Alignment

1.1 Theory, Concepts, & Operations

The structural airworthiness of transport category commercial aircraft is strictly governed by the comprehensive design mandates of 14 CFR Part 25, specifically under Subpart C which regulates airframe structural limits. The structural integrity framework requires the aircraft fuselage, wings, and control surfaces to safely sustain limit loads without suffering detrimental permanent deformation, and ultimate loads without experiencing catastrophic structural separation or collapse. Maintenance, tracking, and structural modification operations are organized globally using the Air Transport Association (ATA) iSpec 2200 numbering system, which partitions airframe systems across dedicated chapters. Chapter 51 establishes general standard practices for structural components, Chapter 52 manages passenger and cargo door assemblies, Chapter 53 controls fuselage structural frames, Chapter 54 dictates nacelle and pylon structures, Chapter 55 governs vertical and horizontal stabilizers, Chapter 56 regulates flight deck and cabin windows, and Chapter 57 manages wing spars, skins, and high-lift structural components.

The underlying certification methodology for modern civil aviation transport aircraft relies on the damage-tolerance design paradigm codified in 14 CFR Section 25.571. This structural engineering philosophy operates on the baseline assumption that initial material micro-flaws, fatigue cracks, or manufacturing defects already exist within primary aircraft structures. The damage-tolerance design framework mandates that the airframe must successfully sustain these pre-existing flaws under cyclic aerodynamic loading and environmental stress throughout its service life. The micro-flaws must not propagate to a critical failure length before being detected and resolved during scheduled maintenance inspections. This damage-tolerance methodology heavily utilizes linear elastic fracture mechanics to calculate crack growth behaviors and establish safe inspection intervals. Fatigue crack growth rates within metallic airframe components are mathematically evaluated utilizing the Paris-Erdogan material law. This relationship models how cyclic stress ranges and geometric correction factors combine to alter the stress intensity factor at the crack tip, driving macro-crack propagation through the structural element.

When a structural repair patch or reinforcement doubler is engineered for an aircraft skin,

the repair design must fully restore the original static strength, fatigue life limit, and damage-tolerance parameters of the original parent structure. Federal Aviation Administration (FAA) Advisory Circular AC 43.13-1B defines the baseline acceptable methods for minor structural repairs. However, major structural repairs require engineering data derived from the manufacturer's Structural Repair Manual (SRM) or custom approvals from a Designated Engineering Representative (DER). Load transmission across a repaired skin joint depends entirely on matching the axial and bending stiffness of the repair doubler to the parent structure. Any significant mismatch in structural stiffness will induce high localized stress concentrations along the boundary of the repair patch, accelerating fatigue crack initiation in the adjacent parent metal. Structural repair engineers must perform finite element analysis and classical hand calculations to verify that bearing, bypass, and net-tension stresses within the repair zone remain safely below the allowable material design limits.

1.2 Quantitative Specifications & Limits

Structural certification under 14 CFR Part 25 mandates that the ultimate load capability of any primary or secondary aircraft structural component must be calculated by applying a precise multiplier factor of exactly 1.5 times the maximum calculated limit load of the airframe structure without experiencing material failure. The fatigue crack growth rate within metallic airframe components is mathematically modeled using the Paris-Erdogan law, which is expressed by the differential fracture mechanics equation $\frac{da}{dN} = C(\Delta K)^m$, where the variable a represents the physical crack length, the variable N defines the absolute number of applied cyclic aerodynamic loading cycles, and the parameters C and m represent material-specific empirical constants derived from laboratory testing.

The stress intensity factor range driving this fracture growth is defined by the mathematical relationship $\Delta K = Y\Delta\sigma\sqrt{\pi a}$, where the variable Y represents the dimensionless geometric correction factor specific to the structural profile, and the variable $\Delta\sigma$ defines the applied cyclic stress range experienced by the metal skin. The theoretical stress concentration factor K_t at the edge of a perfectly circular cutout or un-reinforced open hole within an isotropic infinite plate subjected to uniform uniaxial tension is established at a baseline value of exactly 3.0. All metallic material properties, allowable yield strengths, and fatigue thresholds utilized in the calculation of repair patch margins must strictly conform to the verified engineering parameters published in the MIL-HDBK-5 specification document, or the modern Composite Materials Handbook CMH-17 for advanced composite structures.

Chapter 2

Metallurgical Properties and Heat Treatment of Aerospace Aluminum Alloys

2.1 Theory, Concepts, & Operations

High-strength aerospace aluminum alloys are the primary structural materials utilized across commercial transport airframes, dominated by the aluminum-copper 2000-series family and the aluminum-zinc 7000-series family. The 2024 aluminum alloy, typically processed to the T3 or T351 temper, exhibits exceptional fracture toughness and superior resistance to cyclic fatigue crack propagation under tensile loads. Because of these performance parameters, the 2024-T3 aluminum alloy sheet is the global standard material specified for fuselage external skins and lower wing skin tension panels where cyclic tensile stresses dominate during flight. Conversely, the 7075 aluminum alloy processed to the T6 temper delivers maximum mechanical yield and tensile strengths, making it ideal for upper wing skins and structural floor beams subjected to severe compressive loads. However, 7075-T6 aluminum possesses high vulnerability to stress corrosion cracking (SCC) and rapid exfoliation corrosion along its short transverse grain boundaries when exposed to marine environments or industrial electrolytes.

To mitigate stress corrosion cracking liabilities in thick structural forgings, 7000-series aluminum alloys are deliberately overaged to the T73, T7351, or T76 tempers. This overaging heat treatment precipitates the internal strengthening phases more coarsely and discontinuously along the internal grain boundaries of the alloy, effectively disrupting the continuous anodic path required to drive intergranular corrosion propagation. The mechanical properties of these rolled and forged aluminum alloys are highly anisotropic. The longitudinal grain direction exhibits the highest net tensile strength, the long transverse grain direction displays intermediate strength properties, and the short transverse grain direction possesses the lowest mechanical strength and the highest susceptibility to intergranular delamination. Structural repair doublers must be nested and cut so that the primary tensile loads of the airframe align precisely with the longitudinal grain direction of the repair doubler sheet.

To isolate high-strength core aluminum from pitting and galvanic corrosion, aluminum sheets are standardly manufactured as Alclad materials, which feature a metallurgically bonded surface layer of high-purity aluminum on both sides. This pure aluminum cladding acts as a sacrificial

anode, providing continuous cathodic protection to the copper-rich or zinc-rich core alloy underneath. Any machining, mechanical blending, or chemical blending that penetrates the Alclad layer exposes the reactive core alloy, requiring the immediate application of a chemical conversion coating to restore local corrosion resistance. The heat treatment of aluminum requires three distinct phases: solution heat treatment, rapid quenching, and precipitation aging. Solution heat treatment requires heating the alloy to dissolve the alloying elements into a homogeneous solid solution. This is immediately followed by rapid water quenching to freeze the supersaturated solid solution at room temperature, placing the alloy in the highly formable but low-strength W temper. The final airworthy mechanical strength is achieved via precipitation hardening, executed either naturally at room temperature or artificially inside a precision-controlled aging oven.

2.2 Quantitative Specifications & Limits

The high-purity sacrificial pure aluminum surface cladding layer integrated onto Alclad aerospace sheets must be manufactured to maintain a uniform physical thickness ranging from a minimum of 2.5% to a maximum of 5.0% of the total sheet cross-sectional thickness per side. Solution heat treatment for 2024 aluminum alloy sheets must be executed by heating the material within a highly restricted temperature window ranging from a minimum of 900°F to a maximum of 930°F (482°C to 499°C), followed immediately by a rapid cold water quench completed within a critical transition window of less than 10 seconds to fully lock in the supersaturated solid solution state.

Artificial precipitation aging for high-strength zinc-stabilized 7075-T6 aluminum alloys must be executed inside a calibrated thermal oven maintained at a continuous soaking temperature of exactly 250°F (121°C). If a 7000-series alloy requires overaging to the T73 or T7351 stress-corrosion-resistant temper configuration, a secondary high-temperature aging stage must be executed within an oven environment controlled between a minimum of 325°F and a maximum of 360°F (163°C to 182°C). All mechanical strength margins, yield metrics, and fatigue thresholds utilized during the engineering of the repair doubler must be verified against the grain direction orientation tables, ensuring that the lower short transverse alloy strength limits are applied if multi-axial loading crosses the short transverse grain boundary axis.

Chapter 3

Titanium and High-Strength Steel Alloy Fabrication and Repair Constraints

3.1 Theory, Concepts, & Operations

Advanced titanium alloys, dominated by the alpha-beta Ti-6Al-4V (Grade 5) formulation and the near-alpha Ti-3Al-2.5V composition, are strategically selected for critical structural components operating in high-temperature zones, high-load engine pylons, and severe galvanic corrosion environments. Within the Ti-6Al-4V metallurgy, the aluminum alloying element functions as an alpha-phase stabilizer that provides high-temperature creep resistance, while the vanadium element acts as a beta-phase stabilizer that permits heat-treatment response and enhances material ductility. Fabrication, machining, and structural repair operations involving titanium alloys present severe technical challenges. Titanium possesses an intense chemical affinity for atmospheric oxygen, nitrogen, and hydrogen at elevated temperatures. Consequently, any structural gas tungsten arc welding or thermal cutting operations must be performed inside an inert argon gas chamber or under a comprehensive trailing gas shield. Failure to isolate the hot metal allows atmospheric gases to diffuse into the surface layer, creating a brittle interstitial solid solution known as alpha-case. This alpha-case layer acts as a severe crack initiation site that degrades the fatigue life of the titanium component and must be removed prior to return-to-service.

Furthermore, titanium alloys exhibit a high friction coefficient and low thermal conductivity, making them susceptible to severe galling and cold-welding during machining and fastener installation. Machining titanium requires rigid setups, extremely sharp solid carbide tooling, low cutting speeds, high feed rates, and high-pressure cutting fluids to prevent rapid work hardening. Titanium structural fasteners must be pre-treated with specialized dry film lubricants or micro-encapsulated anti-seize compounds to prevent galling and thread seizure during assembly. For ultra-high-strength structural fittings, landing gear cylinders, and engine mount bolts, High-Strength Low-Alloy (HSLA) steels, such as 300M, 4340M, and 4330M, are utilized. The primary degradation vulnerability of these ultra-high-strength steels is hydrogen embrittlement. This failure mechanism occurs when atomic hydrogen diffuses into the high-strength iron lattice, migrating toward regions of high triaxial tensile stress where it weakens the atomic bonds and triggers sudden, catastrophic brittle fracture without any prior plastic deformation. Hydrogen

is standardly introduced during electroplating, acid pickling, chemical stripping, or corrosion removal. To prevent embrittlement failure, components must undergo a mandatory hydrogen embrittlement relief bake immediately following any chemical processing. Cadmium plating is heavily restricted due to solid metal embrittlement risks, and is replaced by Ion Vapor Deposited (IVD) aluminum or zinc-nickel alloy coatings.

3.2 Quantitative Specifications & Limits

Ultra-high-strength low-alloy structural steels, including the 300M and 4340M formulations utilized in landing gear strut assemblies, are heat-treated to achieve extreme mechanical capabilities, establishing an ultimate tensile strength that exceeds a baseline threshold of 280,000 psi. To systematically mitigate the risk of catastrophic hydrogen embrittlement, any high-strength steel component that undergoes chemical stripping, acid cleaning, or electrolytic plating must be transferred into a calibrated thermal baking oven within a maximum processing time window not to exceed 4.0 hours from the completion of the hydrogen-introducing operation.

The standard hydrogen embrittlement relief baking protocol mandates that the high-strength steel component must be continuously heated at a regulated temperature of 375°F plus or minus 25°F ($191^{\circ}\text{C} \pm 14^{\circ}\text{C}$) for an uninterrupted dwell duration of a minimum of 24.0 hours to facilitate the complete out-diffusion of trapped atomic hydrogen from the metal lattice. Following any mechanical grinding or abrasive machining operations performed on landing gear cylinders or high-strength steel fittings, a mandatory Nital etch inspection must be executed in strict accordance with the ASTM E1417 specification standard to check for localized grinding burns and untempered martensite microstructures; zero grinding burn indications are permitted for airworthiness compliance.

Chapter 4

Composite Material Architecture, Cure Kinetics, and Damage Tolerance

4.1 Theory, Concepts, & Operations

Advanced composite architectures are widely deployed across modern transport airframe structures, utilizing Carbon Fiber Reinforced Polymers (CFRP) and Glass Fiber Reinforced Polymers (GFRP) embedded within high-performance thermosetting epoxy or bismaleimide (BMI) matrices. The structural efficiency of Carbon Fiber Reinforced Polymer laminates is derived from the exceptional axial stiffness and tensile strength of the carbon filaments. Because individual unidirectional composite plies are highly anisotropic, structural engineers stack plies in distinct fiber orientation sequences to construct a quasi-isotropic laminate. A balanced and symmetric layup sequence ensures that the 0-degree plies absorb axial bending and tensile stresses, the plus-minus 45-degree plies resist torsional shear loads and provide impact damage tolerance, and the 90-degree plies provide transverse stability and Poisson's ratio control. Consolidation and curing of these composite laminates require precise control over temperature ramp rates, positive autoclave pressures, and internal vacuum bag drops.

Positive autoclave pressure forces the individual pre-preg plies together to achieve the target fiber volume fraction while compressing volatile gases back into solution, suppressing the formation of internal voids. Simultaneously, a continuous vacuum bag drawdown extracts trapped moisture and low-molecular-weight outgassing products from the curing laminate. The polymerization reaction of thermosetting epoxy resins is highly exothermic; the heat generated by molecular cross-linking must be closely managed via step-staged autoclave temperature profiles to prevent thermal runaway, which causes local matrix degradation and severe internal residual stresses. The real-time degree of cure is monitored using dielectric sensors or differential scanning calorimetry of witness coupons to verify that the final glass transition temperature (T_g) meets structural specifications. Sandwich panel configurations utilize thin Carbon Fiber Reinforced Polymer face sheets bonded to a lightweight Nomex aramid paper or aluminum honeycomb core, providing high bending stiffness with a minimal mass penalty. Damage to sandwich panels often manifests as core crush or face-sheet disbond under impact loads, which drastically lowers local buckling resistance. Composite repair requires the complete removal of the damaged zone, the machining of a tapered scarf joint or stepped-lap profile, and the consolidation of engineered repair plies using localized silicone heat blankets and vacuum bagging.

4.2 Quantitative Specifications & Limits

The fabrication and curing parameters for airworthy Carbon Fiber Reinforced Polymer (CFRP) structures must be controlled to achieve a target fiber volume fraction ranging from a minimum of 60.0% to a maximum of 65.0% of the total laminate volume, while maintaining a net internal void content strictly below a maximum limit of 1.0% of the cross-section. Autoclave consolidation must apply a continuous isostatic positive pressure up to a maximum limit of 100 psi, while the internal vacuum bagging system maintains a continuous drawdown ranging from a minimum of 22 inches of mercury to a maximum of 29 inches of mercury (≥ 22 inHg) throughout the primary heating cycle.

The cross-linking reaction must be verified to ensure that the final glass transition temperature (T_g) of the cured aerospace epoxy matrix achieves an airworthy thermal threshold ranging from a minimum of 250°F to a maximum of 350°F (121°C to 177°C). The machining of a repair cavity within a solid composite laminate requires the fabrication of a precise scarf joint taper; the required scarf taper ratio for primary load-bearing flight structures must be prepared within a strict range from a minimum slope of 1:20 to a maximum flat slope of 1:50 to minimize interfacial peel stresses along the bondline. During the localized curing of the replacement plies using a silicone heat blanket, the spatial placement of monitoring thermocouples must ensure that the repair zone reaches the target cure temperature without exceeding the maximum thermal degradation limit of the surrounding parent composite matrix.

Chapter 5

Non-Destructive Testing (NDT) Protocols for Structural Integrity Verification

5.1 Theory, Concepts, & Operations

Non-Destructive Testing (NDT) protocols represent the primary quality assurance and compliance mechanisms required to verify the structural integrity of airframe components and validate the quality of executed repairs without causing material degradation. Eddy Current Testing (ET) is the primary electromagnetic modality specified for the evaluation of conductive aerospace materials, dominated by aluminum and titanium alloys. Eddy Current Testing is utilized to detect surface and near-surface fatigue cracks, map subsurface corrosion thinning, measure non-conductive paint layer thicknesses, and verify the electrical conductivity of heat-treated alloys to check for thermal damage. The physics of this inspection method relies on a high-frequency probe coil inducing an alternating magnetic field into the conductive alloy, which generates localized circulating eddy currents. Any structural discontinuity, such as a fatigue crack or an intergranular corrosion boundary, disrupts the normal eddy current flow paths, altering the electrical impedance of the probe coil, which is processed and displayed on an NDT impedance plane screen. The standard depth of eddy current penetration is governed by a skin depth equation containing variables for excitation frequency, material magnetic permeability, and electrical conductivity. Low-frequency probes are utilized to penetrate deep into multi-layered structures, while high-frequency probes deliver high resolution for micro-cracks.

Ultrasonic Testing (UT) leverages high-frequency acoustic waveforms to detect internal flaws, calculate material thickness dimensions, and evaluate bondline integrity across composite laminates and metallic sandwich structures. Pulse-echo ultrasonic configurations are standard for monolithic skins, where the precise time-of-flight of the reflected longitudinal acoustic wave determines the depth of an internal defect. For complex geometries, radii, or structural welds, angle-beam shear wave ultrasonic probes are deployed, requiring the application of Snell's Law to calculate the exact refraction angle of the wave as it passes from the plastic wedge into the metal component. In composite aircraft structures, Ultrasonic Testing is critical to isolate internal delaminations, porosity, and adhesive disbonds. Radiographic Testing (RT) utilizes X-rays or gamma rays to inspect internal cellular structures, honeycomb cores, and deep multi-layered

assemblies where ultrasonic energy is scattered. The sensitivity of a radiographic exposure must be verified utilizing Image Quality Indicators (IQIs), also called penetrameters, placed directly on the source side of the target object. Fluorescent Penetrant Inspection (FPI) and Magnetic Particle Inspection (MPI) are deployed to capture surface-breaking micro-defects using specialized developers and controlled ultraviolet black-light environments.

5.2 Quantitative Specifications & Limits

The standard electromagnetic skin depth δ defining the effective penetration depth for an aerospace Eddy Current Testing probe assembly must be calculated using the fracture mechanics wave equation $\delta = \frac{1}{\sqrt{\pi f \mu \sigma}}$, where the variable f represents the operational excitation frequency of the probe coil, the variable μ defines the magnetic permeability of the metal alloy, and the variable σ represents the electrical conductivity of the material. Ultrasonic Testing equipment specified for the inspection of internal flaws and composite delamination tracking must be calibrated to operate within an acoustic frequency spectrum ranging from a minimum of 1 MHz to a maximum of 10 MHz.

Radiographic Testing (RT) quality control mandates that the geometric unsharpness U_g of the final developed radiographic film must be calculated using the geometric optics formula $U_g = \frac{f \cdot t}{D}$, where the variable f defines the exact focal spot size of the X-ray tube emitter, the variable t represents the physical distance from the source side of the inspected object to the recording film plane, and the variable D defines the total source-to-object distance. To achieve high-resolution imaging conformant to the ASTM E1742 specification standard, the geometric unsharpness parameter U_g must be strictly limited to maximum allowable values defined by material thickness, and the film density must match the exposure charts. All NDT evaluations must be executed using reference calibration standards containing precisely machined artificial flaws, such as electrical discharge machined (EDM) notches of known depth and length.

Chapter 6

Fastener Selection, Hole Preparation, and Interference Fit Mechanics

6.1 Theory, Concepts, & Operations

The structural integrity and fatigue life expectancy of mechanically fastened airframe joints depend on the precise selection of aerospace fasteners, meticulous hole preparation, and the engineering physics of interference fit mechanics. Aerospace fasteners are manufactured to strict design standards, including Military Standard (MS), National Aerospace Standard (NAS), and Boeing Aerospace Company (BAC) specifications. Fastener material selection must be carefully matched to the parent airframe material to systematically eliminate the risk of galvanic corrosion and to ensure compatible thermal expansion coefficients across the joint. Titanium Ti-6Al-4V fasteners are the airworthiness standard for securing Carbon Fiber Reinforced Polymer composite and titanium structures, whereas iron-based A286 superalloy or Inconel 718 fasteners are mandated for high-strength steel joints and high-temperature engine zones. Aluminum alloy fasteners are strictly isolated to secondary, non-structural interior brackets due to their low shear strength and vulnerability to stress corrosion cracking.

Hole preparation represents a critical quality-control phase during structural repair execution. For close-tolerance structural bolts, the finished hole diameter must be maintained within tight tolerances, and the internal surface finish must be verified to prevent machining ridges from acting as fatigue crack initiation points. In composite structures, drilling holes requires specialized diamond-coated or solid carbide dagger drill bits combined with strict feed-rate control and rigid backing blocks to prevent exit-side delamination, matrix cracking, and fiber pull-out. Interference fit fasteners are extensively deployed within primary metallic structures to significantly extend the fatigue life of the joint. The physical installation of an interference fit bolt or sleeve intentionally forces a larger-diameter fastener shank into a smaller-diameter reamed hole. This mechanical mismatch induces a permanent radial compressive residual stress field immediately surrounding the fastener hole. This compressive field counteracts the applied cyclic tensile flight loads, effectively retarding fatigue crack initiation and slow crack growth. The radial stress distribution can be modeled using thick-walled cylinder equations derived from Lamé's structural theory. Countersinking is utilized for flush external skin joints to maintain aerodynamic smoothness. The depth of the countersink must be tightly managed to prevent a knife-edge condition, where the remaining material thickness beneath the countersink head is

insufficient to bear the clamp-up loads, leading to a sheet pull-through failure.

6.2 Quantitative Specifications & Limits

The finished hole diameter tolerance for the installation of close-tolerance aerospace bolts must be maintained within a tight engineering window restricted between a minimum of +0.0005 inches and a maximum of -0.0000 inches relative to nominal specifications. The internal surface roughness of the prepared fastener hole must not exceed a maximum limit of exactly 125 micro-inches R_a . The radial interference dimension I for a structural interference fit fastener installation must be precisely calibrated to range from a minimum of 1.0% to a maximum of 3.0% of the nominal fastener shank diameter.

The mechanical reaming parameters for a standard 3/16-inch Hi-Lok interference-fit pin installation must produce a finished hole diameter constrained within a tight range from a minimum of 0.1890 inches to a maximum of 0.1900 inches. To prevent a catastrophic knife-edge condition within flush countersunk joints, the minimum remaining un-countersunk material thickness (keel layer) at the base of the sheet must be maintained at an absolute lower limit of 0.005 inches for thin sheet panels, or meet the specific minimum percentage thickness profiles mandated within the manufacturer's Structural Repair Manual (SRM).

Chapter 7

Riveting Techniques, Flush Countersinking, and Solid/Shank Fastener Installation

7.1 Theory, Concepts, & Operations

Solid shank aluminum rivets, notably the AN470 universal head series and the AN426 or MS20426 100-degree flush head series, are the primary mechanical fasteners utilized to secure metallic airframe skin splices, longitudinal stringers, and internal structural frame connections. The physical installation of a solid rivet requires the application of mechanical compressive force to upset the protruding driven shank end, forming an expanded shop head that mechanically locks the sheet layer stack and induces a continuous structural clamp-up force. The physical dimensions of the formed shop head are strictly regulated by airworthiness criteria. Deviations from these dimensional limits—such as over-driven, undersized, cracked, or asymmetric shop heads—will result in inadequate joint clamp-up and a severe reduction in net fastener shear strength, requiring immediate drill-out and replacement of the defective rivet. Rivet upset is executed utilizing either a pneumatic rivet hammer matched with a heavy steel bucking bar, or an automated pneumatic-hydraulic rivet squeezer. Squeeze riveting is preferred for accessible structures because it delivers uniform, controlled material deformation, eliminates acoustic vibrations, and minimizes the risk of work-hardening the rivet shank prior to full hole filling.

For high-strength primary load-bearing joints, specialized multi-piece fasteners, such as Hi-Loks and lockbolts, are deployed. Hi-Lok fastener assemblies feature an internally threaded pin combined with a specialized collar incorporating a machined hexagonal wrench flat breakout. During installation, the collar is torqued onto the pin until the hexagonal wrench flats cleanly shear off at a pre-calibrated torque threshold, ensuring a consistent, repeatable, and easily inspectable structural preload without requiring a torque wrench. Blind fasteners, such as CherryMAX or Huck blind rivets, are mandated for closed structural cells, trailing edges, and box sections where physical access to the bucking side of the joint is structurally impossible. These blind fasteners utilize an internal mechanical locking collar and a drawing stem to form a blind head against the interior skin face. The pulling tools must be maintained perfectly perpendicular to the aircraft skin during installation to prevent skewed blind heads or stem retention failures. Inspection of installed fasteners requires visual and mechanical verification

of head flushness, checking that the proud or recessed limits are within SRM parameters, and confirming that the thread engagement beyond the collar falls within acceptable bounds.

7.2 Quantitative Specifications & Limits

The physical installation design limits for a properly upset solid shank rivet mandate that the finished driven shop head diameter D_{shop} must measure exactly 1.5 times the nominal rivet shank diameter ($1.5 \cdot D_{nominal}$), and the finished driven shop head height H_{shop} must measure exactly 0.5 times the nominal rivet shank diameter ($0.5 \cdot D_{nominal}$), as verified using a calibrated rivet tool gauge or dial caliper. The mechanical edge distance for any fastener hole must be maintained within a tight operational envelope ranging from an absolute minimum edge distance of 2.0 times the nominal fastener diameter ($2.0 \cdot D_{fastener}$) to a maximum edge distance of 4.0 times the nominal fastener diameter ($4.0 \cdot D_{fastener}$) measured from the center of the hole to the edge of the sheet.

The rivet pitch, defined as the linear spacing distance between adjacent rivets within a single rows layout, must be maintained within a range from a minimum pitch of 3.0 times the nominal rivet diameter ($3.0 \cdot D_{rivet}$) to a maximum pitch of 4.0 times the nominal rivet diameter ($4.0 \cdot D_{rivet}$) to prevent localized sheet wrinkling or net-section tensile tearing. Following installation, an external flush aerodynamic fastener must not stand proud of the surrounding aircraft skin surface by more than a maximum limit of exactly 0.003 inches. The mechanical thread protrusion for an installed Hi-Lok structural pin must verify that a minimum of 0.5 threads to a maximum of 2.0 threads are fully visible showing beyond the face of the compressed locking collar.

Chapter 8

Structural Bonding: Surface Preparation, Adhesive Chemistry, and Cure Profiles

8.1 Theory, Concepts, & Operations

Structural adhesive bonding represents a critical airframe joining methodology that distributes flight loads continuously across the entire faying surface of the joint. This continuous load path eliminates the high stress concentrations inherent to mechanical riveting or bolting, delivering superior high-cycle fatigue performance, enhanced sealing, and optimal aerodynamic smoothness. The structural integrity and environmental durability of a bonded joint depend entirely on the rigorous chemical and mechanical surface preparation of the adherends. Adhesive failure, which manifests as a disbond directly at the metal-to-adhesive interface, is typically caused by surface contamination and is considered a critical structural failure mode. Conversely, cohesive failure occurs when the material shears within the adhesive matrix itself, representing a properly processed bond. For high-strength aluminum alloys, the airworthiness standard for surface preparation involves alkaline degreasing followed by Phosphoric Acid Anodizing (PAA) or the application of an aggressive chemical conversion coating, such as Pasa-Jell 105. Phosphoric Acid Anodizing chemically forces the growth of a highly porous, micro-columnar aluminum oxide surface layer that provides mechanical interlocking for the liquid or film adhesive primer.

The cleanliness and wet-energy state of the prepared metal surface must be verified immediately prior to adhesive application utilizing a manual water break test. Deionized water is poured over the treated metal surface, and the fluid film must remain continuous and unbroken without pulling away from the edges, confirming the complete elimination of hydrophobic organic oils. For composite carbon-fiber adherends, surface preparation involves abrasive grit blasting using aluminum oxide media to abrade the glossy molded resin surface, followed by a double-cloth solvent wipe using methyl ethyl ketone (MEK) or pure acetone. The structural adhesives specified for primary aircraft repairs are predominantly two-part liquid epoxies or heat-curable structural film adhesives backed by woven nylon carrier scrim layers. Film adhesives are preferred for large skin doublers because they provide precise bondline thickness control and a consistent resin-to-catalyst chemical ratio. The cure profile of the structural adhesive is tightly governed by a time-temperature-pressure schedule requiring localized vacuum bagging, precise thermocouple

monitoring arrays, and calibrated silicone heat blankets to prevent void formation and ensure the joint achieves full cross-linking.

8.2 Quantitative Specifications & Limits

The manual water break cleanliness validation test executed on a chemically prepared metal substrate requires that a continuous film of deionized water must remain unbroken and stable across the treated surface for a minimum duration of exactly 30 seconds to certify the surface energy state for bonding. The internal bondline thickness of a cured structural film adhesive assembly must be tightly controlled using integrated glass beads or woven nylon carrier scrims to remain within a strict thickness range from a minimum of 0.003 inches to a maximum of 0.008 inches to maximize lap shear performance.

Mechanical certification of the bonded structural joint requires the execution of destructive testing on representative witness coupons; lap shear strength verification must conform to the parameters of the ASTM D1002 standard, and peel strength evaluation must be executed in accordance with the ASTM D1876 standard. Environmental durability and moisture hydration resistance of the active adhesive matrix system must be validated utilizing a standard wedge crack test conformant to the ASTM D3762 protocol. This test requires tracking the rate of crack propagation along the bondline interface under high-humidity conditions to ensure it remains below the maximum allowable limits mandated within the Structural Repair Manual (SRM).

Chapter 9

Sheet Metal Forming, Bending Allowances, and Jogging Calculations

9.1 Theory, Concepts, & Operations

The fabrication of metallic sheet metal repair parts, reinforcement doublers, and structural angle brackets requires a comprehensive understanding of plastic deformation mechanics, material bend allowances, and elastic springback behavior. When a flat aluminum sheet is mechanically bent within a brake press, the material layers located along the outside radius of the bend are subjected to severe tensile elongation stresses, whereas the material layers located along the inside radius of the bend undergo intense compressive forces. Located within the cross-section of the sheet is a theoretical plane that experiences zero strain, designated as the structural neutral axis. As the inside bend radius decreases, this neutral axis physically shifts inward toward the inside compressed surface of the bend. The exact mathematical location of this neutral axis is quantified by the material-specific empirical K-factor, which defines the ratio of the distance from the inside surface to the neutral axis relative to the total sheet thickness.

Calculating the precise Bend Allowance (BA) is mandatory for flat-pattern layout engineering. The Bend Allowance represents the exact arc length of the material's neutral axis through the transition zone of the bend. An error in the Bend Allowance calculation will produce a fabricated part that is either too long or too short, causing fastener hole misalignment and structural pre-loading during assembly. The minimum allowable bend radius for a specific aluminum sheet is strictly limited by the alloy's ductility and its current heat treatment temper. Squeezing a high-strength aluminum sheet past its minimum bend radius will induce severe tensile micro-cracking along the external radius of the bend or compressive wrinkling along the interior face, violating airworthiness standards. Following the removal of the forming load, the metal undergoes elastic springback, causing the final bend angle to open slightly. To compensate for this, technicians must over-bent the sheet by an empirically derived angle. Jogging is the specialized process of forming a localized offset or step within a sheet metal panel to allow a lap joint to sit completely flush with the surrounding airframe skin. Jogging introduces complex multi-axial stresses and localized thinning within the transition zone, requiring the addition of relief cuts and generous radius transitions to prevent crack initiation.

9.2 Quantitative Specifications & Limits

The mathematical formula specified for calculating the exact flat-pattern layout length of a bent sheet metal segment is defined by the Bend Allowance equation $BA = \frac{\pi}{180} \times \theta \times (R + K \times T)$, where the variable BA represents the calculated neutral axis arc length, the variable θ defines the final bend angle measured in degrees, the variable R represents the designated internal bend radius, the parameter K is the dimensionless material K-factor, and the variable T defines the nominal thickness of the sheet metal.

The structural engineering calculation for the material setback distance from the mold line is defined by the formula $SB = K_{setback} \cdot (R + T)$, where the variable SB represents the setback distance and $K_{setback}$ is the geometric setback factor. For a standard right-angle bracket configuration featuring an exact 90-degree bend, the geometric setback factor $K_{setback}$ is established at a precise value of exactly 1.000. For a bracket assembly featuring a obtuse 45-degree support brace bend, the geometric setback factor $K_{setback}$ is calibrated to an explicit value of exactly 0.414. High-strength 2024-T3 aluminum sheets must be bent transversely relative to the rolling grain direction, or must conform to larger minimum inside bend radius tables to prevent surface cracking.

Chapter 10

Corrosion Identification, Chemical Treatment, and Preventative Coatings

10.1 Theory, Concepts, & Operations

Corrosion represents a pervasive electrochemical degradation mechanism that attacks airframe structures, reducing the load-bearing cross-sectional area, degrading material mechanical properties, and acting as a severe structural stress concentrator that accelerates fatigue crack initiation. Aerospace structures are vulnerable to multiple distinct corrosion morphologies depending on alloy chemistry and environmental exposure. Surface pitting appears as localized cavities that can rapidly penetrate thick skin sections. Intergranular corrosion selectively attacks the grain boundaries of improperly heat-treated aluminum. Exfoliation corrosion propagates rapidly along the elongated grain structures of extrusions and rolled sheets, generating high internal pressures from corrosion byproducts that cause the metal layers to swell, delaminate, and distort the surrounding structure. Fretting corrosion occurs at the faying surfaces of tightly clamped joints subjected to continuous high-frequency, low-amplitude flight vibrations, generating abrasive aluminum oxide debris that accelerates wear and initiates fatigue cracks.

The structural evaluation of identified corrosion requires calculating the exact depth of material loss utilizing precision depth dial indicators or ultrasonic thickness gauges. This material loss must be compared directly against the Allowable Damage Limits (ADL) defined in the manufacturer's Structural Repair Manual (SRM). If the corrosion depth falls within acceptable boundaries, the technician must execute a meticulous blend-out procedure, grinding the pocket to a smooth, gradual radius with strict slope transitions to eliminate stress risers. Mitigating and preventing subsequent corrosion requires the immediate application of specialized chemical conversion coatings and protective primers to passivate the bare metal surface. Chemical conversion coatings, such as Alodine 1201, react with the aluminum substrate to construct a micro-crystalline chrome-oxide surface layer that prevents atmospheric oxidation and provides an optimal anchor profile for subsequent paint adhesion. Components are then coated with high-performance primers, such as two-part epoxy-polyamide systems. Legacy primers relied on strontium chromate pigments for active corrosion inhibition. However, due to modern health regulations, non-chromate primers utilizing rare-earth inhibitors are increasingly mandated. Faying surfaces must be sealed with polysulfide sealants to exclude moisture and eliminate crevice corrosion.

10.2 Quantitative Specifications & Limits

The manual chemical surface passivation process utilizing an Alodine 1201 hexavalent chromium solution on an un-anodized bare aluminum repair surface requires a strict active chemical dwell time duration ranging from a minimum of 2.0 minutes to a maximum of 5.0 minutes before executing a complete deionized water flush to halt the acid reaction. The initial drying time baseline for a zinc chromate primer layer conformant to the TT-P-1757 safety specification is restricted between a minimum of 1.0 hour and a maximum of 2.0 hours to allow full solvent evaporation prior to topcoat paint application.

The operational handling parameters for a standard two-part polysulfide Class B-1/2 structural faying surface sealant mandate that the compound must be fully mixed, applied, and clamped within a maximum workable life limit not to exceed exactly 30 minutes (≤ 30 min). Following assembly, the Class B-1/2 polysulfide sealant must be allowed to sit undisturbed through a full structural curing time requirement of a minimum of 24 hours at room temperature before subjecting the airframe cabin to mechanical pressure testing or flight loads. If corrosion removal requires mechanical blending, the repair pocket must be ground out to establish a smooth, gradual slope transition ratio specified at a minimum of 1:20 (1 inch of depth drop per 20 inches of horizontal blend length) to prevent stress concentration.

Chapter 11

Damage Assessment, Allowable Damage Limits (ADL), and Repair Design Margins

11.1 Theory, Concepts, & Operations

The executing of a structural repair design requires a rigorous analytical engineering assessment of the airframe damage to ensure that the restored assembly satisfies all regulatory ultimate load, limit load, and long-term damage-tolerance tracking criteria. The manufacturer's Structural Repair Manual (SRM) defines explicit boundaries for Allowable Damage Limits (ADL) across various airframe coordinate zones. These tables dictate the maximum allowable dimensions for dents, scratches, gouges, and punctures that can safely remain in service without an emergency repair doubler, or that can be resolved via simple mechanical blend-out. For advanced carbon-fiber composite structures, the evaluation of Barely Visible Impact Damage (BVID) represents a critical safety requirement. Barely Visible Impact Damage occurs when a low-velocity impact—such as a dropped maintenance tool or runway stone strike—leaves only a tiny, negligible indentation on the exterior face sheet that can easily be missed during a visual pre-flight walk-around. However, this minor surface impact can generate extensive internal matrix cracking, core crushing, and multi-layered ply delamination inside the core structure, severely reducing the laminate's Compression After Impact (CAI) strength. Technicians must deploy ultrasonic C-scan or tap testing to map the true spatial boundary of the internal delamination, which frequently extends far beyond the visible surface dent.

When engineering a bonded or mechanically bolted doubler repair patch over an aircraft skin cutout, the repair design must account for the mechanical phenomenon of shear lag. In a bonded lap joint, the longitudinal shear stress is not distributed uniformly across the linear length of the adhesive layer. Instead, the shear stress peaks severely at the extreme edges of the overlap patch and decays to near zero within the central zone of the bondline. This highly non-uniform stress distribution is mathematically scaled by a shear lag parameter containing variables for adhesive shear modulus, adhesive thickness, and the elastic modulus and thickness of the respective metal sheets. To prevent premature peel and cleavage failures at the borders of the repair patch, the edge of the doubler must be meticulously tapered or feathered down to a thin gauge, gradually transitioning the structural stiffness and minimizing localized peel

stresses. For mechanically fastened bolted patches, the repaired joint must be evaluated across multiple separate failure modes: net-tension fracture across the new fastener holes, shear-out tearing of the sheet edge, localized bearing failure of the hole wall, and direct fastener shear failure.

11.2 Quantitative Specifications & Limits

During composite structural damage assessments, an entry-point indentation depth limit of less than 0.100 inches is classified as Barely Visible Impact Damage (BVID), which mandates the immediate execution of a comprehensive automated ultrasonic C-scan inspection to map hidden internal delamination zones. The engineering mathematical formula governing the calculation of the shear lag scaling parameter λ along a structural bonded lap joint is defined by the relationship $\lambda = \sqrt{\frac{G_a}{t_a} \left(\frac{1}{E_1 t_1} + \frac{1}{E_2 t_2} \right)}$, where the variable G_a represents the active shear modulus of the adhesive layer, the variable t_a defines the precise physical thickness of the bondline, the parameters E_1 and E_2 represent the elastic modulus properties of the parent skin and repair doubler respectively, and the variables t_1 and t_2 define the thickness dimensions of the respective sheets.

The structural engineering guidelines for major structural repairs mandate that a new repair patch or reinforcement doubler plate designed to restore an aerodynamic skin cutout must be selected from an aluminum stock sheet that is manufactured to be exactly 1.0 gauge thickness thicker than the original parent skin panel thickness being repaired. This thickness over-sizing provides the necessary margin to absorb eccentric secondary bending moments induced by single-sided patch geometries under tensile flight loads, while maintaining the bearing-bypass stress profiles within the safe boundaries of the bearing-bypass interaction diagram.

Chapter 12

Airworthiness Documentation, Logbook Entries, and Structural Repair Manual (SRM) Compliance

12.1 Theory, Concepts, & Operations

The legal airworthiness and regulatory return-to-service authorization of any commercial or transport category aircraft following a structural repair alteration depend on the meticulous execution of mandatory compliance documentation. These actions are legally mandated under the federal oversight of 14 CFR Part 43 regulations. A structural repair is legally classified as a major repair if the modification has the potential to appreciably alter the airframe's weight and balance profile, net structural strength, aerodynamic performance, engine pylon characteristics, or fundamental flight behavior. All major structural repairs must be executed in strict accordance with FAA-approved technical data, which includes the manufacturer's Structural Repair Manual (SRM), specific Supplemental Type Certificates (STCs), or customized engineering repair schemas authorized and signed off by a Designated Engineering Representative (DER) utilizing an official FAA Form 8110-3 engineering release document.

Upon the physical completion of the structural repair layout and inspection sequence, the certifying licensed airframe mechanic or quality inspector must compile a comprehensive permanent maintenance logbook entry in strict compliance with 14 CFR Section 43.9. This mandatory entry must explicitly describe the initial damage profile, record the exact alphanumeric identifiers of the SRM chapters, figures, and revision levels utilized, and document the specific part numbers, heat lot codes, and material specifications of all installed aluminum sheets and titanium fasteners. The entry must also document the precise numerical results of all mandatory Non-Destructive Testing evaluations, including Eddy Current crack checks and ultrasonic validation metrics. Furthermore, all major repairs require the successful completion of FAA Form 337 (Major Repair and Alteration). This form serves as the permanent centralized archive of the structural modification and is filed directly with the regulatory authority. Every segment of raw metal stock, pre-preg carbon fiber composite tape, structural film adhesive, and high-strength blind fastener utilized during the repair must possess full material traceability backed by an official Certificate of Conformance (C of C) or material test report verifying its chemical composition and heat treatment history, ensuring complete airworthiness compliance.

12.2 Quantitative Specifications & Limits

All permanent aircraft maintenance logbook entries, airworthiness return-to-service certifications, and regulatory sign-offs executed under the authority of 14 CFR Part 43 must be completely finalized, validated, and entered into the permanent airframe record system within a maximum administrative window of exactly 24 hours following the physical completion of the structural repair or inspection task. The finalized documentation must explicitly record the current calendar date, the absolute total airframe operating hours, the total landing cycle counts, the specific Airworthiness Directive (AD) tracking numbers, the Designated Engineering Representative (DER) Form 8110-3 release codes, and the unique handbook identifier (Document ID: MRO-SR-HB-008).

The physical execution of a crack arrest modification requires that the tip of an identified fatigue crack must be immediately modified by drilling a precise stress-relief hole; the stop-drill hole must be completed using a calibrated number 30 drill bit centered precisely over the crack tip, and subsequently finished using a high-precision mechanical reamer tool to establish a perfect, burr-free stop-drill crack tip diameter measuring exactly 0.125 inches (1/8-inch). Every single structural material element, curing adhesive batch, and high-strength fastener lot number must match its associated Certificate of Conformance records; zero material tracking gaps are permitted for airworthiness compliance.

Appendix D: Daily Airframe Structural Repair Checklist

12.3 Operational Checklist Overview and Theory

This section establishes the mandatory quantitative verification gates, dimensional tolerances, and processing constraints required during daily structural walkarounds, line repair modifications, and complete wheel-end or airframe overhaul inspections. To ensure full system compatibility with real-time voice-to-compliance vector retrieval systems and automated RAG chunking algorithms, all quantitative data, fastener distances, hole diameters, chemical dwell times, and sealant curing limits have been entirely reconstructed into dense, context-rich prose sentences. This approach systematically eliminates all traditional tabular grids, lists, or matrix-based structures from the body of this chapter. Every sentence is engineered to carry both the specific operational maintenance task and its exact numerical limit together, ensuring that standard vector chunk windows retrieve complete, actionable data points. Technicians must perform each check utilizing the specific tools indicated, verifying compliance against the exact parameters before authorizing return-to-service.

12.4 Quantitative Checklist Items and Tolerances

Maintenance technicians executing a structural repair inspection must verify that the mechanical edge distance for any fastener hole is maintained within a tight operational range from an absolute minimum edge distance of 2.0 times the nominal rivet diameter ($2.0 \cdot D_{\text{rivet}}$) to a maximum edge distance of 4.0 times the nominal rivet diameter ($4.0 \cdot D_{\text{rivet}}$), measured precisely from the center of the hole to the edge of the sheet panel. The rivet pitch, defining the linear spacing distance between adjacent rivets within a single row layout, must be maintained within a range from a minimum pitch of 3.0 times the nominal rivet diameter ($3.0 \cdot D_{\text{rivet}}$) to a maximum pitch of 4.0 times the nominal rivet diameter ($4.0 \cdot D_{\text{rivet}}$) to prevent localized sheet buckling or net-section tensile tearing. Following solid shank rivet installation, the finished driven shop head diameter D_{shop} must measure exactly 1.5 times the nominal rivet shank diameter ($1.5 \cdot D_{\text{nominal}}$), and the finished driven shop head height H_{shop} must measure exactly 0.5 times the nominal rivet shank diameter ($0.5 \cdot D_{\text{nominal}}$), as verified using a calibrated dial caliper or rivet tool gauge.

The execution of a crack arrest modification requires that the tip of an identified fatigue crack must be immediately modified by drilling a precise stress-relief hole; the stop-drill hole must be completed using a calibrated number 30 drill bit centered precisely over the crack tip, and subsequently finished using a high-precision mechanical reamer tool to establish a perfect, burr-free stop-drill crack tip diameter measuring exactly 0.125 inches (1/8-inch). The structural engineering calculation for the material setback distance from the mold line must be computed using the sheet metal bend formula $SB = K \cdot (R + T)$, where the variable SB represents the setback, K is the material K-factor, R is the inside bend radius, and T is the sheet thickness. For a standard right-angle bracket configuration featuring an exact 90-degree bend, the geometric setback factor K is established at a precise value of exactly 1.000. For an accessory bracket assembly featuring an oblique 45-degree support brace bend, the geometric setback factor K is calibrated to an explicit value of exactly 0.414.

Mechanical reaming parameters for a standard 3/16-inch close-tolerance Hi-Lok interference-fit pin installation must produce a finished hole diameter constrained within a tight range from a minimum of 0.1890 inches to a maximum of 0.1900 inches. Following collar installation, the mechanical thread protrusion for the Hi-Lok pin must verify that a minimum of 0.5 threads to a maximum of 2.0 threads are fully visible showing beyond the face of the compressed locking collar. The manual chemical surface passivation process utilizing an Alodine 1201 solution on an un-anodized bare aluminum repair surface requires a strict active chemical dwell time duration ranging from a minimum of 2.0 minutes to a maximum of 5.0 minutes before executing a complete deionized water flush to halt the acid reaction. The initial drying time baseline for a zinc chromate primer layer conformant to the TT-P-1757 safety specification is restricted between a minimum of 1.0 hour and a maximum of 2.0 hours to allow full solvent evaporation prior to topcoat paint application.

Operational handling parameters for a standard two-part polysulfide Class B-1/2 structural faying surface sealant mandate that the compound must be fully mixed, applied, and clamped within a maximum workable life limit not to exceed exactly 30 minutes (≤ 30 min). Following assembly, the Class B-1/2 polysulfide sealant must be allowed to sit undisturbed through a full structural curing time requirement of a minimum of 24 hours at room temperature before subjecting the airframe cabin to mechanical pressure testing or flight loads. Finally, structural engineering guidelines for major structural alterations mandate that a new repair patch or

reinforcement doubler plate designed to restore an aerodynamic skin cutout must be selected from an aluminum stock sheet that is manufactured to be exactly 1.0 gauge thickness thicker than the original parent skin panel thickness being repaired, in full compliance with FAA Form 337 Major Repair guidelines.