Lead and Copper Site Tiers*

Version: 02_01_2020V1

Tier level	Туре	AW Required Documentation	Documentation Examples	Note Requirements
	Single family home - Lead service line (company		Pictures of either pipe excavated via test hole, OR lead	
Tier I	side)	Visual support	pipe visual in a meter box\vault	Explanation of picture(s) location
			Pictures of either pipe excavated via test hole, lead pipe	
	Single family home - Lead service line (customer		visual in meter box\vault, OR lead line entering through	
	side)	Visual support	foundation wall for domestic plumbing	Explanation of picture(s) location
			Document suporting structure built in this time frame, tap	
		Tap card, building permit, etc.	card for new service install for example AND results from	
	Single family home with copper plumbing with	to support structure age AND	swab testing from interior plumbing. Minimum three (3)	
	lead solder constructed after 1982 (1983 - 1986**)	swab test	non-consecutive joints swabbed.	Notes of where swabbing occurred
	Building or multi family with lead service lines		Pictures of pipe excavated via test hole, lead pipe visual in	
Tier II	(company and/or customer side)	Visual support	meter box, OR lead line stubbing through foundation wall	Explanation of picture(s) location
			Document suporting structure built in this time frame, (tap	
			card for new service install for example) AND results from	
	Building or multi family with copper plumbing with		swab testing from interior plumbing. Minimum three (3)	
	lead solder constructed after 1982 (1983 - 1986**)	Visual and swab test	non-consecutive joints swabbed.	Notes of where swabbing occurred
	For a system where insufficient Tier I OR Tier II are		Tap card for house demonstrating construction before 1983	
	available then utilize single family structures that	Tap card, building permit, etc.	AND customer survey card and confirmation of copper	Notes of where swabbing occurred.
	have copper with lead solder constructed before	to support structure age AND	plumbing. Minimum three (3) non-consecutive joints	Explanation of why no Tier I or Tier II sites are
Tier III	1983	swab test	swabbed.	available
	For all other systems where <i>insufficient</i> Tier I, Tier			
	II or Tier III sites are available. Use sites with		Tap card for house demonstrating construction after	Explanation of why no Tier I, Tier II or Tier III
Other	copper plumbing after 1986**	Tap card\survey card	1986** and confirmation of copper pipe	are available

^{*} Based upon EPA interpetations, if your state has more stringent guidlines, please follow state guidance

^{* *} In states where lead solder may have been banned after 1986 (1988 for example), such states may use that year