

EdgeAI Predictive Monitor -- Motor-Driver Rig Wiring

Arduino Uno + CNC Shield V3; one driver per axis, shared ~ENABLE active-LOW on D8.

Set each driver's current-limit trimpot before running: A4988 Vref = I_{max} x 8 x R_{sense}, DRV8825 Vref = I_{max} / 2.

