

FreshFlow Beverages Pvt. Ltd.

FreshFlow Bottling Plant - Pune Production Facility
FSSAI: 10012022000345 | ISO 22000:2018 / ISO 14001:2015

STANDARD OPERATING PROCEDURE

Cleaning Procedure for Quality Line 29

Department: Quality

Document Number: SOP-029
Revision: Rev 4.2
Classification: CONFIDENTIAL - INTERNAL USE ONLY
Prepared by: Engineering / QA Department
Approved by: Plant Manager

Document Control Information

Parameter	Value
SOP Number	SOP-029
Title	Cleaning Procedure for Quality Line 29
Department	Quality
Plant	FreshFlow Bottling Plant - Pune Production Facility
Prepared By	Employee 10
Reviewed By	Anita Desai
Approved By	Rajesh Kulkarni - Plant Manager
Issue Date	2022-02-12
Next Review Date	2027-05-14
Revision	Rev 3.1

1. Purpose

Ensure finished product, process parameters, and plant operations comply with FreshFlow quality specifications, HACCP plan, and regulatory requirements.

2. Scope

Quality Control team, Shift Supervisors, and Department Operators.

3. Prerequisites and Requirements

3.1 Training Requirements

- QC analyst training
- HACCP awareness training (ISO 22000)

3.2 Tools and Materials Required

- Calibrated instruments as listed in the plant calibration schedule.
- Appropriate PPE as specified in Section 4.
- Completed permit-to-work (if required for maintenance activities).
- Access to relevant equipment manual and P&ID drawings.
- CMMS access to create and close work orders.

4. Health, Safety and Environmental Requirements

! WARNING

This SOP must not be carried out without appropriate PPE and, where required, a valid Permit to Work (SOP-SAF-006). If in doubt about safety, STOP and consult the Safety Officer (EMP009 / EMP017).

4.1 Identified Hazards

- Laboratory chemicals - acids, alkalis, solvents
- Microbiological samples - BSL-1 biological hazard precautions

4.2 Emergency Response

In case of any emergency during this procedure: Press the nearest Emergency Stop, alert personnel in the vicinity, call the Safety Officer and Shift Supervisor. Refer to the Emergency Response Plan (SOP-SAF-004) and site evacuation procedure.

5. Detailed Procedure

5.1 Pre-Task Verification

1. Confirm the relevant equipment is available and no conflicting activities are planned.
2. Check shift handover log for any outstanding issues with this equipment.
3. Verify all required materials, tools, and chemicals are available and correctly labelled.
4. Obtain all required permits (PTW, hot work, confined space as applicable).
5. Brief all involved personnel on this SOP before starting.

5.2 Main Procedure

1. Confirm production has stopped and product has been drained from the system.
2. Ensure CIP supply pump P301 is ready and CIP tanks have correct chemical charge.
3. Connect CIP return line and verify all CIP circuit valves are in correct position.
4. Start pre-rinse with RO water for 5 minutes - verify runoff is clear.
5. Switch to caustic recirculation: 2% NaOH at 75°C for 20 minutes minimum.
6. Monitor caustic concentration with inline conductivity meter - maintain 15-20 mS/cm.
7. Flush with RO water until conductivity <100 uS/cm and pH 6.5-7.5.
8. Perform acid circulation: 1% HNO₃ at 65°C for 15 minutes (passivation step).
9. Final rinse with RO water until conductivity <20 uS/cm and pH 6.5-7.5.
10. Take microbiological swab from defined sample points. Record in QC log.
11. Equipment is released for production only after QC verification (Form FFB-QA-CIP-VER).