

FreshFlow Beverages Pvt. Ltd.

FreshFlow Bottling Plant - Pune Production Facility
FSSAI: 10012022000345 | ISO 22000:2018 / ISO 14001:2015

STANDARD OPERATING PROCEDURE

Sanitization Procedure for Packaging Line 27

Department: Packaging

Document Number: SOP-027
Revision: Rev 1.2
Classification: CONFIDENTIAL - INTERNAL USE ONLY
Prepared by: Engineering / QA Department
Approved by: Plant Manager

Document Control Information

Parameter	Value
SOP Number	SOP-027
Title	Sanitization Procedure for Packaging Line 27
Department	Packaging
Plant	FreshFlow Bottling Plant - Pune Production Facility
Prepared By	Employee 20
Reviewed By	Rajesh Kulkarni
Approved By	Rajesh Kulkarni - Plant Manager
Issue Date	2024-02-05
Next Review Date	2026-05-10
Revision	Rev 2.0

1. Purpose

Pack finished product into secondary and tertiary packaging to protect product integrity and enable safe storage and distribution.

2. Scope

Packaging department operators and warehouse team.

3. Prerequisites and Requirements

3.1 Training Requirements

- Packaging machinery operation training
- Forklift certification (if applicable)

3.2 Tools and Materials Required

- Calibrated instruments as listed in the plant calibration schedule.
- Appropriate PPE as specified in Section 4.
- Completed permit-to-work (if required for maintenance activities).
- Access to relevant equipment manual and P&ID drawings.
- CMMS access to create and close work orders.

4. Health, Safety and Environmental Requirements

! WARNING

This SOP must not be carried out without appropriate PPE and, where required, a valid Permit to Work (SOP-SAF-006). If in doubt about safety, STOP and consult the Safety Officer (EMP009 / EMP017).

4.1 Identified Hazards

- Shrink tunnel (160-200°C) - severe burn if hands inserted
- Robotic cell - robot arm can move unexpectedly if safeguarding bypassed
- Forklift traffic - pedestrian collision risk in warehouse zone

4.2 Emergency Response

In case of any emergency during this procedure: Press the nearest Emergency Stop, alert personnel in the vicinity, call the Safety Officer and Shift Supervisor. Refer to the Emergency Response Plan (SOP-SAF-004) and site evacuation procedure.

5. Detailed Procedure

5.1 Pre-Task Verification

1. Confirm the relevant equipment is available and no conflicting activities are planned.
2. Check shift handover log for any outstanding issues with this equipment.
3. Verify all required materials, tools, and chemicals are available and correctly labelled.
4. Obtain all required permits (PTW, hot work, confined space as applicable).
5. Brief all involved personnel on this SOP before starting.

5.2 Main Procedure

1. Confirm production has stopped and product has been drained from the system.
2. Ensure CIP supply pump P301 is ready and CIP tanks have correct chemical charge.
3. Connect CIP return line and verify all CIP circuit valves are in correct position.
4. Start pre-rinse with RO water for 5 minutes - verify runoff is clear.
5. Switch to caustic recirculation: 2% NaOH at 75°C for 20 minutes minimum.
6. Monitor caustic concentration with inline conductivity meter - maintain 15-20 mS/cm.
7. Flush with RO water until conductivity <100 uS/cm and pH 6.5-7.5.
8. Perform acid circulation: 1% HNO₃ at 65°C for 15 minutes (passivation step).
9. Final rinse with RO water until conductivity <20 uS/cm and pH 6.5-7.5.
10. Take microbiological swab from defined sample points. Record in QC log.
11. Equipment is released for production only after QC verification (Form FFB-QA-CIP-VER).

6. Quality and Verification Checks

Verification Check	When	Responsible	Record
All product contact surfaces visually clean	Before production	Operator	Shift Log
CIP conductivity <=20 uS/cm	After each CIP	Operator	CIP Record
CIP pH 6.5-7.5	After each CIP	Operator	CIP Record
Microbiological swab <10 CFU/cm2	After each CIP	QC Lab	Micro Report
Key process parameters in normal range	At startup	Operator	SCADA Historian
First-off product sample - Brix, pH, CO2	After startup	QC Analyst	QC Lab Report

7. Non-Conformance and Escalation

If any check fails or if the procedure cannot be completed as written: STOP the task. Do not force equipment to operate outside specification. Escalate to the Shift Supervisor (Suresh Patil / Ravi Deshpande). Raise a Non-Conformance Report (NCR) in the CMMS system. QC Manager (Anita Desai) must be notified for any product safety impact.