

FA_IOTv4.2 **GSM LDO CIRCUIT** 4.2V/2.4A OUT 5 GSML ADJ ΕN 10uf10uf 10uf GND PG GSMP/2.1A GS GND SIM_VDD/4.1A SIM_DATA/4.2 В SIM_GND/4.2 11 GND TXD1 EX_ANT 10 GND RESET 9 VCC V_BCKP ANT_DET MI 1PPS FORCE_ON GND С **GSM ON/OFF** GSMP/2.1A PWR_KEY Q5 BC547 D GSM_PWR **GSM Antenna** Ε 0R_{GND@0} C52 NM C53 NM CON-HIROSE-COAXIAL-U.FL GND



