

1 Modern Use Cases Tools

- RTOSes like FreeRTOS, Zephyr, or RTEMS use PIP/PCP.
- Formal verification tools: UPPAAL, SPIN, TLA+ for protocol correctness.
- Mention automotive standards (e.g., AUTOSAR OS supports SRP).