

Attendance Logger: Quick Guide

For lecturers and staff who take attendance with the card reader.

Students tap their ID card on the reader. The device stores the card number and time, and answers with a **light** and a **buzz**. The companion app on the computer later shows who attended each lecture.

Taking attendance in four steps

1 Switch on Press the button once. Green light and a short buzz.	2 Tap cards Hold each card flat on the reader for a moment until it buzzes.	3 Next lecture Hold the button until it buzzes (2 s), then let go. Or start it from the app.	4 Plug in Connect USB-C to the computer and open the companion app to see the results.
---	---	---	--

What the lights and buzzes mean

 **How to read the pictures:** each strip shows about 1.5 seconds from left to right. The top bar is the light (**green** or **red**), the zig-zag underneath is the vibration buzz.

WHEN A CARD IS TAPPED

	Green + one short buzz	Recorded. A registered card.
	Red + one long buzz	Recorded, but the card is not registered. Register it in the companion app (see page 2). The tap is kept.
	Green + two quick buzzes	Already recorded in this lecture. Not counted again. Nothing to do. The student is already marked present.
	Red flashing 4 times, buzzing	Not recorded: the memory is full. Plug into the computer and start a lecture from the app (this empties the device).

WHEN YOU USE THE BUTTON

	Green + short buzz	Switched on and ready for cards.
	Two green blinks	Battery is fine (after a quick tap of the button).
	A buzz while you hold, no light	2 seconds reached. Let go now to start a new lecture.
	Green + three quick buzzes	A new lecture has started. Every card counts again.
	Red + long buzz	Switching off. Also happens by itself after 3 minutes without a tap.

AFTER USING A COMPUTER

	Green + two buzzes	Settings accepted. The reader is on and taking cards.
	Red + three buzzes	Settings refused. Nothing changed. Open <code>STATUS.TXT</code> on the drive: it says which line is wrong.

WARNINGS

	Red blinking 5 times, no buzz	Battery low. If it was already very low the device then switches off. Charge it with the USB-C cable.
	Red flashing 4 times + buzzes, at switch-on	The card reader did not start. Switch off (hold 5 s) and on again. If it repeats, get it serviced.

The power button

WHAT YOU DO	WHAT HAPPENS
Press once (device off)	Switches on: green light and a short buzz.
Quick tap (device on)	Shows the battery: two green blinks = fine, red blinking 5 times = low. While the device is a USB drive on a computer, a tap ends that and starts taking cards instead.
Hold 2 s until it buzzes, then let go	Starts the next lecture (green + three quick buzzes). It keeps the module name and counts the lecture on: <i>Lecture 4</i> becomes <i>Lecture 5</i> .
Keep holding for 5 s	Switches off (red + long buzz). No lecture is started.

On battery the device switches itself off after **3 minutes** without a tap. Press the button to wake it. Your records are safe: they are kept when it switches off.

Lectures and double taps

- Each student counts **once per lecture**, even if the device slept in between. A second tap gets two quick buzzes.
- When one lecture ends and the next begins, start a new lecture (hold the button 2 s, or use the app). Then everyone counts again.
- If you never start a lecture, a card already recorded in the last 6 hours still counts only once.

Using it with the computer

- Plug the device in with the USB-C cable. A drive called **ATTENDANCE** appears. The reader is **off** while it is a drive.
- Open the companion app. It reads the taps and shows attendance for each lecture.
- To start a lecture, use the **Lecture** tab in the app. It saves all taps, empties the device, sets the clock and ejects the drive.
- The device answers green + two buzzes and starts taking cards. **The cable can stay in:** it charges while it works.

Without the app: eject the drive, or tap the button once, to switch the reader back on.

If something is not right

PROBLEM	WHAT TO DO
Nothing happens when a card is tapped	Press the button: the device may have switched itself off. If it is plugged into a computer, the reader is off; eject the drive or tap the button.
Card does not read	Hold the card flat and still on the reader for about a second. Keep it away from phones and other cards in the same wallet.
Every tap shows red	The device does not have the latest card list. Press Send cards to device in the app.
The battery runs low quickly	Charge it fully with the USB-C cable. A tap of the button shows the battery: two green blinks = fine.
Times in the records are wrong	Set the clock: start a lecture from the app, or use Set the device clock .

Registering a new student card

- Tap the new card on the device. It shows **red** with a long buzz, but the tap **is recorded**.
- Plug the device in and open the app. The card appears under *New cards* on the Students tab.
- Press **Register** and fill in the student's details.
- Press **Send cards to device**, then eject. Green + two buzzes means it was stored.

From then on that card shows **green**.

Charging

- Charge with any USB-C charger or computer port. It keeps taking cards while it charges.
- The clock keeps running while the device is off. If the battery ever goes completely flat, set the clock again (the app does it when you start a lecture).