BIOBUZZ DRIVER QUIZ

Team 37102 · all answers are on the Driver Card

Name: _____ Date: _____ Score: _____ / 33

Circle one letter, or write the answer on the line. ★ = must know: a driver gets every ★ right.

A · BEFORE THE MATCH

1. To connect gamepad 1 to the Driver Hub you press:

A) SHARE + ✕ B) OPTIONS + ✕
C) OPTIONS + ○ D) hold R1

2. ★ The battery must read at least:

A) 11.5 V B) 12.0 V
C) 12.5 V D) 14 V

3. For AUTO you load:

A) 3 balls, anywhere B) 4 balls, one per pocket
C) 5 balls D) as many as fit

4. ★ TeleOp INIT says `Alliance RED`, but our bumpers are BLUE. Which button do you press?

_____

5. True or false: it's fine to push the robot into place while TeleOp is in INIT.

_____

6. What must the INIT screen say about the diagnostics log?

_____

B · BUTTONS

7. ★ To aim AND shoot, you:

A) tap R1 B) hold R1
C) hold □ D) press △

8. Holding □ (square):

A) fires the balls
B) aims and drives to the SHOT SPOT, no firing
C) saves the SHOT SPOT
D) unjams the windmill

9. Which button spins the flywheel up early, so it's ready when you get there?

_____

10. The windmill is jammed. What do you do?

_____

11. R2 and L2 are:

A) intake IN / OUT B) fire / aim
C) fast / slow D) flywheel up / down

12. In the normal drive mode, pushing the left stick UP drives the robot:

A) away from you B) toward its intake side
C) toward the goal D) it turns

13. How do you switch field-centric on or off in the middle of a match?

_____

C · SCORING

14. ★ Number the scoring steps 1 – 5:

____ Keep holding R1: it fires one ball at a time
____ Let go, drive off
____ Drive close, launcher toward our goal, tap △
____ Feel the buzz: screen says ON SPOT - FIRE
____ Hold R1: the robot aims and drives to the spot

15. ★ Fill in: "NO BUZZ = NO _____. Never shoot while _____."

16. You hold R1 and the screen says `FIRE HELD`. That means:

A) the robot is broken
B) it's aiming / driving to the spot; it fires anyway after 1.5 s
C) let go and press again
D) the battery is low

17. ★ The gamepad buzzes 3 times in TeleOp. What does it mean, and what do you do?

_____

D · READ THE SCREEN

18. The screen says `Shot speed AUTO 41 in 1445 +0`. Who picked 1445 t/s?

19. `Shot spot … now 58 in (+6)` means:

A) 6 in too close
B) 6 in too far
C) 6 balls left
D) speed +6

20. You pressed D-pad ↑ and the screen says MANUAL. How do you get the camera's speed back?

21. What does `Balls 12 out, results 10` mean?

22. `Launcher READY` means:

A) ok to fire
B) the windmill is full
C) the camera sees the goal
D) AUTO is done

E · FIX IT FAST

23. ★ Balls land SHORT (in front of the goal). You press:

A) D-pad → once (+10)
B) D-pad ← once
C) D-pad ↓
D) △

24. Balls go LONG (over the goal). You press:

A) D-pad →
B) D-pad ← once (−10)
C) L1
D) ○

25. ★ Balls miss to the LEFT or RIGHT. The fix:

A) D-pad ← / →
B) it's aim, not speed: let R1 aim (our goal's tags in view)
C) press ✕
D) drive faster

26. R1 doesn't aim, and the screen says `no BLUE CELL tags`, but we are RED. How do you fix it?

27. SHARE says "Can't save". How do you fix it?

F · LOG EVERY SHOT (practice)

28. The ball went IN. What do you press?

29. Fill in: L1 + D-pad ↓ = _____ · L1 + D-pad → = _____ · L1 + D-pad ← = _____

30. You logged a ball and felt 2 blips. That means:

A) saved
B) NOT saved: no ball waiting (already logged, or more than 10 s ago)
C) the flywheel is off
D) the log is full

31. ★ Why must you hold L1 while you press the D-pad to log?

32. You fired 3 balls in a row. In what order do you log them?

G · PIT CREW: SHOT SPOT

33. Number the steps 1 – 4 to save the SHOT SPOT:

___ Press SHARE (buzz + `SHOT SPOT saved`)
___ Park on the best spot, launcher facing the goal
___ Hold □, then let go (the robot squares up)
___ Check the speed: → / ← until balls land IN

Bonus (no points): the screen says `? - press Share again`. What do you do?

🔑 ANSWER KEY (coach)

fold back or keep away from the drivers

1	B · OPTIONS + ✕	Card p1, Before the match 1
2 ★	C · 12.5 V	Before the match 5: a weak battery makes the flywheel slow and shots short
3	B · 4 balls, one per pocket	Before the match 3
4 ★	✕ (= BLUE; ○ = RED)	Before the match 4: the alliance picks which goal's tags the camera aims at
5	False: keep the robot still in INIT	Before the match 4 (the heading sensor calibrates in INIT)
6	`Diagnostics log ON` (SHARE in INIT switches it)	Before the match 4
7 ★	B · hold R1	Gamepad picture: R1 hold = AIM + FIRE
8	B · aims and drives to the SHOT SPOT, no firing	Gamepad picture
9	△ (flywheel on/off)	Step 1: tap △ to spin up
10	Hold ○ (unjam) about 1 s, then R1 again	Fix it fast: Windmill stuck
11	A · intake IN / OUT	Gamepad picture
12	B · toward its intake side (robot-centric is the default)	Left stick callout
13	Hold OPTIONS 1 s (1 blip = on, 2 = off). In INIT: L1	OPTIONS callout
14 ★	4 · 5 · 1 · 3 · 2 (drive close → hold R1 → buzz → keep holding → let go)	How we score. 1 point only if all 5 are right
15 ★	SHOT · moving	The red rule bar
16	B · aiming / driving to the spot; fires anyway after 1.5 s	Fix it fast: R1 waits
17 ★	20 s left: go PARK (in the loading zone)	The red rule bar
18	The camera, from the distance (41 in)	Read the screen: Shot speed
19	B · 6 in too far	Read the screen: Shot spot
20	Press □	Read the screen: MANUAL → □ = AUTO again
21	12 balls fired, only 10 logged: 2 results missing	Read the screen: Balls · Log every shot
22	A · ok to fire	Read the screen: Launcher
23 ★	A · D-pad → once (+10)	Fix it fast: Balls land SHORT (one press at a time)
24	B · D-pad ← once (−10)	Fix it fast: Balls go LONG
25 ★	B · it's aim, not speed: let R1 aim	Fix it fast: Left / right misses. The D-pad only changes speed
26	Restart TeleOp and press ○ (RED) in INIT	Fix it fast: R1 doesn't aim
27	Turn the launcher toward our goal's tags, then SHARE again	Fix it fast: SHARE "Can't save"
28	Hold L1 + D-pad ↑	Log every shot
29	SHORT · LONG · SIDE	Log every shot. 1 point only if all 3 are right
30	B · NOT saved: no ball waiting	Log every shot: short buzz = saved, 2 blips = not saved
31 ★	The D-pad alone changes the shot speed (trim / presets)	Log every shot (red line)
32	In the order they flew (first ball first)	Log every shot
33	4 · 1 · 3 · 2 (park → check speed → hold □ → SHARE)	Card p2, Pit crew. 1 point only if all 4 are right
Bonus	Save the spot again: at the spot, press SHARE	Card p2, Test it (an old spot from before 10 Nov night)

Pass: 28 / 33 or better **and every ★ right** (2, 4, 7, 14, 15, 17, 23, 25, 31). Below that: go through the Driver Card together, then practise on the field: 10 balls with R1 from the SHOT SPOT, logging each one with L1 + D-pad.