

① Assembly Instruction	Memory Address (Hex)	Machine Language (Hex)	Location for, ,, , n
Data Part	{ 2000 2001		

main: MVI B, 02H	2100	06
	2101	02
MVI C, 03H	2102	0E
	2103	03
CALL f	2104	CD
	2105	17
	2106	21
MOV A,D	2107	7A
STA 2000H	2108	32
	2109	00
	210A	20
MVI B, 03H	210B	06
	210C	03
MVI C, 07H	210D	0E
	210E	07
CALL f	210F	CD
	2110	17
	2111	21

MOV A,D 2112 7A

STA 2001H 2113 32

2114 01

2115 20

RST5 2116 EF

f: MOV A,B 2117 78

ADD C 2118 81

ORA A 2119 B7

RAL 211A 12

MOVD,A 211B 5F

RET 211C C9

John

Red