

	2217	
	2218	B C
	2219	0 3
JMP L2	221A	C 3
	221B	0 7
	221C	22

③ This is for showing the value of keyboard for 0.5s and then for delay the value for accumulator the garbage value comes in so if only for 0.5s it shows the value we give in 8279 by keyboard