

<u>start</u>	MVI A, 82H	2000	3E
		2001	82
OUT 03H		2002	D3
		2003	03
JN 01H		2004	DB
		2005	'01
MOV B,A		2006	47
MVI A, 80H		2007	3E
		2008	80
OUT 00H		2009	D3
<u>loop</u> DCR B	-	200A	00
		200B	05
CPI , 00H		200C	FE
		200D	00
MVI A, 00H		200E	3E
		200F	00
OUT 00H		2010	D3
		2011	00
JN 2 <u>loop</u>		2012	C2
		2013	0B
JMP <u>start</u>		2014	20
		2015	C3
		2016	00
			20