



## [Errno 98] Address already in use

Error occured in line number 205



\_\_\_\_\_\_

## 

Oct 29 23:11:31 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.22.79:4334.

Oct 29 23:11:31 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).

Oct 29 23:11:32 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.22.79:4334.

Oct 29 23:11:32 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).

Oct 29 23:11:32 mcb1 auth.info sshd[8056]: Accepted password for installer from 192.168.22.79 port 56052 ssh2

Oct 29 23:11:32 mcb1 authpriv.info sshd[8056]: pam\_unix(sshd:session): session opened for user installer by (uid=0)



Expected Result : The NETCONF server replies rejecting the protocol operation with an
"access-denied" error.
=======================================
******* Actual Result ************************************
**************************************
[Errno 98] Address already in use
Access Control NMS (negative case) = FAIL