



@ FILE NAME: M_FTC_ID_040.txt

@ TEST SCOPE: M PLANE O-RAN FUNCTIONAL

@ Software Release for B40: v5.0.4

Test Description: Test to validate the success file download process.



****** Connect to the NETCONF Server ********

> connect --ssh --host 192.168.4.41 --port 830 --login operator

Interactive SSH Authentication

Type your password:

Password:

> status

Current NETCONF session:

ID : 2

Host : 192.168.4.41

Port: 830 Transport: SSH Capabilities:

urn:ietf:params:netconf:base:1.0urn:ietf:params:netconf:base:1.1urn:ietf:params:netconf:capability:writable-running:1.0

urn: ietf: params: netconf: capability: candidate: 1.0urn: ietf: params: netconf: capability: rollback-on-error: 1.0urn: i

urn: ietf: params: netconf: capability: validate: 1.1 urn: ietf: params: netconf: capability: startup: 1.0 urn: ietf: params: netconf: capability: xpath: xp

urn:ietf:params:netconf:capability:with-defaults:1.0?basic-mode=explicit&also-supported=report-all,report-all-tagged,trim,explicit

urn:ietf:params:netconf:capability:notification:1.0urn:ietf:params:netconf:capability:interleave:1.0

urn:ietf:params:xml:ns:yang:ietf-yang-metadata?module=ietf-yang-metadata&revision=2016-08-05

urn:ietf:params:xml:ns:yang:1?module=yang&revision=2017-02-20

urn:ietf:params:xml:ns:yang:ietf-inet-types?module=ietf-inet-types&revision=2013-07-15

urn:ietf:params:xml:ns:yang:ietf-yang-types?module=ietf-yang-types&revision=2013-07-15

urn:ietf:params:netconf:capability:yang-library:1.1?revision=2019-01-04&content-id=61

urn: sysrepo: plugind? module = sysrepo-plugind & revision = 2020-12-10

urn:ietf:params:xml:ns:yang:ietf-netconf-acm?module=ietf-netconf-acm&revision=2018-02-14

urn: ietf: params: xml: ns: netconf: base: 1.0? module=ietf-netconf & revision=2013-09-29 & features=writable-running, candidate, rollback-on-error, validate, rollback-on-error, rollback-o

te, startup, url, xpathurn: ietf: params: xml: ns: yang: ietf-netconf-with-defaults? module = ietf-netconf-with-defaults & revision = 2011-06-01 + ietf-netconf-with-defaults & revision = 20

urn:ietf:params:xml:ns:yang:ietf-netconf-notifications?module=ietf-netconf-notifications&revision=2012-02-06

 $urn: ietf: params: xml: ns: yang: ietf-netconf-monitoring? module = ietf-netconf-monitoring \& revision = 2010-10-04 \\ ietf-netconf-monitoring ietf-n$

urn:ietf:params:xml:ns:netconf:notification:1.0?module=notifications&revision=2008-07-14

urn:ietf:params:xml:ns:netmod:notification?module=nc-notifications&revision=2008-07-14

urn:ietf:params:xml:ns:yang:ietf-x509-cert-to-name?module=ietf-x509-cert-to-name&revision=2014-12-10

 $urn: ietf: params: xml: ns: yang: iana-crypt-hash? module = iana-crypt-hash \& revision = 2014-08-06 urn: notification_history? module = notification_hist$

urn:ietf:params:xml:ns:yang:iana-if-type?module=iana-if-type&revision=2017-01-19

******* Create Subscription ********

>subscribe

Ok



Initial Get Filter	
	===
=======================================	
> getfilter-xpath /o-ran-software-management:software-inventory	
Step 3 : TER NETCONF Client sends <pre></pre> to the O-RU NETCONF Server	
	===
> user-rpc	
******* Replace with below xml *******	
=======================================	
<reset xmlns="urn:o-ran:operations:1.0"></reset>	
	===
<pre> <reset xmlns="urn:o-ran:operations:1.0"></reset> ====================================</pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply.	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <nc:rpc-reply <="" td="" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><td>===</td></nc:rpc-reply>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply> xml version="1.0" ?	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply> xml version="1.0" ? <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"></data>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply> xml version="1.0" ? <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><<software-inventory xmlns="urn:o-ran:software-management:1.0"></software-inventory><td>===</td></data>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> </software-slot></software-inventory></data></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> </software-slot></software-inventory></data></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> </software-slot></software-inventory></data></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_WRITE</access> </software-slot></software-inventory></data></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply.	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_WRITE</access> <product-code>STL=O-RU</product-code> <vendor-code>VN</vendor-code></software-slot></software-inventory></data></pre> <access>READ_V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <access>V <a< td=""><td>===</td></a<></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access></access>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_WRITE</access> <product-code>STL=O-RU</product-code> <vendor-code>VN</vendor-code> </software-slot></software-inventory></data></nc:rpc-reply></nc:rpc-reply></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:ok></nc:ok></nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false <access>READ_WRITE</access> <product-code>STL=O-RU</product-code> <vendor-code>VN</vendor-code> <build-id>factory_img</build-id> <build-name>Beta Release</build-name></active></software-slot></software-inventory></data></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. <pre> <nc:rpc-reply message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"><nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_WRITE</access> <product-code>STL=O-RU</product-code> <vendor-code>VN</vendor-code> </software-slot></software-inventory></data></nc:rpc-reply></nc:rpc-reply></pre>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. Concrete	===
Step 4 : O-RU NETCONF Server responds with rpc-reply.	===
Step 4 : O-RU NETCONF Server responds with rpc-reply.	===
Step 4 : O-RU NETCONF Server responds with rpc-reply. -nc:rpc-reply xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="urn:uuid:fed428c1-3aba-4ae2-8b1b-1b63366c108e"> <nc:rpc-reply><?xml version="1.0" ?> <data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"> <software-inventory xmlns="urn:o-ran:software-management:1.0"> <software-slot> <name>swSlot1</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_WRITE</access> <pre> <</pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></software-slot></software-inventory></data></nc:rpc-reply>	===
Step 4 : O-RU NETCONF Server responds with rpc-reply.	===



<name>kernel</name> <version>1.0.0</version> <local-path>/media/sd-mmcblk0p1/image0001.ub</local-path> <integrity>OK</integrity> </files> <files> <name>rootfs</name> <version>1.0.0</version> <local-path>/media/sd-mmcblk0p2/</local-path> <integrity>OK</integrity> </files> </software-slot> <software-slot> <name>swSlot2</name> <status>VALID</status> <active>true</active> <running>true</running> <access>READ_WRITE</access> cproduct-code>STL O-RU <vendor-code>VN</vendor-code> <build-id>90f0b6c</build-id> <build-name>Beta Release</build-name> <build-version>5.0.4</build-version> <files> <name>boot</name> <version>1.0.0</version> <local-path>/media/sd-mmcblk0p1/BOOT0002.BIN</local-path> <integrity>OK</integrity> </files> <files> <name>kernel</name> <version>1.0.0</version> <local-path>/media/sd-mmcblk0p1/image0002.ub</local-path> <integrity>OK</integrity> </files> <files> <name>rootfs</name> <version>1.0.0</version> <local-path>/media/sd-mmcblk0p3/</local-path> <integrity>OK</integrity> </files> </software-slot> <software-slot> <name>swRecoverySlot</name> <status>VALID</status> <active>false</active> <running>false</running> <access>READ_ONLY</access>

cproduct-code>STL=O-RU



```
<vendor-code>VN</vendor-code>
 <build-id>factory_img</build-id>
 <build-name>Beta Release</build-name>
 <build-version>1.3.4</build-version>
 <files>
  <name>boot</name>
  <version>1.0.0</version>
  <local-path>/media/sd-mmcblk0p1/BOOT0003.BIN</local-path>
  <integrity>OK</integrity>
 </files>
 <files>
  <name>kernel</name>
  <version>1.0.0</version>
  <local-path>/media/sd-mmcblk0p1/golden.ub</local-path>
  <integrity>OK</integrity>
 </files>
 <files>
  <name>rootfs</name>
  <version>1.0.0</version>
  <local-path>/media/sd-mmcblk0p1/golden.ub</local-path>
  <integrity>OK</integrity>
 </files>
 </software-slot>
</software-inventory>
</data>
```

SYSTEM LOGS

- Sep 5 13:50:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:58 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:50:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:50:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:50:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:51:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:07\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:51:12 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:51:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:19 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:19\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:51:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:26 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:51:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- $Sep\ 5\ 13:51:30\ garuda\ daemon. info\ net opeer 2-server [858]:\ getsock opt ()\ error\ (Connection\ refused).$
- Sep 5 13:51:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:31\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:34\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:51:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:40 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:51:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:43\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:44 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:44\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:46\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:46 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:47\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:51:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:54 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:51:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:55\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:56\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:58\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:51:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:51:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:51:59\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:51:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:52:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- $Sep\ 5\ 13:52:08\ garuda\ daemon. info\ net opeer 2-server [858]:\ getsock opt ()\ error\ (Connection\ refused).$
- Sep 5 13:52:08 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:52:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:52:10\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:52:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:52:11\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:52:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:52:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:52:19\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:52:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:19 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:22 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:52:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:52:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:52:32\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:52:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:36 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane



- Sep 5 13:52:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:52:43\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:52:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:44 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:44 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:46 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:46 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:52:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:50 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:52:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:52:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:52:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:53:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:04 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:53:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:07\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:08\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:09\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:53:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:18 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- $Sep\ 5\ 13:53:19\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:19 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:53:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:32\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:32 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:53:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:33\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:53:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:44\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:44 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:46 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:46\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:46 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:53:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:53:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:56\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:57 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:57 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:58 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:53:58\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:53:58 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:53:59 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:53:59 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:00\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:00 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:00 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:00 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:54:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.



- Sep 5 13:54:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:01 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:01 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:02 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:02 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:03 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:03 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:04 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:04 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:05 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:05 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:06 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:06 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:07 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:07 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:08\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:08 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:08 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:09 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:09 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:10 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:10 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:11 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:11 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:12 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:12 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:54:13 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:13 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:14 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:14 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:14 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:54:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:15 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:15 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:16 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:16 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:17 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:17 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:18 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:18 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:19 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:19 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:19 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:20\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:20 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:20 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:21 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:21 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:22 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:22 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:23 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:23 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:24 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:24 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:54:25 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:25 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:26 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:26 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:27 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:27 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:28 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:28 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:28 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:54:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:29 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:29 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:30 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:30 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:31 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:31 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:32 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:32 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:33\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:33 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:33 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:34 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:34 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:35 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:35 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:36 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:36 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:54:37 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:37 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:38 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:38 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:39 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:39 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:40 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:40 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:41 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:41 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:42 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:42 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:42 garuda user.notice SYNCMNGR[1181]: Received message from S-Plane
- Sep 5 13:54:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:43 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:43 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:44\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:44 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:44 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:45\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:45 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:45 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:46 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:46\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:46 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:47 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:47 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:48\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:48 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:48 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:49 garuda auth.info sshd[7896]: Accepted password for root from 192.168.4.15 port 54920 ssh2
- Sep 5 13:54:49 garuda authpriv.info sshd[7896]: pam_unix(sshd:session): session opened for user root by (uid=0)
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Accepted a connection on :::830.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Session 92 (user "root", CID 1) created.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Received an SSH message "request-service" of subtype "ssh-userauth".
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Received an SSH message "request-auth" of subtype "password".
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: User "operator" authenticated.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Received an SSH message "request-channel-open" of subtype "session".
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Received an SSH message "request-channel" of subtype "subsystem".
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Session 93 (user "root", CID 1) created.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: There are no subscribers for "ietf-netconf-notifications" notifications.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Generated new event (netconf-session-start).
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/ietf-netconf:get" with ID 2 priority 0 for 1 subscribers.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Processing "/ietf-netconf:get" "rpc" event with ID 2 priority 0 (remaining 1 subscribers).
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Successful processing of "rpc" event with ID 2 priority 0 (remaining 0 subscribers).
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 2 priority 0 succeeded.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Session 2: thread 3 event new RPC.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/ietf-netconf:get" with ID 3 priority 0 for 1 subscribers.
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Processing "/ietf-netconf:get" "rpc" event with ID 3 priority 0 (remaining 1 subscribers).
- Sep 5 13:54:49 garuda daemon.info netopeer2-server[858]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 2.
- Sep 5 13:54:49 garuda user.notice fw_manager[935]: RPC #2 recieved. xpath -> /o-ran-software-management:software-inventory
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Event "operational" with ID 2 succeeded.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Successful processing of "rpc" event with ID 3 priority 0 (remaining 0 subscribers).
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 3 priority 0 succeeded.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.



- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Session 2: thread 1 event new RPC.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/ietf-netconf:get-config" with ID 1 priority 0 for 1 subscribers.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Processing "/ietf-netconf:get-config" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 1 priority 0 succeeded.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:50 garuda daemon.info netopeer2-server[858]: Session 2: thread 0 event new RPC.
- $Sep\ 5\ 13:54:51\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:51 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:51 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:52 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:52\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:52 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:53 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:53 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- $Sep\ 5\ 13:54:54\ garuda\ daemon. info\ net opeer 2-server [858]:\ Trying\ to\ connect\ via\ IPv4\ to\ 192.168.4.15:4334.$
- Sep 5 13:54:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:54 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:54 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).



- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/notifications:create-subscription" with ID 1 priority 0 for 1 subscribers.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Processing "/notifications:create-subscription" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 1 priority 0 succeeded.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Session 2: thread 1 event new RPC.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/ietf-netconf:get" with ID 4 priority 0 for 1 subscribers.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Processing "/ietf-netconf:get" "rpc" event with ID 4 priority 0 (remaining 1 subscribers).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 3.
- Sep 5 13:54:55 garuda user.notice fw_manager[935]: RPC #3 recieved. xpath -> /o-ran-software-management:software-inventory
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Event "operational" with ID 3 succeeded.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Successful processing of "rpc" event with ID 4 priority 0 (remaining 0 subscribers).
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 4 priority 0 succeeded.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Resolving unresolved data nodes and their constraints...
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: There is no leafref
- "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: All data nodes and constraints resolved.
- Sep 5 13:54:55 garuda daemon.info netopeer2-server[858]: Session 2: thread 2 event new RPC.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Published event "rpc" "/o-ran-operations:reset" with ID 1 priority 0 for 1 subscribers.
- Sep 5 13:54:56 garuda user.notice SR_OP[1192]: RPC recived on /o-ran-operations:reset for mplane-triggered reset
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Event "rpc" with ID 1 priority 0 succeeded.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Session 2: thread 1 event new RPC.



- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Trying to connect via IPv4 to 192.168.4.15:4334.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: getsockopt() error (Connection refused).
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Session 2: thread 1 event new RPC.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Session 2: thread 1 event session terminated.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: There are no subscribers for "ietf-netconf-notifications" notifications.
- Sep 5 13:54:56 garuda daemon.info netopeer2-server[858]: Generated new event (netconf-session-end).
- Sep 5 13:54:56 garuda authpriv.debug sshd[8417]: pam_unix(sshd:account): account operator has password changed in future
- Sep 5 13:54:56 garuda auth.info sshd[8417]: Accepted password for operator from 192.168.4.15 port 53264 ssh2
- Sep 5 13:54:56 garuda authpriv.info sshd[8417]: pam_unix(sshd:session): session opened for user operator by (uid=0)

'NoneType' object is not iterable

Error occured in line number 414

Excution_time: 60.43903970718384