@ **FILE NAME:**   **M_FTC_ID_039.txt**

@ **TEST SCOPE:**   **M PLANE O-RAN FUNCTIONAL**

@ **Software Release for B40:**   **v5.0.4**

Test Description : Test to validate the success file download process.

==

********** Connect to the NETCONF Server **********

==

> connect --ssh --host 192.168.4.41 --port 830 --login operator

   Interactive SSH Authentication

   Type your password:

   Password:

   > status

   Current NETCONF session:

   ID   : 3

   Host : 192.168.4.41

   Port : 830

   Transport : SSH

   Capabilities:

   urn:ietf:params:netconf:base:1.0urn:ietf:params:netconf:base:1.1urn:ietf:params:netconf:capability:writable-running:1.0

urn:ietf:params:netconf:capability:candidate:1.0urn:ietf:params:netconf:capability:rollback-on-error:1.0

urn:ietf:params:netconf:capability:validate:1.1urn:ietf:params:netconf:capability:startup:1.0urn:ietf:params:netconf:capability:xpath:1.0

urn:ietf:params:netconf:capability:with-defaults:1.0?basic-mode=explicit&also-supported=report-all,report-all-tagged,trim,explicit

urn:ietf:params:netconf:capability:notification:1.0urn:ietf:params:netconf:capability:interleave:1.0

urn:ietf:params:xml:ns:yang:ietf-yang-metadata?module=ietf-yang-metadata&revision=2016-08-05

urn:ietf:params:xml:ns:yang:1?module=yang&revision=2017-02-20

urn:ietf:params:xml:ns:yang:ietf-inet-types?module=ietf-inet-types&revision=2013-07-15

urn:ietf:params:xml:ns:yang:ietf-yang-types?module=ietf-yang-types&revision=2013-07-15

urn:ietf:params:netconf:capability:yang-library:1.1?revision=2019-01-04&content-id=61

urn:sysrepo:plugind?module=sysrepo-plugind&revision=2020-12-10

urn:ietf:params:xml:ns:yang:ietf-netconf-acm?module=ietf-netconf-acm&revision=2018-02-14

urn:ietf:params:xml:ns:netconf:base:1.0?module=ietf-netconf&revision=2013-09-29&features=writable-running,candidate,rollback-on-error,valida

te,startup,url,xpathurn:ietf:params:xml:ns:yang:ietf-netconf-with-defaults?module=ietf-netconf-with-defaults&revision=2011-06-01

urn:ietf:params:xml:ns:yang:ietf-netconf-notifications?module=ietf-netconf-notifications&revision=2012-02-06

urn:ietf:params:xml:ns:yang:ietf-netconf-monitoring?module=ietf-netconf-monitoring&revision=2010-10-04

urn:ietf:params:xml:ns:netconf:notification:1.0?module=notifications&revision=2008-07-14

urn:ietf:params:xml:ns:netmod:notification?module=nc-notifications&revision=2008-07-14

urn:ietf:params:xml:ns:yang:ietf-x509-cert-to-name?module=ietf-x509-cert-to-name&revision=2014-12-10

urn:ietf:params:xml:ns:yang:iana-crypt-hash?module=iana-crypt-hash&revision=2014-08-06urn:notification_history?module=notification_history

urn:ietf:params:xml:ns:yang:iana-if-type?module=iana-if-type&revision=2017-01-19

==

********** Create Subscription **********

==

==

>subscribe

==

Ok

===

 Initial Get Filter
===

===

> **get --filter-xpath /o-ran-software-management:software-inventory**
===

===

 Step 3 : TER NETCONF Client sends \<rpc\>\<reset\>\</rpc\> to the O-RU NETCONF Server..
===

===

> **user-rpc**

===

===
******* Replace with below xml *******
===
<reset xmlns="urn:o-ran:operations:1.0"></reset>
===
 Step 4 : O-RU NETCONF Server responds with rpc-reply.
===
<nc:rpc-reply xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0"
message-id="urn:uuid:a2789ee9-4810-416d-963c-81179a2c887c"><nc:ok/></nc:rpc-reply>
===
 ############ SYSTEM LOGS ##############
===

```
<?xml version="1.0" ?>
<data xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0">
 <software-inventory xmlns="urn:o-ran:software-management:1.0">
 <software-slot>
  <name>swSlot1</name>
  <status>VALID</status>
  <active>false</active>
  <running>false</running>
  <access>READ_WRITE</access>
  <product-code>STL=O-RU</product-code>
  <vendor-code>VN</vendor-code>
  <build-id>factory_img</build-id>
  <build-name>Beta Release</build-name>
  <build-version>4.2.0</build-version>
  <files>
   <name>boot</name>
   <version>1.0.0</version>
```

```
   <local-path>/media/sd-mmcblk0p1/BOOT0001.BIN</local-path>
   <integrity>OK</integrity>
  </files>
  <files>
   <name>kernel</name>
   <version>1.0.0</version>
   <local-path>/media/sd-mmcblk0p1/image0001.ub</local-path>
   <integrity>OK</integrity>
  </files>
  <files>
   <name>rootfs</name>
   <version>1.0.0</version>
   <local-path>/media/sd-mmcblk0p2/</local-path>
   <integrity>OK</integrity>
  </files>
 </software-slot>
 <software-slot>
  <name>swSlot2</name>
  <status>VALID</status>
  <active>true</active>
  <running>true</running>
  <access>READ_WRITE</access>
  <product-code>STL O-RU</product-code>
  <vendor-code>VN</vendor-code>
  <build-id>90f0b6c</build-id>
  <build-name>Beta Release</build-name>
  <build-version>5.0.4</build-version>
  <files>
   <name>boot</name>
   <version>1.0.0</version>
   <local-path>/media/sd-mmcblk0p1/BOOT0002.BIN</local-path>
   <integrity>OK</integrity>
  </files>
  <files>
   <name>kernel</name>
   <version>1.0.0</version>
   <local-path>/media/sd-mmcblk0p1/image0002.ub</local-path>
   <integrity>OK</integrity>
  </files>
  <files>
   <name>rootfs</name>
   <version>1.0.0</version>
   <local-path>/media/sd-mmcblk0p3/</local-path>
   <integrity>OK</integrity>
  </files>
 </software-slot>
 <software-slot>
  <name>swRecoverySlot</name>
  <status>VALID</status>
```

```xml
<active>false</active>
<running>false</running>
<access>READ_ONLY</access>
<product-code>STL=O-RU</product-code>
<vendor-code>VN</vendor-code>
<build-id>factory_img</build-id>
<build-name>Beta Release</build-name>
<build-version>1.3.4</build-version>
<files>
<name>boot</name>
<version>1.0.0</version>
<local-path>/media/sd-mmcblk0p1/BOOT0003.BIN</local-path>
<integrity>OK</integrity>
</files>
<files>
<name>kernel</name>
<version>1.0.0</version>
<local-path>/media/sd-mmcblk0p1/golden.ub</local-path>
<integrity>OK</integrity>
</files>
<files>
<name>rootfs</name>
<version>1.0.0</version>
<local-path>/media/sd-mmcblk0p1/golden.ub</local-path>
<integrity>OK</integrity>
</files>
</software-slot>
</software-inventory>
</data>
```

```
Apr 14 05:32:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:32:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:32:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:32:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Successfully connected to 192.168.22.208:4334 over IPv4.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Session 108 (user "root", CID 81) created.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Received an SSH message "request-service" of subtype "ssh-userauth".
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Received an SSH message "request-auth" of subtype "password".
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: User "operator" authenticated.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Received an SSH message "request-channel-open" of subtype "session".
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Received an SSH message "request-channel" of subtype "subsystem".
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Call Home client "default-client" session 2 established.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Session 109 (user "root", CID 81) created.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: There are no subscribers for "ietf-netconf-notifications" notifications.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Generated new event (netconf-session-start).
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...
Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.
```

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/ietf-netconf:get" with ID 2 priority 0 for 1 subscribers.

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Processing "/ietf-netconf:get" "rpc" event with ID 2 priority 0 (remaining 1 subscribers).

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Successful processing of "rpc" event with ID 2 priority 0 (remaining 0 subscribers).

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 2 priority 0 succeeded.

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:16 garuda daemon.info netopeer2-server[1186]: Session 2: thread 0 event new RPC.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/ietf-netconf:get" with ID 3 priority 0 for 1 subscribers.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Processing "/ietf-netconf:get" "rpc" event with ID 3 priority 0 (remaining 1 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 2.

Apr 14 05:32:17 garuda user.notice fw_manager[1261]: RPC #2 recieved. xpath -> /o-ran-software-management:software-inventory

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Event "operational" with ID 2 succeeded.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Successful processing of "rpc" event with ID 3 priority 0 (remaining 0 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 3 priority 0 succeeded.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Session 2: thread 0 event new RPC.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/ietf-netconf:get-config" with ID 1 priority 0 for 1 subscribers.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Processing "/ietf-netconf:get-config" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 1 priority 0 succeeded.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Session 2: thread 1 event new RPC.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/notifications:create-subscription" with ID 1 priority 0 for 1 subscribers.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Processing "/notifications:create-subscription" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 1 priority 0 succeeded.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Session 2: thread 1 event new RPC.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/ietf-netconf:get" with ID 4 priority 0 for 1 subscribers.

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Processing "/ietf-netconf:get" "rpc" event with ID 4 priority 0 (remaining 1 subscribers).

Apr 14 05:32:17 garuda daemon.info netopeer2-server[1186]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 3.

Apr 14 05:32:17 garuda user.notice fw_manager[1261]: RPC #3 recieved. xpath -> /o-ran-software-management:software-inventory

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Event "operational" with ID 3 succeeded.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Successful processing of "rpc" event with ID 4 priority 0 (remaining 0 subscribers).

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 4 priority 0 succeeded.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Session 2: thread 3 event new RPC.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/o-ran-software-management:software-download" with ID 1 priority 0 for 1 subscribers.

Apr 14 05:32:18 garuda user.notice fw_manager[1261]: RPC #1 recieved. xpath -> /o-ran-software-management:software-download

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 1 priority 0 succeeded.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:18 garuda daemon.info netopeer2-server[1186]: Session 2: thread 4 event new RPC.

Apr 14 05:32:18 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:32:24 garuda user.notice fw_manager[1261]: Function isDownloadCompleted setting error code 0

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: Processing "notif" "o-ran-software-management" event with ID 1.

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 1 priority 0 (remaining 0 subscribers).

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: Must condition "/software-inventory/software-slot[name = current()][active = 'false' and running = 'false']" not satisfied, but it is not required.

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:25 garuda daemon.info netopeer2-server[1186]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 4.

Apr 14 05:32:25 garuda user.notice fw_manager[1261]: RPC #4 recieved. xpath -> /o-ran-software-management:software-inventory

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Event "operational" with ID 4 succeeded.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Published event "rpc" "/o-ran-software-management:software-install" with ID 1 priority 0 for 1 subscribers.

Apr 14 05:32:26 garuda user.notice fw_manager[1261]: RPC #1 recieved. xpath -> /o-ran-software-management:software-install

Apr 14 05:32:26 garuda user.notice fw_manager[1261]: swSlot1 selected

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Event "rpc" with ID 1 priority 0 succeeded.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Session 2: thread 4 event new RPC.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/fw_manager", but it is not

required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 1.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 1 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/nw_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 2.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 2 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/operations_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 3.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 3 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/pm_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 4.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 4 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/um_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 5.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 5 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/sys_monitor", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 6.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 6 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/fault_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 7.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 7 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/file_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 8.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 8 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/supervision", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 9.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 9 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/sync_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 10.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 10 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/log_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 11.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 11 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/radio_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 12.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 12 priority 0 (remaining 0 subscribers).

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/log_manager", but it is not required.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 13.

Apr 14 05:32:26 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 13 priority 0 (remaining 0 subscribers).

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/fault_manager", but it is not required.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 14.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 14 priority 0 (remaining 0 subscribers).

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/file_manager", but it is not required.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 15.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 15 priority 0 (remaining 0 subscribers).

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/pm_manager", but it is not required.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 16.

Apr 14 05:32:27 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 16 priority 0 (remaining 0 subscribers).

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/supervision", but it is not required.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 17.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 17 priority 0 (remaining 0 subscribers).

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/nw_manager", but it is not required.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 18.

Apr 14 05:32:28 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 18 priority 0 (remaining 0 subscribers).

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/radio_manager", but it is not required.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 19.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 19 priority 0 (remaining 0 subscribers).

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/um_manager", but it is not required.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 20.

Apr 14 05:32:29 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 20 priority 0 (remaining 0 subscribers).

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/sys_monitor", but it is not required.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 21.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 21 priority 0 (remaining 0 subscribers).

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/fw_manager", but it is not required.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 22.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 22 priority 0 (remaining 0 subscribers).

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/sync_manager", but it is not required.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 23.

Apr 14 05:32:30 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 23 priority 0 (remaining 0 subscribers).

Apr 14 05:32:31 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:31 garuda daemon.info netopeer2-server[1186]: There is no instance of "/stli_giru-wdm:system-apps/operations_manager", but it is not required.

Apr 14 05:32:31 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:31 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 24.

Apr 14 05:32:31 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 24 priority 0 (remaining 0 subscribers).

Apr 14 05:32:32 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:32:32 garuda user.err fw_manager[1261]: swInstall failed :Reason: Given build already exists in slot 2

Apr 14 05:32:32 garuda user.notice fw_manager[1261]: RPC #5 recieved. xpath -> /o-ran-software-management:software-inventory

Apr 14 05:32:32 garuda user.err FAULT MANAGER[1200]: sendData : Source ID: 17

Apr 14 05:32:32 garuda user.err FAULT MANAGER[1200]: sendData : Fault ID: 23

Apr 14 05:32:32 garuda user.err FAULT MANAGER[1200]: sendData : FAULT_IS_CLEARED: FALSE

Apr 14 05:32:32 garuda user.err FAULT MANAGER[1200]: sendData : FAULT_SEVERITY: 2

Apr 14 05:32:32 garuda user.err FAULT MANAGER[1200]: sendData : FAULT_TIME: 2027-04-14T05:32:32Z

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no instance of "/notification_history:history/module-notification[module-name='Intialization Fault']", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no instance of "/notification_history:history/module-notification[module-name='Intialization Fault']/module-name", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 25.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 25 priority 0 (remaining 0 subscribers).

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no instance of "/notification_history:history/module-notification[module-name='Intialization Fault']/notif-error", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 26.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 26 priority 0 (remaining 0 subscribers).

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no instance of "/notification_history:history/module-notification[module-name='Intialization Fault']/alert", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 27.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 27 priority 0 (remaining 0 subscribers).

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no instance of "/notification_history:history/module-notification[module-name='Intialization Fault']/epochtime", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "ietf-netconf-notifications" event with ID 28.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 28 priority 0 (remaining 0 subscribers).

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "o-ran-fm" event with ID 1.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 1 priority 0 (remaining 0 subscribers).

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Resolving unresolved data nodes and their constraints...

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: There is no leafref "/software-inventory/software-slot/name" with the value "swSlot1", but it is not required.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: All data nodes and constraints resolved.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Processing "notif" "o-ran-software-management" event with ID 2.

Apr 14 05:32:33 garuda daemon.info netopeer2-server[1186]: Successful processing of "notif" event with ID 2 priority 0 (remaining 0 subscribers).

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: Session 2: thread 2 event new RPC.

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: Session 2: thread 2 event session terminated.

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: There are no subscribers for "ietf-netconf-notifications" notifications.

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: Generated new event (netconf-session-end).

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: Call Home client "default-client" session terminated.

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:38 garuda auth.info sshd[6640]: Accepted password for operator from 192.168.22.208 port 40056 ssh2

Apr 14 05:32:38 garuda authpriv.info sshd[6640]: pam_unix(sshd:session): session opened for user operator by (uid=0)

Apr 14 05:32:39 garuda authpriv.info sshd[5124]: pam_unix(sshd:session): session closed for user root

Apr 14 05:32:39 garuda authpriv.info sshd[6640]: pam_unix(sshd:session): session closed for user operator

Apr 14 05:32:39 garuda daemon.err netopeer2-server[1186]: Session 2: waiting for Call Home thread failed (Connection timed out).

Apr 14 05:32:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:46 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:32:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:32:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:32:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:00 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:33:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:14 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:33:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:28 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:33:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:42 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:33:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:56 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:33:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:33:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:33:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:10 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:34:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:24 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:34:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:38 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:34:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:52 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:34:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:34:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:34:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:06 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:35:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:20 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:35:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:34 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:35:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:48 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:35:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:35:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:35:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:02 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:36:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:16 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane
Apr 14 05:36:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:36:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:36:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:30 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:36:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:44 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:36:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:58 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:36:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:36:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:36:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:12 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:37:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:26 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:37:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:37:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:37:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:40 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane
Apr 14 05:37:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:54 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane
Apr 14 05:37:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:37:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:37:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:08 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:38:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:22 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:38:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:36 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane
Apr 14 05:38:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.
Apr 14 05:38:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).
Apr 14 05:38:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:50 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:38:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:38:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:38:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:04 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:39:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:18 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:39:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:32 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:39:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:46 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:39:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:39:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:39:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:00 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:40:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:14 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:40:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:28 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:40:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:42 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:40:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:56 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:40:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:40:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:40:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:10 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:41:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:24 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:41:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:38 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:41:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:52 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:41:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:41:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:41:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:06 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:42:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:20 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:42:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:34 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:42:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:48 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:42:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:42:59 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:42:59 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:00 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:00 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:01 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:01 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:02 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:43:02 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:02 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:03 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:03 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:04 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:04 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:05 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:05 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:06 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:06 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:07 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:07 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:08 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:08 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:09 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:09 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:10 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:10 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:11 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:11 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:12 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:12 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:13 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:13 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:14 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:14 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:15 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:15 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:16 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:43:16 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:16 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:17 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:17 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:18 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:18 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:19 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:19 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:20 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:20 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:21 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:21 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:22 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:22 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:23 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:23 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:24 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:24 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:25 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:25 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:26 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:26 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:27 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:27 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:28 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:28 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:29 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:29 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:30 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:43:30 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:30 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:31 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:31 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:32 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:32 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:33 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:33 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:34 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:34 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:35 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:35 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:36 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:36 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:37 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:37 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:38 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:38 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:39 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:39 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:40 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:40 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:41 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:41 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:42 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:42 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:43 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:43 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:44 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:43:44 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:44 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:45 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:45 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:46 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:46 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:47 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:47 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:48 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:48 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:49 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:49 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:50 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:50 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:51 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:51 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:52 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:52 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:53 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:53 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:54 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:54 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:55 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:55 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:56 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:56 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:57 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:57 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Apr 14 05:43:58 garuda user.notice SYNCMNGR[1501]: Received message from S-Plane

Apr 14 05:43:58 garuda daemon.info netopeer2-server[1186]: Trying to connect via IPv4 to 192.168.22.208:4334.

Apr 14 05:43:58 garuda daemon.info netopeer2-server[1186]: getsockopt() error (Connection refused).

Sep 5 13:44:27 garuda syslog.info syslogd started: BusyBox v1.31.0

Sep 5 13:44:27 garuda user.notice kernel: klogd started: BusyBox v1.31.0 (2021-03-30 19:10:48 UTC)

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Booting Linux on physical CPU 0x0000000000 [0x410fd034]

Sep 5 13:44:27 garuda user.notice kernel: [0.000000] Linux version 5.4.0-xilinx-v2020.2 (oe-user@oe-host) (gcc version 9.2.0 (GCC)) #1 SMP Mon Sep 5 13:40:07 UTC 2022

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Machine model: xlnx,zynqmp

Sep 5 13:44:27 garuda user.info kernel: [0.000000] earlycon: cdns0 at MMIO 0x00000000ff000000 (options '115200n8')

Sep 5 13:44:27 garuda user.info kernel: [0.000000] printk: bootconsole [cdns0] enabled

Sep 5 13:44:27 garuda user.info kernel: [0.000000] efi: Getting EFI parameters from FDT:

Sep 5 13:44:27 garuda user.info kernel: [0.000000] efi: UEFI not found.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] cma: Reserved 256 MiB at 0x000000002fc00000

Sep 5 13:44:27 garuda user.debug kernel: [0.000000] On node 0 totalpages: 261888

Sep 5 13:44:27 garuda user.debug kernel: [0.000000]   DMA32 zone: 4092 pages used for memmap

Sep 5 13:44:27 garuda user.debug kernel: [0.000000]   DMA32 zone: 0 pages reserved

Sep 5 13:44:27 garuda user.debug kernel: [0.000000]   DMA32 zone: 261888 pages, LIFO batch:63

Sep 5 13:44:27 garuda user.info kernel: [0.000000] psci: probing for conduit method from DT.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] psci: PSCIv1.1 detected in firmware.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] psci: Using standard PSCI v0.2 function IDs

Sep 5 13:44:27 garuda user.info kernel: [0.000000] psci: MIGRATE_INFO_TYPE not supported.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] psci: SMC Calling Convention v1.1

Sep 5 13:44:27 garuda user.info kernel: [0.000000] percpu: Embedded 22 pages/cpu s49880 r8192 d32040 u90112

Sep 5 13:44:27 garuda user.debug kernel: [0.000000] pcpu-alloc: s49880 r8192 d32040 u90112 alloc=22*4096

Sep 5 13:44:27 garuda user.debug kernel: [0.000000] pcpu-alloc: [0] 0 [0] 1 [0] 2 [0] 3

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Detected VIPT I-cache on CPU0

Sep 5 13:44:27 garuda user.info kernel: [0.000000] CPU features: detected: ARM erratum 845719

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Speculative Store Bypass Disable mitigation not required

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Built 1 zonelists, mobility grouping on. Total pages: 257796

Sep 5 13:44:27 garuda user.notice kernel: [0.000000] Kernel command line: earlycon console=ttyPS0,115200 clk_ignore_unused cpuidle.off=1 root=/dev/mmcblk0p3 rw rootwait

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Dentry cache hash table entries: 131072 (order: 8, 1048576 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Inode-cache hash table entries: 65536 (order: 7, 524288 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [0.000000] mem auto-init: stack:off, heap alloc:off, heap free:off

Sep 5 13:44:27 garuda user.info kernel: [0.000000] Memory: 749684K/1047552K available (10172K kernel code, 656K rwdata, 3016K rodata, 704K init, 539K bss, 35724K reserved, 262144K cma-reserved)

Sep 5 13:44:27 garuda user.info kernel: [0.000000] rcu: Hierarchical RCU implementation.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] rcu: RCU event tracing is enabled.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] rcu: RCU calculated value of scheduler-enlistment delay is 25 jiffies.

Sep 5 13:44:27 garuda user.info kernel: [0.000000] NR_IRQS: 64, nr_irqs: 64, preallocated irqs: 0

Sep 5 13:44:27 garuda user.warn kernel: [0.000000] GIC: Adjusting CPU interface base to 0x00000000f902f000

Sep 5 13:44:27 garuda user.info kernel: [0.000000] GIC: Using split EOI/Deactivate mode

Sep 5 13:44:27 garuda user.notice kernel: [0.000000] random: get_random_bytes called from start_kernel+0x2a8/0x42c with crng_init=0

Sep 5 13:44:27 garuda user.info kernel: [0.000000] arch_timer: cp15 timer(s) running at 50.00MHz (phys).

Sep 5 13:44:27 garuda user.info kernel: [0.000000] clocksource: arch_sys_counter: mask: 0xffffffffffffff max_cycles: 0xb8812736b, max_idle_ns: 440795202655 ns

Sep 5 13:44:27 garuda user.info kernel: [0.000003] sched_clock: 56 bits at 50MHz, resolution 20ns, wraps every 4398046511100ns

Sep 5 13:44:27 garuda user.info kernel: [0.008269] Console: colour dummy device 80x25

Sep 5 13:44:27 garuda user.info kernel: [0.012390] Calibrating delay loop (skipped), value calculated using timer frequency.. 100.00 BogoMIPS (lpj=200000)

Sep 5 13:44:27 garuda user.info kernel: [0.022753] pid_max: default: 32768 minimum: 301

Sep 5 13:44:27 garuda user.info kernel: [0.027477] Mount-cache hash table entries: 2048 (order: 2, 16384 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [0.034695] Mountpoint-cache hash table entries: 2048 (order: 2, 16384 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [0.043447] ASID allocator initialised with 32768 entries

Sep 5 13:44:27 garuda user.info kernel: [0.047895] rcu: Hierarchical SRCU implementation.

Sep 5 13:44:27 garuda user.info kernel: [0.052827] EFI services will not be available.

Sep 5 13:44:27 garuda user.info kernel: [0.057225] smp: Bringing up secondary CPUs ...

Sep 5 13:44:27 garuda user.info kernel: [0.061916] Detected VIPT I-cache on CPU1

Sep 5 13:44:27 garuda user.info kernel: [0.061947] CPU1: Booted secondary processor 0x0000000001 [0x410fd034]

Sep 5 13:44:27 garuda user.info kernel: [0.062286] Detected VIPT I-cache on CPU2

Sep 5 13:44:27 garuda user.info kernel: [0.062304] CPU2: Booted secondary processor 0x0000000002 [0x410fd034]

Sep 5 13:44:27 garuda user.info kernel: [0.062613] Detected VIPT I-cache on CPU3

Sep 5 13:44:27 garuda user.info kernel: [0.062630] CPU3: Booted secondary processor 0x0000000003 [0x410fd034]

Sep 5 13:44:27 garuda user.info kernel: [0.062673] smp: Brought up 1 node, 4 CPUs

Sep 5 13:44:27 garuda user.info kernel: [0.097055] SMP: Total of 4 processors activated.

Sep 5 13:44:27 garuda user.info kernel: [0.101727] CPU features: detected: 32-bit EL0 Support

Sep 5 13:44:27 garuda user.info kernel: [0.106831] CPU features: detected: CRC32 instructions

Sep 5 13:44:27 garuda user.info kernel: [0.111962] CPU: All CPU(s) started at EL2

Sep 5 13:44:27 garuda user.info kernel: [0.116011] alternatives: patching kernel code

Sep 5 13:44:27 garuda user.info kernel: [0.121201] devtmpfs: initialized

Sep 5 13:44:27 garuda user.info kernel: [0.127945] clocksource: jiffies: mask: 0xffffffff max_cycles: 0xffffffff, max_idle_ns: 7645041785100000 ns

Sep 5 13:44:27 garuda user.info kernel: [0.133399] futex hash table entries: 1024 (order: 4, 65536 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [0.145621] xor: measuring software checksum speed

Sep 5 13:44:27 garuda user.info kernel: [0.184297]   8regs   : 2622.000 MB/sec

Sep 5 13:44:27 garuda user.info kernel: [0.224321]   32regs   : 3008.000 MB/sec

Sep 5 13:44:27 garuda user.info kernel: [0.264351]   arm64_neon: 2612.000 MB/sec

Sep 5 13:44:27 garuda user.info kernel: [0.264389] xor: using function: 32regs (3008.000 MB/sec)

Sep 5 13:44:27 garuda user.info kernel: [0.268297] pinctrl core: initialized pinctrl subsystem

Sep 5 13:44:27 garuda user.info kernel: [0.273831] DMI not present or invalid.

Sep 5 13:44:27 garuda user.info kernel: [0.277504] NET: Registered protocol family 16

Sep 5 13:44:27 garuda user.info kernel: [0.282856] DMA: preallocated 256 KiB pool for atomic allocations

Sep 5 13:44:27 garuda user.info kernel: [0.287743] audit: initializing netlink subsys (disabled)

Sep 5 13:44:27 garuda user.notice kernel: [0.293150] audit: type=2000 audit(0.232:1): state=initialized audit_enabled=0 res=1

Sep 5 13:44:27 garuda user.info kernel: [0.293537] hw-breakpoint: found 6 breakpoint and 4 watchpoint registers.

Sep 5 13:44:27 garuda user.info kernel: [0.307656] Serial: AMBA PL011 UART driver

Sep 5 13:44:27 garuda user.info kernel: [0.321752] HugeTLB registered 1.00 GiB page size, pre-allocated 0 pages

Sep 5 13:44:27 garuda user.info kernel: [0.322801] HugeTLB registered 32.0 MiB page size, pre-allocated 0 pages

Sep 5 13:44:27 garuda user.info kernel: [0.329469] HugeTLB registered 2.00 MiB page size, pre-allocated 0 pages

Sep 5 13:44:27 garuda user.info kernel: [0.336125] HugeTLB registered 64.0 KiB page size, pre-allocated 0 pages

Sep 5 13:44:27 garuda user.info kernel: [0.347411] cryptd: max_cpu_qlen set to 1000

Sep 5 13:44:27 garuda user.info kernel: [0.421567] raid6: neonx8   gen() 1708 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.489604] raid6: neonx8   xor() 1618 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.557674] raid6: neonx4   gen() 1641 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.625690] raid6: neonx4   xor() 1579 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.693738] raid6: neonx2   gen() 1252 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.761777] raid6: neonx2   xor() 1314 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.829795] raid6: neonx1   gen()   815 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.897835] raid6: neonx1   xor()   989 MB/s

Sep 5 13:44:27 garuda user.info kernel: [0.965920] raid6: int64x8 gen() 1286 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.033928] raid6: int64x8 xor()   842 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.101984] raid6: int64x4 gen() 1085 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.170029] raid6: int64x4 xor()   817 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.238109] raid6: int64x2 gen()   754 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.306128] raid6: int64x2 xor()   665 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.374139] raid6: int64x1 gen()   498 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.442211] raid6: int64x1 xor()   510 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.442249] raid6: using algorithm neonx8 gen() 1708 MB/s

Sep 5 13:44:27 garuda user.info kernel: [1.446205] raid6: .... xor() 1618 MB/s, rmw enabled

Sep 5 13:44:27 garuda user.info kernel: [1.451135] raid6: using neon recovery algorithm

Sep 5 13:44:27 garuda user.info kernel: [1.456085] iommu: Default domain type: Translated

Sep 5 13:44:27 garuda user.notice kernel: [1.460774] SCSI subsystem initialized

Sep 5 13:44:27 garuda user.debug kernel: [1.464304] libata version 3.00 loaded.

Sep 5 13:44:27 garuda user.info kernel: [1.464417] usbcore: registered new interface driver usbfs

Sep 5 13:44:27 garuda user.info kernel: [1.469757] usbcore: registered new interface driver hub

Sep 5 13:44:27 garuda user.info kernel: [1.475031] usbcore: registered new device driver usb

Sep 5 13:44:27 garuda user.info kernel: [1.480064] pps_core: LinuxPPS API ver. 1 registered

Sep 5 13:44:27 garuda user.info kernel: [1.484957] pps_core: Software ver. 5.3.6 - Copyright 2005-2007 Rodolfo Giometti <giometti@linux.it>

Sep 5 13:44:27 garuda user.info kernel: [1.494046] PTP clock support registered

Sep 5 13:44:27 garuda user.info kernel: [1.497941] EDAC MC: Ver: 3.0.0

Sep 5 13:44:27 garuda user.info kernel: [1.501418] zynqmp-ipi-mbox mailbox@ff990400: Registered ZynqMP IPI mbox with TX/RX channels.

Sep 5 13:44:27 garuda user.info kernel: [1.509723] FPGA manager framework

Sep 5 13:44:27 garuda user.info kernel: [1.513537] clocksource: Switched to clocksource arch_sys_counter

Sep 5 13:44:27 garuda user.notice kernel: [1.519042] VFS: Disk quotas dquot_6.6.0

Sep 5 13:44:27 garuda user.info kernel: [1.522883] VFS: Dquot-cache hash table entries: 512 (order 0, 4096 bytes)

Sep 5 13:44:27 garuda user.info kernel: [1.533353] NET: Registered protocol family 2

Sep 5 13:44:27 garuda user.info kernel: [1.534345] tcp_listen_portaddr_hash hash table entries: 512 (order: 1, 8192 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [1.542332] TCP established hash table entries: 8192 (order: 4, 65536 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [1.550054] TCP bind hash table entries: 8192 (order: 5, 131072 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [1.557286] TCP: Hash tables configured (established 8192 bind 8192)

Sep 5 13:44:27 garuda user.info kernel: [1.563568] UDP hash table entries: 512 (order: 2, 16384 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [1.570094] UDP-Lite hash table entries: 512 (order: 2, 16384 bytes, linear)

Sep 5 13:44:27 garuda user.info kernel: [1.577177] NET: Registered protocol family 1

Sep 5 13:44:27 garuda user.info kernel: [1.581648] RPC: Registered named UNIX socket transport module.

Sep 5 13:44:27 garuda user.info kernel: [1.587292] RPC: Registered udp transport module.

Sep 5 13:44:27 garuda user.info kernel: [1.591958] RPC: Registered tcp transport module.

Sep 5 13:44:27 garuda user.info kernel: [1.596629] RPC: Registered tcp NFSv4.1 backchannel transport module.

Sep 5 13:44:27 garuda user.info kernel: [1.603036] PCI: CLS 0 bytes, default 64

Sep 5 13:44:27 garuda user.info kernel: [1.633099] workingset: timestamp_bits=46 max_order=18 bucket_order=0

Sep 5 13:44:27 garuda user.notice kernel: [1.634662] NFS: Registering the id_resolver key type

Sep 5 13:44:27 garuda user.notice kernel: [1.639010] Key type id_resolver registered

Sep 5 13:44:27 garuda user.notice kernel: [1.643062] Key type id_legacy registered

Sep 5 13:44:27 garuda user.info kernel: [1.647046] nfs4filelayout_init: NFSv4 File Layout Driver Registering...

Sep 5 13:44:27 garuda user.info kernel: [1.653717] jffs2: version 2.2. (NAND) (SUMMARY) © 2001-2006 Red Hat, Inc.

Sep 5 13:44:27 garuda user.info kernel: [1.660973] NET: Registered protocol family 38

Sep 5 13:44:27 garuda user.info kernel: [1.665145] Block layer SCSI generic (bsg) driver version 0.4 loaded (major 247)

Sep 5 13:44:27 garuda user.info kernel: [1.672535] io scheduler mq-deadline registered

Sep 5 13:44:27 garuda user.info kernel: [1.676971] io scheduler kyber registered

Sep 5 13:44:27 garuda user.info kernel: [1.682594] ps_pcie_dma init()

Sep 5 13:44:27 garuda user.info kernel: [1.706737] Serial: 8250/16550 driver, 4 ports, IRQ sharing disabled

Sep 5 13:44:27 garuda user.info kernel: [1.708462] Serial: AMBA driver

Sep 5 13:44:27 garuda user.warn kernel: [1.712662] cacheinfo: Unable to detect cache hierarchy for CPU 0

Sep 5 13:44:27 garuda user.info kernel: [1.720629] brd: module loaded

Sep 5 13:44:27 garuda user.info kernel: [1.724992] loop: module loaded

Sep 5 13:44:27 garuda user.err kernel: [1.725793] mtdoops: mtd device (mtddev=name/number) must be supplied

Sep 5 13:44:27 garuda user.info kernel: [1.730365] libphy: Fixed MDIO Bus: probed

Sep 5 13:44:27 garuda user.info kernel: [1.734225] tun: Universal TUN/TAP device driver, 1.6

Sep 5 13:44:27 garuda user.info kernel: [1.739145] usbcore: registered new interface driver asix

Sep 5 13:44:27 garuda user.info kernel: [1.743640] usbcore: registered new interface driver ax88179_178a

Sep 5 13:44:27 garuda user.info kernel: [1.749680] usbcore: registered new interface driver cdc_ether

Sep 5 13:44:27 garuda user.info kernel: [1.755469] usbcore: registered new interface driver net1080

Sep 5 13:44:27 garuda user.info kernel: [1.761090] usbcore: registered new interface driver cdc_subset

Sep 5 13:44:27 garuda user.info kernel: [1.766983] usbcore: registered new interface driver zaurus

Sep 5 13:44:27 garuda user.info kernel: [1.772521] usbcore: registered new interface driver cdc_ncm

Sep 5 13:44:27 garuda user.info kernel: [1.778869] usbcore: registered new interface driver uas

Sep 5 13:44:27 garuda user.info kernel: [1.783419] usbcore: registered new interface driver usb-storage

Sep 5 13:44:27 garuda user.info kernel: [1.789767] rtc_zynqmp ffa60000.rtc: registered as rtc0

Sep 5 13:44:27 garuda user.info kernel: [1.794599] SFP: i2c device initilization

Sep 5 13:44:27 garuda user.info kernel: [1.798533] SFP: alloc_chrdev_region completed, Major number : 245

Sep 5 13:44:27 garuda user.info kernel: [1.804677] SFP: class_create() completed

Sep 5 13:44:27 garuda user.info kernel: [1.808649] SFP: Device memory allocation completed

Sep 5 13:44:27 garuda user.info kernel: [1.813506] SFP: i2c_add_driver() completed

Sep 5 13:44:27 garuda user.info kernel: [1.817644] SFP: sfp_i2c_init_driver() Completed Successfully

Sep 5 13:44:27 garuda user.info kernel: [1.823354] i2c /dev entries driver

Sep 5 13:44:27 garuda user.info kernel: [1.827224] pps pps0: new PPS source ptp0

Sep 5 13:44:27 garuda user.info kernel: [1.830823] xlnx_ptp_timer b0050000.timer_1588_v2_0_1: Acquired ptp_irq: 0x33

Sep 5 13:44:27 garuda user.info kernel: [1.838331] EDAC MC: ECC not enabled

Sep 5 13:44:27 garuda user.info kernel: [1.841566] EDAC DEVICE0: Giving out device to module zynqmp-ocm-edac controller zynqmp_ocm:
DEV ff960000.memory-controller (INTERRUPT)

Sep 5 13:44:27 garuda user.info kernel: [1.853935] sdhci: Secure Digital Host Controller Interface driver

Sep 5 13:44:27 garuda user.info kernel: [1.859687] sdhci: Copyright(c) Pierre Ossman

Sep 5 13:44:27 garuda user.info kernel: [1.864009] sdhci-pltfm: SDHCI platform and OF driver helper

Sep 5 13:44:27 garuda user.info kernel: [1.869875] zynqmp_firmware_probe Platform Management API v1.1

Sep 5 13:44:27 garuda user.info kernel: [1.875433] zynqmp_firmware_probe Trustzone version v1.0

Sep 5 13:44:27 garuda user.info kernel: [1.903645] securefw securefw: securefw probed^M

Sep 5 13:44:27 garuda user.info kernel: [1.903863] alg: No test for xilinx-zynqmp-aes (zynqmp-aes)

Sep 5 13:44:27 garuda user.info kernel: [1.908221] zynqmp_aes zynqmp_aes: AES Successfully Registered

Sep 5 13:44:27 garuda user.info kernel: [1.908221] ^M

Sep 5 13:44:27 garuda user.info kernel: [1.915588] alg: No test for xilinx-keccak-384 (zynqmp-keccak-384)

Sep 5 13:44:27 garuda user.info kernel: [1.921784] alg: No test for xilinx-zynqmp-rsa (zynqmp-rsa)

Sep 5 13:44:27 garuda user.info kernel: [1.927337] usbcore: registered new interface driver usbhid

Sep 5 13:44:27 garuda user.info kernel: [1.932643] usbhid: USB HID core driver

Sep 5 13:44:27 garuda user.info kernel: [1.938641] ARM CCI_400_r1 PMU driver probed

Sep 5 13:44:27 garuda user.info kernel: [1.939089] fpga_manager fpga0: Xilinx ZynqMP FPGA Manager registered

Sep 5 13:44:27 garuda user.info kernel: [1.947372] pktgen: Packet Generator for packet performance testing. Version: 2.75

Sep 5 13:44:27 garuda user.info kernel: [1.955133] Initializing XFRM netlink socket

Sep 5 13:44:27 garuda user.info kernel: [1.958931] NET: Registered protocol family 10

Sep 5 13:44:27 garuda user.info kernel: [1.963651] Segment Routing with IPv6

Sep 5 13:44:27 garuda user.info kernel: [1.967003] sit: IPv6, IPv4 and MPLS over IPv4 tunneling driver

Sep 5 13:44:27 garuda user.info kernel: [1.973089] NET: Registered protocol family 17

Sep 5 13:44:27 garuda user.info kernel: [1.977199] NET: Registered protocol family 15

Sep 5 13:44:27 garuda user.info kernel: [1.981612] bridge: filtering via arp/ip/ip6tables is no longer available by default. Update your scripts to load br_netfilter if you need this.

Sep 5 13:44:27 garuda user.info kernel: [1.994514] 8021q: 802.1Q VLAN Support v1.8

Sep 5 13:44:27 garuda user.info kernel: [1.998721] 9pnet: Installing 9P2000 support

Sep 5 13:44:27 garuda user.notice kernel: [2.002895] Key type dns_resolver registered

Sep 5 13:44:27 garuda user.info kernel: [2.007364] registered taskstats version 1

Sep 5 13:44:27 garuda user.info kernel: [2.012107] Btrfs loaded, crc32c=crc32c-generic

Sep 5 13:44:27 garuda user.info kernel: [2.024171] ff000000.serial: ttyPS0 at MMIO 0xff000000 (irq = 41, base_baud = 6250000) is a xuartps

Sep 5 13:44:27 garuda user.info kernel: [2.033190] printk: console [ttyPS0] enabled

Sep 5 13:44:27 garuda user.info kernel: [2.037486] printk: bootconsole [cdns0] disabled

Sep 5 13:44:27 garuda user.info kernel: [2.046792] ff010000.serial: ttyPS1 at MMIO 0xff010000 (irq = 42, base_baud = 6250000) is a xuartps

Sep 5 13:44:27 garuda user.info kernel: [2.060215] of-fpga-region fpga-full: FPGA Region probed

Sep 5 13:44:27 garuda user.info kernel: [2.066111] XGpio: gpio@b0040000: registered, base is 509

Sep 5 13:44:27 garuda user.info kernel: [2.071812] XGpio: gpio@b0040000: dual channel registered, base is 497

Sep 5 13:44:27 garuda user.info kernel: [2.078924] xilinx-zynqmp-dma fd500000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.086020] xilinx-zynqmp-dma fd510000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.093107] xilinx-zynqmp-dma fd520000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.100199] xilinx-zynqmp-dma fd530000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.107294] xilinx-zynqmp-dma fd540000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.114382] xilinx-zynqmp-dma fd550000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.121476] xilinx-zynqmp-dma fd560000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.128562] xilinx-zynqmp-dma fd570000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.135732] xilinx-zynqmp-dma ffa80000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.142828] xilinx-zynqmp-dma ffa90000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.149918] xilinx-zynqmp-dma ffaa0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.157008] xilinx-zynqmp-dma ffab0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.164105] xilinx-zynqmp-dma ffac0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.171192] xilinx-zynqmp-dma ffad0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.178284] xilinx-zynqmp-dma ffae0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.info kernel: [2.185377] xilinx-zynqmp-dma ffaf0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:27 garuda user.warn kernel: [2.193403] ------------[cut here]------------

Sep 5 13:44:27 garuda user.warn kernel: [2.198018] /amba/spi@ff050000/spidev@0: buggy DT: spidev listed directly in DT

Sep 5 13:44:27 garuda user.warn kernel: [2.205373] WARNING: CPU: 1 PID: 31 at drivers/spi/spidev.c:727 spidev_probe+0xf8/0x1c8

Sep 5 13:44:27 garuda user.warn kernel: [2.213363] Modules linked in:
Sep 5 13:44:27 garuda user.warn kernel: [2.216405] CPU: 1 PID: 31 Comm: kworker/1:1 Not tainted 5.4.0-xilinx-v2020.2 #1
Sep 5 13:44:27 garuda user.warn kernel: [2.223788] Hardware name: xlnx,zynqmp (DT)
Sep 5 13:44:27 garuda user.warn kernel: [2.227960] Workqueue: events deferred_probe_work_func
Sep 5 13:44:27 garuda user.warn kernel: [2.233086] pstate: 60000005 (nZCv daif -PAN -UAO)
Sep 5 13:44:27 garuda user.warn kernel: [2.237859] pc : spidev_probe+0xf8/0x1c8
Sep 5 13:44:27 garuda user.warn kernel: [2.241765] lr : spidev_probe+0xf8/0x1c8
Sep 5 13:44:27 garuda user.warn kernel: [2.245669] sp : ffff8000110537d0
Sep 5 13:44:27 garuda user.warn kernel: [2.248968] x29: ffff8000110537d0 x28: ffff00003fcea270
Sep 5 13:44:27 garuda user.warn kernel: [2.254263] x27: ffff00002e718410 x26: ffff00002d1ce400
Sep 5 13:44:27 garuda user.warn kernel: [2.259557] x25: 0000000000000000 x24: 0000000000000019
Sep 5 13:44:27 garuda user.warn kernel: [2.264852] x23: ffff800010e778c8 x22: 0000000000000000
Sep 5 13:44:27 garuda user.warn kernel: [2.270147] x21: ffff800010e778a8 x20: ffff00002d1d5800
Sep 5 13:44:27 garuda user.warn kernel: [2.275442] x19: 0000000000000000 x18: 0000000000000010
Sep 5 13:44:27 garuda user.warn kernel: [2.280737] x17: 0000000000000000 x16: 0000000000000000
Sep 5 13:44:27 garuda user.warn kernel: [2.286031] x15: ffff00002e6c0868 x14: ffffffffffffffff
Sep 5 13:44:27 garuda user.warn kernel: [2.291326] x13: ffff800091053517 x12: ffff80001105351f
Sep 5 13:44:27 garuda user.warn kernel: [2.296621] x11: ffff800010e44000 x10: 0000000000000000
Sep 5 13:44:27 garuda user.warn kernel: [2.301916] x9 : ffff800010ece000 x8 : 00000000000000dc
Sep 5 13:44:27 garuda user.warn kernel: [2.307211] x7 : 0000000000000006 x6 : ffff800010ece0f2
Sep 5 13:44:27 garuda user.warn kernel: [2.312505] x5 : 0000000000000007 x4 : 0000000000000000
Sep 5 13:44:27 garuda user.warn kernel: [2.317800] x3 : 0000000000000000 x2 : 00000000ffffffff
Sep 5 13:44:27 garuda user.warn kernel: [2.323095] x1 : 7cb760c2113ffb00 x0 : 0000000000000000
Sep 5 13:44:27 garuda user.warn kernel: [2.328390] Call trace:
Sep 5 13:44:27 garuda user.warn kernel: [2.330822] spidev_probe+0xf8/0x1c8
Sep 5 13:44:27 garuda user.warn kernel: [2.334382] spi_drv_probe+0x7c/0xd8
Sep 5 13:44:27 garuda user.warn kernel: [2.337939] really_probe+0xd8/0x2f8
Sep 5 13:44:27 garuda user.warn kernel: [2.341498] driver_probe_device+0x54/0xe8
Sep 5 13:44:27 garuda user.warn kernel: [2.345578] __device_attach_driver+0x80/0xb8
Sep 5 13:44:27 garuda user.warn kernel: [2.349920] bus_for_each_drv+0x74/0xc0
Sep 5 13:44:27 garuda user.warn kernel: [2.353737] __device_attach+0xdc/0x138
Sep 5 13:44:27 garuda user.warn kernel: [2.357556] device_initial_probe+0x10/0x18
Sep 5 13:44:27 garuda user.warn kernel: [2.361722] bus_probe_device+0x90/0x98
Sep 5 13:44:27 garuda user.warn kernel: [2.365542] device_add+0x334/0x600
Sep 5 13:44:27 garuda user.warn kernel: [2.369014] spi_add_device+0xac/0x170
Sep 5 13:44:27 garuda user.warn kernel: [2.372746] of_register_spi_device+0x204/0x388
Sep 5 13:44:27 garuda user.warn kernel: [2.377262] spi_register_controller+0x4b4/0x718
Sep 5 13:44:27 garuda user.warn kernel: [2.381861] cdns_spi_probe+0x28c/0x368
Sep 5 13:44:27 garuda user.warn kernel: [2.385680] platform_drv_probe+0x50/0xa0
Sep 5 13:44:27 garuda user.warn kernel: [2.389672] really_probe+0xd8/0x2f8
Sep 5 13:44:27 garuda user.warn kernel: [2.393231] driver_probe_device+0x54/0xe8
Sep 5 13:44:27 garuda user.warn kernel: [2.397311] __device_attach_driver+0x80/0xb8
Sep 5 13:44:27 garuda user.warn kernel: [2.401651] bus_for_each_drv+0x74/0xc0
Sep 5 13:44:27 garuda user.warn kernel: [2.405469] __device_attach+0xdc/0x138
Sep 5 13:44:27 garuda user.warn kernel: [2.409289] device_initial_probe+0x10/0x18
Sep 5 13:44:27 garuda user.warn kernel: [2.413455] bus_probe_device+0x90/0x98
Sep 5 13:44:27 garuda user.warn kernel: [2.417274] deferred_probe_work_func+0x6c/0xa0
Sep 5 13:44:27 garuda user.warn kernel: [2.421791] process_one_work+0x1c4/0x338
Sep 5 13:44:27 garuda user.warn kernel: [2.425789] worker_thread+0x260/0x488

Sep 5 13:44:27 garuda user.warn kernel: [2.429523] kthread+0x120/0x128

Sep 5 13:44:27 garuda user.warn kernel: [2.432735] ret_from_fork+0x10/0x18

Sep 5 13:44:27 garuda user.warn kernel: [2.436292] ---[end trace 56ab5fd9ecf920b9]---

Sep 5 13:44:27 garuda user.warn kernel: [2.441039] zynqmp_pll_disable() clock disable failed for dpll_int, ret = -13

Sep 5 13:44:27 garuda user.info kernel: [2.448575] macb ff0d0000.ethernet: Not enabling partial store and forward

Sep 5 13:44:27 garuda user.info kernel: [2.455966] libphy: MACB_mii_bus: probed

Sep 5 13:44:27 garuda user.err kernel: [2.462011] macb ff0d0000.ethernet eth0: no PHY found

Sep 5 13:44:27 garuda user.err kernel: [2.482230] xilinx_axienet b0000000.ethernet: IRQ index 0 not found

Sep 5 13:44:27 garuda user.info kernel: [2.488497] xilinx_axienet b0000000.ethernet: Ethernet core IRQ not defined

Sep 5 13:44:27 garuda user.warn kernel: [2.495459] xilinx_axienet b0000000.ethernet: couldn't find phy i/f

Sep 5 13:44:27 garuda user.info kernel: [2.502215] xilinx-axipmon ffa00000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:27 garuda user.info kernel: [2.508725] xilinx-axipmon fd0b0000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:27 garuda user.info kernel: [2.515198] xilinx-axipmon fd490000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:27 garuda user.info kernel: [2.521678] xilinx-axipmon ffa10000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:27 garuda user.info kernel: [2.528312] cdns-i2c ff020000.i2c: 400 kHz mmio ff020000 irq 32

Sep 5 13:44:27 garuda user.info kernel: [2.534694] SFP: In sfp_i2c device probe

Sep 5 13:44:27 garuda user.info kernel: [2.538609] SFP: device name : sfp0

Sep 5 13:44:27 garuda user.info kernel: [2.542091] SFP: minor number : 00

Sep 5 13:44:27 garuda user.info kernel: [2.545477] SFP: Driver name : sfp0

Sep 5 13:44:27 garuda user.info kernel: [2.548954] SFP: I2C Bus number : 1

Sep 5 13:44:27 garuda user.info kernel: [2.552496] SFP: construct_sfp_device() with minor number 0 completed

Sep 5 13:44:27 garuda user.info kernel: [2.558929] SFP: add i2c client : 0

Sep 5 13:44:27 garuda user.info kernel: [2.562431] cdns-i2c ff030000.i2c: 400 kHz mmio ff030000 irq 33

Sep 5 13:44:27 garuda user.info kernel: [2.568642] cdns-wdt fd4d0000.watchdog: Xilinx Watchdog Timer with timeout 60s

Sep 5 13:44:27 garuda user.info kernel: [2.576048] cdns-wdt ff150000.watchdog: Xilinx Watchdog Timer with timeout 10s

Sep 5 13:44:27 garuda user.warn kernel: [2.583617] cpufreq: cpufreq_online: CPU0: Running at unlisted freq: 1325000 KHz

Sep 5 13:44:27 garuda user.err kernel: [2.591015] cpu cpu0: dev_pm_opp_set_rate: failed to find current OPP for freq 1325000000 (-34)

Sep 5 13:44:27 garuda user.warn kernel: [2.599745] cpufreq: cpufreq_online: CPU0: Unlisted initial frequency changed to: 1199999 KHz

Sep 5 13:44:27 garuda user.err kernel: [2.608276] cpu cpu0: dev_pm_opp_set_rate: failed to find current OPP for freq 1325000000 (-34)

Sep 5 13:44:27 garuda user.info kernel: [2.650259] mmc0: SDHCI controller on ff160000.mmc [ff160000.mmc] using ADMA 64-bit

Sep 5 13:44:27 garuda user.info kernel: [2.660252] rtc_zynqmp ffa60000.rtc: setting system clock to 1993-04-04T14:09:02 UTC (733932542)

Sep 5 13:44:27 garuda user.info kernel: [2.669031] of_cfs_init

Sep 5 13:44:27 garuda user.info kernel: [2.671493] of_cfs_init: OK

Sep 5 13:44:27 garuda user.warn kernel: [2.674396] clk: Not disabling unused clocks

Sep 5 13:44:27 garuda user.info kernel: [2.679354] Waiting for root device /dev/mmcblk0p3...

Sep 5 13:44:27 garuda user.info kernel: [2.759642] mmc0: new HS200 MMC card at address 0001

Sep 5 13:44:27 garuda user.info kernel: [2.765041] mmcblk0: mmc0:0001 DG4008 7.28 GiB

Sep 5 13:44:27 garuda user.info kernel: [2.769775] mmcblk0boot0: mmc0:0001 DG4008 partition 1 4.00 MiB

Sep 5 13:44:27 garuda user.info kernel: [2.775878] mmcblk0boot1: mmc0:0001 DG4008 partition 2 4.00 MiB

Sep 5 13:44:27 garuda user.info kernel: [2.781856] mmcblk0rpmb: mmc0:0001 DG4008 partition 3 4.00 MiB, chardev (244:0)

Sep 5 13:44:27 garuda user.info kernel: [2.790240] mmcblk0: p1 p2 p3 p4

Sep 5 13:44:27 garuda user.notice kernel: [2.834995] random: fast init done

Sep 5 13:44:27 garuda user.info kernel: [2.930229] EXT4-fs (mmcblk0p3): recovery complete

Sep 5 13:44:27 garuda user.info kernel: [2.935539] EXT4-fs (mmcblk0p3): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:27 garuda user.info kernel: [2.943663] VFS: Mounted root (ext4 filesystem) on device 179:3.

Sep 5 13:44:27 garuda user.info kernel: [2.949716] devtmpfs: mounted

Sep 5 13:44:27 garuda user.info kernel: [2.952934] Freeing unused kernel memory: 704K

Sep 5 13:44:27 garuda user.info kernel: [2.957426] Run /sbin/init as init process

Sep 5 13:44:27 garuda daemon.info kernel: [3.151203] udevd[314]: starting version 3.2.8

Sep 5 13:44:27 garuda user.notice kernel: [3.158027] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:27 garuda user.notice kernel: [3.164771] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:27 garuda user.notice kernel: [3.171576] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:27 garuda daemon.info kernel: [3.190759] udevd[315]: starting eudev-3.2.8

Sep 5 13:44:27 garuda user.warn kernel: [3.580955] EXT4-fs (mmcblk0p2): warning: mounting fs with errors, running e2fsck is recommended

Sep 5 13:44:27 garuda user.info kernel: [3.591639] EXT4-fs (mmcblk0p2): recovery complete

Sep 5 13:44:27 garuda user.info kernel: [3.596482] EXT4-fs (mmcblk0p2): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:27 garuda user.info kernel: [3.716560] EXT4-fs (mmcblk0p4): recovery complete

Sep 5 13:44:27 garuda user.info kernel: [3.721872] EXT4-fs (mmcblk0p4): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:27 garuda user.info kernel: [3.789387] EXT4-fs (mmcblk0p3): re-mounted. Opts: (null)

Sep 5 13:44:27 garuda user.warn kernel: [14.962935] urandom_read: 4 callbacks suppressed

Sep 5 13:44:27 garuda user.notice kernel: [14.962940] random: dd: uninitialized urandom read (512 bytes read)

Sep 5 13:44:32 garuda user.notice kernel: [25.684728] random: crng init done

Sep 5 13:44:36 garuda user.notice shutdown[855]: shutting down for system reboot

Sep 5 13:44:36 garuda daemon.info init: Switching to runlevel: 6

Sep 5 13:44:38 garuda syslog.info syslogd exiting

Sep 5 13:44:55 garuda syslog.info syslogd started: BusyBox v1.31.0

Sep 5 13:44:55 garuda user.notice kernel: klogd started: BusyBox v1.31.0 (2021-03-30 19:10:48 UTC)

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Booting Linux on physical CPU 0x0000000000 [0x410fd034]

Sep 5 13:44:55 garuda user.notice kernel: [0.000000] Linux version 5.4.0-xilinx-v2020.2 (oe-user@oe-host) (gcc version 9.2.0 (GCC)) #1 SMP Mon Sep 5 13:40:07 UTC 2022

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Machine model: xlnx,zynqmp

Sep 5 13:44:55 garuda user.info kernel: [0.000000] earlycon: cdns0 at MMIO 0x00000000ff000000 (options '115200n8')

Sep 5 13:44:55 garuda user.info kernel: [0.000000] printk: bootconsole [cdns0] enabled

Sep 5 13:44:55 garuda user.info kernel: [0.000000] efi: Getting EFI parameters from FDT:

Sep 5 13:44:55 garuda user.info kernel: [0.000000] efi: UEFI not found.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] cma: Reserved 256 MiB at 0x000000002fc00000

Sep 5 13:44:55 garuda user.debug kernel: [0.000000] On node 0 totalpages: 261888

Sep 5 13:44:55 garuda user.debug kernel: [0.000000]   DMA32 zone: 4092 pages used for memmap

Sep 5 13:44:55 garuda user.debug kernel: [0.000000]   DMA32 zone: 0 pages reserved

Sep 5 13:44:55 garuda user.debug kernel: [0.000000]   DMA32 zone: 261888 pages, LIFO batch:63

Sep 5 13:44:55 garuda user.info kernel: [0.000000] psci: probing for conduit method from DT.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] psci: PSCIv1.1 detected in firmware.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] psci: Using standard PSCI v0.2 function IDs

Sep 5 13:44:55 garuda user.info kernel: [0.000000] psci: MIGRATE_INFO_TYPE not supported.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] psci: SMC Calling Convention v1.1

Sep 5 13:44:55 garuda user.info kernel: [0.000000] percpu: Embedded 22 pages/cpu s49880 r8192 d32040 u90112

Sep 5 13:44:55 garuda user.debug kernel: [0.000000] pcpu-alloc: s49880 r8192 d32040 u90112 alloc=22*4096

Sep 5 13:44:55 garuda user.debug kernel: [0.000000] pcpu-alloc: [0] 0 [0] 1 [0] 2 [0] 3

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Detected VIPT I-cache on CPU0

Sep 5 13:44:55 garuda user.info kernel: [0.000000] CPU features: detected: ARM erratum 845719

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Speculative Store Bypass Disable mitigation not required

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Built 1 zonelists, mobility grouping on. Total pages: 257796

Sep 5 13:44:55 garuda user.notice kernel: [0.000000] Kernel command line: earlycon console=ttyPS0,115200 clk_ignore_unused cpuidle.off=1 root=/dev/mmcblk0p3 rw rootwait

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Dentry cache hash table entries: 131072 (order: 8, 1048576 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Inode-cache hash table entries: 65536 (order: 7, 524288 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [0.000000] mem auto-init: stack:off, heap alloc:off, heap free:off

Sep 5 13:44:55 garuda user.info kernel: [0.000000] Memory: 749684K/1047552K available (10172K kernel code, 656K rwdata, 3016K rodata,

704K init, 539K bss, 35724K reserved, 262144K cma-reserved)

Sep 5 13:44:55 garuda user.info kernel: [0.000000] rcu: Hierarchical RCU implementation.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] rcu: RCU event tracing is enabled.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] rcu: RCU calculated value of scheduler-enlistment delay is 25 jiffies.

Sep 5 13:44:55 garuda user.info kernel: [0.000000] NR_IRQS: 64, nr_irqs: 64, preallocated irqs: 0

Sep 5 13:44:55 garuda user.warn kernel: [0.000000] GIC: Adjusting CPU interface base to 0x00000000f902f000

Sep 5 13:44:55 garuda user.info kernel: [0.000000] GIC: Using split EOI/Deactivate mode

Sep 5 13:44:55 garuda user.notice kernel: [0.000000] random: get_random_bytes called from start_kernel+0x2a8/0x42c with crng_init=0

Sep 5 13:44:55 garuda user.info kernel: [0.000000] arch_timer: cp15 timer(s) running at 50.00MHz (phys).

Sep 5 13:44:55 garuda user.info kernel: [0.000000] clocksource: arch_sys_counter: mask: 0xffffffffffffff max_cycles: 0xb8812736b, max_idle_ns: 440795202655 ns

Sep 5 13:44:55 garuda user.info kernel: [0.000003] sched_clock: 56 bits at 50MHz, resolution 20ns, wraps every 4398046511100ns

Sep 5 13:44:55 garuda user.info kernel: [0.008270] Console: colour dummy device 80x25

Sep 5 13:44:55 garuda user.info kernel: [0.012390] Calibrating delay loop (skipped), value calculated using timer frequency.. 100.00 BogoMIPS (lpj=200000)

Sep 5 13:44:55 garuda user.info kernel: [0.022753] pid_max: default: 32768 minimum: 301

Sep 5 13:44:55 garuda user.info kernel: [0.027475] Mount-cache hash table entries: 2048 (order: 2, 16384 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [0.034695] Mountpoint-cache hash table entries: 2048 (order: 2, 16384 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [0.043447] ASID allocator initialised with 32768 entries

Sep 5 13:44:55 garuda user.info kernel: [0.047894] rcu: Hierarchical SRCU implementation.

Sep 5 13:44:55 garuda user.info kernel: [0.052830] EFI services will not be available.

Sep 5 13:44:55 garuda user.info kernel: [0.057225] smp: Bringing up secondary CPUs ...

Sep 5 13:44:55 garuda user.info kernel: [0.061912] Detected VIPT I-cache on CPU1

Sep 5 13:44:55 garuda user.info kernel: [0.061942] CPU1: Booted secondary processor 0x0000000001 [0x410fd034]

Sep 5 13:44:55 garuda user.info kernel: [0.062277] Detected VIPT I-cache on CPU2

Sep 5 13:44:55 garuda user.info kernel: [0.062294] CPU2: Booted secondary processor 0x0000000002 [0x410fd034]

Sep 5 13:44:55 garuda user.info kernel: [0.062602] Detected VIPT I-cache on CPU3

Sep 5 13:44:55 garuda user.info kernel: [0.062620] CPU3: Booted secondary processor 0x0000000003 [0x410fd034]

Sep 5 13:44:55 garuda user.info kernel: [0.062662] smp: Brought up 1 node, 4 CPUs

Sep 5 13:44:55 garuda user.info kernel: [0.097055] SMP: Total of 4 processors activated.

Sep 5 13:44:55 garuda user.info kernel: [0.101728] CPU features: detected: 32-bit EL0 Support

Sep 5 13:44:55 garuda user.info kernel: [0.106831] CPU features: detected: CRC32 instructions

Sep 5 13:44:55 garuda user.info kernel: [0.111962] CPU: All CPU(s) started at EL2

Sep 5 13:44:55 garuda user.info kernel: [0.116010] alternatives: patching kernel code

Sep 5 13:44:55 garuda user.info kernel: [0.121207] devtmpfs: initialized

Sep 5 13:44:55 garuda user.info kernel: [0.127946] clocksource: jiffies: mask: 0xffffffff max_cycles: 0xffffffff, max_idle_ns: 7645041785100000 ns

Sep 5 13:44:55 garuda user.info kernel: [0.133399] futex hash table entries: 1024 (order: 4, 65536 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [0.145644] xor: measuring software checksum speed

Sep 5 13:44:55 garuda user.info kernel: [0.184300]   8regs   : 2622.000 MB/sec

Sep 5 13:44:55 garuda user.info kernel: [0.224324]   32regs   : 3008.000 MB/sec

Sep 5 13:44:55 garuda user.info kernel: [0.264354]   arm64_neon: 2612.000 MB/sec

Sep 5 13:44:55 garuda user.info kernel: [0.264392] xor: using function: 32regs (3008.000 MB/sec)

Sep 5 13:44:55 garuda user.info kernel: [0.268299] pinctrl core: initialized pinctrl subsystem

Sep 5 13:44:55 garuda user.info kernel: [0.273833] DMI not present or invalid.

Sep 5 13:44:55 garuda user.info kernel: [0.277501] NET: Registered protocol family 16

Sep 5 13:44:55 garuda user.info kernel: [0.282854] DMA: preallocated 256 KiB pool for atomic allocations

Sep 5 13:44:55 garuda user.info kernel: [0.287742] audit: initializing netlink subsys (disabled)

Sep 5 13:44:55 garuda user.notice kernel: [0.293150] audit: type=2000 audit(0.232:1): state=initialized audit_enabled=0 res=1

Sep 5 13:44:55 garuda user.info kernel: [0.293533] hw-breakpoint: found 6 breakpoint and 4 watchpoint registers.

Sep 5 13:44:55 garuda user.info kernel: [0.307656] Serial: AMBA PL011 UART driver

Sep 5 13:44:55 garuda user.info kernel: [0.321761] HugeTLB registered 1.00 GiB page size, pre-allocated 0 pages

Sep 5 13:44:55 garuda user.info kernel: [0.322809] HugeTLB registered 32.0 MiB page size, pre-allocated 0 pages

Sep 5 13:44:55 garuda user.info kernel: [0.329477] HugeTLB registered 2.00 MiB page size, pre-allocated 0 pages

Sep 5 13:44:55 garuda user.info kernel: [0.336134] HugeTLB registered 64.0 KiB page size, pre-allocated 0 pages

Sep 5 13:44:55 garuda user.info kernel: [0.347417] cryptd: max_cpu_qlen set to 1000

Sep 5 13:44:55 garuda user.info kernel: [0.421583] raid6: neonx8   gen() 1709 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.489598] raid6: neonx8   xor() 1618 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.557660] raid6: neonx4   gen() 1642 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.625685] raid6: neonx4   xor() 1578 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.693743] raid6: neonx2   gen() 1252 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.761761] raid6: neonx2   xor() 1313 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.829867] raid6: neonx1   gen()   816 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.897859] raid6: neonx1   xor()   989 MB/s

Sep 5 13:44:55 garuda user.info kernel: [0.965923] raid6: int64x8 gen() 1286 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.033927] raid6: int64x8 xor()   842 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.101980] raid6: int64x4 gen() 1085 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.170014] raid6: int64x4 xor()   817 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.238109] raid6: int64x2 gen()   754 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.306121] raid6: int64x2 xor()   665 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.374178] raid6: int64x1 gen()   499 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.442176] raid6: int64x1 xor()   510 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.442215] raid6: using algorithm neonx8 gen() 1709 MB/s

Sep 5 13:44:55 garuda user.info kernel: [1.446170] raid6: .... xor() 1618 MB/s, rmw enabled

Sep 5 13:44:55 garuda user.info kernel: [1.451101] raid6: using neon recovery algorithm

Sep 5 13:44:55 garuda user.info kernel: [1.456051] iommu: Default domain type: Translated

Sep 5 13:44:55 garuda user.notice kernel: [1.460741] SCSI subsystem initialized

Sep 5 13:44:55 garuda user.debug kernel: [1.464270] libata version 3.00 loaded.

Sep 5 13:44:55 garuda user.info kernel: [1.464381] usbcore: registered new interface driver usbfs

Sep 5 13:44:55 garuda user.info kernel: [1.469722] usbcore: registered new interface driver hub

Sep 5 13:44:55 garuda user.info kernel: [1.474998] usbcore: registered new device driver usb

Sep 5 13:44:55 garuda user.info kernel: [1.480028] pps_core: LinuxPPS API ver. 1 registered

Sep 5 13:44:55 garuda user.info kernel: [1.484922] pps_core: Software ver. 5.3.6 - Copyright 2005-2007 Rodolfo Giometti <giometti@linux.it>

Sep 5 13:44:55 garuda user.info kernel: [1.494011] PTP clock support registered

Sep 5 13:44:55 garuda user.info kernel: [1.497907] EDAC MC: Ver: 3.0.0

Sep 5 13:44:55 garuda user.info kernel: [1.501381] zynqmp-ipi-mbox mailbox@ff990400: Registered ZynqMP IPI mbox with TX/RX channels.

Sep 5 13:44:55 garuda user.info kernel: [1.509689] FPGA manager framework

Sep 5 13:44:55 garuda user.info kernel: [1.513505] clocksource: Switched to clocksource arch_sys_counter

Sep 5 13:44:55 garuda user.notice kernel: [1.519007] VFS: Disk quotas dquot_6.6.0

Sep 5 13:44:55 garuda user.info kernel: [1.522849] VFS: Dquot-cache hash table entries: 512 (order 0, 4096 bytes)

Sep 5 13:44:55 garuda user.info kernel: [1.533315] NET: Registered protocol family 2

Sep 5 13:44:55 garuda user.info kernel: [1.534310] tcp_listen_portaddr_hash hash table entries: 512 (order: 1, 8192 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [1.542296] TCP established hash table entries: 8192 (order: 4, 65536 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [1.550020] TCP bind hash table entries: 8192 (order: 5, 131072 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [1.557252] TCP: Hash tables configured (established 8192 bind 8192)

Sep 5 13:44:55 garuda user.info kernel: [1.563533] UDP hash table entries: 512 (order: 2, 16384 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [1.570060] UDP-Lite hash table entries: 512 (order: 2, 16384 bytes, linear)

Sep 5 13:44:55 garuda user.info kernel: [1.577143] NET: Registered protocol family 1

Sep 5 13:44:55 garuda user.info kernel: [1.581625] RPC: Registered named UNIX socket transport module.

Sep 5 13:44:55 garuda user.info kernel: [1.587256] RPC: Registered udp transport module.

Sep 5 13:44:55 garuda user.info kernel: [1.591924] RPC: Registered tcp transport module.

Sep 5 13:44:55 garuda user.info kernel: [1.596595] RPC: Registered tcp NFSv4.1 backchannel transport module.

Sep 5 13:44:55 garuda user.info kernel: [1.603002] PCI: CLS 0 bytes, default 64

Sep 5 13:44:55 garuda user.info kernel: [1.632970] workingset: timestamp_bits=46 max_order=18 bucket_order=0

Sep 5 13:44:55 garuda user.notice kernel: [1.634515] NFS: Registering the id_resolver key type

Sep 5 13:44:55 garuda user.notice kernel: [1.638798] Key type id_resolver registered

Sep 5 13:44:55 garuda user.notice kernel: [1.642933] Key type id_legacy registered

Sep 5 13:44:55 garuda user.info kernel: [1.646916] nfs4filelayout_init: NFSv4 File Layout Driver Registering...

Sep 5 13:44:55 garuda user.info kernel: [1.653586] jffs2: version 2.2. (NAND) (SUMMARY) © 2001-2006 Red Hat, Inc.

Sep 5 13:44:55 garuda user.info kernel: [1.660842] NET: Registered protocol family 38

Sep 5 13:44:55 garuda user.info kernel: [1.665014] Block layer SCSI generic (bsg) driver version 0.4 loaded (major 247)

Sep 5 13:44:55 garuda user.info kernel: [1.672345] io scheduler mq-deadline registered

Sep 5 13:44:55 garuda user.info kernel: [1.676840] io scheduler kyber registered

Sep 5 13:44:55 garuda user.info kernel: [1.682487] ps_pcie_dma init()

Sep 5 13:44:55 garuda user.info kernel: [1.706318] Serial: 8250/16550 driver, 4 ports, IRQ sharing disabled

Sep 5 13:44:55 garuda user.info kernel: [1.708052] Serial: AMBA driver

Sep 5 13:44:55 garuda user.warn kernel: [1.712237] cacheinfo: Unable to detect cache hierarchy for CPU 0

Sep 5 13:44:55 garuda user.info kernel: [1.720230] brd: module loaded

Sep 5 13:44:55 garuda user.info kernel: [1.724580] loop: module loaded

Sep 5 13:44:55 garuda user.err kernel: [1.725369] mtdoops: mtd device (mtddev=name/number) must be supplied

Sep 5 13:44:55 garuda user.info kernel: [1.729971] libphy: Fixed MDIO Bus: probed

Sep 5 13:44:55 garuda user.info kernel: [1.733824] tun: Universal TUN/TAP device driver, 1.6

Sep 5 13:44:55 garuda user.info kernel: [1.738729] usbcore: registered new interface driver asix

Sep 5 13:44:55 garuda user.info kernel: [1.743219] usbcore: registered new interface driver ax88179_178a

Sep 5 13:44:55 garuda user.info kernel: [1.749265] usbcore: registered new interface driver cdc_ether

Sep 5 13:44:55 garuda user.info kernel: [1.755054] usbcore: registered new interface driver net1080

Sep 5 13:44:55 garuda user.info kernel: [1.760677] usbcore: registered new interface driver cdc_subset

Sep 5 13:44:55 garuda user.info kernel: [1.766557] usbcore: registered new interface driver zaurus

Sep 5 13:44:55 garuda user.info kernel: [1.772104] usbcore: registered new interface driver cdc_ncm

Sep 5 13:44:55 garuda user.info kernel: [1.778458] usbcore: registered new interface driver uas

Sep 5 13:44:55 garuda user.info kernel: [1.783002] usbcore: registered new interface driver usb-storage

Sep 5 13:44:55 garuda user.info kernel: [1.789347] rtc_zynqmp ffa60000.rtc: registered as rtc0

Sep 5 13:44:55 garuda user.info kernel: [1.794183] SFP: i2c device initilization

Sep 5 13:44:55 garuda user.info kernel: [1.798118] SFP: alloc_chrdev_region completed, Major number : 245

Sep 5 13:44:55 garuda user.info kernel: [1.804262] SFP: class_create() completed

Sep 5 13:44:55 garuda user.info kernel: [1.808234] SFP: Device memory allocation completed

Sep 5 13:44:55 garuda user.info kernel: [1.813090] SFP: i2c_add_driver() completed

Sep 5 13:44:55 garuda user.info kernel: [1.817230] SFP: sfp_i2c_init_driver() Completed Successfully

Sep 5 13:44:55 garuda user.info kernel: [1.822939] i2c /dev entries driver

Sep 5 13:44:55 garuda user.info kernel: [1.826802] pps pps0: new PPS source ptp0

Sep 5 13:44:55 garuda user.info kernel: [1.830404] xlnx_ptp_timer b0050000.timer_1588_v2_0_1: Acquired ptp_irq: 0x33

Sep 5 13:44:55 garuda user.info kernel: [1.837917] EDAC MC: ECC not enabled

Sep 5 13:44:55 garuda user.info kernel: [1.841144] EDAC DEVICE0: Giving out device to module zynqmp-ocm-edac controller zynqmp_ocm: DEV ff960000.memory-controller (INTERRUPT)

Sep 5 13:44:55 garuda user.info kernel: [1.853532] sdhci: Secure Digital Host Controller Interface driver

Sep 5 13:44:55 garuda user.info kernel: [1.859270] sdhci: Copyright(c) Pierre Ossman

Sep 5 13:44:55 garuda user.info kernel: [1.863593] sdhci-pltfm: SDHCI platform and OF driver helper

Sep 5 13:44:55 garuda user.info kernel: [1.869463] zynqmp_firmware_probe Platform Management API v1.1

Sep 5 13:44:55 garuda user.info kernel: [1.875016] zynqmp_firmware_probe Trustzone version v1.0

Sep 5 13:44:55 garuda user.info kernel: [1.903207] securefw securefw: securefw probed^M

Sep 5 13:44:55 garuda user.info kernel: [1.903431] alg: No test for xilinx-zynqmp-aes (zynqmp-aes)

Sep 5 13:44:55 garuda user.info kernel: [1.907785] zynqmp_aes zynqmp_aes: AES Successfully Registered

Sep 5 13:44:55 garuda user.info kernel: [1.907785] ^M

Sep 5 13:44:55 garuda user.info kernel: [1.915139] alg: No test for xilinx-keccak-384 (zynqmp-keccak-384)

Sep 5 13:44:55 garuda user.info kernel: [1.921347] alg: No test for xilinx-zynqmp-rsa (zynqmp-rsa)

Sep 5 13:44:55 garuda user.info kernel: [1.926886] usbcore: registered new interface driver usbhid

Sep 5 13:44:55 garuda user.info kernel: [1.932200] usbhid: USB HID core driver

Sep 5 13:44:55 garuda user.info kernel: [1.938193] ARM CCI_400_r1 PMU driver probed

Sep 5 13:44:55 garuda user.info kernel: [1.938646] fpga_manager fpga0: Xilinx ZynqMP FPGA Manager registered

Sep 5 13:44:55 garuda user.info kernel: [1.946929] pktgen: Packet Generator for packet performance testing. Version: 2.75

Sep 5 13:44:55 garuda user.info kernel: [1.954694] Initializing XFRM netlink socket

Sep 5 13:44:55 garuda user.info kernel: [1.958490] NET: Registered protocol family 10

Sep 5 13:44:55 garuda user.info kernel: [1.963207] Segment Routing with IPv6

Sep 5 13:44:55 garuda user.info kernel: [1.966560] sit: IPv6, IPv4 and MPLS over IPv4 tunneling driver

Sep 5 13:44:55 garuda user.info kernel: [1.972650] NET: Registered protocol family 17

Sep 5 13:44:55 garuda user.info kernel: [1.976757] NET: Registered protocol family 15

Sep 5 13:44:55 garuda user.info kernel: [1.981174] bridge: filtering via arp/ip/ip6tables is no longer available by default. Update your scripts to load br_netfilter if you need this.

Sep 5 13:44:55 garuda user.info kernel: [1.994077] 8021q: 802.1Q VLAN Support v1.8

Sep 5 13:44:55 garuda user.info kernel: [1.998281] 9pnet: Installing 9P2000 support

Sep 5 13:44:55 garuda user.notice kernel: [2.002453] Key type dns_resolver registered

Sep 5 13:44:55 garuda user.info kernel: [2.006941] registered taskstats version 1

Sep 5 13:44:55 garuda user.info kernel: [2.011703] Btrfs loaded, crc32c=crc32c-generic

Sep 5 13:44:55 garuda user.info kernel: [2.023729] ff000000.serial: ttyPS0 at MMIO 0xff000000 (irq = 41, base_baud = 6250000) is a xuartps

Sep 5 13:44:55 garuda user.info kernel: [2.032750] printk: console [ttyPS0] enabled

Sep 5 13:44:55 garuda user.info kernel: [2.037045] printk: bootconsole [cdns0] disabled

Sep 5 13:44:55 garuda user.info kernel: [2.046323] ff010000.serial: ttyPS1 at MMIO 0xff010000 (irq = 42, base_baud = 6250000) is a xuartps

Sep 5 13:44:55 garuda user.info kernel: [2.059763] of-fpga-region fpga-full: FPGA Region probed

Sep 5 13:44:55 garuda user.info kernel: [2.065658] XGpio: gpio@b0040000: registered, base is 509

Sep 5 13:44:55 garuda user.info kernel: [2.071343] XGpio: gpio@b0040000: dual channel registered, base is 497

Sep 5 13:44:55 garuda user.info kernel: [2.078464] xilinx-zynqmp-dma fd500000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.085570] xilinx-zynqmp-dma fd510000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.092657] xilinx-zynqmp-dma fd520000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.099751] xilinx-zynqmp-dma fd530000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.106839] xilinx-zynqmp-dma fd540000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.113937] xilinx-zynqmp-dma fd550000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.121023] xilinx-zynqmp-dma fd560000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.128113] xilinx-zynqmp-dma fd570000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.135273] xilinx-zynqmp-dma ffa80000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.142360] xilinx-zynqmp-dma ffa90000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.149450] xilinx-zynqmp-dma ffaa0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.156544] xilinx-zynqmp-dma ffab0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.163637] xilinx-zynqmp-dma ffac0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.170728] xilinx-zynqmp-dma ffad0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.177819] xilinx-zynqmp-dma ffae0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.info kernel: [2.184912] xilinx-zynqmp-dma ffaf0000.dma: ZynqMP DMA driver Probe success

Sep 5 13:44:55 garuda user.warn kernel: [2.192940] ------------[cut here]------------

Sep 5 13:44:55 garuda user.warn kernel: [2.197551] /amba/spi@ff050000/spidev@0: buggy DT: spidev listed directly in DT

Sep 5 13:44:55 garuda user.warn kernel: [2.204905] WARNING: CPU: 1 PID: 31 at drivers/spi/spidev.c:727 spidev_probe+0xf8/0x1c8

Sep 5 13:44:55 garuda user.warn kernel: [2.212896] Modules linked in:

Sep 5 13:44:55 garuda user.warn kernel: [2.215939] CPU: 1 PID: 31 Comm: kworker/1:1 Not tainted 5.4.0-xilinx-v2020.2 #1

Sep 5 13:44:55 garuda user.warn kernel: [2.223321] Hardware name: xlnx,zynqmp (DT)

Sep 5 13:44:55 garuda user.warn kernel: [2.227493] Workqueue: events deferred_probe_work_func

Sep 5 13:44:55 garuda user.warn kernel: [2.232619] pstate: 60000005 (nZCv daif -PAN -UAO)

Sep 5 13:44:55 garuda user.warn kernel: [2.237392] pc : spidev_probe+0xf8/0x1c8

Sep 5 13:44:55 garuda user.warn kernel: [2.241298] lr : spidev_probe+0xf8/0x1c8

Sep 5 13:44:55 garuda user.warn kernel: [2.245203] sp : ffff8000110537d0

Sep 5 13:44:55 garuda user.warn kernel: [2.248501] x29: ffff8000110537d0 x28: ffff00003fcea270

Sep 5 13:44:55 garuda user.warn kernel: [2.253796] x27: ffff00002e718410 x26: ffff00002d1d0c00

Sep 5 13:44:55 garuda user.warn kernel: [2.259091] x25: 0000000000000000 x24: 0000000000000019

Sep 5 13:44:55 garuda user.warn kernel: [2.264385] x23: ffff800010e778c8 x22: 0000000000000000

Sep 5 13:44:55 garuda user.warn kernel: [2.269680] x21: ffff800010e778a8 x20: ffff00002d1d0000

Sep 5 13:44:55 garuda user.warn kernel: [2.274975] x19: 0000000000000000 x18: 0000000000000010

Sep 5 13:44:55 garuda user.warn kernel: [2.280270] x17: 0000000000000000 x16: 0000000000000000

Sep 5 13:44:55 garuda user.warn kernel: [2.285565] x15: ffff00002e6c0868 x14: ffffffffffffffff

Sep 5 13:44:55 garuda user.warn kernel: [2.290859] x13: ffff800091053517 x12: ffff80001105351f

Sep 5 13:44:55 garuda user.warn kernel: [2.296154] x11: ffff800010e44000 x10: 0000000000000000

Sep 5 13:44:55 garuda user.warn kernel: [2.301449] x9 : ffff800010ece000 x8 : 00000000000000dc

Sep 5 13:44:55 garuda user.warn kernel: [2.306744] x7 : 0000000000000006 x6 : ffff800010ece0f2

Sep 5 13:44:55 garuda user.warn kernel: [2.312038] x5 : 0000000000000007 x4 : 0000000000000000

Sep 5 13:44:55 garuda user.warn kernel: [2.317333] x3 : 0000000000000000 x2 : 00000000ffffffff

Sep 5 13:44:55 garuda user.warn kernel: [2.322628] x1 : 781f90689266b400 x0 : 0000000000000000

Sep 5 13:44:55 garuda user.warn kernel: [2.327923] Call trace:

Sep 5 13:44:55 garuda user.warn kernel: [2.330355] spidev_probe+0xf8/0x1c8

Sep 5 13:44:55 garuda user.warn kernel: [2.333916] spi_drv_probe+0x7c/0xd8

Sep 5 13:44:55 garuda user.warn kernel: [2.337481] really_probe+0xd8/0x2f8

Sep 5 13:44:55 garuda user.warn kernel: [2.341040] driver_probe_device+0x54/0xe8

Sep 5 13:44:55 garuda user.warn kernel: [2.345119] __device_attach_driver+0x80/0xb8

Sep 5 13:44:55 garuda user.warn kernel: [2.349462] bus_for_each_drv+0x74/0xc0

Sep 5 13:44:55 garuda user.warn kernel: [2.353287] __device_attach+0xdc/0x138

Sep 5 13:44:55 garuda user.warn kernel: [2.357106] device_initial_probe+0x10/0x18

Sep 5 13:44:55 garuda user.warn kernel: [2.361273] bus_probe_device+0x90/0x98

Sep 5 13:44:55 garuda user.warn kernel: [2.365093] device_add+0x334/0x600

Sep 5 13:44:55 garuda user.warn kernel: [2.368564] spi_add_device+0xac/0x170

Sep 5 13:44:55 garuda user.warn kernel: [2.372297] of_register_spi_device+0x204/0x388

Sep 5 13:44:55 garuda user.warn kernel: [2.376813] spi_register_controller+0x4b4/0x718

Sep 5 13:44:55 garuda user.warn kernel: [2.381420] cdns_spi_probe+0x28c/0x368

Sep 5 13:44:55 garuda user.warn kernel: [2.385239] platform_drv_probe+0x50/0xa0

Sep 5 13:44:55 garuda user.warn kernel: [2.389231] really_probe+0xd8/0x2f8

Sep 5 13:44:55 garuda user.warn kernel: [2.392790] driver_probe_device+0x54/0xe8

Sep 5 13:44:55 garuda user.warn kernel: [2.396870] __device_attach_driver+0x80/0xb8

Sep 5 13:44:55 garuda user.warn kernel: [2.401210] bus_for_each_drv+0x74/0xc0

Sep 5 13:44:55 garuda user.warn kernel: [2.405028] __device_attach+0xdc/0x138

Sep 5 13:44:55 garuda user.warn kernel: [2.408848] device_initial_probe+0x10/0x18

Sep 5 13:44:55 garuda user.warn kernel: [2.413014] bus_probe_device+0x90/0x98

Sep 5 13:44:55 garuda user.warn kernel: [2.416833] deferred_probe_work_func+0x6c/0xa0

Sep 5 13:44:55 garuda user.warn kernel: [2.421349] process_one_work+0x1c4/0x338

Sep 5 13:44:55 garuda user.warn kernel: [2.425340] worker_thread+0x260/0x488

Sep 5 13:44:55 garuda user.warn kernel: [2.429074] kthread+0x120/0x128

Sep 5 13:44:55 garuda user.warn kernel: [2.432285] ret_from_fork+0x10/0x18

Sep 5 13:44:55 garuda user.warn kernel: [2.435843] ---[end trace f05957baa17b149d]---

Sep 5 13:44:55 garuda user.warn kernel: [2.440578] zynqmp_pll_disable() clock disable failed for dpll_int, ret = -13

Sep 5 13:44:55 garuda user.info kernel: [2.448115] macb ff0d0000.ethernet: Not enabling partial store and forward

Sep 5 13:44:55 garuda user.info kernel: [2.455497] libphy: MACB_mii_bus: probed

Sep 5 13:44:55 garuda user.err kernel: [2.461549] macb ff0d0000.ethernet eth0: no PHY found

Sep 5 13:44:55 garuda user.err kernel: [2.482202] xilinx_axienet b0000000.ethernet: IRQ index 0 not found

Sep 5 13:44:55 garuda user.info kernel: [2.488465] xilinx_axienet b0000000.ethernet: Ethernet core IRQ not defined

Sep 5 13:44:55 garuda user.warn kernel: [2.495426] xilinx_axienet b0000000.ethernet: couldn't find phy i/f

Sep 5 13:44:55 garuda user.info kernel: [2.502178] xilinx-axipmon ffa00000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:55 garuda user.info kernel: [2.508688] xilinx-axipmon fd0b0000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:55 garuda user.info kernel: [2.515170] xilinx-axipmon fd490000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:55 garuda user.info kernel: [2.521646] xilinx-axipmon ffa10000.perf-monitor: Probed Xilinx APM

Sep 5 13:44:55 garuda user.info kernel: [2.528288] cdns-i2c ff020000.i2c: 400 kHz mmio ff020000 irq 32

Sep 5 13:44:55 garuda user.info kernel: [2.534663] SFP: In sfp_i2c device probe

Sep 5 13:44:55 garuda user.info kernel: [2.538578] SFP: device name : sfp0

Sep 5 13:44:55 garuda user.info kernel: [2.542058] SFP: minor number : 00

Sep 5 13:44:55 garuda user.info kernel: [2.545444] SFP: Driver name : sfp0

Sep 5 13:44:55 garuda user.info kernel: [2.548921] SFP: I2C Bus number : 1

Sep 5 13:44:55 garuda user.info kernel: [2.552454] SFP: construct_sfp_device() with minor number 0 completed

Sep 5 13:44:55 garuda user.info kernel: [2.558888] SFP: add i2c client : 0

Sep 5 13:44:55 garuda user.info kernel: [2.562389] cdns-i2c ff030000.i2c: 400 kHz mmio ff030000 irq 33

Sep 5 13:44:55 garuda user.info kernel: [2.568588] cdns-wdt fd4d0000.watchdog: Xilinx Watchdog Timer with timeout 60s

Sep 5 13:44:55 garuda user.info kernel: [2.576003] cdns-wdt ff150000.watchdog: Xilinx Watchdog Timer with timeout 10s

Sep 5 13:44:55 garuda user.warn kernel: [2.583577] cpufreq: cpufreq_online: CPU0: Running at unlisted freq: 1325000 KHz

Sep 5 13:44:55 garuda user.err kernel: [2.590973] cpu cpu0: dev_pm_opp_set_rate: failed to find current OPP for freq 1325000000 (-34)

Sep 5 13:44:55 garuda user.warn kernel: [2.599704] cpufreq: cpufreq_online: CPU0: Unlisted initial frequency changed to: 1199999 KHz

Sep 5 13:44:55 garuda user.err kernel: [2.608233] cpu cpu0: dev_pm_opp_set_rate: failed to find current OPP for freq 1325000000 (-34)

Sep 5 13:44:55 garuda user.info kernel: [2.650210] mmc0: SDHCI controller on ff160000.mmc [ff160000.mmc] using ADMA 64-bit

Sep 5 13:44:55 garuda user.info kernel: [2.660271] rtc_zynqmp ffa60000.rtc: setting system clock to 2022-09-05T13:44:38 UTC (1662385478)

Sep 5 13:44:55 garuda user.info kernel: [2.669140] of_cfs_init

Sep 5 13:44:55 garuda user.info kernel: [2.671598] of_cfs_init: OK

Sep 5 13:44:55 garuda user.warn kernel: [2.674506] clk: Not disabling unused clocks

Sep 5 13:44:55 garuda user.info kernel: [2.679477] Waiting for root device /dev/mmcblk0p3...

Sep 5 13:44:55 garuda user.info kernel: [2.759177] mmc0: new HS200 MMC card at address 0001

Sep 5 13:44:55 garuda user.info kernel: [2.764563] mmcblk0: mmc0:0001 DG4008 7.28 GiB

Sep 5 13:44:55 garuda user.info kernel: [2.769284] mmcblk0boot0: mmc0:0001 DG4008 partition 1 4.00 MiB

Sep 5 13:44:55 garuda user.info kernel: [2.775398] mmcblk0boot1: mmc0:0001 DG4008 partition 2 4.00 MiB

Sep 5 13:44:55 garuda user.info kernel: [2.781376] mmcblk0rpmb: mmc0:0001 DG4008 partition 3 4.00 MiB, chardev (244:0)

Sep 5 13:44:55 garuda user.info kernel: [2.789860] mmcblk0: p1 p2 p3 p4

Sep 5 13:44:55 garuda user.info kernel: [2.817209] EXT4-fs (mmcblk0p3): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:55 garuda user.info kernel: [2.825315] VFS: Mounted root (ext4 filesystem) on device 179:3.

Sep 5 13:44:55 garuda user.info kernel: [2.831914] devtmpfs: mounted

Sep 5 13:44:55 garuda user.info kernel: [2.835118] Freeing unused kernel memory: 704K

Sep 5 13:44:55 garuda user.info kernel: [2.839614] Run /sbin/init as init process

Sep 5 13:44:55 garuda user.notice kernel: [2.849145] random: fast init done

Sep 5 13:44:55 garuda daemon.info kernel: [3.049081] udevd[313]: starting version 3.2.8

Sep 5 13:44:55 garuda user.notice kernel: [3.056109] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:55 garuda user.notice kernel: [3.062918] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:55 garuda user.notice kernel: [3.069666] random: udevd: uninitialized urandom read (16 bytes read)

Sep 5 13:44:55 garuda daemon.info kernel: [3.088818] udevd[314]: starting eudev-3.2.8

Sep 5 13:44:55 garuda user.warn kernel: [3.472193] EXT4-fs (mmcblk0p2): warning: mounting fs with errors, running e2fsck is recommended

Sep 5 13:44:55 garuda user.info kernel: [3.481938] EXT4-fs (mmcblk0p2): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:55 garuda user.info kernel: [3.508318] EXT4-fs (mmcblk0p4): mounted filesystem with ordered data mode. Opts: (null)

Sep 5 13:44:55 garuda user.info kernel: [3.577194] EXT4-fs (mmcblk0p3): re-mounted. Opts: (null)

Sep 5 13:44:55 garuda user.warn kernel: [13.754544] urandom_read: 4 callbacks suppressed

Sep 5 13:44:55 garuda user.notice kernel: [13.754549] random: dd: uninitialized urandom read (512 bytes read)

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Plugin "/usr/lib/libyang1/extensions/yangdata.so" successfully loaded.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Plugin "/usr/lib/libyang1/extensions/nacm.so" successfully loaded.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Plugin "/usr/lib/libyang1/extensions/metadata.so" successfully loaded.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Plugin "/usr/lib/libyang1/user_types/user_inet_types.so" successfully loaded.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Plugin "/usr/lib/libyang1/user_types/user_yang_types.so" successfully loaded.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Reading module "ietf-yang-metadata".

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-yang-metadata@2016-08-05" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Reading module "yang".

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "yang" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "yang" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "yang@2017-02-20" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Reading module "ietf-inet-types".

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving derived type "union" failed, it will be attempted later.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving derived type "union" failed, it will be attempted later.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving derived type "union" failed, it will be attempted later.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving derived type "union" failed, it will be attempted later.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-inet-types" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-inet-types" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-inet-types@2013-07-15" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Reading module "ietf-yang-types".

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-yang-types@2013-07-15" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-types" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from

"/etc/sysrepo/yang/yang_models/imported/ietf/ietf-yang-types.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-yang-types@2013-07-15" already in context.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-yang-types@2013-07-15" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "sysrepo" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "sysrepo" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "sysrepo@2021-01-18" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe55" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe53" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe15" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe36" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe56" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe58" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe45" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe23" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe5" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe10" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe49" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe29" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe3" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe39" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe30" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe19" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe17" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe51" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe6" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe4" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe43" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe60" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe54" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe18" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe16" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe42" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe2" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe35" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe28" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe20" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe38" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe48" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe12" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe1" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe11" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe8" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe44" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe50" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe13" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe52" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe32" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe33" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe14" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe46" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe21" after a crashed subscription.

Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe31" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe34" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe40" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe37" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe26" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe9" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe47" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe25" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe24" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe7" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe22" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe59" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe41" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe27" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Removing event pipe "sr_evpipe57" after a crashed subscription.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 81 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 86 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 83 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 91 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 96 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 84 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 92 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 82 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 90 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 89 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 88 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 94 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 87 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 93 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 85 is dead.
Sep 5 13:45:00 garuda daemon.warn netopeer2-server[859]: Connection with CID 95 is dead.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Applying scheduled changes.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-datastores@2018-02-14.yang" file.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-datastores@2018-02-14" successfully parsed as implemented.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-library" in /etc/sysrepo/yang.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-yang-library@2019-01-04.yang" file.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/imported.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/imported/iana.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/imported/ietf.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/custom.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran/operations.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.
Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-inet-types" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/yang_models/imported/ietf/ietf-inet-types.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-inet-types@2013-07-15" already in context.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-inet-types@2013-07-15" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-datastores" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-datastores@2018-02-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-yang-library@2019-01-04" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "sysrepo-monitoring" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/sysrepo-monitoring@2021-01-15.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "sysrepo-monitoring" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "sysrepo-monitoring" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "sysrepo-monitoring@2021-01-15" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "sysrepo-plugind" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/sysrepo-plugind@2020-12-10.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "sysrepo-plugind@2020-12-10" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-with-defaults@2011-06-01.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf@2013-09-29.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-acm" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-acm@2018-02-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-acm@2018-02-14" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf@2013-09-29" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-netconf-with-defaults" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-netconf-with-defaults" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-with-defaults@2011-06-01" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-notifications" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-notifications@2012-02-06.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-netconf-notifications" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-netconf-notifications" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-notifications@2012-02-06" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-origin@2018-02-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-yang-metadata" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-origin" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-origin" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-origin@2018-02-14" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-acm@2018-02-14" now implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-monitoring" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-monitoring@2010-10-04.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-monitoring@2010-10-04" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-nmda" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-nmda@2019-01-07.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-origin" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-origin@2018-02-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-with-defaults" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-with-defaults@2011-06-01.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-netconf-nmda" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-netconf-nmda" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-nmda@2019-01-07" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "nc-notifications" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/nc-notifications@2008-07-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notifications" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/notifications@2008-07-14.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "notifications@2008-07-14" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "nc-notifications@2008-07-14" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "notifications@2008-07-14" now implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-x509-cert-to-name@2014-12-10.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-x509-cert-to-name@2014-12-10" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-crypto-types@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-crypto-types@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-keystore@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-crypto-types" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-crypto-types@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-keystore" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-keystore" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-keystore@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-truststore@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-truststore@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tcp-common@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-tcp-common@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ssh-server" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-ssh-server@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ssh-common" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-ssh-common@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-ssh-common@2019-07-02" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-keystore" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-keystore@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-crypt-hash" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/iana-crypt-hash@2014-08-06.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "iana-crypt-hash@2014-08-06" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-ssh-server@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tls-server" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tls-server@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tls-common" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tls-common@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-tls-common@2019-07-02" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-truststore" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-truststore@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-tls-server@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-netconf-server" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-netconf-server@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in

/etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in

/etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-x509-cert-to-name" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-x509-cert-to-name@2014-12-10.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-client" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tcp-client@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-common" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tcp-common@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-tcp-client@2019-07-02" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-tcp-server" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-tcp-server@2019-07-02.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-tcp-server@2019-07-02" successfully parsed as imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-netconf-server" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-netconf-server" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-netconf-server@2019-07-02" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "stli_giru-wdm" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/stli_giru-wdm@2021-05-06.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "stli_giru-wdm@2021-05-06" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "stli_giru-opm" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/stli_giru-opm@2020-11-08.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "stli_giru-opm@2020-11-08" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "notification_history" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/notification_history.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "notification_history" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/iana-hardware@2018-03-13.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "iana-hardware@2018-03-13" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-hardware@2018-03-13.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-hardware" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/iana-hardware@2018-03-13.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "ietf-hardware" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "ietf-hardware" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-hardware@2018-03-13" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-interfaces@2018-02-20.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-interfaces@2018-02-20" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/iana-if-type@2017-01-19.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-interfaces@2018-02-20.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "iana-if-type@2017-01-19" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-dhcpv6-types" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-dhcpv6-types@2018-01-30.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-dhcpv6-types@2018-01-30" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-ip@2018-02-22.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "ietf-ip@2018-02-22" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-dhcp" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-dhcp@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-dhcp@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-interfaces@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "iana-if-type" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/iana-if-type@2017-01-19.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-ip" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-ip@2018-02-22.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "ietf-hardware" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/ietf-hardware@2018-03-13.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-interfaces" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-interfaces" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-interfaces@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-mplane-int" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-mplane-int@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-interfaces" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-interfaces@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-mplane-int@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-transceiver" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-transceiver@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-transceiver" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-transceiver" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-transceiver@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from

"/etc/sysrepo/yang/o-ran-processing-element@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-processing-element" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-processing-element" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-processing-element@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-supervision" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-supervision@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-supervision@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-hardware@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-hardware" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-hardware" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-hardware@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-fm" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-fm@2019-02-04.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-fm@2019-02-04" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-usermgmt" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-usermgmt@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-usermgmt" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-usermgmt" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-usermgmt@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-sync" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-sync@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-sync" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-sync" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-sync@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-compression-factors@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-compression-factors@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-module-cap" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-module-cap@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-compression-factors" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-compression-factors@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-module-cap" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-module-cap" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-module-cap@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-delay-management" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-delay-management@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-delay-management@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-operations" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-operations@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-operations" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-operations" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-operations@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-uplane-conf" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-uplane-conf@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-processing-element" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-processing-element@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-uplane-conf" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-uplane-conf" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-uplane-conf@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-file-management@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-file-management" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-file-management" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-file-management@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-software-management" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-software-management@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-hardware" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-hardware@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/imported.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/imported/iana.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/imported/ietf.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/custom.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran/operations.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran/interfaces.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran/system.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran/sync.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-file-management" in /etc/sysrepo/yang/yang_models/o-ran/radio.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-file-management@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-software-management" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-software-management" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-software-management@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-performance-management" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-performance-management@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-performance-management@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-trace" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-trace@2019-07-03.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-trace" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-trace" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-trace@2019-07-03" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Searching for "o-ran-troubleshooting" in /etc/sysrepo/yang.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Loading schema from "/etc/sysrepo/yang/o-ran-troubleshooting@2019-02-04.yang" file.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving "o-ran-troubleshooting" unresolved schema nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All "o-ran-troubleshooting" schema nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Module "o-ran-troubleshooting@2019-02-04" successfully parsed as implemented.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: No scheduled changes.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Datastore copied from <startup> to <running>.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Connection 1 created.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Session 1 (user "root", CID 1) created.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Listening on :::830 for SSH connections.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-server" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-keystore" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-truststore" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-acm" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-acm" "done" event on enabled data.

Sep 5 13:45:00 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-acm" "done" event on enabled data.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Triggering "ietf-netconf-acm" "done" event on enabled data.

Sep 5 13:45:01 garuda user.err SYS_MONITOR[874]: previous boot not done by BMC

Sep 5 13:45:01 garuda user.notice nw_manager[888]: Process started

Sep 5 13:45:01 garuda user.notice kernel: [25.844475] random: crng init done

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Processing "ietf-netconf-acm" "done" event with ID 1 priority 0 (remaining 4 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Processing "ietf-keystore" "done" event with ID 1 priority 0 (remaining 1 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint0", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint1", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint2", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint3", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Processing "ietf-netconf-server" "done" event with ID 1 priority 0 (remaining 22 subscribers).

Sep 5 13:45:01 garuda daemon.err netopeer2-server[859]: Call Home client "default-client" was not found.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 13:45:01 garuda user.notice nw_manager[888]: Replaced the running datastore with basic user configuration

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Processing "ietf-keystore" "done" event with ID 2 priority 0 (remaining 1 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Processing "ietf-netconf-server" "done" event with ID 2 priority 0 (remaining 22 subscribers).

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Listening on :::830 for SSH connections.

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 13:45:01 garuda user.notice nw_manager[888]: Read basic system interface details

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: Event change changes to: ietf-hardware

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component : ru-module for component ru-module

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component class: o-ran-hardware:O-RAN-RADIO for component ru-module

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component oran name: ru-module for component ru-module

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component : ru-port0 for component ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component class: iana-hardware:port for component ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component parent: ru-module for component ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component parent rel pos: 0 for component ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component oran name: ru-port0 for component ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component : ru-port1 for component ru-port1

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component class: iana-hardware:port for component ru-port1

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component parent: ru-module for component ru-port1

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component parent rel pos: 1 for component ru-port1

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: [config] component oran name: ru-port1 for component ru-port1

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: Event done changes to: ietf-hardware

Sep 5 13:45:01 garuda user.info nw_manager[888]: SR_HW: Config has changed in :ietf-hardware

Sep 5 13:45:01 garuda user.info nw_manager[888]: IFMNGR: EVENT change CHANGES: for module name: ietf-interfaces

Sep 5 13:45:01 garuda user.info nw_manager[888]: Interface : eth0 Netmask : 255.255.255.0

Sep 5 13:45:01 garuda user.info nw_manager[888]: Interface : eth0 O-RU port name ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: Interface : eth0.100 O-RU port name ru-port0

Sep 5 13:45:01 garuda user.info nw_manager[888]: Base interface : eth0.100 standard port : eth0 O-RU port-number : 0

Sep 5 13:45:01 garuda user.info nw_manager[888]: IFMNGR: EVENT done CHANGES: for module name: ietf-interfaces

Sep 5 13:45:01 garuda user.info nw_manager[888]: VLAN: Added VLAN with VID == 100 to IF -:eth0:- devname eth0.100

Sep 5 13:45:01 garuda user.notice nw_manager[888]: Application subscribed for edit-config,get

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Call Home client "default-client" connecting...

Sep 5 13:45:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:01 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:02 garuda user.info FAULT MANAGEMENT[915]: ========= LISTENING FOR CHANGES =========

Sep 5 13:45:02 garuda daemon.info netopeer2-server[859]: Processing "ietf-netconf-acm" "done" event with ID 2 priority 0 (remaining 4 subscribers).

Sep 5 13:45:02 garuda daemon.info netopeer2-server[859]: Successful processing of "done" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 13:45:02 garuda user.notice USERMGMT[925]: Complete copying o-ran-usermgmt startup configurations

Sep 5 13:45:02 garuda user.notice USERMGMT[925]: LISTENING FOR CHANGES

Sep 5 13:45:02 garuda daemon.info netopeer2-server[859]: Call Home client "default-client" connecting...

Sep 5 13:45:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:02 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:02 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:03 garuda user.notice fw_manager[936]: Process started

Sep 5 13:45:03 garuda user.notice fw_manager[936]: Listening for RPCs

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: LISTENING FOR CHANGES

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: EVENT change CHANGES

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 255

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 248

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 165

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 160

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 150

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 140

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 135

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 7

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Accepted-clock-classes : 6

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM PRC

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM EEC1

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM DNU

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM NONE

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM PRC

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM EEC1

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM DNU

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM NONE

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM PRC

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM EEC1

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM DNU

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Acceptance SSM NONE

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: ssm_timeout : 5

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Change in Configuration of S plane

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: END OF CHANGES

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: EVENT done CHANGES

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: Writing Configuration of S plane

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: END OF CHANGES

Sep 5 13:45:03 garuda user.notice SYNCMNGR[1182]: SYNC-LOCK-STATE CHANGE NOTIFICATION

Sep 5 13:45:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:03 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:03 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:04 garuda user.notice OPM[1193]: Operation manager init :subscribed for edit-config, get, rpc on o-ran-operations

Sep 5 13:45:04 garuda user.notice OPM[1193]: Operation manager init :subscribed for edit-config, get, rpc on o-ran-processing-element

Sep 5 13:45:04 garuda user.notice OPM[1193]: Operation manager init :subscribed for edit-config, get, rpc on o-ran-uplane-conf

Sep 5 13:45:04 garuda user.notice SR_OP[1193]: Event change detected on o-ran-operations

Sep 5 13:45:04 garuda user.notice SR_OP[1193]: [config]timezone name changed to GMT [event: change]

Sep 5 13:45:04 garuda user.notice SR_OP[1193]: Event change detected on o-ran-operations

Sep 5 13:45:04 garuda user.notice SR_OP[1193]: [config]timezone name changed to GMT [event: done]

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: EVENT change CHANGES

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: interface name : eth0.100

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: ru-mac : 98:ae:71:01:64:d8

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: VLAN-ID : 100

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: du-mac : f8:f2:1e:a8:07:6d

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: EVENT done CHANGES

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: interface name : eth0.100

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: ru-mac : 98:ae:71:01:64:d8

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: VLAN-ID : 100

Sep 5 13:45:04 garuda user.notice PROCESSING-ELEMENTS[1193]: FPGA interface element0: du-mac : f8:f2:1e:a8:07:6d

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES:

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-link name : lltxlink0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-array-carrier : txarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint : slltx-endpoint0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-link name : lltxlink1

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-array-carrier : txarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint : slltx-endpoint1

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-link name : lltxlink2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-array-carrier : txarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint : slltx-endpoint2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-link name : lltxlink3

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-array-carrier : txarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint : slltx-endpoint3

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-link name : llrxlink0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-array-carrier : rxarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint : sllrx-endpoint0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-link name : llrxlink1

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES:

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-array-carrier : rxarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint : sllrx-endpoint1

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-link name : llrxlink2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-array-carrier : rxarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint : sllrx-endpoint2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-link name : llrxlink3

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-processing element : element0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-array-carrier : rxarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint : sllrx-endpoint3

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-name : txarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES:

/o-ran-uplane-conf:user-plane-configuration/low-level-tx-endpoints

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES:

/o-ran-uplane-conf:user-plane-configuration/low-level-rx-endpoints

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: EVENT change CHANGES:

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-absolute-frequency-center : 646667

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-frequency-reference-center: 0.000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-name : rxarraycarrier0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-absolute-frequency-center   : 646667

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-frequency-reference-center: 0.000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-center-of-channel-bandwidth : 3600000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-channel-bandwidth : 100000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-active : ACTIVE

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-downlink-radio-frame-offset : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-downlink-sfn-offset : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-gain-correction : 0.000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-n-ta-offset : 25600

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-channel-bandwidth : 100000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-active : ACTIVE

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-gain : 0.000000

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-downlink-radio-frame-offset : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-downlink-sfn-offset : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 1
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint1
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 2
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 1
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint2
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint1
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 3
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint3
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288
Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-number-of-prb : 273

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:04 garuda user.notice file_manager[1224]: Process started

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 4

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint2

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:04 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 3

Sep 5 13:45:04 garuda user.notice file_manager[1224]: Listening for RPCs

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint3

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-number-of-prb : 273

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:04 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 4

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES:

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES:

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES:

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-name : rxarraycarrier0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-absolute-frequency-center   : 646667

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES:

/o-ran-uplane-conf:user-plane-configuration/low-level-rx-endpoints

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-name : txarraycarrier0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: EVENT done CHANGES:

/o-ran-uplane-conf:user-plane-configuration/low-level-tx-endpoints

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-absolute-frequency-center : 646667

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor f50f3f0f

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor af13f0f

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor 3179d766

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor ce87d766

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor c005fe6e

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 2f6c2afb

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 3ffbfe6e

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor f82ac07b

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor dc723537

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor d0942afb

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor 3dafeeee

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor c625e4a3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 7d6c07b

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 19ef3a82

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 238e3537

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor 1294c2c1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor c9ee223d

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c251eeee

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 3f4f0964

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor d632cf8a

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 4000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 39dbe4a3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor af1c0f1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor e6113a82

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor ce87289a

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor ed6cc2c1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 3ffb0192

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor d094d505

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 3612223d

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 7d63f85

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor 238ecac9

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c0b10964

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor c2511112

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 39db1b5d

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 29cecf8a

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor e611c57e

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor ed6c3d3f

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 4000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor 3612ddc3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor c0b1f69c

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-comp-factor 29ce3076

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor f50fc0f1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: rx-compt-factor c000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 3179289a

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-frequency-reference-center: 3700005000.000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c0050192

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-center-of-channel-bandwidth : 3600000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 2f6cd505

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor f82a3f85

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-channel-bandwidth : 100000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor dc72cac9

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-active : ACTIVE

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-downlink-radio-frame-offset : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 3daf1112

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-downlink-sfn-offset : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c6251b5d

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-gain-correction : 0.000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | rx-array-carriers-n-ta-offset : 25600

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 19efc57e

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 12943d3f

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c9eeddc3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor 3f4ff69c

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor d6323076

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: tx-comp-factor c000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-frequency-reference-center: 3700005000.000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-channel-bandwidth : 100000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-active : ACTIVE

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-gain : 0.000000

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-downlink-radio-frame-offset : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | tx-array-carriers-downlink-sfn-offset : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda user.notice supervision[1235]: Process started

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 2

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint2

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint1

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-endpoint name : slltx-endpoint3

Sep 5 13:45:05 garuda user.notice supervision[1235]: Listening for RPCs

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | lltx-ep-eaxc-id : 4

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 2

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint2

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-endpoint name : sllrx-endpoint3

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-compression-type : STATIC

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-iq-bitwidth : 16

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length : 352

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-cp-length-other : 288

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-offset-to-absolute-frequency-center : 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-number-of-prb : 273

Sep 5 13:45:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:05 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-scs : KHZ_30

Sep 5 13:45:05 garuda user.notice PM_MNGER[1245]: Waiting for performance manager results

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-o-du-port-bitmask : 65024

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-band-sector-bitmask : 448

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ccid-bitmask : 56

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-ru-port-bitmask : 7

Sep 5 13:45:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:05 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-eaxc-id : 4

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: FPGA | llrx-ep-non-time-managed-delay-enabled: 0

Sep 5 13:45:05 garuda user.notice UPLANECONF[1193]: END OF CHANGES

Sep 5 13:45:06 garuda user.notice log_manager[1272]: Process started

Sep 5 13:45:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:06 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:06 garuda user.notice log_manager[1272]: Listening for RPCs

Sep 5 13:45:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:06 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:07 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:07 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:08 garuda user.notice wd_manager[1306]: Started monitoring

Sep 5 13:45:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:08 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:08 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:09 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:09 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:10 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:10 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:11 garuda daemon.info dhclient: Internet Systems Consortium DHCP Client 4.4.2

Sep 5 13:45:11 garuda daemon.info dhclient: Copyright 2004-2020 Internet Systems Consortium.

Sep 5 13:45:11 garuda daemon.info dhclient: All rights reserved.

Sep 5 13:45:11 garuda daemon.info dhclient: For info, please visit https://www.isc.org/software/dhcp/

Sep 5 13:45:11 garuda daemon.info dhclient:

Sep 5 13:45:11 garuda daemon.info dhclient: Listening on LPF/eth0/98:ae:71:01:64:d8

Sep 5 13:45:11 garuda daemon.info dhclient: Sending on   LPF/eth0/98:ae:71:01:64:d8

Sep 5 13:45:11 garuda daemon.info dhclient: Sending on   Socket/fallback

Sep 5 13:45:11 garuda daemon.info dhclient: DHCPDISCOVER on eth0 to 255.255.255.255 port 67 interval 3

Sep 5 13:45:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:11 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:11 garuda daemon.err netopeer2-server[859]: connect() failed (Network is unreachable).

Sep 5 13:45:12 garuda daemon.info dhclient: DHCPOFFER of 192.168.4.41 from 192.168.4.15

Sep 5 13:45:12 garuda daemon.info dhclient: DHCPREQUEST for 192.168.4.41 on eth0 to 255.255.255.255 port 67

Sep 5 13:45:12 garuda daemon.info dhclient: DHCPACK of 192.168.4.41 from 192.168.4.15

Sep 5 13:45:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:13 garuda user.info nw_manager[888]: IFMNGR: EVENT change CHANGES: for module name: ietf-interfaces

Sep 5 13:45:13 garuda user.info nw_manager[888]: IFMNGR: EVENT done CHANGES: for module name: ietf-interfaces

Sep 5 13:45:13 garuda user.info nw_manager[888]: IFMNGR: EVENT change CHANGES: for module name: ietf-interfaces

Sep 5 13:45:13 garuda user.info nw_manager[888]: Interface : eth0 Netmask : 255.255.255.0

Sep 5 13:45:13 garuda user.info nw_manager[888]: IFMNGR: EVENT done CHANGES: for module name: ietf-interfaces

Sep 5 13:45:13 garuda daemon.info dhclient[1321]: eth0: : IP=192.168.4.41/255.255.255.0 router=192.168.4.15 domain="vvdntech.com" dns="192.168.4.15" lease=7200

Sep 5 13:45:13 garuda daemon.info dhclient: bound to 192.168.4.41 -- renewal in 2993 seconds.

Sep 5 13:45:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:17 garuda daemon.info dhclient: XMT: Confirm on eth0, interval 930ms.

Sep 5 13:45:17 garuda daemon.info dhclient: RCV: Reply message on eth0 from fe80::5bb2:44e5:874e:988a.

Sep 5 13:45:17 garuda daemon.info dhclient: message status code Success: "All addresses still on link."

Sep 5 13:45:17 garuda daemon.info init: Entering runlevel: 5

Sep 5 13:45:17 garuda user.err vlan_scan[1422]: if_name eth0

Sep 5 13:45:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:25 garuda daemon.debug rngd: Reading entropy from JITTER Entropy generator

Sep 5 13:45:25 garuda daemon.debug rngd: xread_jitter requests 2500 bytes from pipe

Sep 5 13:45:25 garuda daemon.debug rngd: xread_jitter gets 2500 bytes

Sep 5 13:45:25 garuda daemon.debug rngd: Added 2600/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 2740/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 2867/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 2982/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3022/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3059/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3092/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3122/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3149/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3174/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3196/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3216/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3235/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3251/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3267/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3280/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3293/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3304/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3314/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3323/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3332/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3339/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3346/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3352/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3358/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3363/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3368/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3372/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3376/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3379/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3382/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3449/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3510/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3564/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3614/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3659/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3700/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3737/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3771/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Reading entropy from JITTER Entropy generator

Sep 5 13:45:25 garuda daemon.debug rngd: xread_jitter requests 2500 bytes from pipe

Sep 5 13:45:25 garuda daemon.debug rngd: xread_jitter gets 2500 bytes

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3801/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3829/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3854/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3876/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3897/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3915/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3932/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3947/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3961/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3974/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3985/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 3995/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 4005/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 4013/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 4021/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 4028/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Added 4034/4096 bits entropy

Sep 5 13:45:25 garuda daemon.debug rngd: Pool full at 4096, sleeping!

Sep 5 13:45:25 garuda daemon.notice haveged: haveged starting up

Sep 5 13:45:25 garuda auth.info sshd[1588]: Server listening on 0.0.0.0 port 22.

Sep 5 13:45:25 garuda auth.info sshd[1588]: Server listening on :: port 22.

Sep 5 13:45:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:26 garuda daemon.info haveged: haveged: ver: 1.9.5; arch: generic; vend: ; build: (gcc 9.2.0 CTV); collect: 128K

Sep 5 13:45:26 garuda daemon.info haveged: haveged: cpu: (VC); data: 16K (D); inst: 16K (D); idx: 11/40; sz: 15456/64452

Sep 5 13:45:26 garuda daemon.info haveged: haveged: tot tests(BA8): A:1/1 B:1/1 continuous tests(B): last entropy estimate 8.00159

Sep 5 13:45:26 garuda daemon.info haveged: haveged: fills: 0, generated: 0

Sep 5 13:45:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:30 garuda user.info ADRV[1261]: JESD Link established successfully!

Sep 5 13:45:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:47 garuda user.info kernel: [71.261792] device eth0 entered promiscuous mode

Sep 5 13:45:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:45:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:45:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:03 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:46:03 garuda user.notice SYNCMNGR[1182]: SYNC Lock state : FREE RUN

Sep 5 13:46:03 garuda user.notice SYNCMNGR[1182]: SYNCE Lock state : UNLOCKED

Sep 5 13:46:03 garuda user.notice SYNCMNGR[1182]: PTP Lock state : UNLOCKED

Sep 5 13:46:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:03 garuda user.err FAULT MANAGER[874]: sendData : Source ID: 15

Sep 5 13:46:03 garuda user.err FAULT MANAGER[874]: sendData : Fault ID: 18

Sep 5 13:46:03 garuda user.err FAULT MANAGER[874]: sendData : FAULT_IS_CLEARED: FALSE

Sep 5 13:46:03 garuda user.err FAULT MANAGER[874]: sendData : FAULT_SEVERITY: 3

Sep 5 13:46:03 garuda user.err FAULT MANAGER[874]: sendData : FAULT_TIME: 2022-09-05T13:46:03Z

Sep 5 13:46:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:05 garuda user.err FAULT MANAGER[874]: sendData : Source ID: 15

Sep 5 13:46:05 garuda user.err FAULT MANAGER[874]: sendData : Fault ID: 18

Sep 5 13:46:05 garuda user.err FAULT MANAGER[874]: sendData : FAULT_IS_CLEARED: FALSE

Sep 5 13:46:05 garuda user.err FAULT MANAGER[874]: sendData : FAULT_SEVERITY: 3

Sep 5 13:46:05 garuda user.err FAULT MANAGER[874]: sendData : FAULT_TIME: 2022-09-05T13:46:05Z

Sep 5 13:46:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:17 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:46:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:31 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:46:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:45 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:46:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:59 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:46:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:46:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:46:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:47:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:47:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:13 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:47:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:27 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:47:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:41 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:47:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:55 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:47:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:47:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:47:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:09 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:48:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:23 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:48:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:37 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:48:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:51 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:48:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:48:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:48:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:05 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:49:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:19 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:49:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:33 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:49:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:47 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:49:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:49:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:49:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:52 garuda user.notice kernel: [316.445507] EXT4-fs (mmcblk0p2): error count since last fsck: 13
Sep 5 13:49:52 garuda user.notice kernel: [316.451517] EXT4-fs (mmcblk0p2): initial error at time 1807679724: ext4_lookup:1700: inode 7393
Sep 5 13:49:52 garuda user.notice kernel: [316.460215] EXT4-fs (mmcblk0p2): last error at time 1807679771: ext4_lookup:1700: inode 7393
Sep 5 13:49:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:49:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:49:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:50:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:50:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:50:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:50:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:50:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:50:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:01 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:50:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:15 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:50:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:29 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:50:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:43 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:50:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:57 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:50:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:50:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:50:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:11 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:51:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:51:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:51:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:25 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:51:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:39 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:51:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:53 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:51:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:51:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:51:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:07 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:52:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:21 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:52:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:35 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:52:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:49 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:52:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:52:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:52:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:03 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:53:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:17 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:53:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:31 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:53:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:45 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 13:53:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:53:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:53:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:53:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:53:59 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:54:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:13 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:54:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:27 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:54:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:41 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:54:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:55 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:54:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:54:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:54:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:09 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:55:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:23 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:55:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:37 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:55:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:51 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:55:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:55:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:55:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:05 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:56:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:19 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:56:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:33 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:56:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:47 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:56:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:56:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:56:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:01 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:57:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:57:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:57:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:15 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:57:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:29 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:57:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:43 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:57:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:57 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:57:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:57:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:57:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:11 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:58:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:25 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:58:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:39 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:58:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:53 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:58:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:58:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:58:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:07 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:59:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:21 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:59:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:35 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 13:59:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:49 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 13:59:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 13:59:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 13:59:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 13:59:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 13:59:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:00:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:00:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:03 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:00:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:17 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:00:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:31 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:00:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:45 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:00:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:00:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:00:59 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:01:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:13 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:01:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:27 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:01:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:41 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:01:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:01:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:01:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:55 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:01:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:01:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:01:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:09 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:02:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:02:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:02:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:23 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:02:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:37 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:02:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:51 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:02:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:02:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:02:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:05 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:03:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:19 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:03:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:33 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:03:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:47 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:03:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:03:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:03:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:03:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:03:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:01 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:04:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:15 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:04:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:29 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:04:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:43 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:04:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:57 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:04:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:04:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:04:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:11 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:05:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:25 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:05:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:39 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:05:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:05:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:05:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:53 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:05:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:05:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:05:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:07 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:06:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:21 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:06:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:35 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:06:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:49 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:06:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:06:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:06:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:03 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:07:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:18 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:07:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:32 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:07:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:46 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:07:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:07:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:07:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:00 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:08:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:14 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:08:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:28 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:08:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:42 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:08:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:56 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:08:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:08:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:08:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:10 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:09:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:24 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:09:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:38 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:09:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:52 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:09:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:09:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:09:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:09:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:09:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:10:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:10:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:06 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:10:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:20 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:10:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:34 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:10:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:48 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:10:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:10:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:10:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:02 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:11:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:16 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:11:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:11:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:11:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:30 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:11:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:44 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:11:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:58 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:11:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:11:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:11:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:12 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:12:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:26 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:12:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:12:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:12:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:40 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:12:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:54 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:12:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:12:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:12:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:08 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:13:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:22 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:13:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:36 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:13:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:50 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:13:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:13:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:13:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:04 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:14:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:18 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:14:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:32 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:14:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:46 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:14:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:14:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:14:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:14:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:14:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:00 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:15:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:14 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:15:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:15:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:15:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:28 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:15:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:42 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:15:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:56 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:15:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:15:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:15:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:10 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:16:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:24 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:16:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:38 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:16:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:44 garuda daemon.notice netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:52 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:16:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:16:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:16:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:06 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:17:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:20 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:17:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:34 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:17:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:48 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:17:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:17:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:17:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:02 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:18:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:16 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:18:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:30 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:18:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:44 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:18:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:58 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:18:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:18:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:18:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:12 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:19:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:26 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:19:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:40 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:19:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:54 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:19:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:19:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:19:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:08 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:20:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:22 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:20:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:36 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:20:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:50 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:20:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:20:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:20:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:04 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:21:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:18 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:21:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:32 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:21:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:46 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:21:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:21:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:21:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:00 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:22:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:14 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:22:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:28 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:22:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:42 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:22:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:22:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:22:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:56 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:22:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:22:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:22:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:10 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:23:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:24 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:23:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:38 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:23:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:52 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:23:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:23:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:23:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:23:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:23:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:06 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:24:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:20 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:24:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:34 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:24:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:48 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:24:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:24:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:24:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:24:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:24:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:02 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:25:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:16 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:25:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:30 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:25:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:44 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:25:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:58 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:25:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:25:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:25:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:12 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:26:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:26 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:26:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:40 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:26:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:54 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:26:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:26:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:26:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:08 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:27:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:22 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:27:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:36 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:27:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:50 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:27:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:27:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:27:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:04 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:28:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:18 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:28:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:32 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:28:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:36 garuda authpriv.notice sshd[29132]: pam_unix(sshd:auth): authentication failure; logname= uid=0 euid=0 tty=ssh ruser= rhost=192.168.4.15 user=root

Sep 5 14:28:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:38 garuda auth.info sshd[29132]: Failed password for root from 192.168.4.15 port 52836 ssh2

Sep 5 14:28:38 garuda auth.info sshd[29132]: Connection closed by authenticating user root 192.168.4.15 port 52836 [preauth]

Sep 5 14:28:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:46 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:28:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:28:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:28:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:28:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:28:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:00 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:29:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:14 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:29:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:29:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:29:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:28 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:29:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:42 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:29:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:54 garuda authpriv.notice sshd[29954]: pam_unix(sshd:auth): authentication failure; logname= uid=0 euid=0 tty=ssh ruser= rhost=192.168.4.15 user=root

Sep 5 14:29:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:56 garuda auth.info sshd[29954]: Failed password for root from 192.168.4.15 port 47356 ssh2

Sep 5 14:29:56 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:29:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:56 garuda auth.info sshd[29954]: Connection closed by authenticating user root 192.168.4.15 port 47356 [preauth]

Sep 5 14:29:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:29:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:29:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:10 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:30:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:24 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:30:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:38 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:30:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:52 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:30:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:30:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:30:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:06 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:31:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:20 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:31:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:34 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:31:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:48 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:31:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:31:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:31:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:02 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:32:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:16 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:32:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:30 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:32:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:32:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:32:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:44 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:32:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:58 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:32:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:32:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:32:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:12 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:33:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:26 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:33:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:40 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:33:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334

Sep 5 14:33:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:53 garuda auth.info sshd[32463]: Accepted password for root from 192.168.4.15 port 34590 ssh2

Sep 5 14:33:53 garuda authpriv.info sshd[32463]: pam_unix(sshd:session): session opened for user root by (uid=0)

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Accepted a connection on :::830.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Session 88 (user "root", CID 1) created.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-service" of subtype "ssh-userauth".

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-auth" of subtype "password".

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: User "operator" authenticated.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel-open" of subtype "session".

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel" of subtype "subsystem".

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Session 89 (user "root", CID 1) created.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-start).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 1 priority 0 for 1 subscribers.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 1 priority 0 succeeded.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Session 1: thread 1 event new RPC.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 2 priority 0 for 1 subscribers.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 2 priority 0 (remaining 1 subscribers).

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-keystore:keystore/ietf-keystore:asymmetric-keys/ietf-keystore:asymmetric-key/ietf-keystore:name" with the value "genkey", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-interfaces:interfaces/ietf-interfaces:interface/ietf-interfaces:name" with the value "eth0.100", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-interfaces:interfaces/ietf-interfaces:interface[ietf-interfaces:name = current()/../../interface-name]/o-ran-interfaces:vlan-id" with the value "100", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref

"/o-ran-processing-element:processing-elements/o-ran-processing-element:ru-elements/o-ran-processing-element:name" with the value "element0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint1", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint2", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-tx-endpoints/name" with the value "slltx-endpoint3", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint0", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint1", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint2", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: There is no leafref "/user-plane-configuration/static-low-level-rx-endpoints/name" with the value "sllrx-endpoint3", but it is not required.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:53 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 1.

Sep 5 14:33:53 garuda user.notice fw_manager[936]: RPC #1 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:33:54 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 1 succeeded.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 2 priority 0 succeeded.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Session 1: thread 0 event new RPC.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get-config" with ID 1 priority 0 for 1 subscribers.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get-config" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 1 priority 0 succeeded.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:54 garuda daemon.info netopeer2-server[859]: Session 1: thread 3 event new RPC.

Sep 5 14:33:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/notifications:create-subscription" with ID 1 priority 0 for 1 subscribers.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Processing "/notifications:create-subscription" "rpc" event with ID 1 priority 0 (remaining 1 subscribers).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 1 priority 0 (remaining 0 subscribers).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 1 priority 0 succeeded.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Session 1: thread 0 event new RPC.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 3 priority 0 for 1 subscribers.

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 3 priority 0 (remaining 1 subscribers).

Sep 5 14:33:59 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 2.

Sep 5 14:33:59 garuda user.notice fw_manager[936]: RPC #2 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 2 succeeded.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 3 priority 0 (remaining 0 subscribers).

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 3 priority 0 succeeded.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Session 1: thread 0 event new RPC.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 4 priority 0 for 1 subscribers.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 4 priority 0 (remaining 1 subscribers).

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 3.

Sep 5 14:34:05 garuda user.notice fw_manager[936]: RPC #3 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 3 succeeded.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 4 priority 0 (remaining 0 subscribers).

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 4 priority 0 succeeded.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Session 1: thread 2 event new RPC.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Session 1: thread 3 event new RPC.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Session 1: thread 3 event session terminated.

Sep 5 14:34:05 garuda authpriv.info sshd[32463]: pam_unix(sshd:session): session closed for user root

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:34:05 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-end).

Sep 5 14:34:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:08 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:34:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:22 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:34:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:36 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:34:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:50 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:34:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:34:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:34:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:04 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:35:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:06 garuda daemon.info dhclient: DHCPREQUEST for 192.168.4.41 on eth0 to 192.168.4.15 port 67

Sep 5 14:35:06 garuda daemon.info dhclient: DHCPACK of 192.168.4.41 from 192.168.4.15

Sep 5 14:35:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:07 garuda user.info nw_manager[888]: IFMNGR: EVENT change CHANGES: for module name: ietf-interfaces

Sep 5 14:35:07 garuda user.info nw_manager[888]: IFMNGR: EVENT done CHANGES: for module name: ietf-interfaces

Sep 5 14:35:07 garuda user.info nw_manager[888]: IFMNGR: EVENT change CHANGES: for module name: ietf-interfaces

Sep 5 14:35:07 garuda user.info nw_manager[888]: Interface : eth0 Netmask : 255.255.255.0

Sep 5 14:35:07 garuda user.info nw_manager[888]: IFMNGR: EVENT done CHANGES: for module name: ietf-interfaces

Sep 5 14:35:07 garuda daemon.info dhclient[1321]: eth0: : IP=192.168.4.41/255.255.255.0 router=192.168.4.15 domain="vvdntech.com" dns="192.168.4.15" lease=7200

Sep 5 14:35:07 garuda daemon.info dhclient: bound to 192.168.4.41 -- renewal in 2925 seconds.

Sep 5 14:35:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:18 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:35:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:35:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:35:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:32 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:35:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:44 garuda auth.info sshd[2110]: Accepted password for root from 192.168.4.15 port 40934 ssh2

Sep 5 14:35:44 garuda authpriv.info sshd[2110]: pam_unix(sshd:session): session opened for user root by (uid=0)

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Accepted a connection on :::830.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Session 107 (user "root", CID 1) created.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-service" of subtype "ssh-userauth".

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-auth" of subtype "password".

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: User "operator" authenticated.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel-open" of subtype "session".

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel" of subtype "subsystem".

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Session 108 (user "root", CID 1) created.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-start).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 5 priority 0 for 1 subscribers.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 5 priority 0 (remaining 1 subscribers).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 5 priority 0 (remaining 0 subscribers).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 5 priority 0 succeeded.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Session 2: thread 1 event new RPC.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 6 priority 0 for 1 subscribers.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 6 priority 0 (remaining 1 subscribers).

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:44 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 4.

Sep 5 14:35:44 garuda user.notice fw_manager[936]: RPC #4 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 4 succeeded.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 6 priority 0 (remaining 0 subscribers).

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 6 priority 0 succeeded.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Session 2: thread 0 event new RPC.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get-config" with ID 2 priority 0 for 1 subscribers.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get-config" "rpc" event with ID 2 priority 0 (remaining 1 subscribers).

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 2 priority 0 succeeded.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Session 2: thread 1 event new RPC.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:46 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:35:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/notifications:create-subscription" with ID 2 priority 0 for 1 subscribers.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Processing "/notifications:create-subscription" "rpc" event with ID 2 priority 0

(remaining 1 subscribers).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 2 priority 0 (remaining 0 subscribers).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 2 priority 0 succeeded.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Session 2: thread 2 event new RPC.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 7 priority 0 for 1 subscribers.

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 7 priority 0 (remaining 1 subscribers).

Sep 5 14:35:50 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 5.

Sep 5 14:35:50 garuda user.notice fw_manager[936]: RPC #5 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 5 succeeded.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 7 priority 0 (remaining 0 subscribers).

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 7 priority 0 succeeded.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Session 2: thread 2 event new RPC.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 8 priority 0 for 1 subscribers.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 8 priority 0 (remaining 1 subscribers).

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 6.

Sep 5 14:35:56 garuda user.notice fw_manager[936]: RPC #6 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 6 succeeded.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 8 priority 0 (remaining 0 subscribers).

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 8 priority 0 succeeded.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There is no leafref "/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Session 2: thread 1 event new RPC.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Session 2: thread 4 event new RPC.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Session 2: thread 4 event session terminated.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:35:56 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-end).

Sep 5 14:35:56 garuda authpriv.debug sshd[2905]: pam_unix(sshd:account): account operator has password changed in future

Sep 5 14:35:56 garuda auth.info sshd[2905]: Accepted password for operator from 192.168.4.15 port 44414 ssh2

Sep 5 14:35:56 garuda authpriv.info sshd[2905]: pam_unix(sshd:session): session opened for user operator by (uid=0)

Sep 5 14:35:56 garuda authpriv.info sshd[2110]: pam_unix(sshd:session): session closed for user root

Sep 5 14:35:57 garuda authpriv.info sshd[2905]: pam_unix(sshd:session): session closed for user operator

Sep 5 14:35:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:35:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:35:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:00 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:36:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:14 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:36:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:28 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:36:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:42 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane
Sep 5 14:36:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.
Sep 5 14:36:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).
Sep 5 14:36:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:56 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:36:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:36:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:36:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:10 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:37:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:23 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:23 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:24 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:37:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:24 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:24 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:25 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:25 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:26 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:26 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:27 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:27 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:28 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:28 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:29 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:29 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:30 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:30 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:31 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:31 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:32 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:32 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:33 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:33 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:34 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:34 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:35 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:35 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:36 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:36 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:37 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:37 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:38 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:37:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:38 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:38 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:39 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:39 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:40 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:40 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:41 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:41 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:42 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:42 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:43 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:43 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:44 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:44 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:45 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:45 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:46 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:46 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:47 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:47 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:48 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:48 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:49 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:49 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:50 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:50 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:51 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:51 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:52 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:37:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:52 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:52 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:53 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:53 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:54 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:54 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:55 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:55 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:56 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:56 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:57 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:57 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:58 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:58 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:37:59 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:37:59 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:00 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:00 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:01 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:01 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:02 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:02 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:03 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:03 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:04 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:04 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:05 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:05 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:06 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:38:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:06 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:06 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:07 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:07 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:08 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:08 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:09 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:09 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:10 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:10 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:11 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:11 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:12 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:12 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:13 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:13 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:14 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:14 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:15 garuda auth.info sshd[4381]: Accepted password for root from 192.168.4.15 port 49034 ssh2

Sep 5 14:38:15 garuda authpriv.info sshd[4381]: pam_unix(sshd:session): session opened for user root by (uid=0)

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Accepted a connection on :::830.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Session 118 (user "root", CID 1) created.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-service" of subtype "ssh-userauth".

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-auth" of subtype "password".

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: User "operator" authenticated.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel-open" of subtype "session".

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Received an SSH message "request-channel" of subtype "subsystem".

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Session 119 (user "root", CID 1) created.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-start).

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 9 priority 0 for 1 subscribers.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 9 priority 0 (remaining 1 subscribers).

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 9 priority 0 (remaining 0 subscribers).

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 9 priority 0 succeeded.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:15 garuda daemon.info netopeer2-server[859]: Session 3: thread 3 event new RPC.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 10 priority 0 for 1 subscribers.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 10 priority 0 (remaining 1 subscribers).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 7.

Sep 5 14:38:16 garuda user.notice fw_manager[936]: RPC #7 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 7 succeeded.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 10 priority 0 (remaining 0 subscribers).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 10 priority 0 succeeded.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref
"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Session 3: thread 3 event new RPC.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get-config" with ID 3 priority 0 for 1 subscribers.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get-config" "rpc" event with ID 3 priority 0 (remaining 1 subscribers).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 3 priority 0 (remaining 0 subscribers).

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 3 priority 0 succeeded.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/ietf-hardware:name" with the value "ru-port0", but it is not required.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:16 garuda daemon.info netopeer2-server[859]: Session 3: thread 0 event new RPC.

Sep 5 14:38:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:17 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:17 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:18 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:18 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:19 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:19 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:20 garuda user.notice SYNCMNGR[1182]: Received message from S-Plane

Sep 5 14:38:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:20 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:20 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/notifications:create-subscription" with ID 3 priority 0 for 1 subscribers.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Processing "/notifications:create-subscription" "rpc" event with ID 3 priority 0 (remaining 1 subscribers).

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 3 priority 0 (remaining 0 subscribers).

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 3 priority 0 succeeded.

Sep 5 14:38:21 garuda daemon.info netopeer2-server[859]: Session 3: thread 3 event new RPC.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/ietf-netconf:get" with ID 11 priority 0 for 1 subscribers.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Processing "/ietf-netconf:get" "rpc" event with ID 11 priority 0 (remaining 1 subscribers).

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Published event "operational" "/o-ran-software-management:software-inventory" with ID 8.

Sep 5 14:38:22 garuda user.notice fw_manager[936]: RPC #8 recieved. xpath -> /o-ran-software-management:software-inventory

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Event "operational" with ID 8 succeeded.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Successful processing of "rpc" event with ID 11 priority 0 (remaining 0 subscribers).

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 11 priority 0 succeeded.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Resolving unresolved data nodes and their constraints...

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There is no leafref

"/ietf-hardware:hardware/ietf-hardware:component/o-ran-hardware:product-code" with the value "STL=O-RU", but it is not required.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: All data nodes and constraints resolved.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Session 3: thread 3 event new RPC.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Published event "rpc" "/o-ran-operations:reset" with ID 1 priority 0 for 1 subscribers.

Sep 5 14:38:22 garuda user.notice SR_OP[1193]: RPC recived on /o-ran-operations:reset for mplane-triggered reset

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Event "rpc" with ID 1 priority 0 succeeded.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Session 3: thread 0 event new RPC.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Trying to connect via IPv4 to 192.168.4.15:4334.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: getsockopt() error (Connection refused).

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Session 3: thread 0 event new RPC.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Session 3: thread 0 event session terminated.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: There are no subscribers for "ietf-netconf-notifications" notifications.

Sep 5 14:38:22 garuda daemon.info netopeer2-server[859]: Generated new event (netconf-session-end).

Sep 5 14:38:22 garuda authpriv.debug sshd[4948]: pam_unix(sshd:account): account operator has password changed in future

Sep 5 14:38:22 garuda auth.info sshd[4948]: Accepted password for operator from 192.168.4.15 port 48120 ssh2

Sep 5 14:38:22 garuda authpriv.info sshd[4948]: pam_unix(sshd:session): session opened for user operator by (uid=0)

===

'NoneType' object is not iterable

===

Error occured in line number 410

===

Excution_time : 70.39502573013306

===